

BOOT CATALOGUE 2021

REPAIR KITS:

- ♦ C.V. Joint boot
- ♦ Steering boot
- ♦ Shock absorber protection kit

www.ertseinsa.com



NEW APP: your online catalog
Available on



TecAlliance
Certified Data Supplier



Management
System
ISO 9001:2015
IATF 16949:2016



www.tuv.com
ID 9105084237

BOOTS CATALOGUE 2021





GENERAL INDEX

C.V. JOINT BOOT KITS	13-337
STEERING BOOT KITS	339-445
SHOCK ABSORBER PROTECCION KITS	447-532
UNIVERSAL BOOT KITS	533

BOOT KITS INDEX

C.V. JOINT BOOT KITS

KIT	PAGE	KIT	PAGE	KIT	PAGE
500002	23-53-148-333	500073	301	500151	121
500003	30-56-211	500074	94	500152	84-145
500004	80	500075	33-48-311	500153	32
500005	293	500076	31-47-308	500154	18
500006	39-115-148	500077	114-146-262-336	500155	31-337
500007	118	500078	114-145-262	500156	31-47
500009	124	500079	27-54-74-162-306	500158	25-47-207-305
500010	244	500080	207	500159	120
500014	141	500081	26-47-207-305	500169	152-187-233-254
500015	213	500084	31-47	500170	15-51-62-91-125-150-155-174- 196-217-231-250-252-264
500016	78-105-134	500085	25-46-305	500171	110-166
500018	111-143-287	500089	56-77-245-271	500172	150-276-281
500019	90	500090	40-119	500173	187-233
500021	91-125	500091	137	500174	150-231-252-281
500022	72-129	500092	182-192-268	500175	29-85-163-270-307-333
500023	93	500093	51-158-197-234	500176	176-233
500024	19	500094	116	500177	189-255
500025	22-43-53-160-236-267-332	500095	24-54-72	500178	164-202-238
500026	27-181-191	500096	301	500179	76
500027	101	500097	24-102	500180	64-282
500029	121-291	500102	132-245	500181	176
500031	83-171-193-204-210-228-241-261	500105	147-288	500182	191
500032	19-46-296	500106	80-183-193-227-240-260	500183	168
500033	200-333	500107	271	500184	164
500034	43-178-198-207-255-266-279	500108	42-89-123-286	500185	34-108
500036	55-132-308	500109	43-157-232-253-265-277	500186	297
500037	235-285	500110	300	500187	20-298
500039	66-152-171-187-197-209-232-254- 265-283	500111	33-106	500188	244
500040	20-46-97-206-298-337	500112	161-181-201	500189	179
500041	64-151-175-186-196-232-253- 276-282	500113	103	500190	71-304
500042	18-65-148-213-295	500114	173-196	500191	180
500044	26	500115	39-114-148	500192	180-190
500045	92	500116	173-234-278-283	500193	183
500046	26-306	500117	29	500194	17-45-293
500048	28-102	500118	197	500195	67-188-209-235-254-278-284-331
500050	21-52-68-128-159-243-303-332	500119	224-258	500196	180
500052	294	500121	270-307-333	500197	178-198
500053	61-291	500122	125	500198	152-175-186-232-276
500054	91	500123	32-48-203	500199	151-185-217-231-252-282
500055	98	500128	158	500200	189-255-279
500056	16	500129	99-299	500201	180
500057	95	500130	88-195	500202	183
500058	308	500131	88-121-286	500203	182
500059	42-89-123-155-195-264-289	500132	30-243-290	500204	177
500060	142-287	500133	74-131-224	500205	176-250-265
500061	287	500134	71	500206	62-150-185-281
500062	79-136	500135	117	500207	177-188-209-234-254-278
500063	42-64-94-264	500136	163	500208	174
500064	156-232-296	500137	17-45-63-293	500209	213
500065	104	500138	322	500210	183
500066	69-159-269	500139	29-103	500211	198-209
500067	27-50-162-306	500140	96	500212	185-282
500068	297	500141	16-156	500213	73-181-191-223-257
500069	67-178-189-198-210-235-255-284	500142	36-109	500214	248
500070	38-48-327	500143	40-329	500215	177-266
500071	38-48	500145	327	500216	271
500072	39-49-208	500147	38-48-207-327	500217	221
		500148	90	500218	218
		500150	121		

BOOT KITS INDEX

C.V. JOINT BOOT KITS

KIT	PAGE	KIT	PAGE	KIT	PAGE
500219	222	500316	110	500405	117
500220	228	500318	94	500408	34
500221	21-52-69-256-266	500319	96-157-234	500410	203-227
500222	85	500320	151	500411	51-156
500247	54	500326	246	500413	144-214
500248	292	500327	202	500414	17-51-64-196-218-250-253-264-269
500250	56	500328	58	500415	37-109
500251	32-56	500329	54-211	500421	201-237-257
500254	18-45-95-206-294	500330	58	500424	31-105
500255	175-250-265	500331	59-328	500426	99-127-159-198-331
500256	192-225-238-258	500332	300	500428	62-90-150-217-252-292
500257	76-202-238	500333	37-111	500430	66-157
500258	293	500334	62-151	500432	63
500259	247	500345	235-278	500434	38-113
500260	243	500346	227	500436	168
500261	246	500347	79-193-240-259	500437	55-164
500262	212	500348	126-330	500440	205
500263	19-297	500349	18-156-197-265-330	500442	77-182-246
500264	284	500350	17-206	500444	133
500265	107	500351	219	500447	245
500266	151-174-185-217-253-282	500352	112	500451	274
500267	28-75-163-270	500353	162	500477	244
500268	52	500354	89	500478	84
500269	83-142	500355	15-45-292-337	500479	25-73-102-153
500270	127-158-178-218-251-266-269-299-331	500356	15-45-291-337	500480	165
500271	285	500357	91	500481	144-241
500272	269	500358	61-122	500482	94-125
500273	152-187-253-276-283	500359	22-69-159-220	500483	305
500274	248	500360	97-287	500486	197
500275	180-267-279	500361	181	500489	233
500276	65-186	500362	22-220	500492	144-214
500277	192-203-259	500363	80-136-246	500494	203
500278	28-245	500364	219	500498	283
500279	201	500365	158-302	500501	217-281
500280	222	500366	190-236-257	500503	220
500281	219	500367	222	500504	106-260
500282	92-293	500368	224	500505	169
500283	67-152-171-188-209-235-254-278-284	500369	126	500506	237-257
500287	95-126-286	500370	88	500508	76-132
500288	174	500371	94	500509	17-63-175-196-215-269
500289	39	500372	140	500512	190
500290	163	500373	26	500513	200-237-285
500291	199	500374	73	500518	122-252-330
500292	20-158-176-251-266-331	500375	15-51-62-90-155-174-185-231-250-264-281	500522	187
500293	53	500384	202-225	500523	66-127-234-330
500299	25	500385	226	500528	223
500300	130-200-333	500386	227	500531	25-223
500301	129	500387	195	500532	199-220
500307	72	500388	219-279	500533	165-334
500308	127	500391	195	500534	16-231
500309	124	500392	42-206	500542	228
500310	142	500393	200	500544	191-225
500311	67	500394	172-239	500546	233
500312	37-61-122-195	500395	190	500547	182
500313	147	500397	335	500548	239
500314	73	500399	177	500549	155-330
500315	175	500401	58	500550	189
		500404	226	500551	133
				500560	165

BOOT KITS INDEX

C.V. JOINT BOOT KITS

KIT	PAGE	KIT	PAGE	KIT	PAGE
500562	50-300	500098T	84-143	500305T	110
500566	165	500099T	138	500306T	325
500567	73-130	500100T	137-260	500317T	163
500568	57	500101T	29-103	500321T	205-241-247
500569	56	500104T	107-312	500322T	22-52-70-100-189-199-215-256-285
500575	89	500108E	42-89-124-286	500323T	142-204
500576	104	500109E	43-157	500324T	261
500577	224	500110E	300	500335T	33-107
500578	257	500122E	125	500336T	84-273-324-325-335
500580	277	500129E	99-299	500337T	239-259
500583	262	500161T	57-168	500338T	103-131-238
500584	276	500162T	44-168	500339T	102
500588	59	500163T	166-260-263	500340T	225
500589	106-165-203-215	500164T	113	500341T	83-241
500590	119-147	500165T	188-298	500342T	32-79-271
500594	15	500166T	162-237	500343T	228
500595	21-67-98	500167T	79-136	500344T	118
500597	24-130-153-222-256	500168T	33-106-309	500345T	35-86-313
500600	223	500223T	221-236	500389T	240
500601	19-277	500224T	183	500390T	204-240
500602	114	500225T	114-169-242	500396T	216
500604	120	500226T	169	500402T	246
500605	59	500227T	82-108-140-166-204-211-216- 241-261-272-314-334	500403T	229-249
500607	96-218	500228T	229	500407T	135
500609	277	500229T	70	500409T	22-70-100-153-220
500622	122	500230T	249	500412T	145-205
500624	111	500231T	78	500445T	38-112
500628	275	500232T	78-86-134-215-226-259	500449T	126
500632	329	500233T	167	500474T	135
500633	308	500234T	81-227-240-261	500476T	34-139
500636	41-230	500235T	80-86	500487T	212
500637	186-186	500236T	167	500488T	319
500638	192	500237T	82-87-141	500490T	326
500011T	35-82-108-141-166-247-273- 317-335	500238T	139-193-272	500491T	328
500012T	144	500239T	28-54-75-85-131-162-201-224- 258-267-270	500493T	275
500013T	146	500240T	29-55-85-132-191-307-334	500495T	66-177
500014E	141	500241T	164	500496T	167
500016E	78-106-134	500242T	105	500497T	228
500017T	116	500243T	68-127-255-331	500499T	194
500018E	111-143-287	500244T	119	500500T	226-239
500019E	90	500245T	64	500502T	205
500020T	80-136-311	500246T	315	500510T	320-321
500021E	107-139	500249T	314	500511T	226
500022E	72-129	500252T	318-335	500514T	138
500023E	93	500285T	23-53-70-85-100-128-154-161-179- 199-213-215-221-236-251-256-267-270-332	500515T	310
500025E	23-43-53-161-236-267-332	500286T	36-109	500516T	113-262
500027E	102	500287E	95-126-286	500517T	284
500030T	36-141	500294T	30-55-77-104-132-164-192-202- 225-239-251-259-268-271-334	500520T	37-112-168
500032E	19-46-297	500295T	32-182	500521T	248
500038T	24	500296T	81-140-166-204	500524T	181
500040E	21-46-97-206-298	500297T	39-115-149	500525T	138
500042E	18-65-148-213-296	500298T	101	500526T	34-57-81-272-312
500045E	92	500302T	146	500527T	82-272
500050E	21-52-68-128-159-243-304-332	500303T	40-115-146-169	500529T	179
500052E	294	500304T	100	500530T	179
500053E	61-292			500535T	133
500054E	91			500536T	83
500091E	137			500537T	193
				500538T	184

BOOT KITS INDEX

C.V. JOINT BOOT KITS

KIT	PAGE
500539T	258
500540T	247
500541T	169
500543T	36-57
500545T	34-334
500552T	140
500554T	57
500555T	167
500556T	74
500557T	190-237
500558T	247
500559T	316-317
500561T	249
500565T	238-280
500570T	327
500571T	50-322-323
500572T	170
500573T	205-216
500574T	37-83-167-216-321-335
500579T	143
500612T	35-60-81-86-272-313
500613T	23-101-221
500614T	280
500615T	256
500616T	248
500618T	86
500619T	93-218
500620T	99-219
500621T	113
500627T	244
500629T	229
500630T	328
500631T	328
500634T	101-129-279-285
500635T	131
500636T	20-66-176-188-283

BOOT KITS INDEX

STEERING BOOT KITS

KIT	PAGE	KIT	PAGE	KIT	PAGE
101609	362-431	102028	352	102386	389-425-444
101634	362	102030	345-368	102390	389
101635	385	102031	373	102392	343
101657	341-348-361-375-403-433-445	102032	364	102394	356
101676	381	102034	370	102396	393-415
101677	376	102058	412	102418	416
101678	365-378	102059	413	102420	367-423
101679	440	102060	391	102422	398
101680	361-433	102061	350-359-436	102424	380-402
101687	375	102062	370	102426	390-408-444
101688	381	102065	358-388-410	102428	401
101691	346-368	102066	380-402	102431	396
101692	377	102067	371	102433	354
101693	355-414	102068	353	102436	423
101694	385	102069	410	201107	379
101696	391-395	102070	409	510007	392
101697	359	102071	442	510009	356
101698	391	102072	413	510011	443
101699	422	102073	374	510013	343
101704	377	102074	422-430	510015	384
101738	437	102075	345-366	510017	419
101741	352	102076	366-378	510019	444
101743	363	102077	385-434	510021	355
101744	369-420-437	102082	374	510023	347-426
101745	344-357-423	102087	400	510025	379
101749	359-383-397-404-412-428	102101	341	510027	356
101750	354-374-400	102102	347-349-427-432	510029	399
101761	372	102105	414	510032	357
101763	386-434	102106	384	510034	413
101764	442	102107	392	510036	395
101765	422-443	102108	370	510038	417-436
101771	343-366-386-418	102110	400	510040	411
101772	372	102122	365	510042	419
101773	369	102123	365	510044	409
101774	419	102124	413	510045	409
101777	374	102125	353	510047	354-375-400-407
101778	389	102128	364	510049	404-430
101789	383-387-415-427	102132	395-410	510051	345-358-428
101790	384-414-426	102133	393	510053	363-431
101794	379	102135	396	510055	418-435
101796	435	102140	350	510057	342
101802	386-421-427	102145	375	510060	420
101805	387-415	102158	378	510062	405-419
101806	358-387-396	102161	362	510064	406-420-437
101842	352	102162	378	510066	439
101843	441	102246	398	510067	440
101888	388	102328	411	510069	351-436
101980	345-350-380-382-387	102330	398	510071	368
102002	443	102333	351-408	510073	429
102004	341-418	102366	401	510075	421-439
102006	342	102369	396	510077	351
102010	370	102371	358	510080	416-436
102014	433	102373	435	510082	395-414-430
102015	342-363	102375	343-356-366	510084	392
102017	388	102377	397	510087	357-379-401
102019	435	102379	402-411	510089	346
102022	371	102381	402	510091	393-401-403-421-426
102024	342-433	102382	397	510092	426
102027	352	102384	424	510094	364

BOOT KITS INDEX

STEERING BOOT KITS

KIT	PAGE	KIT	PAGE
510096	371	510255	440
510098	439	510256	439
510100	393	510258	380
510102	412	510259	438
510104	411	510260	438
510105	424	510275	389
510108	440	510001C	377
510110	359-397	510002C	354-376
510112	344	510003C	349-360
510114	364		
510116	398		
510118	394		
510120	385		
510124	442		
510127	441		
510128	438		
510130	376		
510132	360		
510136	443		
510137	369		
510138	365		
510139	344-386		
510141	341		
510144	391		
510152	441		
510154	367		
510164	418		
510171	346		
510175	355-434		
510177	416		
510187	367		
510189	368		
510193	357		
510195	437		
510201	388-416		
510203	408		
510206	394		
510208	346		
510210	350		
510212	355		
510215	362		
510216	363		
510219	415		
510221	412		
510222	438		
510224	423		
510229	372		
510231	367-381		
510233	372		
510235	377		
510240	408		
510243	441		
510244	369		
510245	371		
510247	392		
510248	409		
510249	410		
510250	351		
510254	344		

BOOT KITS INDEX

SHOCK ABSORBER PROTECTION KITS

KIT	PAGE	KIT	PAGE	KIT	PAGE
520001	495-518	520061	520	520122	451-471-476
520002	516	520062	475	520123	458
520003	474-516	520063	470	520124	508
520004	481-501-531	520064	501	520125	493
520005	449-456-510-516	520065	507-531	520126	476-505-525
520006	474-491	520066	450-470	520127	482
520007	517	520067	502-520	520128	465
520008	456-462-496-511-513-531	520068	520	520129	458
520009	491	520069	493	520130	532
520010	456	520070	521	520131	458
520011	517	520071	497	520132	488
520012	517	520072	497	520133	477
520013	504-517	520073	497	520134	451
520014	449-455-462-481-518	520074	498	520135	494
520015	456	520075	467-480	520136	511
520016	474-491	520076	498	520137	465-510
520017	474	520077	487-498	520138	452-471
520018	481-501	520078	463-487	520139	525
520019	504	520079	464	520140	458
520020	504-518	520080	487	520141	452-525
520021	449-456-531	520081	475-488	520142	452-513
520022	457	520082	513	520143	477
520023	468	520083	498	520144	452
520024	491	520084	507	520145	499
520025	518	520085	502	520146	526
520026	491	520086	451	520147	485
520027	468	520087	470-508	520148	526
520028	496	520088	502	520149	506-509
520029	474	520089	521	520150	482
520030	519	520090	521	520152	495-526
520031	496	520091	502	520153	466
520032	492	520092	498-522	520154	477
520033	475	520093	475	520155	477
520034	449-462-510-513	520094	502	520157	483-527
520035	481	520095	482-499-511-522	520158	514
520036	449-469-504-513-515	520096	476-476-495	520159	488
520037	475	520097	523	520160	471
520038	463	520098	464	520161	499
520039	519	520099	451-464-470-510	520162	499
520040	457	520100	464	520163	489
520041	487	520101	451-465-471	520164	489-510
520042	485	520102	465	520165	527
520043	492	520103	482	520167	452-472
520044	507	520104	465-476-493	520168	505
520045	519	520105	523	520169	505
520046	492	520106	523	520170	458-466-485-527
520047	487	520107	493	520171	466
520048	462	520108	471	520172	477
520049	450-463	520109	532	520173	527
520050	450-492-496	520110	504	520174	478-503
520051	450-457-463-481-501-520	520112	511	520175	459-508
520052	520	520113	524	520176	527
520053	496	520114	524	520177	494-528
520054	463	520115	488	520178	466-511-514-532
520055	469	520116	482	520179	459
520056	450-469-469-492-493-497-497-501-515	520118	525	520180	466
520058	507-531	520119	488	520181	485
520060	457-470	520120	457	520182	459
		520121	485	520183	483

BOOT KITS INDEX

SHOCK ABSORBER PROTECTION KITS

KIT	PAGE
520184	453
520185	472
520186	486
520187	472
520188	459
520189	459
520190	453-467
520191	460
520193	489
520194	489
520195	489
520196	490
520197	483-532
520198	508
520199	483-532
520200	528
520201	499
520202	490
520203	528
520204	483
520205	484-503
520206	460
520207	472
520208	484
520209	484
520210	460
520211	472
520213	503
520214	529
520215	490
520216	478-500
520217	453-478
520218	529
520219	473
520220	460
520221	454-473-479-500-512
520222	473-490
520223	529
520224	530
520225	530
520226	503
520227	460
520228	530
520229	530
520230	473-500
520231	500
520232	453
520233	461



C.V. JOINT BOOT KITS



500594
APPLICATION

BOX SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 96 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT

500 (312_)
 PANDA (169_)
 PANDA (312_, 319_)
 PANDA Van (169_)

500356
APPLICATION

WHEEL SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 97 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

127 (127_)
 128 (128_)
 FIORINO (127_)
 PANDA (141_)
 RITMO (138_)
 X 1/9 (128_)
 A 112
 PRISMA (831_)

500375
APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



FIAT

PANDA (169_)

500355
APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 97 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

127 (127_)
 128 (128_)
 FIORINO (127_)
 PANDA (141_)
 RITMO (138_)
 X 1/9 (128_)
 A 112
 PRISMA (831_)

500170
APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



FIAT

PUNTO (188_)

500534
APPLICATION

BOX SIDE
 Ø = 19 mm
 Ø = 64 mm
 H = 88 mm



FIAT
 FIAT
 FIAT

FIORINO (225_)
 PANDA (169_)
 QUBO (225_)

500141
APPLICATION

BOX SIDE
 Ø = 19 mm
 Ø = 69,5 mm
 H = 96,4 mm



ABARTH
 ABARTH
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT

500 / 595 (312_)
 GRANDE PUNTO (199_)
 145 (930_)
 146 (930_)
 MITO (955_)
 500 (312_)
 500 C (312_)
 BRAVA (182_)
 BRAVO I (182_)
 BRAVO II (198_)
 CINQUECENTO (170_)
 CINQUECENTO VAN (170)
 DOBLO (119_, 223_)
 DOBLO (223_)
 DOBLO (263_)
 GRANDE PUNTO (199_)
 GRANDE PUNTO Van (199_)
 IDEA (350_)
 LINEA (323_)
 MAREA (185_)
 MULTIPLA (186_)
 PALIO (178_)
 PALIO (178BX)
 PANDA (169_)
 PUNTO (176_)
 PUNTO (188_)
 PUNTO (199_)
 PUNTO EVO (199_)
 PUNTO EVO Van (199_)
 PUNTO Van (188_)
 QUBO (225_)
 SEICENTO / 600 (187_)

FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA
 LANCIA
 LANCIA
 SEICENTO / 600 (287_)
 SIENA (172_)
 SIENA (178_)
 STILO (192_)
 STILO VAN (192_)
 STRADA (178_)
 UNO (146_)
 LYBRA (839_)
 MUSA (350_)
 Y (840_)
 YPSILON (843_)

500056
APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 85 mm
 H = 75 mm



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO

33 (905_)
 33 (905A_)
 33 (907A_)
 33 (907B_)
 ALFASUD (901_)
 ALFASUD (902_)
 ARNA (920_)

500137
APPLICATION

BOX SIDE
 $\emptyset = 19,3 \text{ mm}$
 $\emptyset = 54,5 \text{ mm}$
 $H = 100,8 \text{ mm}$



FIAT	BRAVA (182_)
FIAT	BRAVO I (182_)
FIAT	CINQUECENTO (170_)
FIAT	MAREA (185_)
FIAT	PUNTO (176_)
FIAT	SEICENTO / 600 (187_)
FIAT	SEICENTO / 600 (287_)
FIAT	UNO (146_)

500509
APPLICATION

BOX SIDE
 $\emptyset = 19,3 \text{ mm}$
 $\emptyset = 62 \text{ mm}$
 $H = 83 \text{ mm}$



FIAT	PUNTO (188_)
FIAT	SIENA (178_)

500194
APPLICATION

WHEEL SIDE
 $\emptyset = 19,3 \text{ mm}$
 $\emptyset = 64,7 \text{ mm}$
 $H = 82 \text{ mm}$



FIAT	CINQUECENTO (170_)	FIAT	UNO (146_)
FIAT	FIORINO (146_)	LANCIA	DEDRA (835_)
FIAT	PANDA (141_)	LANCIA	DELTA I (831_)
FIAT	PANDA (169_)	LANCIA	DELTA II (836_)
FIAT	REGATA (138_)	LANCIA	PRISMA (831_)
FIAT	SEICENTO / 600 (187_)	LANCIA	Y10 (156_)
FIAT	SEICENTO / 600 (287_)		
FIAT	TEMPRA (159_)		
FIAT	TIPO (160_)		

500414
APPLICATION

BOX SIDE
 $\emptyset = 19,85 \text{ mm}$
 $\emptyset = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



FIAT	FIORINO (225_)	LANCIA	MUSA (350_)
FIAT	GRANDE PUNTO (199_)	LANCIA	YPSILON (843_)
FIAT	GRANDE PUNTO Van (199_)		
FIAT	IDEA (350_)		
FIAT	PUNTO (199_)		
FIAT	PUNTO EVO (199_)		
FIAT	PUNTO EVO Van (199_)		
FIAT	QUBO (225_)		

500350
APPLICATION

WHEEL SIDE
 $\emptyset = 20 \text{ mm}$
 $\emptyset = 68 \text{ mm}$
 $H = 87 \text{ mm}$



FIAT	127 (127_)
FIAT	DUNA (146_)
FIAT	FIORINO (146_)
FIAT	FIORINO (147_)
FIAT	FIORINO Pick up (146_)
FIAT	UNO (146_)

500254
APPLICATION

WHEEL SIDE
 Ø = 20 mm
 Ø = 70 mm
 H = 80 mm



FIAT	127 (127_)	LANCIA	A 112
FIAT	FIORINO (127_)	LANCIA	DELTA I (831_)
FIAT	FIORINO (147_)	LANCIA	PRISMA (831_)
FIAT	FIORINO Pick up (147_)	LANCIA	Y10 (156_)
FIAT	PANDA (141_)		
FIAT	REGATA (138_)		
FIAT	RITMO (138_)		
FIAT	UNO (146_)		
FIAT	X 1/9 (128_)		

500042
APPLICATION

WHEEL SIDE
 Ø = 20 mm
 Ø = 76 mm
 H = 80 mm



ALFA ROMEO	33 (905_)
ALFA ROMEO	ALFASUD (901_)
ALFA ROMEO	ALFASUD (904_)
ALFA ROMEO	ARNA (920_)

500042E
APPLICATION

WHEEL SIDE
 Ø = 20 mm
 Ø = 76 mm
 H = 80 mm



ALFA ROMEO	33 (905_)
ALFA ROMEO	ALFASUD (901_)
ALFA ROMEO	ALFASUD (904_)
ALFA ROMEO	ARNA (920_)

500154
APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 80 mm
 H = 80 mm



FIAT	PANDA (141_)
FIAT	REGATA (138_)
FIAT	UNO (146_)

500349
APPLICATION

WHEEL SIDE
 Ø = 20 mm
 Ø = 80 mm
 H = 93 mm



FIAT	600
------	-----

500032

APPLICATION

WHEEL SIDE
 Ø = 20,4 mm
 Ø = 72,6 mm
 H = 97,3 mm



FIAT	127 (127_)	FIAT	UNO (146_)
FIAT	128 (128_)	FIAT	X 1/9 (128_)
FIAT	CINQUECENTO (170_)	LANCIA	A 112
FIAT	PANDA (141_)	LANCIA	DEDRA (835_)
FIAT	PANDA (169_)	LANCIA	DELTA II (836_)
FIAT	RITMO (138_)	LANCIA	Y10 (156_)
FIAT	SEICENTO / 600 (187_)		
FIAT	TEMPRA (159_)		
FIAT	TIPO (160_)		

500032E

APPLICATION

WHEEL SIDE
 Ø = 20,4 mm
 Ø = 72,6 mm
 H = 97,3 mm



FIAT	127 (127_)	FIAT	UNO (146_)
FIAT	128 (128_)	FIAT	X 1/9 (128_)
FIAT	CINQUECENTO (170_)	LANCIA	A 112
FIAT	PANDA (141_)	LANCIA	DEDRA (835_)
FIAT	PANDA (169_)	LANCIA	DELTA II (836_)
FIAT	RITMO (138_)	LANCIA	Y10 (156_)
FIAT	SEICENTO / 600 (187_)		
FIAT	TEMPRA (159_)		
FIAT	TIPO (160_)		

500601

APPLICATION

BOX SIDE
 Ø = 20,5 mm
 Ø = 66,5 mm
 H = 94 mm



LANCIA	FLAVIA
--------	--------

500024

APPLICATION

WHEEL SIDE
 Ø = 20,7 mm
 Ø = 74,8 mm
 H = 103 mm



FIAT	CINQUECENTO (170_)
FIAT	SEICENTO / 600 (187_)
FIAT	SEICENTO / 600 (287_)
FIAT	TEMPRA (159_)
FIAT	TIPO (160_)
LANCIA	DEDRA (835_)

500263

APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 64 mm
 H = 84 mm



FIAT	PANDA (141_)
FIAT	PUNTO (176_)
FIAT	SEICENTO / 600 (187_)
FIAT	UNO (146_)
LANCIA	Y (840_)

500187
APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 68 mm
 H = 113 mm



FIAT	BRAVA (182_)
FIAT	BRAVO I (182_)
FIAT	MAREA (185_)
FIAT	MULTIPLA (186_)
FIAT	PALIO (178_)
FIAT	PUNTO (188_)
FIAT	SIENA (172_)
FIAT	SIENA (178_)
FIAT	STRADA (178_)

500636T
APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 69,13 mm
 H = 105 mm



FIAT	PANDA (169_)
------	--------------

500292
APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 70 mm
 H = 88 mm



ABARTH	500 / 595 (312_)	FIAT	PUNTO (199_)
ABARTH	500C / 595C (312_)	FIAT	QUBO (225_)
ALFA ROMEO	MITO (955_)	FIAT	SIENA (172_)
FIAT	DOBLO (119_, 223_)	FIAT	SIENA (178_)
FIAT	DOBLO (223_)	FIAT	STILO (192_)
FIAT	FIORINO (225_)	FIAT	STILO VAN (192_)
FIAT	GRANDE PUNTO (199_)	LANCIA	MUSA (350_)
FIAT	GRANDE PUNTO Van (199_)	LANCIA	YPSILON (843_)
FIAT	IDEA (350_)		
FIAT	LINEA (323_)		
FIAT	PALIO (178BX)		
FIAT	PUNTO (188_)		

500040
APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 70,5 mm
 H = 80 mm



FIAT	127 (127_)	FIAT	RITMO (138_)
FIAT	128 (128_)	FIAT	UNO (146_)
FIAT	DUNA (146_)	FIAT	X 1/9 (128_)
FIAT	FIORINO (127_)	LANCIA	A 112
FIAT	FIORINO (146_)	LANCIA	DELTA I (831_)
FIAT	FIORINO (147_)	LANCIA	PRISMA (831_)
FIAT	FIORINO Pick up (146_)	LANCIA	Y10 (156_)
FIAT	PANDA (141_)		
FIAT	REGATA (138_)		

500040E
APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 70,5 mm
 H = 80 mm



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA

127 (127_)
 FIORINO (127_)
 FIORINO (147_)
 PANDA (141_)
 REGATA (138_)
 RITMO (138_)
 UNO (146_)
 X 1/9 (128_)
 A 112

LANCIA
 LANCIA
 LANCIA

DELTA I (831_)
 PRISMA (831_)
 Y10 (156_)

500595
APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 75 mm
 H = 100 mm



FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

SCUDO (220_)
 ULYSSE (179_)
 ULYSSE (220_)
 PHEDRA (179_)
 ZETA (22_)

500050
APPLICATION

WHEEL SIDE
 Ø = 21,8 mm
 Ø = 82,4 mm
 H = 81,6 mm



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO

145 (930_)
 146 (930_)
 155 (167_)
 164 (164_)
 33 (907A_)
 33 (907B_)
 ALFASUD (901_)
 ALFASUD (904_)
 GTV (916_)

ALFA ROMEO
 LANCIA

SPIDER (916_)
 KAPPA (838_)

500050E
APPLICATION

WHEEL SIDE
 Ø = 21,8 mm
 Ø = 82,4 mm
 H = 81,6 mm



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO

145 (930_)
 146 (930_)
 155 (167_)
 164 (164_)
 33 (907A_)
 33 (907B_)
 ALFASUD (901_)
 ALFASUD (904_)
 GTV (916_)

ALFA ROMEO
 LANCIA

SPIDER (916_)
 KAPPA (838_)

500221
APPLICATION

BOX SIDE
 Ø = 22 mm
 Ø = 66 mm
 H = 93 mm



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

FIORINO (225_)
 GRANDE PUNTO (199_)
 IDEA (350_)
 PUNTO EVO (199_)
 QUBO (225_)
 MUSA (350_)
 YPSILON (843_)

500359

APPLICATION

BOX SIDE
 Ø = 22 mm
 Ø = 69 mm
 H = 86 mm



FIAT
 FIAT
 FIAT

DOBLO (119_, 223_)
 DOBLO (223_)
 GRANDE PUNTO (199_)

500362

APPLICATION

BOX SIDE
 Ø = 22 mm
 Ø = 69 mm
 H = 87 mm



FIAT
 FIAT
 LANCIA

DOBLO (223_)
 GRANDE PUNTO (199_)
 MUSA (350_)

500409T

APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 71 mm
 H = 114,5 mm



FIAT
 FIAT
 FIAT

500 (312_)
 500 C (312_)
 PANDA (169_)

500322T

APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 73 mm
 H = 116 mm



ABARTH
 ALFA ROMEO
 FIAT
 FIAT

FIAT
 FIAT
 FIAT

GRANDE PUNTO (199_)
 MITO (955_)
 GRANDE PUNTO (199_)
 GRANDE PUNTO Van (199_)
 PUNTO (199_)
 PUNTO EVO (199_)
 PUNTO EVO Van (199_)

500025

APPLICATION

BOX SIDE
 Ø = 22 mm
 Ø = 77 mm
 H = 103 mm



ABARTH
 ALFA ROMEO
 FIAT

GRANDE PUNTO (199_)
 MITO (955_)
 GRANDE PUNTO (199_)

500025E
APPLICATION

BOX SIDE
 Ø = 22 mm
 Ø = 77 mm
 H = 103 mm



ABARTH
 ALFA ROMEO
 FIAT

GRANDE PUNTO (199_)
 MITO (955_)
 GRANDE PUNTO (199_)

500285T
APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 77,4 mm
 H = 116,5 mm



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA

500 (312_)
 500 C (312_)
 FIORINO (225_)
 PANDA VAN (312_)
 QUBO (225_)
 YPSILON (312_)

500613T
APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 78 mm
 H = 118 mm



LANCIA

YPSILON (843_)

500002
APPLICATION

WHEEL SIDE
 Ø = 22,4 mm
 Ø = 52,2 mm
 H = 77 mm



ALFA ROMEO 1750-2000 (105_)
 ALFA ROMEO 6 (119_)
 ALFA ROMEO 75 (162B_)
 ALFA ROMEO 90 (162_)
 ALFA ROMEO ALFETTA (116_)
 ALFA ROMEO ALFETTA GT (116_)
 ALFA ROMEO GIULIETTA (116_)
 ALFA ROMEO GTV (116)
 ALFA ROMEO GTV (116_)
 ALFA ROMEO SZ

FIAT CROMA (154_)

500038T
APPLICATION

WHEEL SIDE
 Ø = 22,5 mm
 Ø = 79 mm
 H = 91,65 mm



ABARTH	500 / 595 (312_)	FIAT	PALIO (178BX)
ALFA ROMEO	145 (930_)	FIAT	PANDA (169_)
ALFA ROMEO	146 (930_)	FIAT	PUNTO (176_)
ALFA ROMEO	MITO (955_)	FIAT	PUNTO (188_)
FIAT	500 (312_)	FIAT	PUNTO (199_)
FIAT	500 C (312_)	FIAT	PUNTO EVO (199_)
FIAT	BRAVA (182_)	FIAT	PUNTO Van (188_)
FIAT	BRAVO I (182_)	FIAT	QUBO (225_)
FIAT	BRAVO II (198_)	FIAT	SIENA (178_)
FIAT	DOBL0 (119_, 223_)	FIAT	STILO (192_)
FIAT	DOBL0 (223_)	FIAT	STILO VAN (192_)
FIAT	DOBL0 (263_)	LANCIA	DEDRA (835_)
FIAT	FIORINO (146_)	LANCIA	DELTA II (836_)
FIAT	FIORINO (225_)	LANCIA	LYBRA (839_)
FIAT	FIORINO Pick up (146_)	LANCIA	MUSA (350_)
FIAT	IDEA (350_)	LANCIA	Y (840_)
FIAT	LINEA (323_)	LANCIA	YPSILON (843_)
FIAT	MAREA (185_)		
FIAT	MULTIPLA (186_)		
FIAT	PALIO (178_)		

500097
APPLICATION

WHEEL SIDE
 Ø = 22,8 mm
 Ø = 94,3 mm
 H = 145 mm



FIAT	DUCATO (230_)
FIAT	DUCATO (244_)
FIAT	DUCATO (280_)
FIAT	DUCATO (290_)
FIAT	TALENTO (290_)

500095
APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 51 mm
 H = 80 mm



ALFA ROMEO	145 (930_)	ALFA ROMEO	ARNA (920_)
ALFA ROMEO	146 (930_)		
ALFA ROMEO	33 (905_)		
ALFA ROMEO	33 (905A_)		
ALFA ROMEO	33 (907A_)		
ALFA ROMEO	33 (907B_)		
ALFA ROMEO	ALFASUD (901_)		
ALFA ROMEO	ALFASUD (902_)		
ALFA ROMEO	ALFASUD (904_)		

500597
APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 65 mm
 H = 90 mm



ABARTH	GRANDE PUNTO (199_)
ALFA ROMEO	MITO (955_)
FIAT	GRANDE PUNTO (199_)
FIAT	PUNTO EVO (199_)
FIAT	SEDICI (FY_)

500085
APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 71 mm
 H = 78 mm



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA

127 (127_)
 FIORINO (127_)
 FIORINO (147_)
 FIORINO Pick up (147_)
 PANDA (141_)
 REGATA (138_)
 UNO (146_)
 X 1/9 (128_)
 A 112

LANCIA
 LANCIA
 LANCIA

DELTA I (831_)
 PRISMA (831_)
 Y10 (156_)

500479
APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 72,5 mm
 H = 107,5 mm



FIAT
 FIAT
 FIAT

GRANDE PUNTO (199_)
 PUNTO (188_)
 PUNTO (199_)

500158
APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 73 mm
 H = 74 mm



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT

127 (127_)
 DUNA (146_)
 FIORINO (127_)
 FIORINO (146_)
 FIORINO (147_)
 PANDA (141_)
 REGATA (138_)
 UNO (146_)
 X 1/9 (128_)

LANCIA
 LANCIA
 LANCIA
 LANCIA

A 112
 DELTA I (831_)
 PRISMA (831_)
 Y10 (156_)

500531
APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 73 mm
 H = 87 mm



FIAT
 FIAT

SEDICI
 SEDICI (FY_)

500299
APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 74 mm
 H = 79 mm



FIAT
 FIAT
 LANCIA
 LANCIA

REGATA (138_)
 UNO (146_)
 DELTA I (831_)
 PRISMA (831_)

500044
APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 76 mm
 H = 83 mm



FIAT

CINQUECENTO (170_)

500081
APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 80 mm
 H = 80 mm



FIAT

PANDA (141_)

FIAT

REGATA (138_)

FIAT

RITMO (138_)

FIAT

UNO (146_)

LANCIA

DELTA I (831_)

LANCIA

Y10 (156_)

500373
APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 99 mm
 H = 98 mm



ALFA ROMEO

145 (930_)

ALFA ROMEO

146 (930_)

ALFA ROMEO

147 (937_)

ALFA ROMEO

155 (167_)

ALFA ROMEO

156 (932_)

ALFA ROMEO

164 (164_)

ALFA ROMEO

166 (936_)

ALFA ROMEO

GT (937_)

ALFA ROMEO

GTV (916_)

ALFA ROMEO

SPIDER (916_)

FIAT

126 (126_)

FIAT

BARCHETTA (183_)

FIAT

BRAVA (182_)

FIAT

BRAVO I (182_)

FIAT

COUPE (175_)

FIAT

CROMA (154_)

FIAT

IDEA (350_)

FIAT

MAREA (185_)

FIAT

MULTIPLA (186_)

FIAT

PALIO (178_)

FIAT

PALIO (178BX)

FIAT

PUNTO (176_)

FIAT

PUNTO (188_)

FIAT

SIENA (172_)

FIAT

SIENA (178_)

FIAT

STILO (192_)

FIAT

STILO VAN (192_)

FIAT

STRADA (178_)

FIAT

TEMPRA (159_)

FIAT

TIPO (160_)

FIAT

UNO (146_)

LANCIA

DELTA I (831_)

LANCIA

DELTA II (836_)

LANCIA

KAPPA (838_)

LANCIA

LYBRA (839_)

LANCIA

MUSA (350_)

LANCIA

PRISMA (831_)

LANCIA

THEMA (834_)

500046
APPLICATION

WHEEL SIDE
 Ø = 23,1 mm
 Ø = 75,9 mm
 H = 82 mm



FIAT

REGATA (138_)

FIAT

RITMO (138_)

LANCIA

DELTA I (831_)

LANCIA

PRISMA (831_)

500067
APPLICATION

BOX SIDE
 $\emptyset = 23,2 \text{ mm}$
 $\emptyset = 56,2 \text{ mm}$
 $H = 99 \text{ mm}$



ALFA ROMEO	145 (930_)
ALFA ROMEO	146 (930_)
ALFA ROMEO	164 (164_)
ALFA ROMEO	166 (936_)
FIAT	MAREA (185_)
LANCIA	KAPPA (838_)
LANCIA	LYBRA (839_)

500026
APPLICATION

WHEEL SIDE
 $\emptyset = 23,2 \text{ mm}$
 $\emptyset = 82 \text{ mm}$
 $H = 99 \text{ mm}$



ALFA ROMEO	147 (937_)
ALFA ROMEO	156 (932_)
ALFA ROMEO	166 (936_)
FIAT	BRAVO II (198_)
FIAT	CROMA (194_)
LANCIA	DELTA III (844_)
LANCIA	LYBRA (839_)
LANCIA	THESIS (841_)

500079
APPLICATION

BOX SIDE
 $\emptyset = 23,5 \text{ mm}$
 $\emptyset = 60 \text{ mm}$
 $H = 82,4 \text{ mm}$



ALFA ROMEO	145 (930_)	FIAT	SIENA (172_)
ALFA ROMEO	146 (930_)	FIAT	SIENA (178_)
ALFA ROMEO	147 (937_)	FIAT	STILO (192_)
ALFA ROMEO	156 (932_)	FIAT	STILO VAN (192_)
ALFA ROMEO	164 (164_)	FIAT	STRADA (178_)
ALFA ROMEO	166 (936_)	FIAT	TIPO (160_)
ALFA ROMEO	GT (937_)	FIAT	UNO (146_)
ALFA ROMEO	GTV (916_)	LANCIA	BETA (828_)
ALFA ROMEO	SPIDER (916_)	LANCIA	DEDRA (835_)
FIAT	BARCHETTA (183_)	LANCIA	DELTA I (831_)
FIAT	BRAVA (182_)	LANCIA	DELTA II (836_)
FIAT	BRAVO I (182_)	LANCIA	KAPPA (838_)
FIAT	CROMA (154_)	LANCIA	LYBRA (839_)
FIAT	IDEA (350_)	LANCIA	MUSA (350_)
FIAT	MAREA (185_)	LANCIA	PRISMA (831_)
FIAT	MULTIPLA (186_)	LANCIA	THEMA (834_)
FIAT	PALIO (178_)	LANCIA	TREVI (828_)
FIAT	PALIO (178BX)		
FIAT	PUNTO (176_)		
FIAT	PUNTO (188_)		

500048
APPLICATION

WHEEL SIDE
 $\varnothing = 23,8 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 87 \text{ mm}$



ALFA ROMEO	145 (930_)
ALFA ROMEO	146 (930_)
ALFA ROMEO	147 (937_)
ALFA ROMEO	155 (167_)
ALFA ROMEO	156 (932_)
ALFA ROMEO	164 (164_)
ALFA ROMEO	33 (907A_)
ALFA ROMEO	33 (907B_)
ALFA ROMEO	GTV (916_)
ALFA ROMEO	SPIDER (916_)
FIAT	BARCETTA (183_)
FIAT	BRAVA (182_)
FIAT	BRAVO I (182_)
FIAT	COUPE (175_)
FIAT	CROMA (154_)
FIAT	MAREA (185_)
FIAT	PUNTO (176_)
FIAT	SCUDO (220_)
FIAT	TEMPRA (159_)
FIAT	TIPO (160_)
FIAT	ULYSSE (220_)

LANCIA	DEDRA (835_)
LANCIA	DELTA I (831_)
LANCIA	DELTA II (836_)
LANCIA	KAPPA (838_)
LANCIA	LYBRA (839_)
LANCIA	THEMA (834_)
LANCIA	ZETA (22_)

500278
APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 98 \text{ mm}$



ALFA ROMEO	155 (167_)
ALFA ROMEO	164 (164_)
ALFA ROMEO	GTV (916_)
ALFA ROMEO	SPIDER (916_)
FIAT	COUPE (175_)
FIAT	CROMA (154_)

500239T
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 125 \text{ mm}$



FIAT	500 (312_)
FIAT	500 C (312_)
FIAT	FIORINO (225_)
FIAT	GRANDE PUNTO (199_)
FIAT	IDEA (350_)
FIAT	PANDA (312_, 319_)
FIAT	PUNTO (199_)
FIAT	PUNTO EVO (199_)
FIAT	QUBO (225_)

LANCIA	MUSA (350_)
LANCIA	YPSILON (312_)
LANCIA	YPSILON (843_)

500267
APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 101 \text{ mm}$



FIAT	CROMA (194_)
------	--------------

500175
APPLICATION

BOX SIDE
 Ø = 24 mm
 Ø = 70 mm
 H = 116 mm



ALFA ROMEO	147 (937_)
ALFA ROMEO	156 (932_)
ALFA ROMEO	166 (936_)
ALFA ROMEO	GT (937_)
FIAT	BRAVO II (198_)
FIAT	BRAVO Van (198)
FIAT	DOBLO (263_)
FIAT	IDEA (350_)
FIAT	STILO (192_)

FIAT	STILO VAN (192_)
LANCIA	DELTA III (844_)
LANCIA	LYBRA (839_)
LANCIA	MUSA (350_)

500240T
APPLICATION

WHEEL SIDE
 Ø = 24 mm
 Ø = 84 mm
 H = 115 mm



ALFA ROMEO	GIULIETTA (940_)
ALFA ROMEO	MITO (955_)
FIAT	500L (199_)
FIAT	BRAVO II (198_)
FIAT	DOBLO (263_)
FIAT	GRANDE PUNTO (199_)
FIAT	LINEA (323_)
FIAT	PUNTO (199_)
FIAT	PUNTO EVO (199_)

FIAT	PUNTO EVO Van (199_)
FIAT	STILO (192_)
LANCIA	DELTA III (844_)

500101T
APPLICATION

BOX SIDE
 Ø = 24 mm
 Ø = 84 mm
 H = 129 mm



FIAT	DUCATO (244_)
FIAT	SCUDO (220_)
LANCIA	ZETA (22_)

500117
APPLICATION

WHEEL SIDE
 Ø = 24 mm
 Ø = 85 mm
 H = 87 mm



FIAT	CROMA (154_)
LANCIA	BETA (828_)
LANCIA	BETA H.P.E. (828_)
LANCIA	DELTA I (831_)
LANCIA	PRISMA (831_)
LANCIA	THEMA (834_)
LANCIA	TREVI (828_)

500139
APPLICATION

BOX SIDE
 Ø = 24 mm
 Ø = 98 mm
 H = 100 mm



FIAT	DUCATO (280_)
FIAT	TALENTO (290_)

500132
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 108 \text{ mm}$
 $H = 125,5 \text{ mm}$



ALFA ROMEO	155 (167_)
ALFA ROMEO	164 (164_)
ALFA ROMEO	GTV (916_)
ALFA ROMEO	SPIDER (916_)
FIAT	CROMA (154_)
LANCIA	KAPPA (838_)
LANCIA	THEMA (834_)

500294T
APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



ABARTH	500 / 595 (312_)	FIAT	PALIO (178_)
ABARTH	500C / 595C (312_)	FIAT	PALIO (178BX)
ALFA ROMEO	145 (930_)	FIAT	PANDA (169_)
ALFA ROMEO	146 (930_)	FIAT	PANDA (312_, 319_)
ALFA ROMEO	147 (937_)	FIAT	PANDA VAN (312_)
ALFA ROMEO	155 (167_)	FIAT	PUNTO (176_)
ALFA ROMEO	159 (939_)	FIAT	PUNTO (188_)
ALFA ROMEO	GTV (916_)	FIAT	PUNTO (199_)
ALFA ROMEO	MITO (955_)	FIAT	QUBO (225_)
ALFA ROMEO	SPIDER (916_)	FIAT	SCUDO (220_)
FIAT	500 (312_)	FIAT	SIENA (172_)
FIAT	500 C (312_)	FIAT	SIENA (178_)
FIAT	500L (199_)	FIAT	STILO (192_)
FIAT	500X (334_)	FIAT	STILO VAN (192_)
FIAT	BARCHETTA (183_)	FIAT	STRADA (178_)
FIAT	BRAVA (182_)	FIAT	ULYSSE (220_)
FIAT	BRAVO I (182_)	LANCIA	DEDRA (835_)
FIAT	BRAVO II (198_)	LANCIA	DELTA II (836_)
FIAT	COUPE (175_)	LANCIA	LYBRA (839_)
FIAT	DOBLO (119_, 223_)	LANCIA	MUSA (350_)
FIAT	DOBLO (223_)	LANCIA	PHEDRA (179_)
FIAT	FIORINO (146_)	LANCIA	Y (840_)
FIAT	FIORINO (225_)	LANCIA	Y10 (156_)
FIAT	FIORINO Pick up (146_)	LANCIA	YPSILON (843_)
FIAT	GRANDE PUNTO (199_)	LANCIA	ZETA (22_)
FIAT	GRANDE PUNTO Van (199_)		
FIAT	IDEA (350_)		
FIAT	LINEA (323_)		
FIAT	MAREA (185_)		
FIAT	MULTIPLA (186_)		

500003
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 57 \text{ mm}$
 $H = 70 \text{ mm}$



ALFA ROMEO	147 (937_)
ALFA ROMEO	156 (932_)

500076
APPLICATION

BOX SIDE
 Ø = 25 mm
 Ø = 64 mm
 H = 86 mm



FIAT	127 (127_)
FIAT	128 (128_)
FIAT	FIORINO (127_)
FIAT	PANDA (141_)
FIAT	RITMO (138_)
FIAT	X 1/9 (128_)
LANCIA	A 112
LANCIA	DELTA I (831_)

500084
APPLICATION

BOX SIDE
 Ø = 25 mm
 Ø = 71 mm
 H = 78 mm



FIAT	127 (127_)
FIAT	FIORINO (147_)
FIAT	FIORINO Pick up (147_)
FIAT	PANDA (141_)
FIAT	REGATA (138_)
FIAT	RITMO (138_)
FIAT	UNO (146_)
FIAT	X 1/9 (128_)
LANCIA	A 112

500156
APPLICATION

BOX SIDE
 Ø = 25 mm
 Ø = 71 mm
 H = 78 mm



FIAT	127 (127_)
FIAT	FIORINO (147_)
FIAT	PANDA (141_)
FIAT	REGATA (138_)
FIAT	UNO (146_)
LANCIA	A 112

500155
APPLICATION

BOX SIDE
 Ø = 25 mm
 Ø = 73 mm
 H = 71 mm



FIAT	127 (127_)
FIAT	128 (128_)
FIAT	REGATA (138_)
FIAT	RITMO (138_)
FIAT	UNO (146_)
FIAT	X 1/9 (128_)
LANCIA	DELTA I (831_)

500424
APPLICATION

BOX SIDE
 Ø = 25 mm
 Ø = 78,3 mm
 H = 96 mm



FIAT	SCUDO (270_, 272_)
FIAT	ULYSSE (179_)
LANCIA	PHEDRA (179_)

500153
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 80 \text{ mm}$



FIAT
 FIAT

PANDA (141_)
 REGATA (138_)

500295T
APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 91 \text{ mm}$
 $H = 125 \text{ mm}$



LANCIA

ZETA (22_)

500251
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 107,5 \text{ mm}$
 $H = 80 \text{ mm}$



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO

145 (930_)
 146 (930_)
 147 (937_)
 164 (164_)

500342T
APPLICATION

WHEEL SIDE
 $\varnothing = 25,1 \text{ mm}$
 $\varnothing = 86,75 \text{ mm}$
 $H = 110 \text{ mm}$



FIAT

CROMA (194_)

500123
APPLICATION

WHEEL SIDE
 $\varnothing = 25,3 \text{ mm}$
 $\varnothing = 76,3 \text{ mm}$
 $H = 80 \text{ mm}$



FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA
 LANCIA
 LANCIA
 LANCIA

TEMPRA (159_)
 TIPO (160_)
 UNO (146_)
 DEDRA (835_)
 DELTA I (831_)
 DELTA II (836_)
 PRISMA (831_)
 Y10 (156_)

500111
APPLICATION

WHEEL SIDE
 Ø = 25,3 mm
 Ø = 84,5 mm
 H = 96 mm



ALFA ROMEO	145 (930_)
ALFA ROMEO	146 (930_)
ALFA ROMEO	155 (167_)
ALFA ROMEO	164 (164_)
ALFA ROMEO	33 (905_)
ALFA ROMEO	33 (905A_)
ALFA ROMEO	33 (907A_)
ALFA ROMEO	GTV (916_)
ALFA ROMEO	SPIDER (916_)
FIAT	BARCETTA (183_)
FIAT	BRAVA (182_)
FIAT	BRAVO I (182_)
FIAT	COUPE (175_)
FIAT	CROMA (154_)
FIAT	PUNTO (176_)
FIAT	SCUDO (220_)
FIAT	TEMPRA (159_)
FIAT	TIPO (160_)
FIAT	ULYSSE (220_)
LANCIA	DEDRA (835_)
LANCIA	DELTA I (831_)

LANCIA	KAPPA (838_)
LANCIA	THEMA (834_)
LANCIA	ZETA (22_)

500168T
APPLICATION

WHEEL SIDE
 Ø = 25,5 mm
 Ø = 83 mm
 H = 110 mm



FIAT	SCUDO (220_)
FIAT	ULYSSE (220_)
LANCIA	ZETA (22_)

500075
APPLICATION

BOX SIDE
 Ø = 26 mm
 Ø = 61 mm
 H = 88 mm



FIAT	CROMA (154_)	LANCIA	BETA (828_) Targa
FIAT	FIORINO (146_)	LANCIA	BETA H.P.E. (828_)
FIAT	REGATA (138_)	LANCIA	DEDRA (835_)
FIAT	RITMO (138_)	LANCIA	DELTA I (831_)
FIAT	TEMPRA (159_)	LANCIA	PRISMA (831_)
FIAT	TIPO (160_)	LANCIA	THEMA (834_)
FIAT	UNO (146_)	LANCIA	TREVI (828_)
FIAT	X 1/9 (128_)	LANCIA	Y10 (156_)
LANCIA	BETA (828_)		

500335T
APPLICATION

WHEEL SIDE
 Ø = 26 mm
 Ø = 84 mm
 H = 110 mm



FIAT	SCUDO (220_)
FIAT	SCUDO (270_, 272_)
FIAT	ULYSSE (179_)
FIAT	ULYSSE (220_)
LANCIA	PHEDRA (179_)
LANCIA	ZETA (22_)

500545T
APPLICATION

WHEEL SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 91 \text{ mm}$
 $H = 127 \text{ mm}$



ALFA ROMEO	159 (939_)
ALFA ROMEO	BRERA (939_)
ALFA ROMEO	SPIDER (939_)

500476T
APPLICATION

WHEEL SIDE
 $\varnothing = 26,6 \text{ mm}$
 $\varnothing = 78,2 \text{ mm}$
 $H = 118 \text{ mm}$



ABARTH	GRANDE PUNTO (199_)
ALFA ROMEO	MITO (955_)
FIAT	GRANDE PUNTO (199_)
FIAT	PUNTO EVO (199_)
FIAT	SEDICI (FY_)

500408
APPLICATION

BOX SIDE
 $\varnothing = 26,85 \text{ mm}$
 $\varnothing = 68,35 \text{ mm}$
 $H = 115,65 \text{ mm}$



ALFA ROMEO	147 (937_)
ALFA ROMEO	156 (932_)
ALFA ROMEO	166 (936_)
FIAT	BRAVO II (198_)
FIAT	CROMA (194_)
FIAT	STILO (192_)
LANCIA	DELTA III (844_)
LANCIA	LYBRA (839_)
LANCIA	THESIS (841_)

500185
APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 88 \text{ mm}$



FIAT	FIORINO (225_)
FIAT	QUBO (225_)

500526T
APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 107 \text{ mm}$



ALFA ROMEO	159 (939_)
ALFA ROMEO	BRERA (939_)
ALFA ROMEO	SPIDER (939_)

500612T
APPLICATION
BOX SIDE

$\emptyset = 27 \text{ mm}$
 $\emptyset = 87,5 \text{ mm}$
 $H = 107 \text{ mm}$



ABARTH
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 FIAT

PUNTO EVO (199_)
 159 (939_)
 4C (960_)
 4C SPIDER (961_)
 BRERA (939_)
 GIULIETTA (940_)
 MITO (955_)
 SPIDER (939_)
 500L (199_)

FIAT
 FIAT
 FIAT
 FIAT
 LANCIA

BRAVO II (198_)
 DOBLO (263_)
 LINEA (323_)
 PUNTO EVO (199_)
 DELTA III (844_)

500345T
APPLICATION
WHEEL SIDE

$\emptyset = 27 \text{ mm}$
 $\emptyset = 88 \text{ mm}$
 $H = 100 \text{ mm}$



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA
 LANCIA
 LANCIA

147 (937_)
 156 (932_)
 166 (936_)
 GT (937_)
 GTV (916_)
 SPIDER (916_)
 BRAVO II (198_)
 BRAVO Van (198)
 CROMA (194_)
 DOBLO (263_)
 IDEA (350_)
 STILO (192_)
 STILO VAN (192_)
 DELTA II (836_)
 DELTA III (844_)
 LYBRA (839_)
 MUSA (350_)

500011T
APPLICATION
WHEEL SIDE

$\emptyset = 27,2 \text{ mm}$
 $\emptyset = 98,1 \text{ mm}$
 $H = 144,5 \text{ mm}$



FIAT

DUCATO (244_)

500030T
APPLICATION

WHEEL SIDE
 $\varnothing = 27,5 \text{ mm}$
 $\varnothing = 87,2 \text{ mm}$
 $H = 106,3 \text{ mm}$



ALFA ROMEO	145 (930_)
ALFA ROMEO	146 (930_)
ALFA ROMEO	147 (937_)
ALFA ROMEO	155 (167_)
ALFA ROMEO	156 (932_)
ALFA ROMEO	166 (936_)
ALFA ROMEO	GT (937_)
ALFA ROMEO	GTV (916_)
ALFA ROMEO	SPIDER (916_)
FIAT	BARCETTA (183_)
FIAT	BRAVA (182_)
FIAT	BRAVO I (182_)
FIAT	COUPE (175_)
FIAT	MAREA (185_)
FIAT	MULTIPLA (186_)
FIAT	PUNTO (188_)
FIAT	STILO (192_)
FIAT	STILO VAN (192_)
LANCIA	DELTA II (836_)
LANCIA	KAPPA (838_)
LANCIA	LYBRA (839_)

500543T
APPLICATION

WHEEL SIDE
 $\varnothing = 27,5 \text{ mm}$
 $\varnothing = 96 \text{ mm}$
 $H = 122 \text{ mm}$



LANCIA	THESIS (841_)
--------	---------------

500142
APPLICATION

BOX SIDE
 $\varnothing = 27,55 \text{ mm}$
 $\varnothing = 75,7 \text{ mm}$
 $H = 92 \text{ mm}$



FIAT	DUCATO (230_)
FIAT	DUCATO (244_)
FIAT	SCUDO (220_)
FIAT	ULYSSE (179_)
FIAT	ULYSSE (220_)
LANCIA	PHEDRA (179_)
LANCIA	ZETA (22_)

500286T
APPLICATION

WHEEL SIDE
 $\varnothing = 27,6 \text{ mm}$
 $\varnothing = 97 \text{ mm}$
 $H = 113,89 \text{ mm}$



FIAT	SCUDO (220_)
FIAT	ULYSSE (179_)
FIAT	ULYSSE (220_)
LANCIA	PHEDRA (179_)
LANCIA	ZETA (22_)

500415
APPLICATION

BOX SIDE
 $\varnothing = 27,68 \text{ mm}$
 $\varnothing = 82,52 \text{ mm}$
 $H = 95 \text{ mm}$



FIAT

DUCATO (250_, 290_)

500312
APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 88 \text{ mm}$



FIAT

CROMA (194_)

500574T
APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 122 \text{ mm}$



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 FIAT
 FIAT
 LANCIA

159 (939_)
 BRERA (939_)
 GIULIETTA (940_)
 SPIDER (939_)
 BRAVO II (198_)
 DOBLO (263_)
 DELTA III (844_)

500333
APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 95 \text{ mm}$
 $H = 85 \text{ mm}$



FIAT
 FIAT

SCUDO (220_)
 ULYSSE (220_)

500520T
APPLICATION

WHEEL SIDE
 $\varnothing = 29 \text{ mm}$
 $\varnothing = 91 \text{ mm}$
 $H = 128 \text{ mm}$



FIAT
 LANCIA

ULYSSE (179_)
 PHEDRA (179_)

500445T
APPLICATION

WHEEL SIDE
 $\varnothing = 29,2 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 112 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

SCUDO (220_)
 SCUDO (270_, 272_)
 ULYSSE (179_)
 ULYSSE (220_)
 PHEDRA (179_)
 ZETA (22_)

500434
APPLICATION

BOX SIDE
 $\varnothing = 29,4 \text{ mm}$
 $\varnothing = 87,3 \text{ mm}$
 $H = 81 \text{ mm}$



FIAT
 FIAT
 LANCIA

SCUDO (270_, 272_)
 ULYSSE (179_)
 PHEDRA (179_)

500071
APPLICATION

BOX SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 92 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

BRAVA (182_)
 BRAVO I (182_)
 CINQUECENTO (170_)
 TEMPRA (159_)
 TIPO (160_)
 UNO (146_)
 DEDRA (835_)
 Y10 (156_)

500070
APPLICATION

BOX SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 92 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA
 LANCIA

CINQUECENTO (170_)
 PANDA (141_)
 REGATA (138_)
 UNO (146_)
 DEDRA (835_)
 PRISMA (831_)
 Y10 (156_)

500147
APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT

BRAVA (182_)
 BRAVO I (182_)
 CINQUECENTO (170_)
 FIORINO (146_)
 FIORINO Pick up (146_)
 PALIO (178_)
 PALIO (178BX)
 PANDA (141_)
 REGATA (138_)

FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA
 LANCIA
 SEICENTO / 600 (187_)
 SEICENTO / 600 (287_)
 SIENA (178_)
 TEMPRA (159_)
 TIPO (160_)
 DEDRA (835_)
 DELTA I (831_)
 Y10 (156_)

500072
APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 LANCIA

BRAVA (182_)
 BRAVO I (182_)
 FIORINO (146_)
 FIORINO Pick up (146_)
 PANDA (141_)
 TEMPRA (159_)
 TIPO (160_)
 UNO (146_)
 DEDRA (835_)

LANCIA

Y10 (156_)

500289
APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT
 FIAT

145 (930_)
 146 (930_)
 147 (937_)
 BRAVA (182_)
 BRAVO I (182_)
 DOBLO (119_, 223_)
 MAREA (185_)
 MULTIPLA (186_)
 PALIO (178_)

FIAT
 FIAT
 FIAT
 LANCIA
 LANCIA

PALIO (178BX)
 PUNTO (176_)
 PUNTO (188_)
 DELTA II (836_)
 LYBRA (839_)

500115
APPLICATION

WHEEL SIDE
 $\varnothing = 32 \text{ mm}$
 $\varnothing = 110,7 \text{ mm}$
 $H = 91 \text{ mm}$



FIAT
 FIAT

DUCATO (230_)
 DUCATO (244_)

500006
APPLICATION

BOX SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 95 \text{ mm}$



FIAT
 FIAT
 FIAT

DUCATO (230_)
 DUCATO (244_)
 DUCATO (280_)

500297T
APPLICATION

WHEEL SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 110 \text{ mm}$
 $H = 160 \text{ mm}$



FIAT
 FIAT

DUCATO (230_)
 DUCATO (244_)

500303T

APPLICATION

WHEEL SIDE
 $\varnothing = 33,5 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 110 \text{ mm}$



FIAT
 FIAT

FIORINO (225_)
 QUBO (225_)

500143

APPLICATION

BOX SIDE
 $\varnothing = 35 \text{ mm}$
 $\varnothing = 99 \text{ mm}$
 $H = 115 \text{ mm}$



ALFA ROMEO

166 (936_)

500090

APPLICATION

BOX SIDE
 $\varnothing = 38 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 92 \text{ mm}$



FIAT

DUCATO (244_)

APPLICATION

WHEEL SIDE

 $\varnothing = 17 \text{ mm}$ $\varnothing = 59 \text{ mm}$

H = 78 mm



AIXAM

400

500059

APPLICATION

BOX SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 62,15 \text{ mm}$
 $H = 110 \text{ mm}$



AUSTIN
 AUSTIN
 AUSTIN
 AUSTIN

ALLEGRO (ADO 67)
 AMBASSADOR
 PRINCESS
 PRINCESS 2

500108

APPLICATION

WHEEL SIDE
 $\varnothing = 17,3 \text{ mm}$
 $\varnothing = 70,8 \text{ mm}$
 $H = 101,5 \text{ mm}$



AUSTIN

METRO

500108E

APPLICATION

WHEEL SIDE
 $\varnothing = 17,3 \text{ mm}$
 $\varnothing = 70,8 \text{ mm}$
 $H = 101,5 \text{ mm}$



AUSTIN

METRO

500392

APPLICATION

WHEEL SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 61,75 \text{ mm}$
 $H = 96,6 \text{ mm}$



AUSTIN

MINI

500063

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 100 \text{ mm}$



AUSTIN
 AUSTIN

MAESTRO (XC)
 MONTEGO (XE)

500109

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



AUSTIN
 AUSTIN

METRO
 MINI

500109E

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



AUSTIN

METRO

500034

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 91 \text{ mm}$



AUSTIN

ALLEGRO (ADO 67)

500025

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 103 \text{ mm}$



AUSTIN
 AUSTIN

MAESTRO (XC)
 MONTEGO (XE)

500025E

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 103 \text{ mm}$



AUSTIN
 AUSTIN

MAESTRO (XC)
 MONTEGO (XE)

APPLICATION

WHEEL SIDE
Ø = 28 mm
Ø = 97 mm
H = 135 mm



AUSTIN

METRO

500356
APPLICATION

WHEEL SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 97 \text{ mm}$



AUTOBIANCHI A 112

500355
APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 97 \text{ mm}$



AUTOBIANCHI A 112

500137
APPLICATION

BOX SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 54,5 \text{ mm}$
 $H = 100,8 \text{ mm}$



AUTOBIANCHI Y10

500194
APPLICATION

WHEEL SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 64,7 \text{ mm}$
 $H = 82 \text{ mm}$



AUTOBIANCHI Y10

500254
APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 80 \text{ mm}$



AUTOBIANCHI A 112
 AUTOBIANCHI Y10

500032
APPLICATION

WHEEL SIDE
 $\varnothing = 20,4 \text{ mm}$
 $\varnothing = 72,6 \text{ mm}$
 $H = 97,3 \text{ mm}$



AUTOBIANCHI A 112

500032E
APPLICATION

WHEEL SIDE
 $\varnothing = 20,4 \text{ mm}$
 $\varnothing = 72,6 \text{ mm}$
 $H = 97,3 \text{ mm}$



AUTOBIANCHI A 112

500040
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



AUTOBIANCHI A 112
 AUTOBIANCHI Y10

500040E
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



AUTOBIANCHI A 112
 AUTOBIANCHI Y10

500085
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 78 \text{ mm}$



AUTOBIANCHI A 112
 AUTOBIANCHI Y10

500158
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 74 \text{ mm}$



AUTOBIANCHI A 112
 AUTOBIANCHI Y10

500081
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 80 \text{ mm}$



AUTOBIANCHI Y10

500076
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 86 \text{ mm}$



AUTOBIANCHI A 112

500084
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 78 \text{ mm}$



AUTOBIANCHI A 112

500156
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 78 \text{ mm}$



AUTOBIANCHI A 112

500123
APPLICATION

WHEEL SIDE
 $\varnothing = 25,3 \text{ mm}$
 $\varnothing = 76,3 \text{ mm}$
 $H = 80 \text{ mm}$



AUTOBIANCHI Y10

500075
APPLICATION

BOX SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 88 \text{ mm}$



AUTOBIANCHI Y10

500071
APPLICATION

BOX SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 92 \text{ mm}$



AUTOBIANCHI Y10

500070
APPLICATION

BOX SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 92 \text{ mm}$



AUTOBIANCHI Y10

500147
APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



AUTOBIANCHI Y10

APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



AUTOBIANCHI Y10

500562

APPLICATION

WHEEL SIDE

Ø = 21 mm

Ø = 90 mm

H = 76 mm

BENTLEY
BENTLEYCONTINENTAL (3W_)
CONTINENTAL FLYING
SPUR (3W_)

500067

APPLICATION

BOX SIDE

Ø = 23,2 mm

Ø = 56,2 mm

H = 99 mm

BENTLEY
BENTLEYCONTINENTAL (3W_)
CONTINENTAL FLYING
SPUR (3W_)

500571T

APPLICATION

BOX SIDE

Ø = 28,5 mm

Ø = 62,5 mm

H = 86 mm



BENTLEY

CONTINENTAL (3W_)

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



MINI
 MINI
 MINI

MINI (R50, R53)
 MINI (R52)
 MINI (R56)

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



MINI
 MINI
 MINI

MINI (R50, R53)
 MINI (R52)
 MINI (R56)

500414

APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



MINI
 MINI

MINI (R50, R53)
 MINI (R52)

500411

APPLICATION

BOX SIDE
 $\varnothing = 19,95 \text{ mm}$
 $\varnothing = 71,2 \text{ mm}$
 $H = 87,9 \text{ mm}$



BMW

X3 (E83)

500093

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 84 \text{ mm}$



MINI
 MINI

MINI COUNTRYMAN
 (R60)
 MINI PACEMAN (R61)

500050

APPLICATION

WHEEL SIDE
 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$



BMW

5 (E34)

500050E

APPLICATION

WHEEL SIDE
 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$



BMW

5 (E34)

500268

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 52 \text{ mm}$
 $H = 77 \text{ mm}$



BMW 3 (E30)
 BMW 3 (E36)
 BMW 3 (E46)
 BMW 5 (E39)
 BMW 7 (E38)
 BMW X5 (E53)
 BMW Z3 (E36)
 BMW Z4 (E85)

500221

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 93 \text{ mm}$



MINI

MINI (R50, R53)

500322T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 116 \text{ mm}$



MINI
 MINI

MINI (R50, R53)
 MINI (R52)

500025

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 103 \text{ mm}$



BMW

3 (E30)

500025E

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 103 \text{ mm}$



BMW

3 (E30)

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



MINI

MINI (R50, R53)

MINI

MINI (R52)

MINI

MINI COUNTRYMAN

MINI

(R60)

MINI PACEMAN (R61)

500293

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 100 \text{ mm}$
 $H = 104 \text{ mm}$



BMW

3 (E30)

BMW

3 (E36)

BMW

3 (E46)

BMW

5 (E39)

BMW

7 (E38)

BMW

X5 (E53)

BMW

Z3 (E36)

BMW

Z4 (E85)

500002

APPLICATION

WHEEL SIDE
 $\varnothing = 22,4 \text{ mm}$
 $\varnothing = 52,2 \text{ mm}$
 $H = 77 \text{ mm}$



BMW

3 (E30)

BMW

Z3 (E36)

500329

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 45 \text{ mm}$
 $H = 77 \text{ mm}$



BMW	3 (E36)
BMW	5 (E39)
BMW	Z3 (E36)

500095

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 51 \text{ mm}$
 $H = 80 \text{ mm}$



BMW	1500-2000 (115, 116, 118, 121)
BMW	1600 GT
BMW	2000-3.2 (E9)
BMW	2500-3.3 (E3)
BMW	3 (E21)
BMW	5 (E12)

500247

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 100 \text{ mm}$
 $H = 96 \text{ mm}$



BMW	3 (E30)
BMW	3 (E36)
BMW	5 (E34)
BMW	7 (E23)
BMW	7 (E32)
BMW	7 (E38)
BMW	X5 (E53)
BMW	Z1

500079

APPLICATION

WHEEL SIDE
 $\varnothing = 23,5 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 82,4 \text{ mm}$



BMW	02 (E10)	BMW	6 (E24)
BMW	02 (E6)	BMW	7 (E23)
BMW	1500-2000 (115, 116, 118, 121)		
BMW	1600 GT		
BMW	3 (E21)		
BMW	3 (E30)		
BMW	5 (E12)		
BMW	5 (E28)		

500239T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 125 \text{ mm}$



MINI	MINI (R50, R53)
MINI	MINI (R52)
MINI	MINI COUNTRYMAN (R60)

500240T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 115 \text{ mm}$



MINI	MINI (R50, R53)
MINI	MINI (R56)
MINI	MINI (R57)
MINI	MINI (R58)
MINI	MINI (R59)
MINI	MINI CLUBVAN (R55)
MINI	MINI COUNTRYMAN (R60)
MINI	MINI PACEMAN (R61)

500036

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 90,5 \text{ mm}$
 $H = 88 \text{ mm}$



BMW	3 (E46)
BMW	X5 (E53)

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



BMW	1 (F20)	BMW	X3 (F25)
BMW	1 (F21)	BMW	X4 (F26)
BMW	2 (F22, F87)		
BMW	2 (F23)		
BMW	3 (E90)		
BMW	3 (E91)		
BMW	3 (E92)		
BMW	3 (F30, F80)		
BMW	3 (F31)		
BMW	3 (F34)		
BMW	3 Touring (E91)		
BMW	3 Touring (F31)		
BMW	3 Touring Van (F31)		
BMW	4 (F32, F82)		
BMW	4 (F33, F83)		
BMW	4 (F36)		
BMW	4 Gran (F36)		
BMW	5 (E60)		
BMW	5 (E61)		
BMW	X1 (E84)		
BMW	X3 (E83)		

500437

APPLICATION

BOX SIDE
 $\varnothing = 24,6 \text{ mm}$
 $\varnothing = 75 \text{ mm}$
 $H = 97,15 \text{ mm}$



MINI	MINI (R56)
MINI	MINI (R57)
MINI	MINI (R58)
MINI	MINI (R59)
MINI	MINI CLUBMAN (R55)
MINI	MINI CLUBVAN (R55)

500003

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 57 \text{ mm}$
 $H = 70 \text{ mm}$



BMW	5 (E39)
BMW	7 (E38)
BMW	X5 (E53)
BMW	Z8 (E52)

500089

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 57 \text{ mm}$
 $H = 99 \text{ mm}$



BMW	5 (E28)
BMW	5 (E34)
BMW	6 (E24)
BMW	7 (E32)

500251

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 107,5 \text{ mm}$
 $H = 80 \text{ mm}$



BMW	3 (E46)
BMW	5 (E39)
BMW	7 (E38)
BMW	X5 (E53)
BMW	Z3 (E36)
BMW	Z4 (E85)
BMW	Z4 (E86)

500569

APPLICATION

WHEEL SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 78 \text{ mm}$



BMW	1 (E81)
BMW	1 (E82)
BMW	1 (E87)
BMW	1 (E88)
BMW	3 (E90)
BMW	3 (E91)
BMW	3 (E92)
BMW	3 (E93)
BMW	3 Touring (E91)

BMW	X1 (E84)
BMW	Z4 (E85)

500250

APPLICATION

BOX SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 107,5 \text{ mm}$
 $H = 120 \text{ mm}$



BMW	3 (E30)
BMW	5 (E12)
BMW	5 (E28)
BMW	5 (E34)
BMW	7 (E23)
BMW	7 (E32)
BMW	Z3 (E36)

500568

APPLICATION

WHEEL SIDE
 $\varnothing = 26,8 \text{ mm}$
 $\varnothing = 50,7 \text{ mm}$
 $H = 78 \text{ mm}$



BMW 1 (E81)
 BMW 1 (E82)
 BMW 1 (E87)
 BMW 1 (E88)
 BMW 3 (E90)
 BMW 3 (E91)
 BMW 3 (E92)
 BMW 3 (E93)
 BMW 3 (F31)

BMW 5 (E60)
 BMW 5 (E61)
 BMW 6 (E63)
 BMW 6 (E64)
 BMW X1 (E84)
 BMW X3 (E83)
 BMW Z4 (E85)
 BMW Z4 (E86)

500526T

APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 107 \text{ mm}$



BMW X5 (E70)
 BMW X5 (F15, F85)
 BMW X6 (E71, E72)

500543T

APPLICATION

WHEEL SIDE
 $\varnothing = 27,5 \text{ mm}$
 $\varnothing = 96 \text{ mm}$
 $H = 122 \text{ mm}$



BMW X5 (E53)

500554T

APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 133 \text{ mm}$



BMW 3 (E46)
 BMW X5 (E53)

500161T

APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 95 \text{ mm}$
 $H = 130 \text{ mm}$



BMW 3 (E46)
 BMW X5 (E53)

500330

APPLICATION

WHEEL SIDE

Ø = 30 mm

Ø = 44 mm

H = 77 mm



BMW	1 (E81)
BMW	1 (E82)
BMW	1 (E87)
BMW	1 (E88)
BMW	3 (E36)
BMW	3 (E46)
BMW	3 (E90)
BMW	3 (E91)
BMW	3 (E92)

BMW	3 (E93)
BMW	5 (E60)
BMW	X3 (E83)
BMW	Z4 (E85)

500401

APPLICATION

BOX SIDE

Ø = 30,5 mm

Ø = 94,15 mm

H = 103,5 mm



BMW	3 (E36)
BMW	3 (E46)
BMW	3 (E90)
BMW	X3 (E83)

500328

APPLICATION

WHEEL SIDE

Ø = 31 mm

Ø = 51 mm

H = 76 mm



BMW	1 (E81)
BMW	1 (E82)
BMW	1 (E87)
BMW	1 (E88)
BMW	3 (E36)
BMW	3 (E46)
BMW	3 (E90)
BMW	3 (E91)
BMW	3 (E92)
BMW	3 (E93)
BMW	5 (E60)
BMW	5 (E61)
BMW	6 (E63)
BMW	6 (E64)
BMW	X1 (E84)
BMW	X3 (E83)
BMW	Z4 (E85)
BMW	Z4 (E86)
BMW	Z4 (E89)

500331

APPLICATION

WHEEL SIDE

Ø = 33 mm

Ø = 54 mm

H = 78 mm



BMW	1 (E82)
BMW	1 (E88)
BMW	3 (E46)
BMW	3 (E90)
BMW	3 (E91)
BMW	3 (E92)
BMW	3 (E93)
BMW	5 (E60)
BMW	5 (E61)
BMW	6 (E63)
BMW	6 (E64)
BMW	7 (E65, E66, E67)
BMW	X5 (F15, F85)
BMW	X6 (E71, E72)
BMW	X6 (F16, F86)
BMW	Z4 (E85)
BMW	Z4 (E86)
BMW	Z4 (E89)

500588

APPLICATION

WHEEL SIDE

Ø = 38 mm

Ø = 69 mm

H = 57 mm



BMW	3 (E46)
BMW	Z3 (E36)

500605

APPLICATION

WHEEL SIDE

Ø = 45 mm

Ø = 69 mm

H = 69 mm



BMW	3 (E46)
BMW	Z3 (E36)

APPLICATION

BOX SIDE
Ø = 27 mm
Ø = 87,5 mm
H = 107 mm



CADILLAC
CADILLAC

BLS
BLS Wagon

500312

APPLICATION

BOX SIDE



OPEL	MOVANO (E9, U9)
OPEL	MOVANO (F9)
OPEL	MOVANO (H9)
OPEL	MOVANO (J9)
OPEL	VIVARO (E7)
OPEL	VIVARO (F7)
OPEL	VIVARO (J7)

500358

APPLICATION

BOX SIDE



OPEL	MOVANO (E9, U9)
OPEL	MOVANO (F9)
OPEL	MOVANO (H9)
OPEL	MOVANO (J9)
VAUXHALL	MOVANO Mk I (A) (ED, HD, UD)
VAUXHALL	MOVANO Mk I (A) (FD)
VAUXHALL	MOVANO Mk I (A) (JD)

500053

APPLICATION

WHEEL SIDE
 Ø = 17,8 mm
 Ø = 77 mm
 H = 80 mm



OPEL	KADETT D (42, 32_, 37_, 39)	OPEL	KADETT E (37_, 47_)
OPEL	KADETT D (31_-34_, 41_-44_)	OPEL	KADETT E (39_, 49_)
OPEL	KADETT D (35_, 36_, 45_, 46_)	OPEL	KADETT E (43B_)
OPEL	KADETT E (33_, 34_, 43_, 44_)	OPEL	VECTRA A (J89)
OPEL	KADETT E (35_, 36_, 45_, 46_)	OPEL	VECTRA B (38_)
		VAUXHALL	ASTRA
		VAUXHALL	ASTRA Mk II
		VAUXHALL	CAVALIER Mk II

500053E

APPLICATION

WHEEL SIDE
 Ø = 17,8 mm
 Ø = 77 mm
 H = 80 mm



OPEL	KADETT D (42, 32_, 37_, 39)	OPEL	KADETT E (37_, 47_)
OPEL	KADETT D (31_-34_, 41_-44_)	OPEL	KADETT E (39_, 49_)
OPEL	KADETT D (35_, 36_, 45_, 46_)	OPEL	KADETT E (43B_)
OPEL	KADETT E (33_, 34_, 43_, 44_)	OPEL	VECTRA A (J89)
OPEL	KADETT E (35_, 36_, 45_, 46_)	OPEL	VECTRA B (38_)
		VAUXHALL	ASTRA
		VAUXHALL	ASTRA Mk II
		VAUXHALL	CAVALIER Mk II

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



OPEL

AGILA (A) (H00)

500206

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 83 \text{ mm}$



DAEWOO

MATIZ (KLYA)

500428

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59,25 \text{ mm}$
 $H = 90 \text{ mm}$

OPEL
OPELADAM
CORSA D

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$

OPEL
OPEL
OPEL
VAUXHALLAGILA (A) (H00)
CORSA C (F08, F68)
MERIVA
MERIVA Mk I (A)

500334

APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 90 \text{ mm}$



DAEWOO

TICO (KLY3)

500137

APPLICATION

BOX SIDE

Ø = 19,3 mm

Ø = 54,5 mm

H = 100,8 mm



OPEL	AGILA (A) (H00)	OPEL	CORSA A (91_, 92_, 96_, 97_)
OPEL	ASCONA C (81_, 86_, 87_, 88_)	OPEL	CORSA A (93_, 94_, 98_, 99_)
OPEL	ASCONA C (84_, 89_)	OPEL	CORSA B (73_, 78_, 79_)
OPEL	ASTRA CLASSIC	OPEL	CORSA B (F35)
OPEL	ASTRA CLASSIC (L48)	OPEL	KADETT D (31_-34_, 41_-44_)
OPEL	ASTRA CLASSIC (L48) I	OPEL	KADETT D (35_, 36_, 45_, 46_)
OPEL	ASTRA FAMILY	OPEL	KADETT E (33_, 34_, 43_, 44_)
OPEL	ASTRA CLASSIC Wagon	OPEL	KADETT E (35_, 36_, 45_, 46_)
OPEL	ASTRA F (51_, 52_)	OPEL	KADETT E (37_, 47_)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	OPEL	KADETT E (38_, 48_)
OPEL	ASTRA F (53_B)	OPEL	KADETT E (39_, 49_)
OPEL	ASTRA F (55_)	OPEL	KADETT E (43B_)
OPEL	ASTRA F (56_, 57_)	OPEL	MERIVA B
OPEL	ASTRA F CLASSIC	OPEL	TIGRA (95_)
OPEL	ASTRA G (F07_)	OPEL	VECTRA A (J89)
OPEL	ASTRA G (F08_, F48_)	OPEL	VECTRA B (31_)
OPEL	ASTRA G (F35_)	OPEL	VECTRA B (36_)
OPEL	ASTRA G (F67)	OPEL	VECTRA B (38_)
OPEL	ASTRA G (F69_)	OPEL	ZAFIRA A (F75_)
OPEL	ASTRA G (F70)	OPEL	ZAFIRA B (A05)
OPEL	ASTRA G CLASSIC (F08, F48)	OPEL	ASTRA
OPEL	ASTRA G CLASSIC (F69)	VAUXHALL	ASTRA Mk II
OPEL	ASTRA G CLASSIC	VAUXHALL	ASTRA Mk III (F)
OPEL	Caravan (F35)	VAUXHALL	ASTRA Mk IV (G)
OPEL	ASTRA H (L08)	VAUXHALL	CAVALIER Mk II
OPEL	ASTRA H (L35)	VAUXHALL	CORSA Mk I (B)
OPEL	ASTRA H (L48)	VAUXHALL	ZAFIRA Mk I (A) (F75)
OPEL	ASTRA H (L67)		
OPEL	ASTRA H (L69)		
OPEL	ASTRA H (L70)		
OPEL	ASTRA J		
OPEL	COMBO (71_)		

500509

APPLICATION

BOX SIDE

Ø = 19,3 mm

Ø = 62 mm

H = 83 mm



OPEL	INSIGNIA
OPEL	INSIGNIA A
OPEL	MERIVA

500432

APPLICATION

BOX SIDE

Ø = 19,5 mm

Ø = 61,5 mm

H = 91 mm



OPEL	ADAM
OPEL	CORSA D
VAUXHALL	CORSA Mk III (D) (L_8)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



DAEWOO

MATIZ (KLYA)

500180

APPLICATION

BOX SIDE
 $\varnothing = 19,82 \text{ mm}$
 $\varnothing = 57,83 \text{ mm}$
 $H = 89,6 \text{ mm}$



CHEVROLET
 CHEVROLET
 CHEVROLET
 CHEVROLET
 DAEWOO
 DAEWOO
 DAEWOO
 DAEWOO

AVEO (T200)
 AVEO (T250, T255)
 MATIZ (M200, M250)
 SPARK
 KALOS (KLAS)
 MATIZ
 MATIZ (KLA4)
 MATIZ (KLYA)

500414

APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 VAUXHALL

COMBO
 CORSA C (F08, F68)
 CORSA D
 INSIGNIA
 INSIGNIA A
 MERIVA
 TIGRA
 MERIVA Mk I (A)

500063

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 100 \text{ mm}$



OPEL
 OPEL

AGILA (A) (H00)
 CORSA B (73_, 78_,
 79_)

500245T

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 123,5 \text{ mm}$



OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL

AGILA (A) (H00)
 ASTRA G (F08_, F48_)
 ASTRA G (F35_)
 ASTRA G (F69_)
 CORSA B (73_, 78_,
 79_)
 CORSA C (F08, F68)
 CORSA C (F08, W5L)

VAUXHALL

CORSA Mk II (C) (F08,
 W5L)

500276

APPLICATION

BOX SIDE
 $\varnothing = 20$ mm
 $\varnothing = 70$ mm
H = 83 mm



OPEL	AGILA (A) (H00)
OPEL	CORSA B (73_, 78_, 79_)
VAUXHALL	CORSA Mk I (B)

500042

APPLICATION

WHEEL SIDE
 $\varnothing = 20$ mm
 $\varnothing = 76$ mm
H = 80 mm



OPEL	ASCONA C (81_, 86_, 87_, 88_)	OPEL	KADETT E (37_, 47_)
OPEL	ASCONA C (84_, 89_)	OPEL	KADETT E (38_, 48_)
OPEL	ASTRA F (51_, 52_)	OPEL	KADETT E (39_, 49_)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	OPEL	KADETT E (43B_)
OPEL	ASTRA F (53_B)	OPEL	MANTA B (53_, 55_)
OPEL	ASTRA F (55_)	OPEL	VECTRA A (J89)
OPEL	ASTRA F (56_, 57_)	VAUXHALL	CAVALIER Mk II
OPEL	ASTRA F CLASSIC		
OPEL	CORSA A (91_, 92_, 96_, 97_)		
OPEL	CORSA A (93_, 94_, 98_, 99_)		
OPEL	KADETT D (31_-34_, 41_-44_)		
OPEL	KADETT D (35_, 36_, 45_, 46_)		
OPEL	KADETT E (33_, 34_, 43_, 44_)		
OPEL	KADETT E (35_, 36_, 45_, 46_)		

500042E

APPLICATION

WHEEL SIDE
 $\varnothing = 20$ mm
 $\varnothing = 76$ mm
H = 80 mm



OPEL	ASCONA C (81_, 86_, 87_, 88_)	OPEL	KADETT E (39_, 49_)
OPEL	ASCONA C (84_, 89_)	OPEL	KADETT E (43B_)
OPEL	ASTRA F (51_, 52_)	OPEL	MANTA B (53_, 55_)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	OPEL	VECTRA A (J89)
OPEL	ASTRA F (53_B)	VAUXHALL	CAVALIER Mk II
OPEL	ASTRA F (56_, 57_)		
OPEL	ASTRA F CLASSIC		
OPEL	CORSA A (93_, 94_, 98_, 99_)		
OPEL	KADETT D (31_-34_, 41_-44_)		
OPEL	KADETT D (35_, 36_, 45_, 46_)		
OPEL	KADETT E (33_, 34_, 43_, 44_)		
OPEL	KADETT E (35_, 36_, 45_, 46_)		
OPEL	KADETT E (37_, 47_)		
OPEL	KADETT E (38_, 48_)		

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



OPEL
 VAUXHALL
 VAUXHALL

FRONTERA A (5_MWL4)
 BRAVA
 FRONTERA Mk I (A)

500430

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 61,3 \text{ mm}$
 $H = 97 \text{ mm}$



OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 VAUXHALL
 VAUXHALL
 VAUXHALL

COMBO
 CORSA C (F08, F68)
 CORSA C (F08, W5L)
 MERIVA
 TIGRA
 COMBO Mk II (C) (F25)
 CORSA Mk II (C) (F08, W5L)
 CORSAVAN Mk II (C)

VAUXHALL
 VAUXHALL

MERIVA Mk I (A)
 TIGRA

500523

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 94,5 \text{ mm}$



OPEL
 OPEL

CORSA C (F08, F68)
 MERIVA

500636T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 69,13 \text{ mm}$
 $H = 105 \text{ mm}$



OPEL
 VAUXHALL

AGILA (A) (H00)
 AGILA Mk I (A)

500495T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 106 \text{ mm}$



CHEVROLET
 CHEVROLET
 CHEVROLET
 CHEVROLET
 CHEVROLET
 CHEVROLET
 DAEWOO
 DAEWOO

AVEO (T200)
 AVEO (T250, T255)
 KALOS
 MATIZ (M200, M250)
 SPARK
 SPARK (M300)
 KALOS (KLAS)
 MATIZ

500311

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 88 \text{ mm}$



DAEWOO
 DAEWOO

LANOS (KLAT)
 NUBIRA (KLAJ)

500195

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$



DAEWOO
 DAEWOO
 DAEWOO
 DAEWOO

CIELO
 LANOS (KLAT)
 NEXIA (KLETN)
 NUBIRA (KLAJ)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



DAEWOO
 DAEWOO

LANOS (KLAT)
 NUBIRA (KLAJ)

500595

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 75 \text{ mm}$
 $H = 100 \text{ mm}$



OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL

COMBO (X19)
 COMBO Life (X19)
 COMBO MPV
 CORSA F
 CROSSLAND X
 CROSSLAND X (P17)
 CROSSLAND X Van
 GRANDLAND X
 GRANDLAND X (A18)

OPEL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL

GRANDLAND X Van
 COMBO
 COMBO Mk IV (E) MPV
 (X19)
 CORSA Mk V (F)
 CROSSLAND X
 CROSSLAND X (P17)
 GRANDLAND X (75)

500069

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 81,8 \text{ mm}$
 $H = 92,3 \text{ mm}$



DAEWOO
 DAEWOO
 OPEL
 OPEL
 VAUXHALL

LEGANZA (KLAV)
 REZZO (KLAU, U100)
 FRONTERA A (5_MWL4)
 FRONTERA A (5_SUD2)
 FRONTERA Mk I (A)

500221

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 93 \text{ mm}$



OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
VAUXHALL

AGILA (A) (H00)
COMBO
CORSA C (F08, F68)
CORSA C (F08, W5L)
CORSA D
MERIVA
TIGRA
COMBO Mk II (C) (F25)

VAUXHALL

CORSA Mk II (C) (F08,
W5L)

500066

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 66,6 \text{ mm}$
 $H = 99 \text{ mm}$



DAEWOO
DAEWOO
OPEL

CIELO
ESPERO (KLEJ)
ASCONA C (81_, 86_,
87_, 88_)
ASCONA C (84_, 89_)
ASTRA CLASSIC
ASTRA CLASSIC (L48)
ASTRA CLASSIC Wagon
ASTRA F (51_, 52_)
ASTRA F (53_, 54_,
58_, 59_)
ASTRA F (53_B)
ASTRA F (55_)
ASTRA F (56_, 57_)
ASTRA G (F07_)
ASTRA G (F08_, F48_)
ASTRA G (F35_)
ASTRA G (F67)
ASTRA G (F69_)
ASTRA G (F70)
ASTRA G CLASSIC (F08,
F48)
ASTRA G CLASSIC
Caravan (F35)
ASTRA H (L08)
ASTRA H (L35)
ASTRA H (L48)
ASTRA H (L67)
ASTRA H (L69)
ASTRA H (L70)
CALIBRA A (85_)
KADETT D (31_-34_,
41_-44_)

OPEL	KADETT D (35_, 36_, 45_, 46_)
OPEL	KADETT E (33_, 34_, 43_, 44_)
OPEL	KADETT E (35_, 36_, 45_, 46_)
OPEL	KADETT E (37_, 47_)
OPEL	KADETT E (38_, 48_)
OPEL	KADETT E (39_, 49_)
OPEL	KADETT E (43B_)
OPEL	SIGNUM
OPEL	SINTRA
OPEL	VECTRA A (J89)
OPEL	VECTRA B (31_)
OPEL	VECTRA B (36_)
OPEL	VECTRA B (38_)
OPEL	VECTRA C
OPEL	ZAFIRA A (F75_)
OPEL	ZAFIRA B (A05)
VAUXHALL	ASTRA
VAUXHALL	ASTRA Mk II
VAUXHALL	ASTRA Mk III (F)
VAUXHALL	CALIBRA
VAUXHALL	CAVALIER Mk II

500359

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 86 \text{ mm}$



OPEL
OPEL
OPEL
OPEL
VAUXHALL
VAUXHALL

COMBO
CORSA C (F08, F68)
MERIVA
MERIVA B
COMBO Mk II (C) (F25)
MERIVA Mk I (A)

500409T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 114,5 \text{ mm}$



OPEL
OPEL

ADAM
CORSA D

500322T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 116 \text{ mm}$



OPEL
OPEL
OPEL
OPEL

ADAM
AGILA (A) (H00)
AGILA (B) (H08)
CORSA D

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



CHEVROLET	EPICA (KL1_)
CHEVROLET	EVANDA
CHEVROLET	LACETTI
CHEVROLET	LACETTI (J200)
CHEVROLET	NUBIRA
CHEVROLET	REZZO
DAEWOO	EVANDA (KLAL)
DAEWOO	LACETTI (KLAN)
DAEWOO	LEGANZA (KLAV)
DAEWOO	MAGNUS
DAEWOO	NUBIRA (J150)
DAEWOO	NUBIRA (J150) ORION
DAEWOO	NUBIRA (KLAJ)
DAEWOO	NUBIRA (KLAN)
DAEWOO	NUBIRA Wagon (J150)
DAEWOO	REZZO (KLAU, U100)
DAEWOO	TOSCA
OPEL	ASTRA CLASSIC
OPEL	ASTRA CLASSIC (L48)
OPEL	ASTRA CLASSIC (L48)
	ASTRA FAMILY

OPEL	ASTRA CLASSIC Wagon
OPEL	ASTRA H (L08)
OPEL	ASTRA H (L35)
OPEL	ASTRA H (L48)
OPEL	ASTRA H (L67)
OPEL	ASTRA H (L69)
OPEL	ASTRA H (L70)
OPEL	ASTRA J
OPEL	INSIGNIA
OPEL	INSIGNIA A
OPEL	MERIVA
OPEL	MERIVA B
OPEL	ZAFIRA B (A05)

500229T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 79 \text{ mm}$
 $H = 122 \text{ mm}$



OPEL
OPEL
VAUXHALL

AGILA (A) (H00)
CORSIA B (73_, 78_
79_)
CORSIA Mk I (B)

500190

APPLICATION

WHEEL SIDE
 $\emptyset = 22,2 \text{ mm}$
 $\emptyset = 75,7 \text{ mm}$
 $H = 112 \text{ mm}$



DAEWOO	ESPERO (KLEJ)	OPEL	VECTRA B (38_)
DAEWOO	NEXIA (KLETN)	OPEL	ZAFIRA A (F75_)
OPEL	ASTRA F (51_, 52_)	VAUXHALL	ASTRA Mk IV (G)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	VAUXHALL	COMBO Mk I (B)
OPEL	ASTRA F (53_B)	VAUXHALL	ZAFIRA Mk I (A) (F75)
OPEL	ASTRA F (55_)		
OPEL	ASTRA F (56_, 57_)		
OPEL	ASTRA F CLASSIC		
OPEL	ASTRA G (F07_)		
OPEL	ASTRA G (F08_, F48_)		
OPEL	ASTRA G (F35_)		
OPEL	ASTRA G (F67)		
OPEL	ASTRA G (F69_)		
OPEL	ASTRA G (F70)		
OPEL	COMBO (71_)		
OPEL	CORSA B (73_, 78_, 79_)		
OPEL	TIGRA (95_)		
OPEL	VECTRA B (31_)		
OPEL	VECTRA B (36_)		

500134

APPLICATION

BOX SIDE
 $\emptyset = 22,3 \text{ mm}$
 $\emptyset = 78,65 \text{ mm}$
 $H = 104 \text{ mm}$



OPEL	AGILA (A) (H00)	OPEL	KADETT E (38_, 48_)
OPEL	ASTRA F (51_, 52_)	OPEL	KADETT E (39_, 49_)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	OPEL	KADETT E (43B_)
OPEL	ASTRA F (53_B)	OPEL	TIGRA (95_)
OPEL	ASTRA F (55_)	OPEL	VECTRA A (J89)
OPEL	ASTRA F (56_, 57_)	OPEL	VECTRA B (31_)
OPEL	ASTRA F CLASSIC	OPEL	VECTRA B (36_)
OPEL	ASTRA G (F07_)	OPEL	VECTRA B (38_)
OPEL	ASTRA G (F08_, F48_)	OPEL	ZAFIRA A (F75_)
OPEL	ASTRA G (F35_)	VAUXHALL	ASTRA Mk IV (G)
OPEL	ASTRA G (F67)	VAUXHALL	CORSA Mk II (C) (F08, W5L)
OPEL	ASTRA G (F69_)	VAUXHALL	NOVA
OPEL	ASTRA G (F70)		
OPEL	COMBO (71_)		
OPEL	CORSA A		
OPEL	CORSA A (91_, 92_, 96_, 97_)		
OPEL	CORSA A (93_, 94_, 98_, 99_)		
OPEL	CORSA B (73_)		
OPEL	CORSA B (73_, 78_, 79_)		
OPEL	CORSA C (F08, F68)		
OPEL	CORSA C (F08, W5L)		
OPEL	KADETT D (_42, 32_, 37_, 39_)		
OPEL	KADETT D (31_-34_, 41_-44_)		
OPEL	KADETT D (35_, 36_, 45_, 46_)		
OPEL	KADETT E (33_, 34_, 43_, 44_)		
OPEL	KADETT E (35_, 36_, 45_, 46_)		

500022

APPLICATION

WHEEL SIDE
 Ø = 22,7 mm
 Ø = 77,8 mm
 H = 108,5 mm



OPEL	ASTRA F (51_, 52_)	VAUXHALL	ASTRA Mk II
OPEL	ASTRA F (53_, 54_, 58_, 59_)	VAUXHALL	ASTRA Mk III (F)
OPEL	ASTRA F (56_, 57_)	VAUXHALL	ASTRA Mk IV (G)
OPEL	CORSA A	VAUXHALL	NOVA
OPEL	CORSA A (91_, 92_, 96_, 97_)		
OPEL	CORSA A (93_, 94_, 98_, 99_)		

500022E

APPLICATION

WHEEL SIDE
 Ø = 22,7 mm
 Ø = 77,8 mm
 H = 108,5 mm



OPEL	ASTRA F (51_, 52_)	VAUXHALL	ASTRA Mk II
OPEL	ASTRA F (53_, 54_, 58_, 59_)	VAUXHALL	ASTRA Mk III (F)
OPEL	ASTRA F (56_, 57_)	VAUXHALL	ASTRA Mk IV (G)
OPEL	CORSA A	VAUXHALL	NOVA
OPEL	CORSA A (91_, 92_, 96_, 97_)		
OPEL	CORSA A (93_, 94_, 98_, 99_)		

500095

APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 51 mm
 H = 80 mm



OPEL	OMEGA A (16_, 17_, 19_)
OPEL	OMEGA A (66_, 67_)
VAUXHALL	CARLTON Mk III

500307

APPLICATION

BOX SIDE
 Ø = 23 mm
 Ø = 56 mm
 H = 97 mm



CHEVROLET	AVEO (T200)
CHEVROLET	AVEO (T250, T255)
CHEVROLET	KALOS
CHEVROLET	LACETTI
CHEVROLET	LACETTI (J200)
CHEVROLET	NUBIRA
CHEVROLET	REZZO
DAEWOO	CIELO
DAEWOO	KALOS (KLAS)
DAEWOO	LACETTI
DAEWOO	LACETTI (KLAN)
DAEWOO	LANOS (KLAT)
DAEWOO	NEXIA (KLETN)
DAEWOO	NUBIRA (J150)
DAEWOO	NUBIRA (J150) I ORION
DAEWOO	NUBIRA (KLAN)
DAEWOO	NUBIRA Wagon (J150)
DAEWOO	RACER

500479

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 72,5 \text{ mm}$
 $H = 107,5 \text{ mm}$



OPEL

CORSA D

500314

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 129 \text{ mm}$



OPEL

KADETT D (42, 32, 37, 39)

OPEL

KADETT E (37, 47)

OPEL

KADETT D (31, 34, 41, 44)

OPEL

KADETT E (38, 48)

OPEL

KADETT D (35, 36, 45, 46)

OPEL

KADETT E (39, 49)

OPEL

KADETT D (35, 36, 45, 46)

OPEL

KADETT E (43B)

OPEL

KADETT E (33, 34, 43, 44)

VAUXHALL

ASTRA Mk II

VAUXHALL

CAVALIER Mk II

VAUXHALL

CAVALIER Mk III

VAUXHALL

CAVALIER Mk III (87)

500374

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 91 \text{ mm}$



OPEL

ASCONA C (84, 89)

OPEL

KADETT E (35, 36, 45, 46)

OPEL

KADETT D (42, 32, 37, 39)

OPEL

KADETT E (39, 49)

OPEL

KADETT D (31, 34, 41, 44)

OPEL

KADETT E (43B)

OPEL

KADETT D (35, 36, 45, 46)

OPEL

KADETT E (33, 34, 43, 44)

500213

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 97 \text{ mm}$



DAEWOO

LEGANZA (KLAV)

500567

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 192 \text{ mm}$



OPEL

MOVANO (E9, U9)

VAUXHALL

MOVANO Mk I (A) (JD)

OPEL

MOVANO (F9)

VAUXHALL

MOVANO Mk I (A) (X70)

OPEL

MOVANO (H9)

VAUXHALL

MOVANO Mk I (A) Chassis/Cab (X70)

OPEL

MOVANO (J9)

VAUXHALL

MOVANO Mk I (A) Van (X70)

OPEL

VIVARO (E7)

VAUXHALL

VIVARO (E7)

OPEL

VIVARO (F7)

VAUXHALL

VIVARO (F7)

OPEL

VIVARO (J7)

VAUXHALL

VIVARO (J7)

VAUXHALL

MOVANO Mk I (A) (ED, HD, UD)

VAUXHALL

VIVARO (J7)

VAUXHALL

MOVANO Mk I (A) (FD)

500079

APPLICATION

WHEEL SIDE
 $\emptyset = 23,5 \text{ mm}$
 $\emptyset = 60 \text{ mm}$
 $H = 82,4 \text{ mm}$



OPEL	ADMIRAL B
OPEL	MONZA A (22_)
OPEL	OMEGA A (16_, 17_, 19_)
OPEL	OMEGA A (66_, 67_)
OPEL	OMEGA B (21_, 22_, 23_)
OPEL	OMEGA B (25_, 26_, 27_)
OPEL	SENATOR A (29_)
OPEL	SENATOR B (29_)
VAUXHALL	OMEGA (B)
VAUXHALL	ROYALE
VAUXHALL	SENATOR
VAUXHALL	SENATOR Mk II (B)

500556T

APPLICATION

WHEEL SIDE
 $\emptyset = 23,5 \text{ mm}$
 $\emptyset = 79 \text{ mm}$
 $H = 121,5 \text{ mm}$



CHEVROLET	AVEO (T200)	DAEWOO	LACETTI (KLAN)
CHEVROLET	AVEO (T250, T255)	DAEWOO	NUBIRA (KLAN)
CHEVROLET	CAPTIVA (C100, C140)	OPEL	ANTARA
CHEVROLET	KALOS		
CHEVROLET	LACETTI		
CHEVROLET	LACETTI (J200)		
CHEVROLET	NUBIRA		
DAEWOO	KALOS (KLAS)		
DAEWOO	LACETTI		

500133

APPLICATION

BOX SIDE
 $\emptyset = 23,7 \text{ mm}$
 $\emptyset = 71,4 \text{ mm}$
 $H = 111 \text{ mm}$



OPEL	ARENA
OPEL	ARENA (TB, TF)
OPEL	ARENA (THB)

500239T

APPLICATION

WHEEL SIDE

Ø = 24 mm

Ø = 60 mm

H = 125 mm



CHEVROLET	EPICA (KL1_)
CHEVROLET	EVANDA
CHEVROLET	LACETTI (J200)
CHEVROLET	NUBIRA
CHEVROLET	VOLT
DAEWOO	NUBIRA (KLAN)
DAEWOO	REZZO (KLAU, U100)
OPEL	ASTRA GTC J
OPEL	ASTRA J
OPEL	COMBO
OPEL	CORSA C (F08, F68)
OPEL	CORSA D
OPEL	INSIGNIA
OPEL	INSIGNIA A
OPEL	MERIVA
OPEL	MERIVA B
OPEL	TIGRA
OPEL	ZAFIRA TOURER C (P12)
VAUXHALL	CORSA Mk II (C) (F08, W5L)
VAUXHALL	MERIVA Mk I (A)

500267

APPLICATION

BOX SIDE

Ø = 24 mm

Ø = 64 mm

H = 101 mm



CHEVROLET	VECTRA	OPEL	VECTRA B (36_)
OPEL	ASTRA F (51_, 52_)	OPEL	VECTRA B (38_)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	OPEL	VECTRA C
OPEL	ASTRA F (55_)	OPEL	ZAFIRA A (F75_)
OPEL	ASTRA F (56_, 57_)	OPEL	ZAFIRA B
OPEL	ASTRA G (F07_)	OPEL	ZAFIRA B (A05)
OPEL	ASTRA G (F08_, F48_)	VAUXHALL	ASTRA Mk III (F)
OPEL	ASTRA G (F35_)	VAUXHALL	CORSA Mk II (C) (F08, W5L)
OPEL	ASTRA G (F67)	VAUXHALL	VECTRA (B)
OPEL	ASTRA G (F69_)	VAUXHALL	VECTRA Mk II (C)
OPEL	ASTRA G (F70)	VAUXHALL	ZAFIRA Mk I (A) (F75)
OPEL	ASTRA H (L08)		
OPEL	ASTRA H (L35)		
OPEL	ASTRA H (L48)		
OPEL	ASTRA H (L67)		
OPEL	ASTRA H (L69)		
OPEL	ASTRA H (L70)		
OPEL	CORSA C (F08, F68)		
OPEL	SIGNUM		
OPEL	VECTRA B (31_)		

500179

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 104 \text{ mm}$



CHEVROLET	AVEO (T200)
CHEVROLET	AVEO (T250, T255)
CHEVROLET	EPICA (KL1_)
CHEVROLET	EVANDA
CHEVROLET	KALOS
CHEVROLET	LACETTI
CHEVROLET	LACETTI (J200)
CHEVROLET	NUBIRA
CHEVROLET	REZZO
DAEWOO	EVANDA (KLAL)
DAEWOO	KALOS (KLAS)
DAEWOO	LACETTI
DAEWOO	LACETTI (KLAN)
DAEWOO	LEGANZA (KLAV)
DAEWOO	MAGNUS
DAEWOO	NUBIRA (J150)
DAEWOO	NUBIRA (J150) I ORION
DAEWOO	NUBIRA (KLAJ)
DAEWOO	NUBIRA (KLAN)
DAEWOO	NUBIRA Wagon (J150)
DAEWOO	REZZO (KLAU, U100)

500508

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 115 \text{ mm}$



DAEWOO	ARANOS
DAEWOO	CIELO
DAEWOO	ESPERO (KLEJ)
DAEWOO	NEXIA (KLETN)
DAEWOO	RACER

500257

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 101 \text{ mm}$



OPEL	CAMPO (TF_)
OPEL	FRONTERA B (6B_)
OPEL	MONTEREY A (UBS_)
OPEL	MONTEREY B
VAUXHALL	FRONTERA Mk II (B)

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



OPEL ASTRA CLASSIC
 OPEL ASTRA CLASSIC (L48)
 OPEL ASTRA CLASSIC Wagon
 OPEL ASTRA G (F07_)
 OPEL ASTRA G (F08_, F48_)
 OPEL ASTRA G (F35_)
 OPEL ASTRA H (L08)
 OPEL ASTRA H (L35)
 OPEL ASTRA H (L48)
 OPEL ASTRA H (L67)
 OPEL ASTRA H (L69)
 OPEL ASTRA H (L70)
 OPEL COMBO
 OPEL CORSA C (F08, F68)
 OPEL CORSA C (F08, W5L)
 OPEL MERIVA
 OPEL SIGNUM
 OPEL VECTRA B (31_)
 OPEL VECTRA C
 OPEL ZAFIRA A (F75_)
 OPEL ZAFIRA B

OPEL ZAFIRA B (A05)
 VAUXHALL ASTRA Mk V (H)
 VAUXHALL MERIVA Mk I (A)
 VAUXHALL ZAFIRA Mk I (A) (F75)

500089

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 57 \text{ mm}$
 $H = 99 \text{ mm}$



OPEL ASTRA G (F07_)
 OPEL ASTRA G (F08_, F48_)
 OPEL ASTRA G (F35_)
 OPEL ASTRA G (F69_)
 OPEL OMEGA A (16_, 17_, 19_)
 OPEL OMEGA A (66_, 67_)
 OPEL OMEGA B (21_, 22_, 23_)
 OPEL OMEGA B (25_, 26_, 27_)
 OPEL SENATOR A (29_)
 OPEL SENATOR B (29_)
 OPEL ZAFIRA A (F75_)
 VAUXHALL ASTRA Mk IV (G)
 VAUXHALL CARLTON Mk III
 VAUXHALL OMEGA (B)

500442

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 109 \text{ mm}$



OPEL CORSA D
 OPEL CORSA E

500231T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 110 \text{ mm}$



OPEL	ASTRA G (F07_)
OPEL	ASTRA G (F08_, F48_)
OPEL	ASTRA G (F35_)
OPEL	ASTRA G (F69_)
OPEL	SINTRA
OPEL	ZAFIRA A (F75_)
VAUXHALL	ASTRA Mk IV (G)
VAUXHALL	SINTRA
VAUXHALL	ZAFIRA Mk I (A) (F75)

500232T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 138 \text{ mm}$



OPEL	SPEEDSTER
------	-----------

500016

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 126,5 \text{ mm}$



VAUXHALL	MOVANO Mk I (A) (ED, HD, UD)
VAUXHALL	MOVANO Mk I (A) (FD)
VAUXHALL	MOVANO Mk I (A) (JD)

500016E

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 126,5 \text{ mm}$



VAUXHALL	MOVANO Mk I (A) (ED, HD, UD)
VAUXHALL	MOVANO Mk I (A) (FD)
VAUXHALL	MOVANO Mk I (A) (JD)

500342T

APPLICATION

WHEEL SIDE
 $\varnothing = 25,1 \text{ mm}$
 $\varnothing = 86,75 \text{ mm}$
 $H = 110 \text{ mm}$



CHEVROLET	VECTRA	OPEL	VECTRA B (31_)
OPEL	ASTRA F (51_, 52_)	OPEL	VECTRA B (36_)
OPEL	ASTRA F (53_, 54_, 58_, 59_)	OPEL	VECTRA B (38_)
OPEL	ASTRA F (53_B)	OPEL	VECTRA C
OPEL	ASTRA F (56_, 57_)	OPEL	ZAFIRA A (F75_)
OPEL	ASTRA G (F07_)	VAUXHALL	VECTRA Mk II (C)
OPEL	ASTRA G (F08_, F48_)	VAUXHALL	ZAFIRA Mk I (A) (F75)
OPEL	ASTRA G (F35_)		
OPEL	ASTRA G (F67)		
OPEL	ASTRA G (F69_)		
OPEL	ASTRA G (F70)		
OPEL	ASTRA G CLASSIC (F08, F48)		
OPEL	ASTRA G CLASSIC (F69)		
OPEL	ASTRA G CLASSIC Caravan (F35)		
OPEL	CALIBRA A (85_)		
OPEL	SIGNUM		
OPEL	SINTRA		
OPEL	VECTRA A (J89)		

500062

APPLICATION

BOX SIDE
 $\varnothing = 25,7 \text{ mm}$
 $\varnothing = 72,7 \text{ mm}$
 $H = 103,2 \text{ mm}$



OPEL	ARENA (TB, TF)
OPEL	ARENA (THB)

500347

APPLICATION

BOX SIDE
 $\varnothing = 25,85 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 100 \text{ mm}$



OPEL	ASTRA G (F07_)	VAUXHALL	ZAFIRA Mk I (A) (F75)
OPEL	ASTRA G (F08_, F48_)		
OPEL	ASTRA G (F35_)		
OPEL	ASTRA G (F67)		
OPEL	ASTRA G (F69_)		
OPEL	VECTRA B (31_)		
OPEL	VECTRA B (36_)		
OPEL	VECTRA B (38_)		
OPEL	ZAFIRA A (F75_)		

500167T

APPLICATION

WHEEL SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 78 \text{ mm}$
 $H = 134 \text{ mm}$



OPEL	COMBO	VAUXHALL	CORSA Mk I (B)
OPEL	COMBO (71_)		
OPEL	CORSA B (73_, 78_, 79_)		
OPEL	CORSA C (F08, F68)		
OPEL	CORSA C (F08, W5L)		
OPEL	MERIVA		
OPEL	TIGRA		
OPEL	TIGRA (95_)		

500020T

APPLICATION

WHEEL SIDE
 Ø = 26 mm
 Ø = 78,5 mm
 H = 110 mm



OPEL

COMMODORE B

500363

APPLICATION

BOX SIDE
 Ø = 26 mm
 Ø = 82 mm
 H = 124 mm



OPEL

MOVANO (E9, U9)

OPEL

MOVANO (F9)

OPEL

MOVANO (H9)

OPEL

MOVANO (J9)

VAUXHALL

MOVANO Mk I (A) (ED, HD, UD)

VAUXHALL

MOVANO Mk I (A) (FD)

VAUXHALL

MOVANO Mk I (A) (JD)

500004

APPLICATION

WHEEL SIDE
 Ø = 26 mm
 Ø = 89,5 mm
 H = 107 mm



OPEL

ASTRA F (51_, 52_)

OPEL

ASTRA F (53_, 54_, 58_, 59_)

OPEL

ASTRA F (56_, 57_)

OPEL

ASTRA G (F07_)

OPEL

ASTRA G (F08_, F48_)

OPEL

ASTRA G (F35_)

OPEL

ASTRA G (F67)

OPEL

ASTRA G (F69_)

OPEL

ASTRA G (F70)

OPEL

CALIBRA A (85_)

OPEL

VECTRA B (31_)

OPEL

VECTRA B (36_)

OPEL

VECTRA B (38_)

OPEL

ZAFIRA A (F75_)

VAUXHALL

ASTRA Mk III (F)

500235T

APPLICATION

WHEEL SIDE
 Ø = 26,5 mm
 Ø = 89 mm
 H = 149 mm



CHEVROLET

EPICA (KL1_)

CHEVROLET

EVANDA

CHEVROLET

LACETTI (J200)

CHEVROLET

NUBIRA

CHEVROLET

REZZO

DAEWOO

EVANDA (KLAL)

DAEWOO

LEGANZA (KLAV)

DAEWOO

MAGNUS

DAEWOO

NUBIRA (J150)

DAEWOO

NUBIRA (J150) | ORION

DAEWOO

NUBIRA (KLAL)

DAEWOO

NUBIRA Wagon (J150)

DAEWOO

REZZO (KLAU, U100)

DAEWOO

TOSCA

VAUXHALL

SINTRA

500106

APPLICATION

WHEEL SIDE
 Ø = 26,8 mm
 Ø = 90 mm
 H = 108 mm



OPEL

MONTEREY A (UBS_)

500526T

APPLICATION

BOX SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 71 \text{ mm}$
 $H = 107 \text{ mm}$



OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL

ASTRA GTC J
 ASTRA H (L08)
 ASTRA H (L35)
 ASTRA H (L48)
 ASTRA H (L67)
 ASTRA J
 CASCADA (W13)
 INSIGNIA
 INSIGNIA A

OPEL
 OPEL
 OPEL

SIGNUM
 ZAFIRA B (A05)
 ZAFIRA TOURER C (P12)

500234T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 87 \text{ mm}$
 $H = 123 \text{ mm}$



OPEL
 SPEEDSTER

500612T

APPLICATION

BOX SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 87,5 \text{ mm}$
 $H = 107 \text{ mm}$



OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 OPEL
 VAUXHALL

ASTRA H (L08)
 ASTRA H (L35)
 ASTRA H (L48)
 ASTRA H (L67)
 ASTRA H (L70)
 SIGNUM
 VECTRA C
 ZAFIRA B (A05)
 ASTRA Mk V (H)

VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL

ASTRA Mk V (H) Wagon (A04)
 ASTRA TwinTop Mk V (H)
 ASTRAMAN Mk V (H)
 SIGNUM
 VECTRA Mk II (C)
 ZAFIRA Mk II (B) (M75)

500296T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 89 \text{ mm}$
 $H = 119 \text{ mm}$



OPEL
 OPEL

SIGNUM
 VECTRA C

500227T

APPLICATION

WHEEL SIDE
 Ø = 27 mm
 Ø = 89 mm
 H = 125 mm



OPEL ASTRA CLASSIC
 OPEL ASTRA CLASSIC (L48)
 OPEL ASTRA GTC J
 OPEL ASTRA H (L08)
 OPEL ASTRA H (L35)
 OPEL ASTRA H (L48)
 OPEL ASTRA H (L67)
 OPEL ASTRA H (L69)
 OPEL ASTRA H (L70)
 OPEL ASTRA J
 OPEL CASCADA (W13)
 OPEL INSIGNIA
 OPEL INSIGNIA A
 OPEL MERIVA B
 OPEL SIGNUM
 OPEL VECTRA C
 OPEL VIVARO (E7)
 OPEL VIVARO (F7)
 OPEL VIVARO (J7)
 OPEL ZAFIRA B
 OPEL ZAFIRA B (A05)

OPEL ZAFIRA TOURER C (P12)
 VAUXHALL VIVARO (F7)
 VAUXHALL VIVARO (J7)

500237T

APPLICATION

WHEEL SIDE
 Ø = 27 mm
 Ø = 90 mm
 H = 132 mm



OPEL ARENA
 OPEL ARENA (TB, TF)
 OPEL ARENA (THB)
 VAUXHALL ARENA

500527T

APPLICATION

BOX SIDE
 Ø = 27 mm
 Ø = 92 mm
 H = 95 mm



OPEL ASTRA GTC J
 OPEL ASTRA J
 OPEL INSIGNIA
 OPEL INSIGNIA A
 OPEL MERIVA B
 OPEL ZAFIRA TOURER C (P12)

500011T

APPLICATION

WHEEL SIDE
 Ø = 27,2 mm
 Ø = 98,1 mm
 H = 144,5 mm



OPEL MOVANO (E9, U9)
 OPEL MOVANO (F9)
 OPEL MOVANO (H9)
 OPEL MOVANO (J9)

500536T

APPLICATION

WHEEL SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 81,5 \text{ mm}$
 $H = 120 \text{ mm}$



OPEL
 OPEL

CORSA D
 CORSA E

500341T

APPLICATION

WHEEL SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 84 \text{ mm}$
 $H = 116 \text{ mm}$



OPEL
 OPEL
 OPEL
 VAUXHALL

ASTRA G (F07_)
 ASTRA G (F08_, F48_)
 ZAFIRA A (F75_)
 ZAFIRA Mk I (A) (F75)

500031

APPLICATION

WHEEL SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 85 \text{ mm}$
 $H = 97 \text{ mm}$



OPEL
 OPEL
 OPEL
 VAUXHALL

CAMPO (TF_)
 MONTEREY A (UBS_)
 SPEEDSTER
 MONTEREY

500269

APPLICATION

BOX SIDE
 $\emptyset = 28 \text{ mm}$
 $\emptyset = 74 \text{ mm}$
 $H = 88 \text{ mm}$



OPEL
 OPEL
 OPEL
 VAUXHALL
 VAUXHALL

MOVANO (H9)
 VIVARO (F7)
 VIVARO (J7)
 VIVARO (F7)
 VIVARO (J7)

500574T

APPLICATION

BOX SIDE
 $\emptyset = 28 \text{ mm}$
 $\emptyset = 80 \text{ mm}$
 $H = 122 \text{ mm}$



OPEL
 OPEL

ASTRA GTC J
 INSIGNIA

500478

APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 105 \text{ mm}$



CHEVROLET

CAPTIVA (C100, C140)

500098T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 142 \text{ mm}$

OPEL
OPELARENA (TB, TF)
ARENA (THB)

500336T

APPLICATION

WHEEL SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 99,1 \text{ mm}$
 $H = 122,8 \text{ mm}$

OPEL
OPEL
OPELASTRA GTC J
CASCADA (W13)
INSIGNIA

500152

APPLICATION

BOX SIDE
 $\varnothing = 30,5 \text{ mm}$
 $\varnothing = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$

OPEL
OPEL
OPEL
VAUXHALLVAUXHALL
VAUXHALLMOVANO (E9, U9)
MOVANO (F9)
MOVANO (J9)
MOVANO Mk I (A) (ED,
HD, UD)
MOVANO Mk I (A) (FD)
MOVANO Mk I (A) (JD)

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



CHRYSLER
 CHRYSLER
 CHRYSLER

NEON II
 PT CRUISER
 PT CRUISER (PT_)

500239T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 125 \text{ mm}$



CHRYSLER

PT CRUISER (PT_)

500175

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 116 \text{ mm}$



CHRYSLER

DELTA

500222

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 120 \text{ mm}$



CHRYSLER
 CHRYSLER

VOYAGER II (ES)
 VOYAGER III (GS)

500240T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 115 \text{ mm}$



CHRYSLER

VOYAGER IV (RG, RS)

500232T

APPLICATION

WHEEL SIDE
 $\emptyset = 25 \text{ mm}$
 $\emptyset = 89 \text{ mm}$
 $H = 138 \text{ mm}$



CHRYSLER

VOYAGER III (GS)

500618T

APPLICATION

BOX SIDE
 $\emptyset = 25,5 \text{ mm}$
 $\emptyset = 85,5 \text{ mm}$
 $H = 112 \text{ mm}$

CHRYSLER
CHRYSLERSEBRING (JR)
VOYAGER III (GS)

500235T

APPLICATION

WHEEL SIDE
 $\emptyset = 26,5 \text{ mm}$
 $\emptyset = 89 \text{ mm}$
 $H = 149 \text{ mm}$



CHRYSLER

300 M (LR)

500612T

APPLICATION

BOX SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 87,5 \text{ mm}$
 $H = 107 \text{ mm}$



CHRYSLER

DELTA

500345T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 88 \text{ mm}$
 $H = 100 \text{ mm}$



CHRYSLER

DELTA

APPLICATION

WHEEL SIDE

Ø = 27 mm

Ø = 90 mm

H = 132 mm



CHRYSLER

VOYAGER III (GS)

500131

APPLICATION

BOX SIDE



CITROEN	BX (XB-_)
CITROEN	C15 (VD-_)
CITROEN	LNA
CITROEN	VISA
PEUGEOT	104
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	205 II (20A/C)

500130

APPLICATION

BOX SIDE



CITROEN	AX (ZA-_)	PEUGEOT	306 (7B, N3, N5)
CITROEN	BERLINGO (M_)	PEUGEOT	306 (7D, N3, N5)
CITROEN	BERLINGO (MF)	PEUGEOT	306 (7E, N3, N5)
CITROEN	BX (XB-_)	PEUGEOT	309 I (10A, 10C)
CITROEN	C15 (VD-_)	PEUGEOT	309 II (3A, 3C)
CITROEN	SAXO (S0, S1)	PEUGEOT	405 I (15B)
CITROEN	VISA	PEUGEOT	405 I (15E)
CITROEN	XSARA	PEUGEOT	405 II (4B)
CITROEN	XSARA (N0)	PEUGEOT	405 II (4E)
CITROEN	XSARA (N1)	PEUGEOT	PARTNER (5)
CITROEN	XSARA (N2)	PEUGEOT	PARTNER (5F)
CITROEN	ZX (N2)		
PEUGEOT	205		
PEUGEOT	106 (1A)		
PEUGEOT	106 I (1A, 1C)		
PEUGEOT	106 II (1)		
PEUGEOT	205 I (20D, 741B)		
PEUGEOT	205 I (741A/C)		
PEUGEOT	205 II (20A/C)		
PEUGEOT	205 Mk II (20A/C)		
PEUGEOT	306 (7A, 7C, N3, N5)		

500370

APPLICATION

BOX/WHEEL SIDE



CITROEN	AX (ZA-_)	PEUGEOT	306 Van (7_, N_)
CITROEN	BERLINGO (M_)	PEUGEOT	309 II (3A, 3C)
CITROEN	BERLINGO (MF)	PEUGEOT	PARTNER (5)
CITROEN	BX (XB-_)	PEUGEOT	PARTNER (5F)
CITROEN	LNA		
CITROEN	SAXO (S0, S1)		
CITROEN	SAXO (S3_)		
CITROEN	XSARA		
CITROEN	XSARA (N0)		
CITROEN	XSARA (N1)		
CITROEN	XSARA (N2)		
PEUGEOT	306		
PEUGEOT	106 I (1A, 1C)		
PEUGEOT	106 II (1)		
PEUGEOT	106 Van (1_)		
PEUGEOT	205 I (20D, 741B)		
PEUGEOT	205 I (741A/C)		
PEUGEOT	306 (7A, 7C, N3, N5)		
PEUGEOT	306 (7B, N3, N5)		
PEUGEOT	306 (7D, N3, N5)		
PEUGEOT	306 (7E, N3, N5)		

500059

APPLICATION

BOX SIDE
 $\emptyset = 17 \text{ mm}$
 $\emptyset = 62,15 \text{ mm}$
 $H = 110 \text{ mm}$



CITROEN	C15 (VD-_)
CITROEN	VISA
PEUGEOT	205
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	205 II (20A/C)
PEUGEOT	309 I (10A, 10C)
PEUGEOT	309 II (3A, 3C)

500575

APPLICATION

BOX SIDE
 $\emptyset = 17 \text{ mm}$
 $\emptyset = 70 \text{ mm}$
 $H = 166 \text{ mm}$



PEUGEOT	104
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	305 I (581A)
PEUGEOT	305 I (581D)
PEUGEOT	305 II (581E)
PEUGEOT	305 II (581M)

500354

APPLICATION

WHEEL SIDE
 $\emptyset = 17 \text{ mm}$
 $\emptyset = 72 \text{ mm}$
 $H = 95 \text{ mm}$



PEUGEOT	104
---------	-----

500108

APPLICATION

WHEEL SIDE
 $\emptyset = 17,3 \text{ mm}$
 $\emptyset = 70,8 \text{ mm}$
 $H = 101,5 \text{ mm}$



CITROEN	C15 (VD-_)
CITROEN	VISA
PEUGEOT	104
PEUGEOT	205
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	205 II (20A/C)

500108E

APPLICATION

WHEEL SIDE
 $\emptyset = 17,3 \text{ mm}$
 $\emptyset = 70,8 \text{ mm}$
 $H = 101,5 \text{ mm}$



CITROEN	C15 (VD-_)
CITROEN	VISA
PEUGEOT	104
PEUGEOT	205
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	205 II (20A/C)

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



CITROEN
 CITROEN

C2 (JM_)
 C3 I (FC_)

500148

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 89 \text{ mm}$



CITROEN

VISA

500019

APPLICATION

WHEEL SIDE
 $\varnothing = 18,6 \text{ mm}$
 $\varnothing = 70,6 \text{ mm}$
 $H = 114,5 \text{ mm}$



CITROEN

VISA

500019E

APPLICATION

WHEEL SIDE
 $\varnothing = 18,6 \text{ mm}$
 $\varnothing = 70,6 \text{ mm}$
 $H = 114,5 \text{ mm}$



CITROEN

VISA

500428

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59,25 \text{ mm}$
 $H = 90 \text{ mm}$



CITROEN
 PEUGEOT

C1 (PM_, PN_)
 107

500170

APPLICATION

BOX SIDE
 Ø = 19 mm
 Ø = 60 mm
 H = 84 mm



CITROEN	C2 (JM_)
CITROEN	C2 ENTERPRISE
CITROEN	C3 (HB_)
CITROEN	C3 I (FC_)
CITROEN	C-ELYSEE
PEUGEOT	208
PEUGEOT	301
PEUGEOT	206+ (T3E)

500054

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 71,5 mm
 H = 79,6 mm



CITROEN	AX (ZA-)	PEUGEOT	205 II (20A/C)
CITROEN	SAXO (S0, S1)	PEUGEOT	309 I (10A, 10C)
PEUGEOT	205	PEUGEOT	309 II (3A, 3C)
PEUGEOT	106 (1A)		
PEUGEOT	106 I (1A, 1C)		
PEUGEOT	106 II (1)		
PEUGEOT	106 Van (1_)		
PEUGEOT	205 I (20D, 741B)		
PEUGEOT	205 I (741A/C)		

500054E

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 71,5 mm
 H = 79,6 mm



CITROEN	AX (ZA-)	PEUGEOT	309 I (10A, 10C)
PEUGEOT	205	PEUGEOT	309 II (3A, 3C)
PEUGEOT	106 (1A)		
PEUGEOT	106 I (1A, 1C)		
PEUGEOT	106 II (1)		
PEUGEOT	106 Van (1_)		
PEUGEOT	205 I (20D, 741B)		
PEUGEOT	205 I (741A/C)		
PEUGEOT	205 II (20A/C)		

500021

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 78 mm
 H = 113 mm



CITROEN	C15 (VD-)
CITROEN	VISA
PEUGEOT	205
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	205 II (20A/C)
PEUGEOT	305 I (581A)
PEUGEOT	309 I (10A, 10C)
PEUGEOT	309 II (3A, 3C)

500357

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 80 mm
 H = 97 mm



CITROEN	ZX (N2)
PEUGEOT	306 (7A, 7C, N3, N5)
PEUGEOT	306 (7B, N3, N5)
PEUGEOT	306 (7D, N3, N5)
PEUGEOT	306 (7E, N3, N5)

500282

APPLICATION

BOX SIDE
 $\emptyset = 19,25 \text{ mm}$
 $\emptyset = 67,7 \text{ mm}$
 $H = 93 \text{ mm}$



PEUGEOT	306 (7A, 7C, N3, N5)
PEUGEOT	306 (7B, N3, N5)
PEUGEOT	306 (7D, N3, N5)
PEUGEOT	306 (7E, N3, N5)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

500045

APPLICATION

WHEEL SIDE
 $\emptyset = 19,5 \text{ mm}$
 $\emptyset = 78,5 \text{ mm}$
 $H = 85,5 \text{ mm}$



CITROEN	AX (ZA-_)	PEUGEOT	309 II (3A, 3C)
CITROEN	BERLINGO (M_)	PEUGEOT	405 I (15B)
CITROEN	BERLINGO (MF)	PEUGEOT	405 II (4B)
CITROEN	C15 (VD-_)	PEUGEOT	405 II (4E)
CITROEN	SAXO (S0, S1)	PEUGEOT	PARTNER (5)
CITROEN	VISA	PEUGEOT	PARTNER (5F)
CITROEN	ZX (N2)		
PEUGEOT	205		
PEUGEOT	106 I (1A, 1C)		
PEUGEOT	106 II (1)		
PEUGEOT	205 I (20D, 741B)		
PEUGEOT	205 I (741A/C)		
PEUGEOT	205 II (20A/C)		
PEUGEOT	205 Mk II (20A/C)		
PEUGEOT	305 II (581E)		
PEUGEOT	305 II (581M)		
PEUGEOT	306 (7A, 7C, N3, N5)		
PEUGEOT	306 (7B, N3, N5)		
PEUGEOT	306 (7D, N3, N5)		
PEUGEOT	306 (7E, N3, N5)		
PEUGEOT	309 I (10A, 10C)		

500045E

APPLICATION

WHEEL SIDE
 $\emptyset = 19,5 \text{ mm}$
 $\emptyset = 78,5 \text{ mm}$
 $H = 85,5 \text{ mm}$



CITROEN	AX (ZA-_)	PEUGEOT	405 II (4E)
CITROEN	BERLINGO (M_)	PEUGEOT	PARTNER (5)
CITROEN	BERLINGO (MF)	PEUGEOT	PARTNER (5F)
CITROEN	C15 (VD-_)		
CITROEN	SAXO (S0, S1)		
CITROEN	ZX (N2)		
PEUGEOT	106 I (1A, 1C)		
PEUGEOT	106 II (1)		
PEUGEOT	205 I (20D, 741B)		
PEUGEOT	205 I (741A/C)		
PEUGEOT	205 II (20A/C)		
PEUGEOT	205 Mk II (20A/C)		
PEUGEOT	305 II (581E)		
PEUGEOT	305 II (581M)		
PEUGEOT	306 (7A, 7C, N3, N5)		
PEUGEOT	306 (7B, N3, N5)		
PEUGEOT	306 (7D, N3, N5)		
PEUGEOT	306 (7E, N3, N5)		
PEUGEOT	309 I (10A, 10C)		
PEUGEOT	309 II (3A, 3C)		
PEUGEOT	405 II (4B)		

500619T

APPLICATION

WHEEL SIDE
 $\varnothing = 19,8 \text{ mm}$
 $\varnothing = 67,6 \text{ mm}$
 $H = 98,2 \text{ mm}$



CITROEN
PEUGEOT

C1 (PM_, PN_) 107

500023

APPLICATION

WHEEL SIDE
 $\varnothing = 19,8 \text{ mm}$
 $\varnothing = 78,6 \text{ mm}$
 $H = 105,4 \text{ mm}$

[illegible]

BERLINGO (M_)
BERLINGO (MF)
BX (XB-_)
C15 (VD-_)
VISA
XANTIA (X1)
ZX (N2)
205
306
106 I (1A, 1C)
205 I (20D, 741B)
205 I (741A/C)
205 II (20A/C)
305 I (581A)
305 I (581D)
305 II (581E)
305 II (581M)
306 (7A, 7C, N3, N5)
306 (7B, N3, N5)
306 (7D, N3, N5)
306 (7E, N3, N5)

PEUGEOT	306 Van (7_, N_)
PEUGEOT	405 I (15B)
PEUGEOT	405 I (15E)
PEUGEOT	405 II (4B)
PEUGEOT	405 II (4E)
PEUGEOT	405 Mk II (4B)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

500023E

APPLICATION

WHEEL SIDE
 $\varnothing = 19,8 \text{ mm}$
 $\varnothing = 78,6 \text{ mm}$
 $H = 105,4 \text{ mm}$

[illegible]

BERLINGO (M_)
BERLINGO (MF)
BX (XB-_)
C15 (VD-_)
XANTIA (X1)
ZX (N2)
306
106 I (1A, 1C)
205 I (20D, 741B)
205 II (20A/C)
305 I (581A)
305 I (581D)
305 II (581E)
305 II (581M)
306 (7A, 7C, N3, N5)
306 (7B, N3, N5)
306 (7D, N3, N5)
306 (7E, N3, N5)
306 Van (7_, N_)
405 I (15B)
405 I (15E)

PEUGEOT	405 II (4B)
PEUGEOT	405 II (4E)
PEUGEOT	405 Mk II (4B)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

500318

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 36 mm
 H = 81 mm



CITROEN	2 CV
CITROEN	ACADIANE
CITROEN	AMI
CITROEN	DYANE
CITROEN	MEHARI

500074

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 54 mm
 H = 90 mm



CITROEN	AX (ZA-_)
CITROEN	SAXO (S0, S1)
CITROEN	SAXO (S3-)
PEUGEOT	106 (1A)
PEUGEOT	106 I (1A, 1C)
PEUGEOT	106 II (1)
PEUGEOT	106 Van (1-)

500063

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 61 mm
 H = 100 mm



PEUGEOT	205 II (20A/C)
PEUGEOT	405 I (15B)
PEUGEOT	405 I (15E)

500482

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 63 mm
 H = 87 mm



CITROEN	C15 (VD-_)	PEUGEOT	207 (WA_, WC_)
CITROEN	C3 (HB-)	PEUGEOT	207 CC (WD-)
CITROEN	C3 I (FC-)	PEUGEOT	207 SW (WK-)
CITROEN	C3 II		
CITROEN	C3 Picasso		
PEUGEOT	207		
PEUGEOT	208		
PEUGEOT	2008		
PEUGEOT	1007 (KM-)		

500371

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 63 mm
 H = 105 mm



CITROEN	AX (ZA-_)
PEUGEOT	309 I (10A, 10C)

500057

APPLICATION

BOX SIDE
 $\emptyset = 20 \text{ mm}$
 $\emptyset = 63 \text{ mm}$
 $H = 165 \text{ mm}$



CITROEN	AX (ZA-_)
CITROEN	SAXO (S0, S1)
CITROEN	SAXO (S3_)
PEUGEOT	106 (1A)
PEUGEOT	106 I (1A, 1C)
PEUGEOT	106 II (1)
PEUGEOT	106 Van (1_)

500254

APPLICATION

WHEEL SIDE
 $\emptyset = 20 \text{ mm}$
 $\emptyset = 70 \text{ mm}$
 $H = 80 \text{ mm}$



CITROEN	SAXO (S0, S1)
PEUGEOT	106 I (1A, 1C)
PEUGEOT	106 II (1)

500287

APPLICATION

WHEEL SIDE
 $\emptyset = 20,4 \text{ mm}$
 $\emptyset = 76 \text{ mm}$
 $H = 113 \text{ mm}$



CITROEN	C15 (VD-_)
CITROEN	LNA
CITROEN	VISA
PEUGEOT	104
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	304 (_04B_)
PEUGEOT	304 (_04C_)
PEUGEOT	304 (_04D_)
PEUGEOT	304 (_04M_)
PEUGEOT	305 I (581D)
PEUGEOT	305 II (581E)
PEUGEOT	305 II (581M)
PEUGEOT	309 I (10A, 10C)
PEUGEOT	309 II (3A, 3C)
PEUGEOT	405 I (15B)
PEUGEOT	405 I (15E)
PEUGEOT	405 II (4B)
PEUGEOT	405 II (4E)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

500287E

APPLICATION

WHEEL SIDE
 $\emptyset = 20,4 \text{ mm}$
 $\emptyset = 76 \text{ mm}$
 $H = 113 \text{ mm}$



CITROEN	C15 (VD-_)	PEUGEOT	304 (_04M_)
CITROEN	LNA	PEUGEOT	305 I (581D)
CITROEN	VISA	PEUGEOT	305 II (581E)
PEUGEOT	104	PEUGEOT	305 II (581M)
PEUGEOT	205 I (20D, 741B)	PEUGEOT	309 I (10A, 10C)
PEUGEOT	205 I (741A/C)	PEUGEOT	309 II (3A, 3C)
PEUGEOT	304 (_04B_)		
PEUGEOT	304 (_04C_)		
PEUGEOT	304 (_04D_)		

500607

APPLICATION

BOX SIDE
 $\varnothing = 20,8 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 81 \text{ mm}$



CITROEN
CITROEN
PEUGEOT

C2 (JM_)
C3 I (FC_)
1007 (KM)

500140

APPLICATION

BOX SIDE
 $\varnothing = 20,8 \text{ mm}$
 $\varnothing = 72,6 \text{ mm}$
 $H = 97,5 \text{ mm}$



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

BERLINGO (M_)
BERLINGO (MF)
BX (XB-_)
C15 (VD-_)
VISA
XANTIA (X1)
XANTIA (X2)
XM (Y3)
XSARA (N0)
XSARA (N1)
XSARA (N2)
ZX (N2)
205
205 I (20D, 741B)
205 I (741A/C)
205 II (20A/C)
305 I (581A)
305 I (581D)
305 II (581E)
305 II (581M)
306 (7A, 7C, N3, N5)

PEUGEOT	306 (7B, N3, N5)
PEUGEOT	306 (7D, N3, N5)
PEUGEOT	306 (7E, N3, N5)
PEUGEOT	309 I (10A, 10C)
PEUGEOT	309 II (3A, 3C)
PEUGEOT	405 I (15B)
PEUGEOT	405 I (15E)
PEUGEOT	405 II (4B)
PEUGEOT	405 II (4E)
PEUGEOT	405 Mk II (4B)
PEUGEOT	605 (6B)
PEUGEOT	806 (221)
PEUGEOT	807 (E)
PEUGEOT	EXPERT (222)
PEUGEOT	EXPERT (223)
PEUGEOT	EXPERT (224)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

500319

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 101 \text{ mm}$



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOT

2 CV
ACADIANE
AMI
DYANE
LNA
MEHARI
ZX (N2)
306 (7A, 7C, N3, N5)
306 (7B, N3, N5)

PEUGEOT	306 (7D, N3, N5)
PEUGEOT	306 (7E, N3, N5)

500360

APPLICATION

BOX SIDE
 $\emptyset = 21 \text{ mm}$
 $\emptyset = 70 \text{ mm}$
 $H = 94 \text{ mm}$



CITROEN	BERLINGO (M_)
CITROEN	BERLINGO (MF)
CITROEN	C15 (VD-_)
CITROEN	VISA
CITROEN	XSARA
CITROEN	XSARA (N0)
CITROEN	XSARA (N1)
CITROEN	XSARA (N2)
CITROEN	ZX (N2)
PEUGEOT	205
PEUGEOT	205 I (20D, 741B)
PEUGEOT	205 I (741A/C)
PEUGEOT	205 II (20A/C)
PEUGEOT	306 (7A, 7C, N3, N5)
PEUGEOT	306 (7B, N3, N5)
PEUGEOT	306 (7D, N3, N5)
PEUGEOT	306 (7E, N3, N5)
PEUGEOT	309 I (10A, 10C)
PEUGEOT	405 I (15B)
PEUGEOT	405 I (15E)
PEUGEOT	405 II (4B)

PEUGEOT	405 II (4E)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

500040

APPLICATION

WHEEL SIDE
 $\emptyset = 21 \text{ mm}$
 $\emptyset = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



CITROEN	SAXO (S0, S1)
PEUGEOT	106 I (1A, 1C)
PEUGEOT	106 II (1)

500040E

APPLICATION

WHEEL SIDE
 $\emptyset = 21 \text{ mm}$
 $\emptyset = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



CITROEN	SAXO (S0, S1)
PEUGEOT	106 I (1A, 1C)
PEUGEOT	106 II (1)

500595

APPLICATION

WHEEL SIDE

Ø = 21 mm

Ø = 75 mm

H = 100 mm



CITROEN	BERLINGO (ER_, EC_)	PEUGEOT	208 II (UB_, UP_, UW_, UJ_)
CITROEN	BERLINGO (K9)	PEUGEOT	3008 SUV (M_)
CITROEN	C3 Aircross II	PEUGEOT	308 (LB_)
CITROEN	C3 Aircross II (2R_, 2C_)	PEUGEOT	308 II
CITROEN	C3 Aircross II Van (2C_, 2R_)	PEUGEOT	308 SW II
CITROEN	C3 III (SX)	PEUGEOT	308 SW II (LC_)
CITROEN	C3 III Van (SX_, SY_)	PEUGEOT	5008 II
CITROEN	C4 Cactus	PEUGEOT	508 II (F3_, FB_, FH_)
CITROEN	C4 Cactus Van (0B_, 0P_)	PEUGEOT	508 II (FB_, F3_)
CITROEN	C4 Grand Picasso II	PEUGEOT	508 II (FB_, FH_, F3_)
CITROEN	C4 II (B7)	PEUGEOT	508 SW II (F4_, FC_, FJ_)
CITROEN	C4 Picasso II	PEUGEOT	508 SW II (FC_, FJ_, F4_)
CITROEN	C4 Spacetourer	PEUGEOT	806 (221)
CITROEN	C4 Spacetourer Van (3D_)	PEUGEOT	807 (E)
CITROEN	C5 Aircross	PEUGEOT	EXPERT
CITROEN	C8 (EA_, EB_)	PEUGEOT	EXPERT (222)
CITROEN	DS3	PEUGEOT	EXPERT (223)
CITROEN	DS4	PEUGEOT	EXPERT (224)
CITROEN	Evasion (22, U6)	PEUGEOT	EXPERT (VF3A_, VF3U_, VF3X_)
CITROEN	Grand C4 Spacetourer	PEUGEOT	EXPERT Tepee (VF3V_)
CITROEN	Grand C4 Spacetourer (3A_, 3E_)	PEUGEOT	PARTNER (K9)
CITROEN	Grand C4 Spacetourer Van (3A_, 3E_)	PEUGEOT	RIFTER
CITROEN	Jumpy		
CITROEN	Jumpy (BS_, BT_, BY_, BZ_)		
CITROEN	Jumpy (BU_, BV_, BW_, BX_)		
CITROEN	Jumpy (BU_, BV_, BW_, BX_) I Dispatch		
CITROEN	Jumpy (U6U)		
CITROEN	Jumpy I Dispatch		
DS	DS 3		
DS	DS 3 Crossback		
DS	DS7 Crossback		
PEUGEOT	208		
PEUGEOT	2008		
PEUGEOT	3008		
PEUGEOT	2008 (CU_)		
PEUGEOT	208 II		

500055

APPLICATION

WHEEL SIDE

Ø = 21 mm

Ø = 76 mm

H = 78 mm



CITROEN	2 CV	CITROEN	XANTIA (X2)
CITROEN	ACADIANE		
CITROEN	AMI		
CITROEN	AXEL		
CITROEN	DYANE		
CITROEN	GS		
CITROEN	JUMPER (230P)		
CITROEN	LNA		
CITROEN	MEHARI		

500129

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 77,5 \text{ mm}$
 $H = 76 \text{ mm}$



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT

BX (XB-_)
 VISA
 305 II (581E)
 305 II (581M)

500129E

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 77,5 \text{ mm}$
 $H = 76 \text{ mm}$



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT

BX (XB-_)
 VISA
 305 II (581E)
 305 II (581M)

500620T

APPLICATION

WHEEL SIDE
 $\varnothing = 21,2 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 97 \text{ mm}$



CITROEN
 PEUGEOT

C1 (PM_, PN_)
 107

500426

APPLICATION

BOX SIDE
 $\varnothing = 21,75 \text{ mm}$
 $\varnothing = 74,04 \text{ mm}$
 $H = 89,25 \text{ mm}$



CITROEN
 CITROEN

C4 Grand Picasso I
 (UA_)
 C4 Picasso I (UD_)

500409T

APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 71 mm
 H = 114,5 mm



CITROEN	BERLINGO (M_)	PEUGEOT	106 II (1)
CITROEN	BERLINGO (MF)	PEUGEOT	206 (2A/C)
CITROEN	C1 (PM_, PN_)	PEUGEOT	206 (2D)
CITROEN	C15 (VD-_)	PEUGEOT	206 (2E/K)
CITROEN	C2 (JM_)	PEUGEOT	306 (7B, N3, N5)
CITROEN	C3 I (FC_)	PEUGEOT	306 (7D, N3, N5)
CITROEN	C4 (LA_)	PEUGEOT	306 (7E, N3, N5)
CITROEN	C4 I (LC_)	PEUGEOT	307 (3A/C)
CITROEN	C5 I (DC_)	PEUGEOT	307 (3B)
CITROEN	C5 I (DE_)	PEUGEOT	307 (3E)
CITROEN	C5 II (RC_)	PEUGEOT	405 II (4B)
CITROEN	C5 II (RE_)	PEUGEOT	405 II (4E)
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)	PEUGEOT	406 (8B)
CITROEN	JUMPY (U6U)	PEUGEOT	406 (8C)
CITROEN	XANTIA (X1)	PEUGEOT	406 (8E/F)
CITROEN	XANTIA (X2)	PEUGEOT	407 (6D_)
CITROEN	XSARA (N1)	PEUGEOT	407 (6E_)
CITROEN	XSARA PICASSO (N68)	PEUGEOT	PARTNER (5)
CITROEN	ZX (N2)	PEUGEOT	PARTNER (5F)
PEUGEOT	107		

500304T

APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 72 mm
 H = 106 mm



CITROEN	AX (ZA-_)
CITROEN	SAXO (S0, S1)
CITROEN	SAXO (S3_)
PEUGEOT	106 (1A)
PEUGEOT	106 I (1A, 1C)
PEUGEOT	106 II (1)
PEUGEOT	106 Van (1_)

500322T

APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 73 mm
 H = 116 mm



CITROEN	C2 (JM_)
CITROEN	C2 ENTERPRISE
CITROEN	C2 ENTERPRISE (JG_)
CITROEN	C3 I (FC_)
CITROEN	C-ELYSEE
PEUGEOT	208
PEUGEOT	301
PEUGEOT	208 (CR_)

500285T

APPLICATION

WHEEL SIDE
 Ø = 22 mm
 Ø = 77,4 mm
 H = 116,5 mm



CITROEN	BERLINGO (MF)	PEUGEOT	208
CITROEN	C15 (VD-_)	PEUGEOT	2008
CITROEN	C2 (JM_)	PEUGEOT	1007 (KM_)
CITROEN	C3 (HB_)	PEUGEOT	206 (2A/C)
CITROEN	C3 I (FC_)	PEUGEOT	206 (2E/K)
CITROEN	C3 II	PEUGEOT	207 (WA_, WC_)
CITROEN	DS3	PEUGEOT	207 CC (WD_)
PEUGEOT	206	PEUGEOT	207 SW (WK_)
PEUGEOT	207		

500613T

APPLICATION

WHEEL SIDE
 $\emptyset = 22 \text{ mm}$
 $\emptyset = 78 \text{ mm}$
 $H = 118 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 PEUGEOT

C2 (JM_)
 C3 (HB_)
 C3 I (FC_)
 1007 (KM_)

500298T

APPLICATION

WHEEL SIDE
 $\emptyset = 22 \text{ mm}$
 $\emptyset = 82 \text{ mm}$
 $H = 126 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN

BERLINGO (M_)
 BERLINGO (MF)
 C15 (VD-_)
 JUMPER (230)
 JUMPER (230P)
 SAXO (S0, S1)
 XSARA
 XSARA (N0)
 XSARA (N1)
 XSARA (N2)

CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 ZX (N2)
 106 I (1A, 1C)
 106 II (1)
 205 II (20A/C)
 306 (7A, 7C, N3, N5)
 306 (7B, N3, N5)
 306 (7D, N3, N5)
 306 (7E, N3, N5)
 PARTNER (5)
 PARTNER (5F)

500634T

APPLICATION

WHEEL SIDE
 $\emptyset = 22,5 \text{ mm}$
 $\emptyset = 74 \text{ mm}$
 $H = 99 \text{ mm}$



CITROEN
 CITROEN
 CITROEN

C3 II
 C3 Picasso
 DS3

500027

APPLICATION

WHEEL SIDE
 $\emptyset = 22,8 \text{ mm}$
 $\emptyset = 85 \text{ mm}$
 $H = 104 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN

BERLINGO (M_)
 BERLINGO (MF)
 BX (XB-_)
 JUMPER (244)
 JUMPY (BS_, BT_, BY_, BZ_)
 JUMPY (U6U)
 XANTIA (X1)
 XANTIA (X2)
 XM (Y3)
 XSARA (N0)
 XSARA (N1)
 XSARA (N2)
 ZX (N2)
 205 I (20D, 741B)
 205 I (741A/C)
 205 II (20A/C)
 306 (7A, 7C, N3, N5)
 306 (7B, N3, N5)
 306 (7D, N3, N5)
 306 (7E, N3, N5)

PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 309 I (10A, 10C)
 309 II (3A, 3C)
 405 I (15B)
 405 I (15E)
 405 II (4B)
 405 II (4E)
 405 Mk II (4B)
 406 (8B)
 406 (8C)
 406 (8E/F)
 605 (6B)
 806 (221)
 BOXER (244)
 BOXER (244, Z_)
 ER (244)
 EXPERT (222)
 EXPERT (223)
 EXPERT (224)
 PARTNER (5)
 PARTNER (5F)

500027E

APPLICATION

WHEEL SIDE
 Ø = 22,8 mm
 Ø = 85 mm
 H = 104 mm



CITROEN BX (XB-)
 CITROEN XANTIA (X1)
 CITROEN XM (Y3)
 PEUGEOT 205 I (741A/C)
 PEUGEOT 306 (7A, 7C, N3, N5)
 PEUGEOT 309 I (10A, 10C)
 PEUGEOT 309 II (3A, 3C)
 PEUGEOT 405 I (15B)
 PEUGEOT 405 I (15E)

PEUGEOT 605 (6B)

500097

APPLICATION

WHEEL SIDE
 Ø = 22,8 mm
 Ø = 94,3 mm
 H = 145 mm



CITROEN C25 (280_, 290_)
 CITROEN JUMPER (230)
 CITROEN JUMPER (230L)
 CITROEN JUMPER (230P)
 CITROEN JUMPER (244)
 CITROEN JUMPER (244, Z_)
 CITROEN XANTIA (X1)
 CITROEN XM (Y3)
 PEUGEOT BOXER (230P)

PEUGEOT BOXER (244)
 PEUGEOT BOXER (244, Z_)
 PEUGEOT BOXER (ZCT_)
 PEUGEOT ER (230L)
 PEUGEOT ER (244)
 PEUGEOT J5 (280L)
 PEUGEOT J5 (280P)
 PEUGEOT J5 (290L)
 PEUGEOT J5 (290P)

500479

APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 72,5 mm
 H = 107,5 mm



CITROEN C3 I (FC_)
 PEUGEOT 1007 (KM_)

500339T

APPLICATION

WHEEL SIDE
 Ø = 23 mm
 Ø = 81 mm
 H = 132 mm



CITROEN BERLINGO (M_)
 CITROEN BERLINGO (MF)
 CITROEN XSARA
 CITROEN XSARA (N0)
 CITROEN XSARA (N1)
 CITROEN XSARA (N2)
 PEUGEOT 306 (7A, 7C, N3, N5)
 PEUGEOT 306 (7D, N3, N5)
 PEUGEOT 306 (7E, N3, N5)

PEUGEOT 306 Van (7_, N_)
 PEUGEOT PARTNER (5)
 PEUGEOT PARTNER (5F)

500048

APPLICATION

WHEEL SIDE
 Ø = 23,8 mm
 Ø = 91,5 mm
 H = 87 mm



CITROEN EVASION (22, U6)
 CITROEN JUMPY (BS_, BT_, BY_, BZ_)
 CITROEN JUMPY (BU_, BV_, BW_, BX_)
 CITROEN JUMPY (U6U)
 PEUGEOT 806 (221)
 PEUGEOT EXPERT (222)
 PEUGEOT EXPERT (223)

PEUGEOT EXPERT (224)

500338T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 79 \text{ mm}$
 $H = 135 \text{ mm}$



CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

SAXO (S0, S1)
 208
 3008
 106 I (1A, 1C)
 106 II (1)

500101T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 129 \text{ mm}$



CITROEN

ZX (N2)

500113

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 96 \text{ mm}$
 $H = 90 \text{ mm}$



CITROEN
 CITROEN

CX I (MA)
 CX II

500139

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 98 \text{ mm}$
 $H = 100 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

C25 (280_, 290_)
 CX I (MA)
 CX II
 J5 (280L)
 J5 (280P)
 J5 (290L)
 J5 (290P)

500065

APPLICATION

BOX SIDE

Ø = 24,3 mm

Ø = 78,3 mm

H = 102 mm



CITROEN	BX (XB_)	PEUGEOT	306 (7E, N3, N5)
CITROEN	C15 (VD_)	PEUGEOT	309 I (10A, 10C)
CITROEN	C8 (EA_, EB_)	PEUGEOT	405 I (15B)
CITROEN	EVASION (22, U6)	PEUGEOT	405 I (15E)
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)	PEUGEOT	405 II (4B)
CITROEN	JUMPY (BU_, BV_, BW_, BX_)	PEUGEOT	405 II (4E)
CITROEN	JUMPY (U6U)	PEUGEOT	605 (6B)
CITROEN	XANTIA (X1)	PEUGEOT	806 (221)
CITROEN	XANTIA (X2)	PEUGEOT	807 (E)
CITROEN	XM (Y4)	PEUGEOT	EXPERT (222)
CITROEN	ZX (N2)	PEUGEOT	EXPERT (224)
PEUGEOT	205 II (20A/C)		
PEUGEOT	305 I (581A)		
PEUGEOT	305 I (581D)		
PEUGEOT	305 II (581E)		
PEUGEOT	305 II (581M)		
PEUGEOT	306 (7A, 7C, N3, N5)		
PEUGEOT	306 (7B, N3, N5)		
PEUGEOT	306 (7D, N3, N5)		

500294T

APPLICATION

WHEEL SIDE

Ø = 24,5 mm

Ø = 83 mm

H = 120 mm



CITROEN	C8 (EA_, EB_)	PEUGEOT	806 (221)
CITROEN	EVASION (22, U6)	PEUGEOT	807 (E)
CITROEN	JUMPY	PEUGEOT	EXPERT
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)	PEUGEOT	EXPERT (222)
CITROEN	JUMPY (BU_, BV_, BW_, BX_)	PEUGEOT	EXPERT (223)
CITROEN	JUMPY (U6U)	PEUGEOT	EXPERT (224)
PEUGEOT	206 (2A/C)	PEUGEOT	EXPERT (VF3A_, VF3U_, VF3X_)
		PEUGEOT	EXPERT Tepee (VF3V_)

500576

APPLICATION

BOX SIDE

Ø = 25 mm

Ø = 69 mm

H = 194 mm



PEUGEOT	J7
PEUGEOT	J9

500424

APPLICATION

BOX SIDE

Ø = 25 mm
Ø = 78,3 mm
H = 96 mm



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
CITROEN

C5 III (RD_)
C5 III (TD_)
C8 (EA_, EB_)
DS4
JUMPY
JUMPY (BS_, BT_, BY_, BZ_)
JUMPY (BU_, BV_, BW_, BX_)
JUMPY (U6U)
NEMO
NEMO (AA_)
DS
DS 4 / DS 4 CROSS-BACK
308 (4A_, 4C_)
308 CC
807 (E)
BIPPER (AA_)
BIPPER Tepee
EXPERT
EXPERT (222)

PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

EXPERT (223)
EXPERT (224)
EXPERT (VF3A_, VF3U_, VF3X_)
EXPERT Tepee (VF3V_)

500242T

APPLICATION

BOX SIDE

Ø = 25 mm
Ø = 90 mm
H = 138 mm



CITROEN
CITROEN
CITROEN

AX (ZA-_)
JUMPER (244)
JUMPY (BS_, BT_, BY_, BZ_)
JUMPY (U6U)
XANTIA (X1)
XANTIA (X2)
XM (Y3)
XM (Y4)
306 (7A, 7C, N3, N5)
306 (7B, N3, N5)
306 (7D, N3, N5)
306 (7E, N3, N5)
306 Van (7_, N_)
405 II (4B)
405 II (4E)
405 Mk II (4B)
605 (6B)
806 (221)
BOXER (244)
BOXER (244, Z_)

PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

ER (244)
EXPERT (222)
EXPERT (223)
EXPERT (224)

500016

APPLICATION

WHEEL SIDE

Ø = 25 mm
Ø = 91,5 mm
H = 126,5 mm



PEUGEOT

J9

500016E

APPLICATION

WHEEL SIDE
 Ø = 25 mm
 Ø = 91,5 mm
 H = 126,5 mm



PEUGEOT

J9

500111

APPLICATION

WHEEL SIDE
 Ø = 25,3 mm
 Ø = 84,5 mm
 H = 96 mm

CITROEN
CITROEN

CITROEN

CITROEN
PEUGEOT
PEUGEOT
PEUGEOT

EVASION (22, U6)
 JUMPY (BS_, BT_, BY_,
 BZ_)
 JUMPY (BU_, BV_, BW_,
 BX_) I DISPATCH
 JUMPY (U6U)
 806 (221)
 EXPERT (222)
 EXPERT (223)

PEUGEOT

EXPERT (224)

500589

APPLICATION

BOX SIDE
 Ø = 25,5 mm
 Ø = 75 mm
 H = 92,2 mm

CITROEN
CITROEN
CITROEN

C5 III (RD_)
 C5 III (TD_)
 C6 (TD_)

500168T

APPLICATION

WHEEL SIDE
 Ø = 25,5 mm
 Ø = 83 mm
 H = 110 mm

CITROEN
CITROEN
CITROEN

CITROEN

CITROEN
PEUGEOT
PEUGEOT

C8 (EA_, EB_)
 EVASION (22, U6)
 JUMPY (BS_, BT_, BY_,
 BZ_)
 JUMPY (BU_, BV_, BW_,
 BX_)
 JUMPY (U6U)
 806 (221)
 807 (E)

PEUGEOT
PEUGEOT
PEUGEOT

EXPERT (222)
 EXPERT (223)
 EXPERT (224)

500504

APPLICATION

BOX SIDE
 Ø = 26 mm
 Ø = 81 mm
 H = 102 mm

CITROEN
CITROEN
CITROENPEUGEOT
PEUGEOT

C4 AIRCROSS
 C-CROSSER (EP_)
 C-CROSSER ENTER-
 PRISE
 4008
 4007 (GP_)

500335T

APPLICATION

WHEEL SIDE

Ø = 26 mm

Ø = 84 mm

H = 110 mm



CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

DS

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

C3 AIRCROSS II

C3 III (SX)

C4 CACTUS

C4 Grand Picasso II

C4 II (B7)

C4 Picasso II

C8 (EA_, EB_)

DS3

EVASION (22, U6)

JUMPY

JUMPY (BS_, BT_, BY_, BZ_)

JUMPY (BU_, BV_, BW_, BX_)

JUMPY (U6U)

DS 3

208

3008

308 II

308 SW II

5008 II

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

806 (221)

807 (E)

EXPERT

EXPERT (222)

EXPERT (223)

EXPERT (224)

EXPERT (VF3A_, VF3U_, VF3X_)

EXPERT Tepee (VF3V_)

500265

APPLICATION

BOX SIDE

Ø = 26 mm

Ø = 85 mm

H = 108 mm



CITROEN

CITROEN

CITROEN

CITROEN

PEUGEOT

XANTIA (X1)

XANTIA (X2)

XM (Y3)

XM (Y4)

605 (6B)

500104T

APPLICATION

WHEEL SIDE

Ø = 26,3 mm

Ø = 83 mm

H = 122 mm



PEUGEOT

605 (6B)

500021E

APPLICATION

WHEEL SIDE

Ø = 26,6 mm

Ø = 82 mm

H = 113 mm



CITROEN

CITROEN

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

C15 (VD-_)

VISA

205

205 I (20D, 741B)

205 I (741A/C)

205 II (20A/C)

305 I (581A)

309 I (10A, 10C)

309 II (3A, 3C)

500185

APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 88 \text{ mm}$



CITROEN	BERLINGO (M_)	PEUGEOT	306 (7E, N3, N5)
CITROEN	BERLINGO (MF)	PEUGEOT	306 Van (7_, N_)
CITROEN	C1 II	PEUGEOT	307 (3A/C)
CITROEN	C2 (JM_)	PEUGEOT	307 (3B)
CITROEN	C2 ENTERPRISE	PEUGEOT	307 (3E)
CITROEN	C3 (HB_)	PEUGEOT	307 (3H)
CITROEN	C3 I (FC_)	PEUGEOT	PARTNER
CITROEN	C3 II	PEUGEOT	PARTNER (5)
CITROEN	C3 Picasso	PEUGEOT	PARTNER (5F)
CITROEN	C4 (LA_)		
CITROEN	C4 I (LC_)		
CITROEN	C-ELYSEE		
CITROEN	DS3		
CITROEN	XSARA		
CITROEN	XSARA (N0)		
CITROEN	XSARA (N1)		
CITROEN	XSARA (N2)		
PEUGEOT	108		
PEUGEOT	206		
PEUGEOT	207		
PEUGEOT	208		
PEUGEOT	301		
PEUGEOT	2008		
PEUGEOT	1007 (KM_)		
PEUGEOT	206 (2A/C)		
PEUGEOT	206 (2D)		
PEUGEOT	206 (2E/K)		
PEUGEOT	206 Van		
PEUGEOT	207 (WA_, WC_)		
PEUGEOT	207 CC (WD_)		
PEUGEOT	207 SW (WK_)		
PEUGEOT	306 (7A, 7C, N3, N5)		
PEUGEOT	306 (7B, N3, N5)		
PEUGEOT	306 (7D, N3, N5)		

500227T

APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 125 \text{ mm}$



CITROEN C5 III (RD_)

500011T

APPLICATION

WHEEL SIDE
 $\varnothing = 27,2 \text{ mm}$
 $\varnothing = 98,1 \text{ mm}$
 $H = 144,5 \text{ mm}$



CITROEN	C3 (HB_)	PEUGEOT	BOXER (244)
CITROEN	JUMPER (230L)	PEUGEOT	BOXER (244, Z_)
CITROEN	JUMPER (230P)	PEUGEOT	ER (244)
CITROEN	JUMPER (244)		
CITROEN	JUMPER (244, Z_)		
CITROEN	XANTIA (X1)		
CITROEN	XANTIA (X2)		
CITROEN	XM (Y4)		
PEUGEOT	605 (6B)		

500142

APPLICATION

BOX SIDE
 $\emptyset = 27,55 \text{ mm}$
 $\emptyset = 75,7 \text{ mm}$
 $H = 92 \text{ mm}$



CITROEN	C8 (EA_, EB_)	PEUGEOT	ER (230L)
CITROEN	EVASION (22, U6)	PEUGEOT	ER (244)
CITROEN	JUMPER (230)	PEUGEOT	EXPERT (222)
CITROEN	JUMPER (230L)	PEUGEOT	EXPERT (223)
CITROEN	JUMPER (230P)	PEUGEOT	EXPERT (224)
CITROEN	JUMPER (244)		
CITROEN	JUMPER (244, Z_)		
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)		
CITROEN	JUMPY (BU_, BV_, BW_, BX_)		
CITROEN	JUMPY (U6U)		
CITROEN	XM (Y3)		
CITROEN	XM (Y4)		
PEUGEOT	605 (6B)		
PEUGEOT	806 (221)		
PEUGEOT	807 (E)		
PEUGEOT	BOXER (230P)		
PEUGEOT	BOXER (244)		
PEUGEOT	BOXER (244, Z_)		
PEUGEOT	BOXER (ZCT_)		

500286T

APPLICATION

WHEEL SIDE
 $\emptyset = 27,6 \text{ mm}$
 $\emptyset = 97 \text{ mm}$
 $H = 113,89 \text{ mm}$



CITROEN	C8 (EA_, EB_)	PEUGEOT	EXPERT (222)
CITROEN	EVASION (22, U6)	PEUGEOT	EXPERT (223)
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)	PEUGEOT	EXPERT (224)
CITROEN	JUMPY (BU_, BV_, BW_, BX_)		
CITROEN	JUMPY (U6U)		
PEUGEOT	806 (221)		
PEUGEOT	807 (E)		

500415

APPLICATION

BOX SIDE
 $\emptyset = 27,68 \text{ mm}$
 $\emptyset = 82,52 \text{ mm}$
 $H = 95 \text{ mm}$



CITROEN	JUMPER
PEUGEOT	BOXER
PEUGEOT	ER

500171

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 62 mm

H = 83 mm



CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

CITROEN

BERLINGO (M_)

BERLINGO (MF)

C2 (JM_)

C3 (HB_)

C3 I (FC_)

C3 II

C3 Picasso

C4 (LA_)

C4 I (LC_)

DS3

XSARA (N0)

XSARA (N1)

XSARA (N2)

206

207

208

2008

1007 (KM_)

206 (2A/C)

206 (2D)

206 (2E/K)

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

PEUGEOT

206 Van

207 (WA_, WC_)

207 CC (WD_)

207 SW (WK_)

306 (7A, 7C, N3, N5)

306 (7B, N3, N5)

306 (7D, N3, N5)

306 (7E, N3, N5)

307 (3A/C)

307 (3B)

307 (3E)

307 (3H)

PARTNER (5)

PARTNER (5F)

500305T

APPLICATION

WHEEL SIDE

Ø = 28 mm

Ø = 72 mm

H = 106 mm



CITROEN

CITROEN

CITROEN

PEUGEOT

PEUGEOT

AX (ZA_)

SAXO (S0, S1)

SAXO (S3_)

106 I (1A, 1C)

106 II (1)

500316

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 84 mm

H = 75 mm



CITROEN

CITROEN

XANTIA (X1)

XANTIA (X2)

500624

APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 103 \text{ mm}$



CITROEN
 CITROEN
 CITROEN

CITROEN
 CITROEN
 CITROEN

CITROEN

CITROEN

CITROEN

PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

C8 (EA_, EB_)
 EVASION (22, U6)
 EVASION MPV (22, U6) I
 SYNERGIE
 JUMPER (244)
 JUMPER (244, Z_)
 JUMPY (BS_, BT_, BY_,
 BZ_)
 JUMPY (BS_, BT_, BY_,
 BZ_) I DISPATCH
 JUMPY (BU_, BV_, BW_,
 BX_)
 JUMPY (U6U)
 806 (221)
 807 (E)
 BOXER (244)
 BOXER (244, Z_)
 BOXER (ZCT_)
 ER (244)
 EXPERT (222)
 EXPERT (223)

PEUGEOT

EXPERT (224)

500333

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 95 \text{ mm}$
 $H = 85 \text{ mm}$



CITROEN
 CITROEN

CITROEN

CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT

EVASION (22, U6)
 JUMPY (BS_, BT_, BY_,
 BZ_)
 JUMPY (BU_, BV_, BW_,
 BX_)
 JUMPY (U6U)
 806 (221)
 EXPERT (222)
 EXPERT (223)

PEUGEOT

EXPERT (224)

500018

APPLICATION

WHEEL SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 116 \text{ mm}$



PEUGEOT
 PEUGEOT
 PEUGEOT

205 I (20D, 741B)
 205 I (741A/C)
 205 II (20A/C)

500018E

APPLICATION

WHEEL SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 116 \text{ mm}$



PEUGEOT
 PEUGEOT

205 I (20D, 741B)
 205 I (741A/C)

500352

APPLICATION

BOX SIDE
 $\varnothing = 29 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 190 \text{ mm}$



PEUGEOT 405 II (4B)
 PEUGEOT 405 II (4E)
 PEUGEOT 405 Mk II (4B)
 PEUGEOT J9

500520T

APPLICATION

WHEEL SIDE
 $\varnothing = 29 \text{ mm}$
 $\varnothing = 91 \text{ mm}$
 $H = 128 \text{ mm}$



CITROEN C8 (EA_, EB_)
 PEUGEOT 807 (E)

500445T

APPLICATION

WHEEL SIDE
 $\varnothing = 29,2 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 112 \text{ mm}$



CITROEN	C4 Grand Picasso I (UA_)	PEUGEOT	407 (6D_)
CITROEN	C4 Grand Picasso II	PEUGEOT	407 (6E_)
CITROEN	C4 II (B7)	PEUGEOT	508 SW
CITROEN	C4 Picasso I (UD_)	PEUGEOT	607 (9D, 9U)
CITROEN	C4 Picasso II	PEUGEOT	807 (E)
CITROEN	C5 III (RD_)	PEUGEOT	BOXER (244)
CITROEN	C5 III (TD_)	PEUGEOT	BOXER (244, Z_)
CITROEN	C8 (EA_, EB_)	PEUGEOT	BOXER (ZCT_)
CITROEN	DS4	PEUGEOT	ER (244)
CITROEN	DS5	PEUGEOT	EXPERT
CITROEN	EVASION (22, U6)	PEUGEOT	EXPERT (222)
CITROEN	JUMPER (244)	PEUGEOT	EXPERT (223)
CITROEN	JUMPER (244, Z_)	PEUGEOT	EXPERT (224)
CITROEN	JUMPY	PEUGEOT	EXPERT (VF3A_, VF3U_, VF3X_)
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)	PEUGEOT	EXPERT Tepee (VF3V_)
CITROEN	JUMPY (BU_, BV_, BW_, BX_)	PEUGEOT	RCZ
CITROEN	JUMPY (U6U)	PEUGEOT	TRAVELLER
CITROEN	JUMPY I DISPATCH		
CITROEN	SPACETOURER		
DS	DS 4 / DS 4 CROSS-BACK		
DS	DS5		
PEUGEOT	508		
PEUGEOT	3008		
PEUGEOT	5008		
PEUGEOT	308 (4A_, 4C_)		
PEUGEOT	308 CC		
PEUGEOT	308 II		
PEUGEOT	308 SW		
PEUGEOT	308 SW II		
PEUGEOT	407 (6C_)		

500434

APPLICATION

BOX SIDE
 $\emptyset = 29,4 \text{ mm}$
 $\emptyset = 87,3 \text{ mm}$
 $H = 81 \text{ mm}$



CITROEN

C4 Grand Picasso I
(UA_)

PEUGEOT

EXPERT Tepee (VF3V_)

CITROEN

C4 Picasso I (UD_)

CITROEN

C5 III (RD_)

CITROEN

C5 III (TD_)

CITROEN

C8 (EA_, EB_)

CITROEN

JUMPER

CITROEN

JUMPY

PEUGEOT

508

PEUGEOT

3008

PEUGEOT

5008

PEUGEOT

308 (4A_, 4C_)

PEUGEOT

308 CC

PEUGEOT

308 SW

PEUGEOT

407 (6C_)

PEUGEOT

407 (6D_)

PEUGEOT

407 (6E_)

PEUGEOT

508 SW

PEUGEOT

607 (9D, 9U)

PEUGEOT

EXPERT (VF3A_, VF3U_,
VF3X_)

500164T

APPLICATION

WHEEL SIDE
 $\emptyset = 30 \text{ mm}$
 $\emptyset = 77 \text{ mm}$
 $H = 113 \text{ mm}$



CITROEN

C2 (JM_)

CITROEN

C3 (HB_)

CITROEN

C3 I (FC_)

500621T

APPLICATION

WHEEL SIDE
 $\emptyset = 30 \text{ mm}$
 $\emptyset = 78,1 \text{ mm}$
 $H = 117,2 \text{ mm}$



CITROEN

C2 (JM_)

CITROEN

C3 (HB_)

CITROEN

C3 I (FC_)

PEUGEOT

1007 (KM_)

500516T

APPLICATION

WHEEL SIDE
 $\emptyset = 30 \text{ mm}$
 $\emptyset = 92 \text{ mm}$
 $H = 115 \text{ mm}$



CITROEN

C-CROSSER (EP_)

CITROEN

C-CROSSER ENTER-
PRISE

PEUGEOT

4007 (GP_)

500602

APPLICATION

BOX SIDE
 $\emptyset = 30,5 \text{ mm}$
 $\emptyset = 63 \text{ mm}$
 $H = 80,9 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 PEUGEOT

C2 (JM_)
 C3 (HB_)
 C3 I (FC_)
 1007 (KM_)

500078

APPLICATION

BOX SIDE
 $\emptyset = 30,5 \text{ mm}$
 $\emptyset = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$



CITROEN
 PEUGEOT
 PEUGEOT

SAXO (S0, S1)
 106 I (1A, 1C)
 106 II (1)

500077

APPLICATION

BOX SIDE
 $\emptyset = 30,5 \text{ mm}$
 $\emptyset = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$



CITROEN
 PEUGEOT
 PEUGEOT

SAXO (S0, S1)
 106 I (1A, 1C)
 106 II (1)

500225T

APPLICATION

WHEEL SIDE
 $\emptyset = 31 \text{ mm}$
 $\emptyset = 74 \text{ mm}$
 $H = 111 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

C1 II
 C2 (JM_)
 C2 ENTERPRISE
 C3 I (FC_)
 C-ELYSEE
 108
 206
 208
 301

PEUGEOT 206 (2A/C)
 PEUGEOT 206 (2E/K)
 PEUGEOT 206 Van
 PEUGEOT 206+ (T3E)

500115

APPLICATION

WHEEL SIDE
 $\emptyset = 32 \text{ mm}$
 $\emptyset = 110,7 \text{ mm}$
 $H = 91 \text{ mm}$



CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

JUMPER (230)
 JUMPER (230L)
 JUMPER (230P)
 JUMPER (244)
 JUMPER (244, Z_)
 BOXER (230P)
 BOXER (244)
 BOXER (244, Z_)
 BOXER (ZCT_)

PEUGEOT ER (230L)
 PEUGEOT ER (244)

500006

APPLICATION

BOX SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 95 \text{ mm}$



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

JUMPER (230)
JUMPER (230L)
JUMPER (230P)
JUMPER (244)
JUMPER (244, Z_)
BOXER (230P)
BOXER (244)
BOXER (244, Z_)
BOXER (ZCT)

PEUGEOT
PEUGEOT

ER (230L)
ER (244)

500297T

APPLICATION

WHEEL SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 110 \text{ mm}$
 $H = 160 \text{ mm}$



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

JUMPER (230)
JUMPER (230L)
JUMPER (230P)
JUMPER (244)
JUMPER (244, Z_)
BOXER (230P)
BOXER (244)
BOXER (244, Z_)
BOXER (ZCT)

PEUGEOT
PEUGEOT

ER (230L)
ER (244)

500303T

APPLICATION

WHEEL SIDE
 $\varnothing = 33,5 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 110 \text{ mm}$

[illegible]

BERLINGO (M_)
BERLINGO (MF)
C3 (HB_)
C3 I (FC_)
C3 II
C3 Picasso
C4 (LA_)
C4 I (LC_)
DS3
XSARA
XSARA (N0)
XSARA (N1)
XSARA (N2)
206
207
208
2008
1007 (KM_)
206 (2A/C)
206 (2D)
206 (2E/K)
206 Van
207 (WA_, WC_)
207 CC (WD_)
207 SW (WK_)
306 (7A, 7C, N3, N5)
306 (7B, N3, N5)
306 (7D, N3, N5)
306 (7E, N3, N5)
306 Van (7_, N_)
307 (3A/C)
307 (3B)
307 (3E)
307 (3H)

PEUGEOT
PEUGEOT
PEUGEOT

PARTNER
PARTNER (5)
PARTNER (5F)

500017T

APPLICATION

WHEEL SIDE
 $\emptyset = 33,7 \text{ mm}$
 $\emptyset = 84 \text{ mm}$
 $H = 118 \text{ mm}$



CITROEN	BERLINGO (M_)	PEUGEOT	306 (7A, 7C, N3, N5)
CITROEN	BERLINGO (MF)	PEUGEOT	306 (7D, N3, N5)
CITROEN	C15 (VD-_)	PEUGEOT	307 (3A/C)
CITROEN	C5 I (DC_)	PEUGEOT	307 (3H)
CITROEN	C5 I (DE_)	PEUGEOT	405 II (4B)
CITROEN	JUMPY (BS_, BT_, BY_, BZ_)	PEUGEOT	405 Mk II (4B)
CITROEN	JUMPY (U6U)	PEUGEOT	406 (8B)
CITROEN	XANTIA (X1)	PEUGEOT	406 (8C)
CITROEN	XANTIA (X2)	PEUGEOT	406 (8E/F)
CITROEN	XSARA	PEUGEOT	PARTNER (5)
CITROEN	XSARA (N0)	PEUGEOT	PARTNER (5F)
CITROEN	XSARA (N1)		
CITROEN	XSARA (N2)		
CITROEN	XSARA PICASSO (N68)		
CITROEN	ZX (N2)		
PEUGEOT	206		
PEUGEOT	206 (2A/C)		
PEUGEOT	206 (2D)		
PEUGEOT	206 (2E/K)		
PEUGEOT	206 Van		

500094

APPLICATION

BOX SIDE
 $\emptyset = 33,8 \text{ mm}$
 $\emptyset = 84 \text{ mm}$
 $H = 101,3 \text{ mm}$



CITROEN	C15 (VD-_)
CITROEN	XANTIA (X1)
CITROEN	XSARA (N0)
CITROEN	XSARA (N1)
CITROEN	XSARA (N2)
CITROEN	XSARA PICASSO (N68)
PEUGEOT	306 (7A, 7C, N3, N5)
PEUGEOT	306 (7B, N3, N5)
PEUGEOT	306 (7E, N3, N5)

500405

APPLICATION

BOX SIDE

Ø = 34 mm

Ø = 68,88 mm

H = 96 mm



CITROEN	BERLINGO (B9)	PEUGEOT	508
CITROEN	BERLINGO (M_)	PEUGEOT	3008
CITROEN	BERLINGO (MF)	PEUGEOT	5008
CITROEN	C2 (JM_)	PEUGEOT	1007 (KM_)
CITROEN	C3 I (FC_)	PEUGEOT	206 (2A/C)
CITROEN	C3 II	PEUGEOT	206 (2D)
CITROEN	C3 III (SX)	PEUGEOT	206 (2E/K)
CITROEN	C3 Picasso	PEUGEOT	207 (WA_, WC_)
CITROEN	C4	PEUGEOT	207 CC (WD_)
CITROEN	C4 (LA_)	PEUGEOT	207 SW (WK_)
CITROEN	C4 CACTUS	PEUGEOT	307 (3A/C)
CITROEN	C4 Grand Picasso I	PEUGEOT	307 (3B)
	(UA_)	PEUGEOT	307 (3E)
CITROEN	C4 I (LC_)	PEUGEOT	307 (3H)
CITROEN	C4 II (B7)	PEUGEOT	308 (4A_, 4C_)
CITROEN	C4 Picasso I (UD_)	PEUGEOT	308 CC
CITROEN	C5 II (RC_)	PEUGEOT	308 SW
CITROEN	C5 II (RE_)	PEUGEOT	407 (6D_)
CITROEN	C5 III (RD_)	PEUGEOT	407 (6E_)
CITROEN	C5 III (TD_)	PEUGEOT	508 SW
CITROEN	DS3	PEUGEOT	PARTNER
CITROEN	DS4	PEUGEOT	PARTNER (5)
CITROEN	DS5	PEUGEOT	PARTNER (5F)
CITROEN	XSARA PICASSO (N68)	PEUGEOT	PARTNER Tepee
DS	DS 3	PEUGEOT	PARTNER Van
DS	DS 4 / DS 4 CROSS-	PEUGEOT	PARTNER Van (5) I
	BACK		PARTNER ORIGIN I
DS	DS5		RANCH
PEUGEOT	207	PEUGEOT	RCZ
PEUGEOT	208		

500135

APPLICATION

BOX SIDE

Ø = 34 mm

Ø = 79,5 mm

H = 103,5 mm



CITROEN	BERLINGO (M_)	PEUGEOT	306 (7B, N3, N5)
CITROEN	BERLINGO (MF)	PEUGEOT	306 (7D, N3, N5)
CITROEN	C15 (VD-)	PEUGEOT	306 (7E, N3, N5)
CITROEN	C4 (LA_)	PEUGEOT	306 Van (7_, N_)
CITROEN	C4 I (LC_)	PEUGEOT	307 (3A/C)
CITROEN	C5 I (DC_)	PEUGEOT	307 (3B)
CITROEN	C5 I (DE_)	PEUGEOT	307 (3E)
CITROEN	C5 II (RC_)	PEUGEOT	307 (3H)
CITROEN	C5 II (RE_)	PEUGEOT	405 II (4B)
CITROEN	JUMPY (BS_, BT_, BY_,	PEUGEOT	405 II (4E)
	BZ_)	PEUGEOT	406 (8B)
CITROEN	JUMPY (U6U)	PEUGEOT	406 (8C)
CITROEN	XANTIA (X1)	PEUGEOT	406 (8E/F)
CITROEN	XANTIA (X2)	PEUGEOT	407 (6D_)
CITROEN	XSARA	PEUGEOT	407 (6E_)
CITROEN	XSARA (N0)	PEUGEOT	PARTNER
CITROEN	XSARA (N1)	PEUGEOT	PARTNER (5)
CITROEN	XSARA (N2)	PEUGEOT	PARTNER (5F)
CITROEN	XSARA PICASSO (N68)		
CITROEN	ZX (N2)		
PEUGEOT	106 II (1)		
PEUGEOT	206 (2A/C)		
PEUGEOT	206 (2D)		
PEUGEOT	206 (2E/K)		
PEUGEOT	206 Van		
PEUGEOT	306 (7A, 7C, N3, N5)		

500344T

APPLICATION

WHEEL SIDE

Ø = 36 mm

Ø = 85 mm

H = 116 mm



CITROEN	BERLINGO (B9)	PEUGEOT	206 (2A/C)
CITROEN	BERLINGO (M_)	PEUGEOT	206 (2D)
CITROEN	BERLINGO (MF)	PEUGEOT	206 (2E/K)
CITROEN	C2 (JM_)	PEUGEOT	207 (WA_, WC_)
CITROEN	C3 I (FC_)	PEUGEOT	207 CC (WD_)
CITROEN	C3 II	PEUGEOT	207 SW (WK_)
CITROEN	C3 III (SX)	PEUGEOT	307 (3A/C)
CITROEN	C3 Picasso	PEUGEOT	307 (3B)
CITROEN	C4	PEUGEOT	307 (3E)
CITROEN	C4 (LA_)	PEUGEOT	307 (3H)
CITROEN	C4 CACTUS	PEUGEOT	308 (4A_, 4C_)
CITROEN	C4 Grand Picasso I (UA_)	PEUGEOT	308 CC
CITROEN	C4 Grand Picasso II	PEUGEOT	308 II
CITROEN	C4 I (LC_)	PEUGEOT	308 SW
CITROEN	C4 II (B7)	PEUGEOT	308 SW II
CITROEN	C4 Picasso I (UD_)	PEUGEOT	406 (8B)
CITROEN	C4 Picasso II	PEUGEOT	406 (8C)
CITROEN	C5 I (DC_)	PEUGEOT	406 (8E/F)
CITROEN	C5 I (DE_)	PEUGEOT	407 (6D_)
CITROEN	C5 II (RC_)	PEUGEOT	407 (6E_)
CITROEN	C5 II (RE_)	PEUGEOT	5008 II
CITROEN	C5 III (RD_)	PEUGEOT	508 SW
CITROEN	C5 III (TD_)	PEUGEOT	EXPERT
CITROEN	C-ELYSEE	PEUGEOT	PARTNER
CITROEN	DS3	PEUGEOT	PARTNER (5)
CITROEN	DS4	PEUGEOT	PARTNER (5F)
CITROEN	DS5	PEUGEOT	PARTNER Tepee
CITROEN	JUMPY	PEUGEOT	PARTNER Van
CITROEN	XSARA	PEUGEOT	PARTNER Van (5) I
CITROEN	XSARA (N0)	PEUGEOT	PARTNER ORIGIN I
CITROEN	XSARA (N1)	PEUGEOT	RANCH
CITROEN	XSARA (N2)	PEUGEOT	RCZ
CITROEN	XSARA PICASSO (N68)	PEUGEOT	TRAVELLER
DS	DS 3		
DS	DS 4 / DS 4 CROSS-BACK		
DS	DS5		
PEUGEOT	207		
PEUGEOT	208		
PEUGEOT	301		
PEUGEOT	508		
PEUGEOT	2008		
PEUGEOT	3008		
PEUGEOT	5008		
PEUGEOT	1007 (KM_)		

500007

APPLICATION

BOX SIDE

Ø = 36,2 mm

Ø = 96,3 mm

H = 97,9 mm



CITROEN	XM (Y3)
CITROEN	XM (Y4)
PEUGEOT	605 (6B)

500590

APPLICATION

BOX SIDE
 $\emptyset = 38 \text{ mm}$
 $\emptyset = 70 \text{ mm}$
 $H = 94 \text{ mm}$



CITROEN	C5 (DE_, RE_)
CITROEN	C5 I (DC_)
CITROEN	C5 I (DE_)
CITROEN	C5 II (RC_)
CITROEN	C5 II (RE_)
CITROEN	C5 III (RD_)
CITROEN	C5 III (TD_)
PEUGEOT	1007 (KM_)

500090

APPLICATION

BOX SIDE
 $\emptyset = 38 \text{ mm}$
 $\emptyset = 84 \text{ mm}$
 $H = 92 \text{ mm}$



CITROEN	C5 I (DC_)	PEUGEOT	607 (9D, 9U)
CITROEN	C5 I (DE_)		
CITROEN	XANTIA (X1)		
CITROEN	XANTIA (X2)		
CITROEN	XM (Y4)		
PEUGEOT	406 (8B)		
PEUGEOT	406 (8C)		
PEUGEOT	406 (8E/F)		
PEUGEOT	605 (6B)		

500244T

APPLICATION

WHEEL SIDE
 $\emptyset = 38,5 \text{ mm}$
 $\emptyset = 97 \text{ mm}$
 $H = 128 \text{ mm}$



CITROEN	C4 (LA_)
CITROEN	C4 I (LC_)
CITROEN	C5 I (DC_)
CITROEN	C5 I (DE_)
CITROEN	C5 II (RC_)
CITROEN	C5 II (RE_)
CITROEN	XANTIA (X1)
CITROEN	XANTIA (X2)
CITROEN	XM (Y4)
PEUGEOT	307 (3A/C)
PEUGEOT	307 (3B)
PEUGEOT	307 (3E)
PEUGEOT	307 (3H)
PEUGEOT	406 (8B)
PEUGEOT	406 (8C)
PEUGEOT	406 (8E/F)
PEUGEOT	407 (6C_)
PEUGEOT	407 (6D_)
PEUGEOT	407 (6E_)
PEUGEOT	605 (6B)
PEUGEOT	607 (9D, 9U)

500604

APPLICATION

BOX SIDE
 $\emptyset = 39,7 \text{ mm}$
 $\emptyset = 77,5 \text{ mm}$
 $H = 100,5 \text{ mm}$



CITROEN	C4 (LA_)
CITROEN	C4 Grand Picasso I (UA_)
CITROEN	C4 I (LC_)
CITROEN	C4 II (B7)
CITROEN	C5 I (DC_)
CITROEN	C5 I (DE_)
CITROEN	JUMPY
PEUGEOT	307 (3A/C)
PEUGEOT	307 (3B)
PEUGEOT	307 (3E)
PEUGEOT	406 (8B)
PEUGEOT	406 (8C)
PEUGEOT	406 (8E/F)
PEUGEOT	407 (6C_)
PEUGEOT	407 (6D_)
PEUGEOT	407 (6E_)
PEUGEOT	607 (9D, 9U)
PEUGEOT	EXPERT
PEUGEOT	EXPERT (VF3A_, VF3U_, VF3X_)

PEUGEOT

EXPERT Tepee (VF3V_)

500159

APPLICATION

BOX SIDE
 $\emptyset = 41 \text{ mm}$
 $\emptyset = 78 \text{ mm}$
 $H = 62 \text{ mm}$



CITROEN	2 CV
CITROEN	ACADIANE
CITROEN	AMI
CITROEN	DYANE
CITROEN	LNA
CITROEN	MEHARI

500151

APPLICATION

BOX SIDE



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

11 (B/C37_)
9 (L42_)
CLIO I (5/357_, B/C57_)
LAGUNA I (556_, B56_)
LAGUNA I (K56_)
MASTER I (T_)
MEGANE (JA0/1_)
MEGANE I (BA0/1_)
MEGANE I (DA0/1_)

RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

MEGANE I (EA0/1_)
MEGANE I (LA0/1_)
RAPID (F40_, G40_)
SCÉNIC I (JA0/1_)
SUPER 5 (B/C40_)

500150

APPLICATION

BOX SIDE



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

19 I (B/C53_)
19 I (L53_)
19 II (B/C53_)
19 II (L53_)
CLIO I (5/357_, B/C57_)
LAGUNA I (556_, B56_)
LAGUNA I (K56_)
MEGANE (JA0/1_)
MEGANE I (BA0/1_)

RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

MEGANE I (DA0/1_)
MEGANE I (EA0/1_)
MEGANE I (LA0/1_)
RAPID (F40_, G40_)
SCÉNIC I (JA0/1_)
SUPER 5 (B/C40_)
TWINGO I (C06_)

500131

APPLICATION

BOX SIDE



RENAULT

14 (121_)

500029

APPLICATION

BOX SIDE



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

19 I (B/C53_)
19 I (D53_)
19 I (L53_)
19 II (853_, D53_)
19 II (B/C53_)
19 II (L53_)
21 (B48_)
21 (K48_)
21 (L48_)

RENAULT
RENAULT
RENAULT

CLIO I (5/357_, B/C57_)
LAGUNA I (556_, B56_)
LAGUNA I (K56_)

APPLICATION

BOX SIDE



RENAULT
RENAULT

[illegible]

AVANTIME (DE0_)
CLIO II (BB0/1/2_,
CB0/1/2_)
ESPACE III (JE0_)
ESPACE IV (JK0/1_)
KANGOO (FC0/1_)
KANGOO (KC0/1_)
LAGUNA I (556_, B56_)
LAGUNA I (K56_)
LAGUNA II (BG0/1_)
LAGUNA II (KG0/1_)
MASTER II (ED/HD/UD)
MASTER II (FD)
MASTER II (JD)
MEGANE (JA0/1_)
MEGANE I (BA0/1_)
MEGANE I (DA0/1_)
MEGANE I (EA0/1_)
MEGANE I (KA0/1_)
MEGANE I (LA0/1_)
SAFRANE II (B54_)

RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

SCÉNIC I (JA0/1_)
SPORT SPIDER (EFO_)
THALIA I (LB0/1/2_)
TRAFIC II (EL)
TRAFIC II (FL)
TRAFIC II (JL)
VEL SATIS (BJ0)

500358

APPLICATION

BOX SIDE



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

AVANTIME (DE0_)
 ESPACE III (JE0_)
 ESPACE IV (JK0/1_)
 MASTER II (ED/HD/UD)
 MASTER II (FD)
 MASTER II (JD)
 TRAFIC II (EL)
 TRAFIC II (FL)
 TRAFIC II (JL)

RENAULT

VEL SATIS (BJ0)

500622

APPLICATION

BOX SIDE



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

CLIO II (BB0/1/2_ ,
CB0/1/2_)
ESPACE III (JE0_)
KANGOO (KC0/1_)
MEGANE (JA0/1_)
MEGANE I (BA0/1_)
MEGANE I (DA0/1_)
MEGANE I (LA0/1_)
SCÉNIC I (JA0/1_)

500518

APPLICATION

BOX SIDE



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

19 I (B/C53_)
19 I (D53_)
19 I (L53_)
19 II (B/C53_)
19 II (L53_)
21 (B48_)
21 (K48_)
21 (L48_)
25 (B29)

RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

CLIO I (5/357_, B/C57_)
 ESPACE II (J/S63_)
 ESPACE III (JE0_)
 LAGUNA I (556_, B56_)
 LAGUNA I (K56_)
 SPORT SPIDER (EF0_)

500059

APPLICATION

BOX SIDE

Ø = 17 mm

Ø = 62,15 mm

H = 110 mm



RENAULT	12
RENAULT	17
RENAULT	11 (B/C37_)
RENAULT	12 (117_)
RENAULT	15 (130_)
RENAULT	18 (134_)
RENAULT	18 (135_)
RENAULT	4 (112_)
RENAULT	4 (R21_, R23_)
RENAULT	5 (122_)
RENAULT	6 (118_)
RENAULT	9 (L42_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	FUEGO (136_)
RENAULT	MEGANE (JA0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (LA0/1_)
RENAULT	RAPID (F40_, G40_)
RENAULT	RODEO 4 (ACL_)

RENAULT	RODEO 5 (4D_, 5E_)
RENAULT	RODEO 6 (ACL_)
RENAULT	SCÉNIC I (JA0/1_)
RENAULT	SUPER 5 (B/C40_)
RENAULT	TWINGO I (C06_)

500108

APPLICATION

WHEEL SIDE

Ø = 17,3 mm

Ø = 70,8 mm

H = 101,5 mm



RENAULT	12
RENAULT	17
RENAULT	11 (B/C37_)
RENAULT	12 (117_)
RENAULT	14 (121_)
RENAULT	15 (130_)
RENAULT	18 (134_)
RENAULT	18 (135_)
RENAULT	4 (112_)
RENAULT	4 (R21_, R23_)
RENAULT	5 (122_)
RENAULT	6 (118_)
RENAULT	9 (L42_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	FUEGO (136_)
RENAULT	MEGANE (JA0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (LA0/1_)
RENAULT	RAPID (F40_, G40_)

RENAULT	RODEO 4 (ACL_)
RENAULT	RODEO 5 (4D_, 5E_)
RENAULT	RODEO 6 (ACL_)
RENAULT	SCÉNIC I (JA0/1_)
RENAULT	SUPER 5 (B/C40_)
RENAULT	TWINGO I (C06_)

500108E

APPLICATION

WHEEL SIDE
 $\varnothing = 17,3 \text{ mm}$
 $\varnothing = 70,8 \text{ mm}$
 $H = 101,5 \text{ mm}$



RENAULT 12
 RENAULT 17
 RENAULT 11 (B/C37_)
 RENAULT 12 (117_)
 RENAULT 15 (130_)
 RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 4 (112_)
 RENAULT 4 (R21_, R23_)
 RENAULT 5 (122_)
 RENAULT 6 (118_)
 RENAULT 9 (L42_)
 RENAULT CLIO I (5/357_, B/C57_)
 RENAULT FUEGO (136_)
 RENAULT MEGANE (JA0/1_)
 RENAULT MEGANE I (BA0/1_)
 RENAULT MEGANE I (DA0/1_)
 RENAULT MEGANE I (EA0/1_)
 RENAULT MEGANE I (LA0/1_)
 RENAULT RAPID (F40_, G40_)
 RENAULT RODEO 4 (ACL_)

RENAULT RODEO 5 (4D_, 5E_)
 RENAULT RODEO 6 (ACL_)
 RENAULT SCÉNIC I (JA0/1_)
 RENAULT SUPER 5 (B/C40_)
 RENAULT TWINGO I (C06_)
 RENAULT TWINGO I (S06_)

500009

APPLICATION

BOX SIDE
 $\varnothing = 17,6 \text{ mm}$
 $\varnothing = 77,85 \text{ mm}$
 $H = 108,15 \text{ mm}$



RENAULT 12
 RENAULT 17
 RENAULT 18
 RENAULT 11 (B/C37_)
 RENAULT 12 (117_)
 RENAULT 15 (130_)
 RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 4 (112_)
 RENAULT 4 (R21_, R23_)
 RENAULT 5 (122_)
 RENAULT 5 (238_)
 RENAULT 6 (118_)
 RENAULT 9 (L42_)
 RENAULT CLIO I (5/357_, B/C57_)
 RENAULT EXPRESS
 RENAULT FUEGO (136_)
 RENAULT MEGANE I (BA0/1_)
 RENAULT MEGANE I (DA0/1_)
 RENAULT RAPID (F40_, G40_)
 RENAULT RODEO 4 (ACL_)

RENAULT RODEO 5 (4D_, 5E_)
 RENAULT RODEO 6 (ACL_)
 RENAULT SUPER 5 (B/C40_)
 RENAULT TWINGO I (C06_)
 RENAULT TWINGO I (S06_)

500309

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 130 \text{ mm}$



RENAULT 12
 RENAULT 17
 RENAULT 12 (117_)
 RENAULT 15 (130_)
 RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 20 (127_)
 RENAULT 5 (122_)
 RENAULT FUEGO (136_)

500170

APPLICATION

BOX SIDE
 Ø = 19 mm
 Ø = 60 mm
 H = 84 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

GRAND SCÉNIC II
 (JM0/1_)
 KANGOO (FC0/1_)
 KANGOO (KC0/1_)
 SCÉNIC I (JA0/1_)
 SCÉNIC II (JM0/1_)
 THALIA II (LU1/2_)

500021

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 78 mm
 H = 113 mm



RENAULT
 RENAULT
 RENAULT

12
 12 (117_)
 RAPID (F40_, G40_)

500122

APPLICATION

WHEEL SIDE
 Ø = 19,8 mm
 Ø = 75,55 mm
 H = 83 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

11 (B/C37_)
 19 I (B/C53_)
 19 I (L53_)
 9 (L42_)
 MASTER I (T_)
 RAPID (F40_, G40_)
 SUPER 5 (B/C40_)

500122E

APPLICATION

WHEEL SIDE
 Ø = 19,8 mm
 Ø = 75,55 mm
 H = 83 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

11 (B/C37_)
 19 I (B/C53_)
 19 I (L53_)
 9 (L42_)
 MASTER I (T_)
 RAPID (F40_, G40_)
 SUPER 5 (B/C40_)

500482

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 63 mm
 H = 87 mm



DACIA
 DACIA
 DACIA
 DACIA
 RENAULT
 RENAULT
 RENAULT
 RENAULT

LOGAN (FS_)
 LOGAN (US_)
 LOGAN MCV (KS_)
 SANDERO
 FLUENCE (L30_)
 GRAND SCÉNIC III
 (JZ0/1_)
 LOGAN I (LS_)
 MEGANE CC (EZ0/1_)

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1_)
 SCÉNIC III (JZ0/1_)
 TWINGO II (CN0_)

500348

APPLICATION

WHEEL SIDE
 Ø = 20 mm
 Ø = 74 mm
 H = 110 mm



RENAULT	5 (122_)
RENAULT	5 (238_)

500369

APPLICATION

BOX SIDE
 Ø = 20 mm
 Ø = 80 mm
 H = 110 mm



RENAULT	19 I (B/C53_)	RENAULT	TWINGO I (S06_)
RENAULT	19 I (D53_)		
RENAULT	19 I (L53_)		
RENAULT	19 II (853_, D53_)		
RENAULT	19 II (B/C53_)		
RENAULT	19 II (L53_)		
RENAULT	CLIO I (5/357_, B/C57_)		
RENAULT	RAPID (F40_, G40_)		
RENAULT	TWINGO I (C06_)		

500287

APPLICATION

WHEEL SIDE
 Ø = 20,4 mm
 Ø = 76 mm
 H = 113 mm



RENAULT	12	RENAULT	20 (127_)
RENAULT	17	RENAULT	5 (122_)
RENAULT	18		
RENAULT	12 (117_)		
RENAULT	14 (121_)		
RENAULT	15 (130_)		
RENAULT	16 (115_)		
RENAULT	18 (134_)		
RENAULT	18 (135_)		

500287E

APPLICATION

WHEEL SIDE
 Ø = 20,4 mm
 Ø = 76 mm
 H = 113 mm



RENAULT	12	RENAULT	20 (127_)
RENAULT	17	RENAULT	5 (122_)
RENAULT	18		
RENAULT	12 (117_)		
RENAULT	14 (121_)		
RENAULT	15 (130_)		
RENAULT	16 (115_)		
RENAULT	18 (134_)		
RENAULT	18 (135_)		

500449T

APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 62 mm
 H = 96 mm



RENAULT	CLIO (KR0/1_)
RENAULT	CLIO III (BR0/1, CR0/1_)
RENAULT	CLIO III (SB_, SR_)
RENAULT	LAGUNA III (BT0/1)
RENAULT	LAGUNA III (KT0/1)
RENAULT	MODUS / GRAND MO-
	DUS (F/JPO_)
RENAULT	VEL SATIS (BJ0_)

500523

APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 69 mm
 H = 94,5 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

FLUENCE (L30_)
 GRAND SCÉNIC III
 (JZ0/1_)
 MEGANE CC (EZ0/1_)
 MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1)
 SCÉNIC III (JZ0/1_)

500270

APPLICATION

BOX SIDE
 Ø = 21 mm
 Ø = 80 mm
 H = 84 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

ESPACE III (JE0_)
 LAGUNA I (556_, B56_)
 LAGUNA I (K56_)
 SAFRANE I (B54_)
 SAFRANE II (B54_)

500243T

APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 82 mm
 H = 146 mm



RENAULT
 RENAULT
 RENAULT

LAGUNA I (556_, B56_)
 LAGUNA I (K56_)
 SAFRANE I (B54_)

500308

APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 84 mm
 H = 124 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

18 (134_)
 18 (135_)
 20 (127_)
 25 (B29_)
 30 (127_)
 ESPACE I (J11_)
 FUEGO (136_)
 MASTER I (T_)
 TRAFIC (T1, T3, T4)

RENAULT

TRAFIC (T5, T6, T7)

500426

APPLICATION

BOX SIDE
 Ø = 21,75 mm
 Ø = 74,04 mm
 H = 89,25 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

GRAND SCÉNIC III
 (JZ0/1_)
 MEGANE CC (EZ0/1_)
 MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1)
 SCÉNIC III (JZ0/1_)

500050

APPLICATION

WHEEL SIDE
 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$



RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 19 I (B/C53_)
 RENAULT 19 I (D53_)
 RENAULT 19 I (L53_)
 RENAULT 19 II (853_, D53_)
 RENAULT 19 II (B/C53_)
 RENAULT 19 II (L53_)
 RENAULT 19 II (S53_)
 RENAULT 20 (127_)
 RENAULT 21 (B48_)
 RENAULT 21 (K48_)
 RENAULT 21 (L48_)
 RENAULT 25 (B29_)
 RENAULT 30 (127_)
 RENAULT CLIO I (5/357_, B/C57_)
 RENAULT CLIO I (S57_)
 RENAULT ESPACE I (J11_)
 RENAULT ESPACE II (J/S63_)
 RENAULT FUEGO (136_)
 RENAULT LAGUNA I (556_, B56_)

RENAULT LAGUNA I (K56_)
 RENAULT MEGANE (JA0/1_)
 RENAULT MEGANE I (BA0/1_)
 RENAULT MEGANE I (DA0/1_)
 RENAULT MEGANE I (EA0/1_)
 RENAULT SAFRANE I (B54_)
 RENAULT SCÉNIC I (JA0/1_)
 RENAULT TRAFIC (P6)
 RENAULT TRAFIC (PXX)
 RENAULT TRAFIC (T1, T3, T4)
 RENAULT TRAFIC (T5, T6, T7)
 RENAULT TRAFIC (TXW)
 RENAULT TRAFIC (TXX)

500050E

APPLICATION

WHEEL SIDE
 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$



RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 19 I (B/C53_)
 RENAULT 19 I (D53_)
 RENAULT 19 I (L53_)
 RENAULT 19 II (853_, D53_)
 RENAULT 19 II (B/C53_)
 RENAULT 19 II (L53_)
 RENAULT 19 II (S53_)
 RENAULT 20 (127_)
 RENAULT 21 (B48_)
 RENAULT 21 (K48_)
 RENAULT 21 (L48_)
 RENAULT 25 (B29_)
 RENAULT 30 (127_)
 RENAULT CLIO I (5/357_, B/C57_)
 RENAULT CLIO I (S57_)
 RENAULT ESPACE I (J11_)
 RENAULT ESPACE II (J/S63_)
 RENAULT FUEGO (136_)
 RENAULT LAGUNA I (556_, B56_)

RENAULT LAGUNA I (K56_)
 RENAULT MEGANE (JA0/1_)
 RENAULT MEGANE I (BA0/1_)
 RENAULT MEGANE I (DA0/1_)
 RENAULT MEGANE I (EA0/1_)
 RENAULT SAFRANE I (B54_)
 RENAULT SCÉNIC I (JA0/1_)
 RENAULT TRAFIC (P6)
 RENAULT TRAFIC (PXX)
 RENAULT TRAFIC (T1, T3, T4)
 RENAULT TRAFIC (T5, T6, T7)
 RENAULT TRAFIC (TXW)
 RENAULT TRAFIC (TXX)

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



RENAULT FLUENCE (L30_)
 RENAULT GRAND SCÉNIC III (JZ0/1_)
 RENAULT MEGANE CC (EZ0/1_)
 RENAULT MEGANE III (BZ0_)
 RENAULT MEGANE III (DZ0/1_)
 RENAULT MEGANE III (KZ0/1_)
 RENAULT SCÉNIC III (JZ0/1_)

500301

APPLICATION

WHEEL SIDE
 $\emptyset = 22 \text{ mm}$
 $\emptyset = 85 \text{ mm}$
 $H = 95 \text{ mm}$



RENAULT
 RENAULT
 RENAULT

25 (B29_)
 ESPACE I (J11_)
 ESPACE II (J/S63_)

500634T

APPLICATION

WHEEL SIDE
 $\emptyset = 22,5 \text{ mm}$
 $\emptyset = 74 \text{ mm}$
 $H = 99 \text{ mm}$



DACIA
 DACIA
 DACIA
 DACIA
 RENAULT
 RENAULT
 RENAULT

DUSTER
 LOGAN (LS_)
 LOGAN MCV (KS_)
 SANDERO
 CLIO III (BR0/1, CR0/1_)
 MODUS / GRAND MO-
 DUS (F/JPO_)
 TWINGO II (CNO_)

500022

APPLICATION

WHEEL SIDE
 $\emptyset = 22,7 \text{ mm}$
 $\emptyset = 77,8 \text{ mm}$
 $H = 108,5 \text{ mm}$



RENAULT
 RENAULT
 RENAULT
 RENAULT

ESPACE I (J11_)
 ESPACE II (J/S63_)
 ESPACE III (JE0_)
 ESPACE IV (JK0/1_)

500022E

APPLICATION

WHEEL SIDE
 $\emptyset = 22,7 \text{ mm}$
 $\emptyset = 77,8 \text{ mm}$
 $H = 108,5 \text{ mm}$



RENAULT
 RENAULT
 RENAULT
 RENAULT

ESPACE I (J11_)
 ESPACE II (J/S63_)
 ESPACE III (JE0_)
 ESPACE IV (JK0/1_)

500597

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 65 mm

H = 90 mm



RENAULT	FLUENCE (L30_)
RENAULT	GRAND SCÉNIC III (JZ0/1_)
RENAULT	KANGOO (FW0/1_)
RENAULT	KANGOO / GRAND KANGOO (KW0/1_)
RENAULT	KANGOO BE BOP (KW0/1_)
RENAULT	KANGOO Express (FW0/1_)
RENAULT	KANGOO/GRAND KANGOO
RENAULT	LAGUNA III (BT0/1)
RENAULT	LAGUNA III (KT0/1)
RENAULT	MEGANE CC (EZ0/1_)
RENAULT	MEGANE III (BZ_)
RENAULT	MEGANE III (BZ0_)
RENAULT	MEGANE III (DZ0/1_)
RENAULT	MEGANE III (KZ0/1)
RENAULT	SCÉNIC III (JZ0/1_)

500300

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 65 mm

H = 104 mm



DACIA	LOGAN MCV (KS_)	RENAULT	MEGANE I (DA0/1_)
DACIA	SANDERO	RENAULT	MEGANE I (EA0/1_)
DACIA	SOLENZA (B41_)	RENAULT	MEGANE I (KA0/1_)
RENAULT	CLIO II (BB0/1/2_)	RENAULT	MEGANE I (LA0/1_)
	CB0/1/2_)	RENAULT	SANDERO/STEPWAY II (B8_)
RENAULT	CLIO II (SB0/1/2_)	RENAULT	SCÉNIC I (JA0/1_)
RENAULT	ESPACE III (JE0_)	RENAULT	SPORT SPIDER (EF0_)
RENAULT	KANGOO (FC0/1_)	RENAULT	THALIA I (LB0/1/2_)
RENAULT	KANGOO (FW0/1_)	RENAULT	THALIA II (LU1/2_)
RENAULT	KANGOO (KC0/1_)	RENAULT	TWINGO I (C06_)
RENAULT	KANGOO / GRAND KANGOO (KW0/1_)	RENAULT	TWINGO I (S06_)
RENAULT	KANGOO BE BOP (KW0/1_)	RENAULT	TWINGO II (CN0_)
RENAULT	LAGUNA I (556_, B56_)		
RENAULT	LAGUNA I (K56_)		
RENAULT	LOGAN I (KS_)		
RENAULT	LOGAN I (LS_)		
RENAULT	LOGAN II (B8_)		
RENAULT	MEGANE (JA0/1_)		
RENAULT	MEGANE I (BA0/1_)		

500567

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 82 mm

H = 192 mm



RENAULT	AVANTIME (DE0_)
RENAULT	ESPACE III (JE0_)
RENAULT	MASTER II (ED/HD/UD)
RENAULT	MASTER II (FD)
RENAULT	MASTER II (JD)
RENAULT	TRAFIC II (EL)
RENAULT	TRAFIC II (FL)
RENAULT	TRAFIC II (JL)
RENAULT	VEL SATIS (BJ0_)

500133

APPLICATION

BOX SIDE

Ø = 23,7 mm

Ø = 71,4 mm

H = 111 mm



RENAULT	18 (134_)
RENAULT	18 (135_)
RENAULT	20 (127_)
RENAULT	21 (B48_)
RENAULT	21 (K48_)
RENAULT	21 (L48_)
RENAULT	21 (S48_)
RENAULT	25 (B29_)
RENAULT	30 (127_)
RENAULT	ESPACE I (J11_)
RENAULT	ESPACE II (J/S63_)
RENAULT	ESPACE III (JE0_)
RENAULT	FUEGO (136_)
RENAULT	LAGUNA I (556_, B56_)
RENAULT	LAGUNA I (K56_)
RENAULT	MASTER I (T_)
RENAULT	MEGANE (JA0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (LA0/1_)

RENAULT	SCÉNIC I (JA0/1_)
RENAULT	TRAFIC (P6)
RENAULT	TRAFIC (PXX)
RENAULT	TRAFIC (T1, T3, T4)
RENAULT	TRAFIC (T5, T6, T7)
RENAULT	TRAFIC (TXW)
RENAULT	TRAFIC (TXX)

500239T

APPLICATION

WHEEL SIDE

Ø = 24 mm

Ø = 60 mm

H = 125 mm



RENAULT	GRAND SCÉNIC III (JZ0/1_)
RENAULT	MEGANE III (BZ0_)
RENAULT	MEGANE III (DZ0/1_)
RENAULT	MEGANE III (KZ0/1)
RENAULT	SCÉNIC III (JZ0/1_)

500635T

APPLICATION

BOX SIDE

Ø = 24 mm

Ø = 68 mm

H = 108 mm



RENAULT	GRAND SCÉNIC IV
RENAULT	GRAND SCÉNIC IV (R9_)
RENAULT	MEGANE IV
RENAULT	MEGANE IV (B9A/M/N_)
RENAULT	MEGANE IV (B9A/M_)
RENAULT	MEGANE IV (K9A/M_)
RENAULT	MEGANE IV Grandtour (K9A/M/N_)
RENAULT	SCÉNIC IV

RENAULT	SCÉNIC IV (J9_)
RENAULT	TALISMAN (KP_)
RENAULT	TALISMAN (L2M_)

500338T

APPLICATION

WHEEL SIDE

Ø = 24 mm

Ø = 79 mm

H = 135 mm



RENAULT	KANGOO (FC0/1_)
RENAULT	KANGOO (KC0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (LA0/1_)
RENAULT	SCÉNIC I (JA0/1_)

500508

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 115 \text{ mm}$



RENAULT

ESPACE I (J11_)

500240T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 115 \text{ mm}$



RENAULT
 RENAULT
 RENAULT
 RENAULT

MEGANE CC (EZ0/1_)
 MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1)

500036

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 90,5 \text{ mm}$
 $H = 88 \text{ mm}$



RENAULT

CLIO I (5/357_, B/C57_)

500102

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 93 \text{ mm}$
 $H = 127 \text{ mm}$



RENAULT
 RENAULT

MASTER I (T_)
 TRAFIC (T1, T3, T4)

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



RENAULT
 RENAULT

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

FLUENCE (L3_)
 GRAND SCÉNIC III
 (JZ0/1_)
 MEGANE CC (EZ0/1_)
 MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1)
 SCÉNIC III (JZ0/1_)

500444

APPLICATION

BOX SIDE

Ø = 25 mm

Ø = 65 mm

H = 100 mm



RENAULT	CLIO (KR0/1_)
RENAULT	CLIO III (BR0/1, CR0/1_)
RENAULT	CLIO III (SB_, SR_)
RENAULT	ESPACE IV (JK0/1_)
RENAULT	GRAND SCÉNIC II (JM0/1_)
RENAULT	GRAND SCÉNIC III (JZ0/1_)
RENAULT	LAGUNA II (BG0/1_)
RENAULT	LAGUNA II (KG0/1_)
RENAULT	MEGANE II (BM0/1_, CM0/1_)
RENAULT	MEGANE II (EM0/1_)
RENAULT	MEGANE II (KM_)
RENAULT	MEGANE II (KM0/1_)
RENAULT	MEGANE II (LM0/1_)
RENAULT	MODUS / GRAND MODUS (F/JPO_)
RENAULT	SCÉNIC II (JM0/1_)

500535T

APPLICATION

WHEEL SIDE

Ø = 25 mm

Ø = 74 mm

H = 114 mm



RENAULT	CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT	CLIO II (SB0/1/2_)
RENAULT	GRAND SCÉNIC II (JM0/1_)
RENAULT	KANGOO (FC0/1_)
RENAULT	KANGOO (KC0/1_)
RENAULT	LAGUNA II (BG0/1_)
RENAULT	LAGUNA II (KG0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE II (BM0/1_, CM0/1_)
RENAULT	MEGANE II (EM0/1_)
RENAULT	MEGANE II (KM_)
RENAULT	MEGANE II (KM0/1_)
RENAULT	MEGANE II (LM0/1_)
RENAULT	MEGANE II Box Body (KM_)
RENAULT	SCÉNIC II (JM0/1_)
RENAULT	THALIA I (LB0/1/2_)
RENAULT	THALIA II (LU1/2_)

500551

APPLICATION

BOX SIDE

Ø = 25 mm

Ø = 74 mm

H = 117 mm



RENAULT	ESPACE IV (JK0/1_)	RENAULT	MEGANE II (KM0/1_)
RENAULT	LAGUNA (DT0/1)	RENAULT	MEGANE II (LM0/1_)
RENAULT	LAGUNA II (BG0/1_)	RENAULT	MEGANE III (DZ0/1_)
RENAULT	LAGUNA II (KG0/1_)	RENAULT	SCÉNIC II (JM0/1_)
RENAULT	LAGUNA III (BT0/1)	RENAULT	TRAFIC II (EL)
RENAULT	LAGUNA III (KT0/1)	RENAULT	TRAFIC II (FL)
RENAULT	MEGANE II (BM0/1_, CM0/1_)	RENAULT	TRAFIC II (JL)
RENAULT	MEGANE II (EM0/1_)		

500232T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 138 \text{ mm}$



RENAULT

ESTAFETTE (213_)

500016

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 126,5 \text{ mm}$



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

20 (127_)
 30 (127_)
 MASTER I (T_)
 MASTER II (FD)
 TRAFIC (T1, T3, T4)

500016E

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 126,5 \text{ mm}$



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

20 (127_)
 30 (127_)
 MASTER I (T_)
 MASTER II (FD)
 TRAFIC (T1, T3, T4)

500407T

APPLICATION

BOX SIDE

Ø = 25,5 mm
Ø = 67,54 mm
H = 102 mm



DACIA	LOGAN (FS_)	RENAULT	MEGANE III (BZ0_)
DACIA	LOGAN (LS_)	RENAULT	MODUS / GRAND MO-
DACIA	LOGAN (US_)		DUS (F/JPO_)
DACIA	LOGAN MCV (KS_)	RENAULT	SANDERO/STEPWAY I
DACIA	SANDERO		(BS_)
DACIA	SOLENZA (B41_)	RENAULT	SANDERO/STEPWAY II
RENAULT	CLIO (KR0/1_)		(B8_)
RENAULT	CLIO II (BB0/1/2_,	RENAULT	SCÉNIC II (JM0/1_)
	CB0/1/2_)	RENAULT	THALIA I (LB0/1/2_)
RENAULT	CLIO II (SB0/1/2_)	RENAULT	THALIA II (LU1/2_)
RENAULT	CLIO III (BR0/1, CR0/1_)	RENAULT	TWINGO II (CNO_)
RENAULT	CLIO III (SB_, SR_)		
RENAULT	FLUENCE (L30_)		
RENAULT	GRAND SCÉNIC II		
	(JM0/1_)		
RENAULT	KANGOO (FW0/1_)		
RENAULT	KANGOO / GRAND		
	KANGOO (KW0/1_)		
RENAULT	KANGOO BE BOP		
	(KW0/1_)		
RENAULT	LAGUNA II (BG0/1_)		
RENAULT	LAGUNA II (KG0/1_)		
RENAULT	LOGAN EXPRESS (US_)		
RENAULT	LOGAN I (KS_)		
RENAULT	LOGAN I (LS_)		
RENAULT	LOGAN II (B8_)		
RENAULT	MEGANE II (BM0/1_,		
	CM0/1_)		
RENAULT	MEGANE II (EM0/1_)		
RENAULT	MEGANE II (KM_)		
RENAULT	MEGANE II (KM0/1_)		
RENAULT	MEGANE II (LM0/1_)		
RENAULT	MEGANE II Box Body		
	(KM_)		

500474T

APPLICATION

WHEEL SIDE

Ø = 25,5 mm
Ø = 80 mm
H = 104 mm



DACIA	LOGAN (FS_)
DACIA	LOGAN (LS_)
DACIA	LOGAN (US_)
DACIA	LOGAN MCV (KS_)
DACIA	SANDERO
RENAULT	CLIO II (BB0/1/2_,
	CB0/1/2_)
RENAULT	CLIO III (BR0/1, CR0/1_)
RENAULT	GRAND SCÉNIC II
	(JM0/1_)
RENAULT	KANGOO (FC0/1_)
RENAULT	KANGOO (KC0/1_)
RENAULT	MEGANE II (BM0/1_,
	CM0/1_)
RENAULT	MEGANE II (EM0/1_)
RENAULT	MODUS / GRAND MO-
	DUS (F/JPO_)
RENAULT	SCÉNIC II (JM0/1_)
RENAULT	TWINGO II (CNO_)

500062

APPLICATION

BOX SIDE

Ø = 25,7 mm
 Ø = 72,7 mm
 H = 103,2 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

19 I (B/C53_)
 19 I (L53_)
 19 II (853_, D53_)
 19 II (B/C53_)
 19 II (L53_)
 25 (B29_)
 CLIO I (5/357_, B/C57_)
 CLIO II (BB0/1/2_,

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

MEGANE I (LA0/1_)
 RAPID (F40_, G40_)
 SAFRANE I (B54_)
 TRAFIC (PXX)
 TRAFIC (TXW)
 TRAFIC (TXX)
 TWINGO I (C06_)
 TWINGO I (S06_)

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

ESPACE II (J/S63_)
 ESPACE III (JE0_)
 EXPRESS
 KANGOO (FC0/1_)
 KANGOO (KC0/1_)
 LAGUNA I (556_, B56_)
 LAGUNA I (K56_)
 MEGANE (JA0/1_)
 MEGANE I (BA0/1_)
 MEGANE I (DA0/1_)
 MEGANE I (EA0/1_)
 MEGANE I (KA0/1_)

500167T

APPLICATION

WHEEL SIDE

Ø = 26 mm
 Ø = 78 mm
 H = 134 mm



RENAULT

CLIO I (5/357_, B/C57_)

500020T

APPLICATION

WHEEL SIDE

Ø = 26 mm
 Ø = 78,5 mm
 H = 110 mm



RENAULT

25 (B29_)

500363

APPLICATION

BOX SIDE

Ø = 26 mm
 Ø = 82 mm
 H = 124 mm



RENAULT
 RENAULT

MASTER I (P_)
 MASTER I (T_)

500100T

APPLICATION

WHEEL SIDE
 $\varnothing = 26,1 \text{ mm}$
 $\varnothing = 84,5 \text{ mm}$
 $H = 131 \text{ mm}$



RENAULT	19 I (B/C53_)
RENAULT	19 I (L53_)
RENAULT	19 II (853_, D53_)
RENAULT	19 II (B/C53_)
RENAULT	21 (B48_)
RENAULT	21 (K48_)
RENAULT	21 (L48_)
RENAULT	CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT	ESPACE II (J/S63_)
RENAULT	ESPACE III (JE0_)
RENAULT	MEGANE (JA0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (KA0/1_)
RENAULT	MEGANE I (LA0/1_)
RENAULT	SCÉNIC I (JA0/1_)
RENAULT	SPORT SPIDER (EF0_)

500091

APPLICATION

WHEEL SIDE
 $\varnothing = 26,35 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 126,5 \text{ mm}$



RENAULT	TRAFIC (TXW)
---------	--------------

500091E

APPLICATION

WHEEL SIDE
 $\varnothing = 26,35 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 126,5 \text{ mm}$



RENAULT	TRAFIC (TXW)
---------	--------------

500099T

APPLICATION

WHEEL SIDE

Ø = 26,4 mm

Ø = 83 mm

H = 132,5 mm



RENAULT	19 I (B/C53_)
RENAULT	19 I (D53_)
RENAULT	19 I (L53_)
RENAULT	19 II (853_, D53_)
RENAULT	19 II (B/C53_)
RENAULT	19 II (L53_)
RENAULT	19 II (S53_)
RENAULT	21 (B48_)
RENAULT	21 (K48_)
RENAULT	21 (L48_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT	CLIO II (SB0/1/2_)
RENAULT	EXPRESS
RENAULT	KANGOO (FC0/1_)
RENAULT	KANGOO (KC0/1_)
RENAULT	LAGUNA I (556_, B56_)
RENAULT	LAGUNA I (K56_)
RENAULT	MEGANE I (KA0/1_)
RENAULT	RAPID (F40_, G40_)

RENAULT	SAFRANE I (B54_)
RENAULT	THALIA I (LB0/1/2_)
RENAULT	TWINGO I (C06_)
RENAULT	TWINGO I (S06_)

500525T

APPLICATION

BOX SIDE

Ø = 26,5 mm

Ø = 69 mm

H = 95 mm



RENAULT	CAPTUR (J5_)
RENAULT	CLIO III (BR0/1, CR0/1_)
RENAULT	CLIO IV
RENAULT	CLIO IV (BH_)
RENAULT	CLIO IV (KH_)
RENAULT	FLUENCE (L30_)
RENAULT	GRAND SCÉNIC III (JZ0/1_)
RENAULT	KANGOO (FW0/1_)
RENAULT	KANGOO / GRAND KANGOO (KW0/1_)
RENAULT	KANGOO BE BOP (KW0/1_)
RENAULT	LAGUNA (DT0/1)
RENAULT	LAGUNA III (BT0/1)
RENAULT	LAGUNA III (KT0/1)
RENAULT	MEGANE CC (EZ0/1_)
RENAULT	MEGANE III (BZ0_)
RENAULT	MEGANE III (DZ0/1_)
RENAULT	MEGANE III (KZ0/1)
RENAULT	MEGANE IV

RENAULT	MEGANE IV (B9A/M_)
RENAULT	MEGANE IV (K9A/M_)
RENAULT	SCÉNIC III (JZ0/1_)
RENAULT	TALISMAN (KP_)
RENAULT	TALISMAN (L2M_)
RENAULT	ZOE (BFM_)

500514T

APPLICATION

WHEEL SIDE

Ø = 26,5 mm

Ø = 87 mm

H = 110 mm



DACIA	DUSTER
RENAULT	GRAND SCÉNIC III (JZ0/1_)
RENAULT	LAGUNA III (BT0/1)
RENAULT	LAGUNA III (KT0/1)
RENAULT	MEGANE III (BZ0_)
RENAULT	MEGANE III (DZ0/1_)
RENAULT	MEGANE III (KZ0/1)

500476T

APPLICATION

WHEEL SIDE
 Ø = 26,6 mm
 Ø = 78,2 mm
 H = 118 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

CAPTUR (J5_)
 CAPTUR (J5_) | KAPTUR
 CLIO III (BR0/1, CR0/1_)
 CLIO IV
 CLIO IV (BH_)
 CLIO IV (KH_)
 DUSTER (HS_)
 FLUENCE (L30_)
 GRAND SCÉNIC III
 (JZ0/1_)
 KANGOO (FC0/1_)
 KANGOO (FW0/1_)
 KANGOO (KC0/1_)
 RENAULT
 KANGOO / GRAND
 KANGOO (KW0/1_)
 KANGOO BE BOP
 (KW0/1_)
 RENAULT
 LAGUNA (DT0/1)
 LAGUNA III (BT0/1)
 LAGUNA III (KT0/1)
 RENAULT
 MEGANE CC (EZ0/1_)

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1)
 SCÉNIC III (JZ0/1_)
 ZOE (BFM_)

500021E

APPLICATION

WHEEL SIDE
 Ø = 26,6 mm
 Ø = 82 mm
 H = 113 mm



RENAULT
 RENAULT
 RENAULT

12
 12 (117_)
 RAPID (F40_, G40_)

500238T

APPLICATION

WHEEL SIDE
 Ø = 26,9 mm
 Ø = 88 mm
 H = 141 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

19 I (B/C53_)
 19 I (D53_)
 19 I (L53_)
 19 I (S53_)
 19 II (B/C53_)
 19 II (L53_)
 CLIO II (BB0/1/2_,
 CB0/1/2_)
 ESPACE II (J/S63_)
 ESPACE III (JE0_)
 LAGUNA I (556_, B56_)
 LAGUNA I (K56_)
 LAGUNA II (BG0/1_)
 LAGUNA II (KG0/1_)
 MEGANE (JA0/1_)
 MEGANE I (BA0/1_)
 MEGANE I (DA0/1_)
 MEGANE I (EA0/1_)
 MEGANE I (KA0/1_)
 RENAULT
 MEGANE I (LA0/1_)

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

MEGANE II (BM0/1_,
 CM0/1_)
 SAFRANE I (B54_)
 SAFRANE II (B54_)
 SCÉNIC I (JA0/1_)
 SPORT SPIDER (EF0_)

500372

APPLICATION

BOX SIDE

Ø = 27 mm

Ø = 80 mm

H = 113 mm



RENAULT	11 (B/C37_)
RENAULT	18 (134_)
RENAULT	18 (135_)
RENAULT	19 I (B/C53_)
RENAULT	19 I (D53_)
RENAULT	19 I (L53_)
RENAULT	19 II (853_, D53_)
RENAULT	19 II (B/C53_)
RENAULT	19 II (L53_)
RENAULT	19 II (S53_)
RENAULT	21 (B48_)
RENAULT	21 (K48_)
RENAULT	21 (L48_)
RENAULT	9 (L42_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	FUEGO (136_)
RENAULT	MASTER I (T_)
RENAULT	RAPID (F40_, G40_)
RENAULT	SUPER 5 (B/C40_)
RENAULT	SUPER 5 (S40_)
RENAULT	TWINGO I (C06_)

500552T

APPLICATION

WHEEL SIDE

Ø = 27 mm

Ø = 80 mm

H = 120 mm



RENAULT	GRAND SCÉNIC II (JM0/1_)	RENAULT	SCÉNIC III (JZ0/1_)
RENAULT	MEGANE II (BM0/1_, CM0/1_)		
RENAULT	MEGANE II (EM0/1_)		
RENAULT	MEGANE II (KM_)		
RENAULT	MEGANE II (KM0/1_)		
RENAULT	MEGANE II (LM0/1_)		
RENAULT	SCÉNIC II (JM0/1_)		

500296T

APPLICATION

WHEEL SIDE

Ø = 27 mm

Ø = 89 mm

H = 119 mm



RENAULT	VEL SATIS (BJ0_)
---------	------------------

500227T

APPLICATION

WHEEL SIDE

Ø = 27 mm

Ø = 89 mm

H = 125 mm



RENAULT	TRAFIC II (FL)
RENAULT	TRAFIC II (JL)
RENAULT	VEL SATIS (BJ0_)

500237T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 90 \text{ mm}$
 $H = 132 \text{ mm}$



RENAULT
 RENAULT
 RENAULT

TRAFIC (PXX)
 TRAFIC (TXW)
 TRAFIC (TXX)

500011T

APPLICATION

WHEEL SIDE
 $\emptyset = 27,2 \text{ mm}$
 $\emptyset = 98,1 \text{ mm}$
 $H = 144,5 \text{ mm}$



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

AVANTIME (DE0_)
 ESPACE III (JE0_)
 ESPACE IV (JK0/1_)
 LAGUNA I (556_, B56_)
 MASTER II (ED/HD/UD)
 MASTER II (FD)
 MASTER II (JD)
 SAFRANE II (B54_)

500030T

APPLICATION

WHEEL SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 87,2 \text{ mm}$
 $H = 106,3 \text{ mm}$



DACIA
 RENAULT
 RENAULT

LOGAN (LS_)
 CLIO III (BR0/1, CR0/1_)
 MODUS / GRAND MO-
 DUS (F/JPO_)

500014

APPLICATION

WHEEL SIDE
 $\emptyset = 27,7 \text{ mm}$
 $\emptyset = 85,5 \text{ mm}$
 $H = 131 \text{ mm}$



RENAULT
 RENAULT
 RENAULT

11 (B/C37_)
 9 (L42_)
 SUPER 5 (B/C40_)

500014E

APPLICATION

WHEEL SIDE
 $\emptyset = 27,7 \text{ mm}$
 $\emptyset = 85,5 \text{ mm}$
 $H = 131 \text{ mm}$



RENAULT
 RENAULT
 RENAULT

11 (B/C37_)
 9 (L42_)
 SUPER 5 (B/C40_)

500060

APPLICATION

BOX SIDE
 Ø = 28 mm
 Ø = 62 mm
 H = 114 mm



RENAULT	11 (B/C37_)
RENAULT	11 (S37_)
RENAULT	18 (134_)
RENAULT	18 (135_)
RENAULT	19 I (B/C53_)
RENAULT	19 I (D53_)
RENAULT	19 I (L53_)
RENAULT	19 II (853_, D53_)
RENAULT	19 II (B/C53_)
RENAULT	19 II (L53_)
RENAULT	19 II (S53_)
RENAULT	21 (B48_)
RENAULT	21 (K48_)
RENAULT	21 (L48_)
RENAULT	9 (L42_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	FUEGO (136_)
RENAULT	RAPID (F40_, G40_)
RENAULT	SUPER 5 (B/C40_)
RENAULT	SUPER 5 (S40_)
RENAULT	TWINGO I (C06_)

500310

APPLICATION

BOX SIDE
 Ø = 28 mm
 Ø = 72 mm
 H = 120 mm



RENAULT	11 (B/C37_)	RENAULT	SUPER 5 (B/C40_)
RENAULT	16 (115_)		
RENAULT	18 (134_)		
RENAULT	18 (135_)		
RENAULT	20 (127_)		
RENAULT	25 (B29_)		
RENAULT	5 (122_)		
RENAULT	9 (L42_)		
RENAULT	FUEGO (136_)		

500269

APPLICATION

BOX SIDE
 Ø = 28 mm
 Ø = 74 mm
 H = 88 mm



RENAULT	AVANTIME (DE0_)
RENAULT	ESPACE III (JEO_)
RENAULT	ESPACE IV (JK0/1_)
RENAULT	VEL SATIS (BJ0_)

500323T

APPLICATION

WHEEL SIDE
 Ø = 28 mm
 Ø = 80 mm
 H = 135 mm



RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	KANGOO (FC0/1_)
RENAULT	KANGOO (KC0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (KA0/1_)
RENAULT	MEGANE I (LA0/1_)

500098T

APPLICATION

WHEEL SIDE
 Ø = 28 mm
 Ø = 92 mm
 H = 142 mm



RENAULT
 RENAULT
 RENAULT

25 (B29_)
 TRAFIC (TXW)
 TRAFIC (TXX)

500018

APPLICATION

WHEEL SIDE
 Ø = 28,5 mm
 Ø = 73,5 mm
 H = 116 mm



RENAULT 11 (B/C37_)
 RENAULT 16 (115_)
 RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 19 I (B/C53_)
 RENAULT 19 I (D53_)
 RENAULT 19 I (L53_)
 RENAULT 19 II (853_, D53_)
 RENAULT 19 II (B/C53_)
 RENAULT 19 II (L53_)
 RENAULT 19 II (S53_)
 RENAULT 20 (127_)
 RENAULT 21 (B48_)
 RENAULT 21 (K48_)
 RENAULT 21 (L48_)
 RENAULT 21 (S48_)
 RENAULT 25 (B29_)
 RENAULT 9 (L42_)
 RENAULT FUEGO (136_)
 RENAULT MEGANE (JA0/1_)
 RENAULT MEGANE I (BA0/1_)

RENAULT MEGANE I (DA0/1_)
 RENAULT MEGANE I (EA0/1_)
 RENAULT MEGANE I (LA0/1_)
 RENAULT RAPID (F40_, G40_)
 RENAULT SCÉNIC I (JA0/1_)
 RENAULT SUPER 5 (B/C40_)

500018E

APPLICATION

WHEEL SIDE
 Ø = 28,5 mm
 Ø = 73,5 mm
 H = 116 mm



RENAULT 11 (B/C37_)
 RENAULT 16 (115_)
 RENAULT 18 (134_)
 RENAULT 18 (135_)
 RENAULT 21 (B48_)
 RENAULT 21 (K48_)
 RENAULT 21 (L48_)
 RENAULT 21 (S48_)
 RENAULT 9 (L42_)

RENAULT FUEGO (136_)
 RENAULT RAPID (F40_, G40_)
 RENAULT SUPER 5 (B/C40_)

500579T

APPLICATION

WHEEL SIDE
 Ø = 28,5 mm
 Ø = 92 mm
 H = 110 mm



RENAULT LAGUNA II (BG0/1_)
 RENAULT LAGUNA II (KG0/1_)
 RENAULT MEGANE II (BM0/1_,
 CM0/1_)
 RENAULT MEGANE II (EM0/1_)
 RENAULT MEGANE II (KM0/1_)
 RENAULT MEGANE II (LM0/1_)

APPLICATION

LAGUNA III (BT0/1)
MEGANE III (DZ0/1_)
SCÉNIC III (JZ0/1)

APPLICATION

RENAULT	MEGANE II (KM0/1_)
RENAULT	RAPID (F40_, G40_)
RENAULT	SANDERO/STEPWAY I (BS_)
RENAULT	SCÉNIC I (JA0/1_)
RENAULT	SUPER 5 (B/C40_)
RENAULT	TWINGO I (C06)

APPLICATION

DACIA	LOGAN (LS_)
DACIA	LOGAN MCV (KS_)
DACIA	SANDERO
RENAULT	LAGUNA II (BG0/1_)
RENAULT	LAGUNA II (KG0/1_)
RENAULT	LOGAN I (KS_)
RENAULT	LOGAN I (LS_)
RENAULT	TWINGO I (C06)

APPLICATION

RENAULT	LOGAN I (KS_)
RENAULT	LOGAN I (LS_)

500412T

APPLICATION

WHEEL SIDE
 $\emptyset = 30 \text{ mm}$
 $\emptyset = 99 \text{ mm}$
 $H = 125 \text{ mm}$



RENAULT

KOLEOS (HY_)

500152

APPLICATION

BOX SIDE
 $\emptyset = 30,5 \text{ mm}$
 $\emptyset = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$



RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

CLIO II (BB0/1/2_)

CB0/1/2_)

ESPACE III (JE0_)

ESPACE IV (JK0/1_)

KANGOO (FC0/1_)

KANGOO (KC0/1_)

LAGUNA I (556_, B56_)

LAGUNA I (K56_)

LAGUNA II (BG0/1_)

LAGUNA II (KG0/1_)

MASTER I (P_)

MASTER I (T_)

MASTER II (ED/HD/UD)

MASTER II (FD)

MASTER II (JD)

MEGANE (JA0/1_)

MEGANE I (BA0/1_)

MEGANE I (DA0/1_)

MEGANE I (EA0/1_)

MEGANE I (KA0/1_)

MEGANE I (LA0/1_)

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

SAFRANE I (B54_)

SAFRANE II (B54_)

SCÉNIC I (JA0/1_)

THALIA I (LB0/1/2_)

THALIA II (LU1/2_)

TRAFIC II (EL)

TRAFIC II (FL)

TRAFIC II (JL)

500078

APPLICATION

BOX SIDE
 $\emptyset = 30,5 \text{ mm}$
 $\emptyset = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$



RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

11 (B/C37_)

19 I (B/C53_)

19 I (L53_)

19 II (B/C53_)

19 II (L53_)

19 II (S53_)

21 (B48_)

21 (K48_)

21 (L48_)

5 (122_)

9 (L42_)

CLIO I (5/357_, B/C57_)

CLIO II (BB0/1/2_)

CB0/1/2_)

CLIO II (SB0/1/2_)

KANGOO (FC0/1_)

KANGOO (KC0/1_)

LAGUNA I (556_, B56_)

LAGUNA I (K56_)

MASTER I (P_)

MASTER I (T_)

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

MASTER II (ED/HD/UD)

MASTER II (FD)

MASTER II (JD)

MEGANE (JA0/1_)

MEGANE I (BA0/1_)

MEGANE I (DA0/1_)

MEGANE I (EA0/1_)

MEGANE I (KA0/1_)

MEGANE I (LA0/1_)

RAPID (F40_, G40_)

SAFRANE I (B54_)

SCÉNIC I (JA0/1_)

SUPER 5 (B/C40_)

TWINGO I (C06_)

500077

APPLICATION

BOX SIDE

Ø = 30,5 mm
 Ø = 85,44 mm
 H = 88 mm



RENAULT	11 (B/C37_)
RENAULT	19 I (B/C53_)
RENAULT	19 I (D53_)
RENAULT	19 I (L53_)
RENAULT	19 II (853_, D53_)
RENAULT	19 II (B/C53_)
RENAULT	19 II (L53_)
RENAULT	19 II (S53_)
RENAULT	21 (B48_)
RENAULT	21 (K48_)
RENAULT	21 (L48_)
RENAULT	9 (L42_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT	EXPRESS
RENAULT	KANGOO (FC0/1_)
RENAULT	KANGOO (KC0/1_)
RENAULT	LAGUNA I (556_, B56_)
RENAULT	LAGUNA I (K56_)
RENAULT	MEGANE (JA0/1_)

RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (KA0/1_)
RENAULT	MEGANE I (LA0/1_)
RENAULT	RAPID (F40_, G40_)
RENAULT	SCÉNIC I (JA0/1_)
RENAULT	SPORT SPIDER (EF0_)
RENAULT	SUPER 5 (B/C40_)
RENAULT	SUPER 5 (S40_)
RENAULT	THALIA I (LB0/1/2_)
RENAULT	THALIA II (LU1/2_)
RENAULT	TWINGO I (C06_)
RENAULT	TWINGO I (S06_)
RENAULT	TWINGO II (CN0_)

500013T

APPLICATION

WHEEL SIDE

Ø = 32,3 mm
 Ø = 70,7 mm
 H = 136 mm



RENAULT	19 I (B/C53_)
RENAULT	19 I (L53_)
RENAULT	19 II (853_, D53_)
RENAULT	19 II (B/C53_)
RENAULT	19 II (L53_)
RENAULT	CLIO I (5/357_, B/C57_)
RENAULT	RAPID (F40_, G40_)
RENAULT	TWINGO I (C06_)
RENAULT	TWINGO I (S06_)

500303T

APPLICATION

WHEEL SIDE

Ø = 33,5 mm
 Ø = 76 mm
 H = 110 mm



RENAULT	GRAND SCÉNIC II (JM0/1_)
RENAULT	SCÉNIC II (JM0/1_)

500302T

APPLICATION

WHEEL SIDE

Ø = 34 mm
 Ø = 77,5 mm
 H = 135 mm



RENAULT	CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT	CLIO II (SB0/1/2_)
RENAULT	MEGANE (JA0/1_)
RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (KA0/1_)
RENAULT	MEGANE I (LA0/1_)

RENAULT	SCÉNIC I (JA0/1_)
RENAULT	THALIA I (LB0/1/2_)

500105

APPLICATION

WHEEL SIDE
 $\emptyset = 37 \text{ mm}$
 $\emptyset = 83 \text{ mm}$
 $H = 112 \text{ mm}$



RENAULT	16 (115_)
RENAULT	20 (127_)
RENAULT	5 (122_)

500590

APPLICATION

BOX SIDE
 $\emptyset = 38 \text{ mm}$
 $\emptyset = 70 \text{ mm}$
 $H = 94 \text{ mm}$



RENAULT	MEGANE II (BM0/1_, CM0/1_)
---------	-------------------------------

500313

APPLICATION

BOX SIDE
 $\emptyset = 55 \text{ mm}$
 $\emptyset = 55 \text{ mm}$
 $H = 125 \text{ mm}$



RENAULT	16 (115_)
RENAULT	18 (134_)
RENAULT	18 (135_)
RENAULT	20 (127_)
RENAULT	5 (122_)

500042

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 80 \text{ mm}$



DAF

LF 45

500042E

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 80 \text{ mm}$



DAF

LF 45

500002

APPLICATION

WHEEL SIDE
 $\varnothing = 22,4 \text{ mm}$
 $\varnothing = 52,2 \text{ mm}$
 $H = 77 \text{ mm}$

DAF
DAF46
66

500115

APPLICATION

WHEEL SIDE
 $\varnothing = 32 \text{ mm}$
 $\varnothing = 110,7 \text{ mm}$
 $H = 91 \text{ mm}$



DAF

85 CF

500006

APPLICATION

BOX SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 95 \text{ mm}$



DAF

85 CF

APPLICATION

WHEEL SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 110 \text{ mm}$
 $H = 160 \text{ mm}$



DAF

85 CF



500172

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 55,5 \text{ mm}$
 $H = 90 \text{ mm}$



DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU

APPLAUSE I (A101,
 A111)
 CHARADE III (G100,
 G101, G102)
 CHARADE III (G102)
 COPEN (L880_, L881_)
 CUORE V (L7_)
 MOVE (L6, L9)
 SIRION (M1)

500206

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 83 \text{ mm}$



DAIHATSU

CHARADE III (G100,
 G101, G102)

500174

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 87 \text{ mm}$



DAIHATSU
 DAIHATSU
 DAIHATSU

SIRION (M1)
 TERIOS (J1_)
 YRV (M2)

500428

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59,25 \text{ mm}$
 $H = 90 \text{ mm}$



DAIHATSU

CHARADE

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



DAIHATSU
 DAIHATSU

SIRION (M1)
 YRV (M2)

500334

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 62 mm
 H = 90 mm



DAIHATSU
 DAIHATSU

CHARADE I (G10)
 CUORE I (L55, L60)

500199

APPLICATION

BOX SIDE
 Ø = 19 mm
 Ø = 65 mm
 H = 87 mm



DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU

CHARADE II (G11, G30)
 CUORE II (L80, L81)
 CUORE III (L200, L201)
 CUORE IV (L500)
 CUORE IV (L500, L501)
 CUORE V (L7_)
 HIJET
 HIJET (_U20)
 HIJET (S8_)

DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 MOVE (L6, L9)
 SIRION (M1)
 TERIOS (J1_)
 YRV (M2)

500266

APPLICATION

BOX SIDE
 Ø = 19 mm
 Ø = 65 mm
 H = 87 mm



DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU

1000
 1300
 CHARADE III (G100,
 G101, G102)
 CUORE I (L55, L60)
 CUORE II (L80, L81)
 CUORE III (L200, L201)
 CUORE IV (L500)
 CUORE IV (L500, L501)

DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 CUORE V (L7_)
 MOVE (L6, L9)
 SIRION (M1)
 TERIOS (J1_)
 YRV (M2)

500320

APPLICATION

WHEEL SIDE
 Ø = 19 mm
 Ø = 66,5 mm
 H = 78 mm



DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU

55 WIDE
 850 (E65)
 CUORE I (L55, L60)
 HIJET
 HIJET (_U20)
 HIJET (_U60)
 HIJET (S8_)
 HIJET (S85)

500041

APPLICATION

WHEEL SIDE
 Ø = 19,6 mm
 Ø = 67,2 mm
 H = 83 mm



DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU

APPLAUSE I (A101,
 A111)
 CHARADE II (G11, G30)
 CHARADE III (G100,
 G101, G102)
 CUORE III (L200, L201)
 CUORE IV (L500, L501)
 CUORE V (L7_)
 MOVE (L6, L9)

DAIHATSU
 DAIHATSU
 SIRION (M1)
 YRV (M2)

500198

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



DAIHATSU
 DAIHATSU
 DAIHATSU

SIRION (M1)
 TERIOS (J1_)
 YRV (M2)

500273

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 93 \text{ mm}$



DAIHATSU
 DAIHATSU

CHARADE IV (G200,
 G202)
 GRAN MOVE (G3)

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



DAIHATSU
 DAIHATSU

APPLAUSE I (A101,
 A111)
 CHARADE III (G100,
 G101, G102)

500169

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 92 \text{ mm}$



DAIHATSU
 DAIHATSU
 DAIHATSU
 DAIHATSU

APPLAUSE I (A101,
 A111)
 APPLAUSE II (A101)
 CHARADE IV (G200,
 G202)
 CHARADE IV (G203)
 GRAN MOVE (G3)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



DAIHATSU
 DAIHATSU

APPLAUSE I (A101,
 A111)
 CHARADE III (G100,
 G101, G102)

500409T

APPLICATION

WHEEL SIDE
 $\emptyset = 22 \text{ mm}$
 $\emptyset = 71 \text{ mm}$
 $H = 114,5 \text{ mm}$



DAIHATSU

CHARADE

500597

APPLICATION

BOX SIDE
 $\emptyset = 23 \text{ mm}$
 $\emptyset = 65 \text{ mm}$
 $H = 90 \text{ mm}$



DAIHATSU

CHARADE

500479

APPLICATION

WHEEL SIDE
 $\emptyset = 23 \text{ mm}$
 $\emptyset = 72,5 \text{ mm}$
 $H = 107,5 \text{ mm}$



DAIHATSU

SIRION (M1)

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77,4 mm
H = 116,5 mm



DODGE

NEON II

APPLICATION

BOX SIDE
Ø = 17 mm
Ø = 62,15 mm
H = 110 mm



FORD
FORD
FORD
FORD
FORD
FORD

SCORPIO I (GAE, GGE)
SCORPIO I (GGE)
SCORPIO II (GFR, GGR)
SCORPIO II (GGR, GNR)
SIERRA (GBC)
SIERRA (GBC, GBG)

500375

APPLICATION

BOX SIDE
Ø = 18 mm
Ø = 59 mm
H = 84 mm



FORD
FORD

FIESTA V (JD_, JH_)
FUSION (JU_)

500170

APPLICATION

BOX SIDE
Ø = 19 mm
Ø = 60 mm
H = 84 mm



FORD
FORD

FIESTA V (JD_, JH_)
FUSION (JU_)

500549

APPLICATION

BOX SIDE
Ø = 19 mm
Ø = 67,4 mm
H = 87 mm



FORD
FORD
FORD
FORD
FORD

C-MAX (DM2)
FOCUS C-MAX
FOCUS II
FOCUS II (DA_)
FUSION (JU_)

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 69,5 \text{ mm}$
 $H = 96,4 \text{ mm}$



FORD	ESCORT (AFH, ATH)
FORD	ESCORT '81 (AVA)
FORD	ESCORT '86 (AVF)
FORD	ESCORT '91 (AVL)
FORD	ESCORT '95 (AVL)
FORD	ESCORT I (ADH, AF)
FORD	ESCORT I (AFH, ATH)
FORD	ESCORT II
FORD	ESCORT II (ATH)
FORD	ESCORT III (AWA)
FORD	ESCORT III (GAA)
FORD	ESCORT IV (ABFT, AWF, GAF)
FORD	ESCORT IV (AVF, AWF)
FORD	ESCORT V (AVL, GAL)
FORD	ESCORT V (GAL)
FORD	ESCORT VI (GAL)
FORD	ESCORT VII (AAL, ABL, GAL)
FORD	ESCORT VII (AFL, GAL)
FORD	ESCORT VII (ANL, GAL)

FORD	FIESTA (FVD)
FORD	FIESTA (WFTV)
FORD	FIESTA I (GFBT)
FORD	FIESTA II (FBD)
FORD	FIESTA III (GFJ)
FORD	ORION I (AFD)
FORD	ORION II (AFF)
FORD	ORION III (GAL)

500411

APPLICATION

BOX SIDE
 $\varnothing = 19,95 \text{ mm}$
 $\varnothing = 71,2 \text{ mm}$
 $H = 87,9 \text{ mm}$



FORD TOURNEO CONNECT
FORD TRANSIT CONNECT
(P65 , P70 , P80)

500064

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 79,5 \text{ mm}$
 $H = 112 \text{ mm}$



FORD	FIESTA (J3_, J5_)
FORD	FIESTA (JV_)
FORD	FIESTA III (GFJ)
FORD	FIESTA IV (JA_, JB_)

500349

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 93 \text{ mm}$



FORD	C-MAX (DM2)
FORD	FOCUS II (DA)

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



FORD	ESCORT '81 (AVA)
FORD	ESCORT '86 (AVF)
FORD	ESCORT '91 (AVL)
FORD	ESCORT III (AWA)
FORD	ESCORT III (GAA)
FORD	ESCORT IV (ABFT, AWF, GAF)
FORD	ESCORT IV (AVF, AWF)
FORD	ESCORT V (AVL, GAL)
FORD	ESCORT V (GAL)
FORD	ESCORT VI (GAL)
FORD	ESCORT VII (AAL, ABL, GAL)
FORD	ESCORT VII (AFL, GAL)
FORD	ESCORT VII (ANL, GAL)
FORD	FIESTA (FVD)
FORD	FIESTA (J3_, J5_)
FORD	FIESTA (WFVT)
FORD	FIESTA I (GFBT)
FORD	FIESTA II (FBD)
FORD	FIESTA III (GFJ)

FORD	FIESTA IV (JA_, JB_)
FORD	KA (RB_)
FORD	ORION II (AFF)
FORD	ORION III (GAL)

500109E

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



FORD	ESCORT III (AWA)
FORD	ESCORT III (GAA)
FORD	FIESTA I (GFBT)
FORD	FIESTA II (FBD)
FORD	FIESTA III (GFJ)

500430

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 61,3 \text{ mm}$
 $H = 97 \text{ mm}$



FORD	FIESTA V
FORD	FIESTA V (JD_, JH_)
FORD	FIESTA VI
FORD	FUSION (JU_)

500319

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 101 \text{ mm}$



FORD	FIESTA (J3_, J5_)
FORD	FIESTA (JV_)
FORD	FIESTA IV (JA_, JB_)
FORD	KA (RB_)
FORD	KA Van (RB)
FORD	PUMA (EC_)
FORD	STREET KA (RL2)

APPLICATION

WHEEL SIDE
Ø = 21 mm
Ø = 67 mm
H = 84 mm



FORD
FORD

FIESTA V (JD_, JH_)
FUSION (JU_)

500292

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 70 mm
H = 88 mm



FORD
FORD

TOURNEO CONNECT
TRANSIT CONNECT
(P65_, P70_, P80_)

500270

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 80 mm
H = 84 mm



FORD

GALAXY (WGR)

500365

APPLICATION

BOX SIDE
Ø = 21,5 mm
Ø = 70 mm
H = 85 mm



FORD

GALAXY (WGR)

500128

APPLICATION

WHEEL SIDE
Ø = 21,75 mm
Ø = 49 mm
H = 80 mm



FORD
FORD
FORD
FORD
FORD
FORD

P 100 II
SIERRA (BNC)
SIERRA (BNG)
SIERRA (GB4, GBG)
SIERRA (GBC)
SIERRA (GBC, GBG)

APPLICATION

BOX SIDE
Ø = 21,75 mm
Ø = 74,04 mm
H = 89,25 mm



FORD
FORD
FORD
FORD

C-MAX (DM2)
FOCUS C-MAX
FOCUS II
FOCUS II (DA_)

500050

APPLICATION

WHEEL SIDE
Ø = 21,8 mm
Ø = 82,4 mm
H = 81,6 mm



FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT CLASSIC (AAL, ABL)
ESCORT V (ALL)
ESCORT V (AVL, GAL)
ESCORT V (GAL)
ESCORT VI (ALL)
ESCORT VI (GAL)
FIESTA III (GFJ)
FIESTA IV (JA_, JB_)

FORD

ORION III (GAL)

500050E

APPLICATION

WHEEL SIDE
Ø = 21,8 mm
Ø = 82,4 mm
H = 81,6 mm



FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT CLASSIC (AAL, ABL)
ESCORT V (ALL)
ESCORT V (AVL, GAL)
ESCORT V (GAL)
ESCORT VI (ALL)
ESCORT VI (GAL)
FIESTA III (GFJ)
FIESTA IV (JA_, JB_)

FORD

ORION III (GAL)

500066

APPLICATION

BOX SIDE
Ø = 22 mm
Ø = 66,6 mm
H = 99 mm



FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT IV (ABFT, AWF, GAF)
ESCORT IV (AVF, AWF)
ESCORT V (ALL)
ESCORT V (AVL, GAL)
ESCORT V (GAL)
FIESTA III (GFJ)
ORION II (AFF)
ORION III (GAL)

500359

APPLICATION

BOX SIDE
Ø = 22 mm
Ø = 69 mm
H = 86 mm



FORD
FORD

FOCUS (DAW, DBW)
FOCUS (DNW)

APPLICATION

WHEEL SIDE

Ø = 22 mm

Ø = 77 mm

H = 103 mm



FORD	ESCORT '81 (AVA)
FORD	ESCORT '86 (AVF)
FORD	ESCORT '91 (AVL)
FORD	ESCORT '95 (AVL)
FORD	ESCORT CLASSIC (AAL, ABL)
FORD	ESCORT CLASSIC (ANL)
FORD	ESCORT III (ALD)
FORD	ESCORT III (AWA)
FORD	ESCORT III (GAA)
FORD	ESCORT IV (ABFT, AWF, GAF)
FORD	ESCORT IV (ALF)
FORD	ESCORT IV (AVF, AWF)
FORD	ESCORT V (ALL)
FORD	ESCORT V (AVL, GAL)
FORD	ESCORT V (GAL)
FORD	ESCORT VI (ALL)
FORD	ESCORT VI (GAL)
FORD	ESCORT VII (AAL, ABL, GAL)
FORD	ESCORT VII (AFL, GAL)
FORD	ESCORT VII (ALL)
FORD	ESCORT VII (ANL, GAL)
FORD	FIESTA (F3L, F5L)
FORD	FIESTA (J3_, J5_)
FORD	FIESTA (JV_)
FORD	FIESTA I (GFBT)
FORD	FIESTA II (FBD)
FORD	FIESTA III (GFJ)
FORD	FIESTA IV (JA_, JB_)
FORD	ORION I (AFD)
FORD	ORION II (AFF)
FORD	ORION III (GAL)
FORD	P 100 I
FORD	PUMA (EC_)
FORD	PUMA (EC_)
FORD	SCORPIO I (GAE, GGE)
FORD	SCORPIO I (GGE)
FORD	SCORPIO II (GGR, GNR)
FORD	SIERRA (BNG)
FORD	SIERRA (GBC, GBG)

500025E

APPLICATION

WHEEL SIDE

Ø = 22 mm

Ø = 77 mm

H = 103 mm



FORD	ESCORT '81 (AVA)	FORD	SCORPIO I (GAE, GGE)
FORD	ESCORT '86 (AVF)	FORD	SCORPIO I (GGE)
FORD	ESCORT '91 (AVL)	FORD	SCORPIO II (GGR, GNR)
FORD	ESCORT '95 (AVL)	FORD	SIERRA (BNG)
FORD	ESCORT CLASSIC (AAL, ABL)	FORD	SIERRA (GBC, GBG)
FORD	ESCORT III (ALD)		
FORD	ESCORT III (AWA)		
FORD	ESCORT III (GAA)		
FORD	ESCORT IV (ABFT, AWF, GAF)		
FORD	ESCORT IV (ALF)		
FORD	ESCORT IV (AVF, AWF)		
FORD	ESCORT V (ALL)		
FORD	ESCORT V (AVL, GAL)		
FORD	ESCORT V (GAL)		
FORD	ESCORT VI (ALL)		
FORD	ESCORT VI (GAL)		
FORD	ESCORT VII (AAL, ABL, GAL)		
FORD	ESCORT VII (AFL, GAL)		
FORD	ESCORT VII (ALL)		
FORD	ESCORT VII (ANL, GAL)		
FORD	FIESTA (F3L, F5L)		
FORD	FIESTA (J3_, J5_)		
FORD	FIESTA I (GFBT)		
FORD	FIESTA II (FBD)		
FORD	FIESTA III (GFJ)		
FORD	FIESTA IV (JA_, JB_)		
FORD	ORION I (AFD)		
FORD	ORION II (AFF)		
FORD	ORION III (GAL)		
FORD	P 100 I		
FORD	PUMA (EC_)		

500285T

APPLICATION

WHEEL SIDE

Ø = 22 mm

Ø = 77,4 mm

H = 116,5 mm



FORD	FOCUS II (DA_)
------	----------------

500112

APPLICATION

WHEEL SIDE

Ø = 23 mm

Ø = 94 mm

H = 93,7 mm



FORD	MAVERICK (UDS, UNS)
------	---------------------

APPLICATION

BOX SIDE
Ø = 23,2 mm
Ø = 56,2 mm
H = 99 mm



FORD

GALAXY (WGR)

500079

APPLICATION

WHEEL SIDE
Ø = 23,5 mm
Ø = 60 mm
H = 82,4 mm



FORD
FORD
FORD

FORD
FORD
FORD
FORD
FORD

CONSUL (GGFL)
CONSUL (GGNL)
ESCORT VII (AAL, ABL, GAL)
GRANADA (GGFL, GGTL)
GRANADA (GGNL)
GRANADA (GU)
SCORPIO I (GAE, GGE)
SCORPIO I (GGE)

FORD
FORD
FORD
FORD

SIERRA (BNC)
SIERRA (GB4, GBG)
SIERRA (GBC)
SIERRA (GBC, GBG)

500353

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 52 mm
H = 82 mm



FORD
FORD
FORD
FORD
FORD

SIERRA (BNC)
SIERRA (BNG)
SIERRA (GB4, GBG)
SIERRA (GBC)
SIERRA (GBC, GBG)

500166T

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 58 mm
H = 107 mm



FORD
FORD

FIESTA III (GFJ)
FIESTA IV (JA_, JB_)

500239T

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 60 mm
H = 125 mm



FORD
FORD

C-MAX (DM2)
FOCUS II (DA_)

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 64 mm
H = 101 mm



FORD

ESCORT VII (AAL, ABL, GAL)

500290

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 68 mm
H = 85 mm



FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

CONSUL (GGCL)
CONSUL (GGFL)
CONSUL (GGNL)
GRANADA (GGCL)
GRANADA (GGFL, GGTL)
GRANADA (GGNL)
GRANADA (GNU)
GRANADA (GU)

500175

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 70 mm
H = 116 mm



FORD

GALAXY (WGR)

500317T

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 72 mm
H = 108,5 mm



FORD
FORD

KA (RB_)
KA Van (RB)

500136

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 87 mm
H = 103 mm



FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT V (AVL, GAL)
ESCORT V (GAL)
ESCORT VI (GAL)
ESCORT VII (AAL, ABL, GAL)
ESCORT VII (AFL, GAL)
ESCORT VII (ALL)
ESCORT VII (ANL, GAL)

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 90 mm
H = 125 mm



FORD
FORD
FORD

MONDEO I (BNP)
MONDEO I (GBP)
MONDEO II (BNP)

500178

APPLICATION

BOX SIDE
Ø = 24,5 mm
Ø = 76 mm
H = 103 mm



FORD

MAVERICK (UDS, UNS)

500294T

APPLICATION

WHEEL SIDE
Ø = 24,5 mm
Ø = 83 mm
H = 120 mm



FORD
FORD
FORD
FORD

FOCUS (DAW, DBW)
KA (RU8)
TOURNEO CONNECT
TRANSIT CONNECT
(P65_, P70_, P80_)

500437

APPLICATION

BOX SIDE
Ø = 24,6 mm
Ø = 75 mm
H = 97,15 mm



FORD

FOCUS C-MAX

500184

APPLICATION

BOX SIDE
Ø = 24,7 mm
Ø = 70,25 mm
H = 100,4 mm



FORD
FORD
FORD
FORD

MONDEO II (BAP)
MONDEO III (B4Y)
MONDEO III (B5Y)
MONDEO III (BWY)

APPLICATION

WHEEL SIDE
Ø = 24,85 mm
Ø = 75 mm
H = 114 mm



FORD

FIESTA VI

500566

APPLICATION

WHEEL SIDE
Ø = 25 mm
Ø = 74 mm
H = 99 mm



FORD
FORD
FORD
FORD

FOCUS (DAW, DBW)
MONDEO III (B4Y)
MONDEO III (B5Y)
MONDEO III (BWY)

500533

APPLICATION

BOX SIDE
Ø = 25,5 mm
Ø = 70,5 mm
H = 92 mm



FORD

FOCUS II (DA_)

500589

APPLICATION

BOX SIDE
Ø = 25,5 mm
Ø = 75 mm
H = 92,2 mm



FORD
FORD
FORD

GALAXY (WA6)
MONDEO IV (BA7)
S-MAX (WA6)

500560

APPLICATION

BOX SIDE
Ø = 26 mm
Ø = 77,5 mm
H = 95 mm



FORD
FORD
FORD

GALAXY (WA6)
MONDEO IV (BA7)
S-MAX (WA6)

500163T

APPLICATION

WHEEL SIDE
 $\emptyset = 26 \text{ mm}$
 $\emptyset = 80 \text{ mm}$
 $H = 133 \text{ mm}$



FORD

MONDEO I (GBP)

500296T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 89 \text{ mm}$
 $H = 119 \text{ mm}$



FORD

FORD

FORD

FORD

FORD

TOURNEO CONNECT

TRANSIT (FA_ _)

TRANSIT (FB_ _, FC_ _,

FD_ _, FS_ _, FZ_ _)

TRANSIT (FM_ _, FN_

_)

TRANSIT CONNECT

(P65_ , P70_ , P80_)

500227T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 89 \text{ mm}$
 $H = 125 \text{ mm}$



FORD

FORD

FORD

FORD

FORD

FORD

FORD

GALAXY (WA6)

MONDEO IV (BA7)

S-MAX (WA6)

TOURNEO CONNECT

TRANSIT (FA_ _)

TRANSIT (FB_ _, FC_ _,

FD_ _, FS_ _, FZ_ _)

TRANSIT (FM_ _, FN_

_)

FORD

TRANSIT CONNECT
(P65_ , P70_ , P80_)

500011T

APPLICATION

WHEEL SIDE
 $\emptyset = 27,2 \text{ mm}$
 $\emptyset = 98,1 \text{ mm}$
 $H = 144,5 \text{ mm}$



FORD

GALAXY (WGR)

500171

APPLICATION

BOX SIDE
 $\emptyset = 28 \text{ mm}$
 $\emptyset = 62 \text{ mm}$
 $H = 83 \text{ mm}$



FORD

FORD

FORD

FOCUS (DAW, DBW)

FOCUS (DFW)

FOCUS (DNW)

500574T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 122 \text{ mm}$



FORD

KUGA I

500233T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 107 \text{ mm}$



FORD
 FORD
 FORD

FOCUS (DAW, DBW)
 FOCUS (DFW)
 MONDEO II (BAP)

500496T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 118 \text{ mm}$



FORD
 FORD

FORD
 FORD
 FORD

C-MAX (DM2)
 C-MAX II (DXA/CB7,
 DXA/CEU)
 FOCUS C-MAX
 FOCUS II (DA_)
 FOCUS III

500236T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 117 \text{ mm}$



FORD
 FORD
 FORD

MONDEO II (BAP)
 MONDEO II (BFP)
 MONDEO II (BNP)

500555T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 118 \text{ mm}$



FORD
 FORD
 FORD
 FORD

FOCUS (DAW, DBW)
 MONDEO III (B4Y)
 MONDEO III (B5Y)
 MONDEO III (BWY)

APPLICATION

BOX SIDE
Ø = 28 mm
Ø = 95 mm
H = 130 mm



FORD
FORD

MONDEO I (BNP)
MONDEO I (GBP)

500162T

APPLICATION

WHEEL SIDE
Ø = 28 mm
Ø = 97 mm
H = 135 mm



FORD
FORD

MAVERICK (UDS, UNS)
MONDEO I (GBP)

500436

APPLICATION

BOX SIDE
Ø = 28,15 mm
Ø = 64 mm
H = 91,61 mm



FORD
FORD
FORD
FORD

C-MAX (DM2)
FOCUS C-MAX
FOCUS II
FOCUS II (DA_)

500183

APPLICATION

BOX SIDE
Ø = 29 mm
Ø = 67 mm
H = 83 mm



FORD
FORD
FORD

FOCUS (DAW, DBW)
FOCUS (DFW)
FOCUS (DNW)

500520T

APPLICATION

WHEEL SIDE
Ø = 29 mm
Ø = 91 mm
H = 128 mm



FORD
FORD
FORD

GALAXY (WA6)
MONDEO IV (BA7)
S-MAX (WA6)

500225T

APPLICATION

WHEEL SIDE
 $\varnothing = 31 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 111 \text{ mm}$



FORD
 FORD
 FORD
 FORD
 FORD
 FORD

FIESTA V
 FIESTA V (JD_, JH_)
 FOCUS (DAW, DBW)
 FOCUS (DFW)
 FOCUS (DNW)
 FUSION (JU_)

500541T

APPLICATION

WHEEL SIDE
 $\varnothing = 31 \text{ mm}$
 $\varnothing = 79 \text{ mm}$
 $H = 118 \text{ mm}$



FORD
 FORD
 FORD
 FORD

C-MAX (DM2)
 FOCUS C-MAX
 FOCUS II
 FOCUS II (DA_)

500226T

APPLICATION

WHEEL SIDE
 $\varnothing = 31 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 107 \text{ mm}$



FORD
 FORD
 FORD
 FORD
 FORD
 FORD
 FORD
 FORD
 FORD

C-MAX (DM2)
 FOCUS (DAW, DBW)
 FOCUS (DFW)
 FOCUS (DNW)
 FOCUS C-MAX
 FOCUS II (DA_)
 MONDEO III (B4Y)
 MONDEO III (B5Y)
 MONDEO III (BWY)

500303T

APPLICATION

WHEEL SIDE
 $\varnothing = 33,5 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 110 \text{ mm}$



FORD
 FORD
 FORD

FOCUS (DAW, DBW)
 FOCUS (DFW)
 FOCUS (DNW)

500505

APPLICATION

BOX SIDE
 $\varnothing = 35 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 100 \text{ mm}$



FORD
 FORD
 FORD

C-MAX (DM2)
 FOCUS II (DA_)
 FOCUS III

APPLICATION

WHEEL SIDE
Ø = 37,8 mm
Ø = 85,2 mm
H = 115,8 mm



FORD
FORD
FORD
FORD
FORD
FORD

C-MAX (DM2)
FOCUS (DAW, DBW)
FOCUS (DFW)
FOCUS (DNW)
FOCUS C-MAX
FOCUS II (DA_)

500039

APPLICATION

WHEEL SIDE
 $\emptyset = 20,2 \text{ mm}$
 $\emptyset = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



FORD ASIA /
 OCEANIA

TELSTAR

500283

APPLICATION

WHEEL SIDE
 $\emptyset = 21 \text{ mm}$
 $\emptyset = 73 \text{ mm}$
 $H = 91 \text{ mm}$



FORD ASIA /
 OCEANIA

LASER (BA_2, BA_3,
 BA_4, BJ_2)

500031

APPLICATION

WHEEL SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 85 \text{ mm}$
 $H = 97 \text{ mm}$



FORD ASIA /
 OCEANIA

TELSTAR

APPLICATION

BOX SIDE

 $\varnothing = 24,55 \text{ mm}$ $\varnothing = 81,75 \text{ mm}$ $H = 81,5 \text{ mm}$ 

FORD USA

PROBE I

500114
APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 77,6 \text{ mm}$
 $H = 90 \text{ mm}$



HOLDEN
 HOLDEN

ASTRA (TR)
 ASTRA (TS)

500116
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 88 \text{ mm}$



HOLDEN

BARINA (MH)

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



HONDA
 HONDA
 HONDA

CROSSTOUR
 CR-V II (RD_)
 CR-V III (RE)

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



HONDA
 HONDA
 HONDA

CITY
 CIVIC VII (EP, EU, EV)
 CIVIC VII (ES)

500266

APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



HONDA
 HONDA
 HONDA

ACTY (TN)
 DOMANI
 TODAY

500208

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 84 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

CITY
 CIVIC I (AN, AR)
 CIVIC II (EE)
 CIVIC III (AG, AH, AJ, AL)
 JAZZ I (AA)
 LOGO (GA)

500288

APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 77,5 \text{ mm}$
 $H = 90 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

CITY
 CITY (CG_)
 CIVIC I (AN, AR)
 CIVIC II (EE)
 CIVIC III (AG, AH, AJ, AL)
 CIVIC III (AK, AM, AU)
 CIVIC IV (EC, ED, EE)
 JAZZ I (AA)
 LOGO (GA)

500509

APPLICATION

BOX SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 83 \text{ mm}$



HONDA
 HONDA

CIVIC VII (EP, EU, EV)
 CIVIC VII (ES)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



HONDA
 HONDA

ACTY (TN)
 TODAY

500315

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 92 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

CITY (GD6, GD7, GD8,
 GD9)
 CITY (GM)
 CIVIC VII (EP, EU, EV)
 CIVIC VII (ES)
 CIVIC VIII (FA, FD)
 JAZZ II (GD, GE3)
 JAZZ III (GE_, GG_, GP_)

500198

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



HONDA

ACTY (TN)

500255

APPLICATION

WHEEL SIDE
 $\varnothing = 20,5 \text{ mm}$
 $\varnothing = 84,8 \text{ mm}$
 $H = 106 \text{ mm}$



HONDA
 HONDA

CIVIC VI (MA, MB)
 CIVIC VI (MB, MC)

500205

APPLICATION

BOX SIDE
 $\varnothing = 20,9 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 92 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

CIVIC IV (EC, ED, EE)
 CIVIC IV (ED)
 CIVIC V (EJ)
 CIVIC VI (EJ, EK)
 CIVIC VI (EJ, EM1)
 CIVIC VI (MA, MB)
 CRX III (EG, EH) Targa
 DOMANI

500176

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 91 \text{ mm}$



HONDA

CIVIC VII (EP, EU, EV)

500181

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 88 \text{ mm}$



HONDA
 HONDA
 HONDA

ACCORD VI (CG, CH, CK)
 ACCORD VI (CH, CL)
 CIVIC VII (EM2)

500636T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 69,13 \text{ mm}$
 $H = 105 \text{ mm}$



HONDA
 HONDA

CROSSTOUR
 CR-V III (RE)

500292

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



HONDA

CIVIC VII (EP, EU, EV)

APPLICATION

WHEEL SIDE
Ø = 21 mm
Ø = 70 mm
H = 106 mm



HONDA CR-V II (RD_)

500207

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 71,5 mm
H = 90 mm



HONDA	ACCORD I (SJ, SY)	HONDA	CRX I (AF, AS)
HONDA	ACCORD II (AC, AD)	HONDA	PRELUDE I (SN)
HONDA	ACCORD III (CA)	HONDA	PRELUDE II (AB)
HONDA	CIVIC I (AN, AR)	HONDA	QUINTET (SU)
HONDA	CIVIC II (EE)		
HONDA	CIVIC II (SL, SS)		
HONDA	CIVIC III (AG, AH, AJ, AL)		
HONDA	CIVIC IV (EC, ED, EE)		
HONDA	CONCERTO (HW, MA)		

500204

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 73 mm
H = 98 mm



HONDA CIVIC VI (EJ, EK)
HONDA CIVIC VI (MA, MB)
HONDA CIVIC VI (MB, MC)
HONDA CIVIC VIII (FK, FN)

500215

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 74 mm
H = 94 mm



HONDA HR-V (GH)

500399

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 74 mm
H = 95 mm



HONDA	ACCORD I (SJ, SY)	HONDA	CIVIC IV (EC, ED, EE)
HONDA	ACCORD II (AC, AD)	HONDA	CIVIC IV (ED)
HONDA	ACCORD III (CA)	HONDA	CONCERTO (HW, MA)
HONDA	CIVIC I (AN, AR)	HONDA	CRX I (AF, AS)
HONDA	CIVIC I (SB)	HONDA	PRELUDE I (SN)
HONDA	CIVIC I (SF)	HONDA	PRELUDE II (AB)
HONDA	CIVIC II (EE)	HONDA	QUINTET (SU)
HONDA	CIVIC III (AG, AH, AJ, AL)		
HONDA	CIVIC III (AK, AM, AU)		

500034

APPLICATION

WHEEL SIDE

Ø = 21 mm

Ø = 76 mm

H = 91 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

ACCORD I (SJ, SY)
ACCORD II (AC, AD)
CIVIC I (SB)
CIVIC I (SF)
CIVIC II (SL, SS)
CIVIC II (WC)
CIVIC III (AG, AH, AJ, AL)
CONCERTO (HW, MA)
CONCERTO (HWW)

HONDA
HONDA
HONDA
HONDA

CRX I (AF, AS)
PRELUDE I (SN)
PRELUDE II (AB)
QUINTET (SU)

500270

APPLICATION

BOX SIDE

Ø = 21 mm

Ø = 80 mm

H = 84 mm



HONDA

ACCORD V (CE, CF)

500197

APPLICATION

WHEEL SIDE

Ø = 21 mm

Ø = 81 mm

H = 91 mm



HONDA
HONDA
HONDA
HONDA

CIVIC VI (EJ, EK)
CIVIC VI (MA, MB)
CIVIC VI (MB, MC)
PRELUDE III (BA)

500069

APPLICATION

BOX SIDE

Ø = 21 mm

Ø = 81,8 mm

H = 92,3 mm



HONDA
HONDA

CIVIC I (AN, AR)
CIVIC II (EE)

500189

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 93 \text{ mm}$



HONDA ACCORD IV (CB)
 HONDA ACCORD IV (CB, CC)
 HONDA ACCORD V (CC, CD)
 HONDA ACCORD V (CE)
 HONDA ACCORD V (CE, CF)
 HONDA ACCORD VI (CG)
 HONDA ACCORD VI (CG, CH, CK)
 HONDA ACCORD VI (CH, CL)
 HONDA ACCORD VII (CL, CN)
 HONDA ASCOT
 HONDA CIVIC IV (EC, ED, EE)
 HONDA CIVIC IV (ED)
 HONDA CIVIC VI (EJ, EK)
 HONDA CIVIC VI (MA, MB)
 HONDA CIVIC VI (MB, MC)
 HONDA CR-V I (RD)
 HONDA CRX II (ED, EE)
 HONDA CRX III (EG, EH) Targa
 HONDA DOMANI
 HONDA FR-V (BE)
 HONDA PRELUDE III (BA)

HONDA PRELUDE IV (BB)
 HONDA PRELUDE V (BB)
 HONDA STREAM (RN)

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



HONDA CIVIC VII (EP, EU, EV)

500530T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 115 \text{ mm}$



HONDA CIVIC VI (EJ, EK)
 HONDA CIVIC VII (EP, EU, EV)
 HONDA CIVIC VII (ES)
 HONDA CIVIC VIII (FA, FD)
 HONDA JAZZ II (GD, GE3)
 HONDA JAZZ III (GE_, GG_, GP_)
 HONDA LOGO (GA)

500529T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 116 \text{ mm}$



HONDA CITY (GM)
 HONDA CIVIC VI (EJ, EK)
 HONDA CIVIC VII (EP, EU, EV)
 HONDA CIVIC VII (ES)
 HONDA CIVIC VIII (FA, FD)
 HONDA JAZZ II (GD, GE3)
 HONDA JAZZ III (GE_, GG_, GP_)

500191

APPLICATION

WHEEL SIDE

Ø = 22 mm

Ø = 90 mm

H = 98 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

ACCORD V (CC, CD)
ACCORD V (CD)
ACCORD V (CE, CF)
PRELUDE III (BA)
PRELUDE IV (BB)
PRELUDE V (BB)
SHUTTLE (RA)

500201

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 74 mm

H = 93 mm



HONDA
HONDA
HONDA

CIVIC III (AG, AH, AJ, AL)
CIVIC III (AK, AM, AU)
CRX I (AF, AS)

500196

APPLICATION

WHEEL SIDE

Ø = 23 mm

Ø = 77 mm

H = 95 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

CITY
CIVIC I (AN, AR)
CIVIC II (EE)
CIVIC III (AG, AH, AJ, AL)
CIVIC III (AK, AM, AU)
CIVIC IV (EC, ED, EE)
CIVIC IV (ED)
CRX I (AF, AS)

500275

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 78 mm

H = 91,5 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

ACCORD III (CA)
ACCORD V (CC, CD)
ACCORD V (CE, CF)
ACCORD VI (CG)
ACCORD VI (CG, CH, CK)
ACCORD VI (CH, CL)
CIVIC I (AN, AR)
CIVIC II (EE)
CIVIC VI (MB, MC)

HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

CONCERTO (HW, MA)
CONCERTO (HWW)
CR-V I (RD)
CRX II (ED, EE)
INTEGRA (DA)
INTEGRA (DC2, DC4)
PRELUDE III (BA)
PRELUDE V (BB)

500192

APPLICATION

WHEEL SIDE

Ø = 23 mm

Ø = 82 mm

H = 96 mm



HONDA
HONDA
HONDA

ACCORD II (AC, AD)
ACCORD III (CA)
PRELUDE II (AB)

500213

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 97 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA

CIVIC VI (EJ, EK)
 CIVIC VI (EJ, EM1)
 CIVIC VI (MA, MB)
 DOMANI

500112

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 94 \text{ mm}$
 $H = 93,7 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

ACCORD IV (CB)
 ACCORD IV (CB, CC)
 ACCORD V (CC, CD)
 ACCORD V (CD)
 ACCORD V (CE)
 CR-V III (RE)
 PRELUDE IV (BB)
 PRELUDE V (BB)
 SHUTTLE (RA)

500026

APPLICATION

WHEEL SIDE
 $\varnothing = 23,2 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 99 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

ACCORD III (CA)
 CIVIC IV (ED)
 CONCERTO (HW, MA)
 CRX II (ED, EE)
 HR-V (GH)
 INTEGRA (DA)
 PRELUDE III (BA)

500361

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 85 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

ACCORD I (SJ, SY)
 ACCORD II (AC, AD)
 ACCORD III (CA)
 CONCERTO (HW, MA)
 CONCERTO (HWW)
 PRELUDE II (AB)

500524T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 124 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

CIVIC IX (FK)
 CIVIC VII (EP, EU, EV)
 CIVIC VIII (FA, FD)
 CIVIC VIII (FK, FN)
 FR-V (BE)
 HR-V (GH)
 STREAM (RN)

500547

APPLICATION

BOX SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 76,5 \text{ mm}$
 $H = 91 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA

ACCORD VII (CL, CN)
 ACCORD VII (CM, CN)
 CR-V II (RD_)
 FR-V (BE)

500442

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 109 \text{ mm}$



HONDA
 HONDA

CIVIC IX (FK)
 CIVIC VIII (FK, FN)

500203

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 100 \text{ mm}$



HONDA
 HONDA
 HONDA

ACCORD I (SJ, SY)
 ACCORD II (AC, AD)
 PRELUDE II (AB)

500092

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 89 \text{ mm}$



HONDA
 HONDA

CIVIC VI (EJ, EK)
 CIVIC VI (MA, MB)

500295T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 91 \text{ mm}$
 $H = 125 \text{ mm}$



HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA
 HONDA

ACCORD VI (CG, CH, CK)
 ACCORD VII (CL, CN)
 ACCORD VII (CM)
 ACCORD VII (CM, CN)
 CIVIC VII (EP, EU, EV)
 CIVIC VIII (FK, FN)
 CR-V I (RD)
 CR-V II (RD_)
 CR-V III (RE)

HONDA
 HONDA
 HONDA
 HONDA

FR-V (BE)
 INTEGRA (DC5)
 PRELUDE V (BB)
 STREAM (RN)

APPLICATION

WHEEL SIDE
Ø = 26 mm
Ø = 88 mm
H = 113 mm



HONDA
HONDA
HONDA
HONDA

ACCORD VI (CG)
ACCORD VI (CG, CH, CK)
ACCORD VI (CH, CL)
CIVIC VII (EP, EU, EV)

500106

APPLICATION

WHEEL SIDE
Ø = 26,8 mm
Ø = 90 mm
H = 108 mm



HONDA
HONDA

LEGEND I (HS, KA)
LEGEND I (KA_)

500202

APPLICATION

BOX SIDE
Ø = 27 mm
Ø = 78 mm
H = 92 mm



HONDA
HONDA

ACCORD II (AC, AD)
PRELUDE II (AB)

500210

APPLICATION

WHEEL SIDE
Ø = 27 mm
Ø = 82 mm
H = 97 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

ACCORD III (CA)
CIVIC I (AN, AR)
CIVIC IV (EC, ED, EE)
CIVIC IV (ED)
CRX I (AF, AS)
CRX II (ED, EE)

500193

APPLICATION

WHEEL SIDE
Ø = 27 mm
Ø = 84 mm
H = 91 mm



HONDA
HONDA
HONDA

ACCORD II (AC, AD)
CR-V I (RD)
PRELUDE II (AB)

APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 128 \text{ mm}$



HONDA	ACCORD VII (CL, CN)
HONDA	ACCORD VII (CM, CN)
HONDA	ACCORD VIII (CU)
HONDA	ACCORD VIII (CW)
HONDA	CR-V II (RD_)
HONDA	FR-V (BE)
HONDA	LEGEND IV (KB_)

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI

ATOS (IL44, MX)
 ATOS PRIME (MX)
 i10 (PA)

500206

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 83 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI

ATOS (IL44, MX)
 ATOS PRIME (MX)
 GETZ (TB)

500199

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI

ATOS (IL44, MX)
 ATOS PRIME (MX)
 GETZ (TB)

500266

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI

ATOS (IL44, MX)
 ATOS PRIME (MX)
 GETZ (TB)

500212

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 84 \text{ mm}$



KIA
 KIA
 KIA

PICANTO (BA)
 PRIDE
 PRIDE (DA)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



HYUNDAI
 HYUNDAI
 KIA
 KIA

ATOS PRIME (MX)
 GETZ (TB)
 PRIDE
 PRIDE (DA)

500637

APPLICATION

BOX SIDE
 $\varnothing = 19,8 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 95 \text{ mm}$



HYUNDAI

i20 (PB, PBT)

500637

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 91 \text{ mm}$



KIA
 KIA

CEE'D (ED)
 PRO CEE'D (ED)

500276

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 83 \text{ mm}$



KIA
 KIA
 KIA

PICANTO (BA)
 RIO (DC)
 RIO (DC_)

500198

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



KIA
 KIA

PRIDE
 PRIDE (DA)

500273

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 93 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI

ACCENT (X-3)
 ACCENT I (X-3)
 ACCENT II (LC)
 GETZ (TB)

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA
 KIA
 KIA
 KIA
 KIA

ACCENT I (X-3)
 LANTRA I (J-1)
 PONY (X-1)
 S (SLC)
 CERATO (LD)
 RIO (DC)
 RIO (DC_)
 SHUMA (FB)
 SHUMA II (FB)

500169

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 92 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA

ACCENT (X-3)
 ACCENT I (X-3)
 PONY / EXCEL (X-2)
 SHUMA (FB)

500173

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 93 \text{ mm}$



HYUNDAI
 HYUNDAI

ACCENT II (LC)
 GETZ (TB)

500522

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 63,5 \text{ mm}$
 $H = 99 \text{ mm}$



HYUNDAI
 HYUNDAI
 KIA
 KIA

ACCENT IV (RB)
 ACCENT IV (RB) | SOLA-
 RIS | SOLARIS / ACCENT
 CERATO II (TD)
 RIO III (UB)

500165T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 102 \text{ mm}$



KIA

PICANTO (BA)

500636T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 69,13 \text{ mm}$
 $H = 105 \text{ mm}$

HYUNDAI
HYUNDAIATOS (IL44, MX)
i10 (PA)

500207

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 71,5 \text{ mm}$
 $H = 90 \text{ mm}$

HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAICOUPE (RD)
PONY (X-1)
PONY / EXCEL (X-2)
S (SLC)

500195

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$

HYUNDAI
HYUNDAI
KIA
KIA
KIAACCENT (X-3)
ACCENT I (X-3)
CARENS I (FC)
SHUMA (FB)
SHUMA II (FB)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$

HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
KIA
KIACOUPE (GK)
PONY (X-2)
PONY / EXCEL (X-2)
S (SLC)
PRIDE
PRIDE (DA)

500069

APPLICATION

BOX SIDE

Ø = 21 mm

Ø = 81,8 mm

H = 92,3 mm

HYUNDAI
HYUNDAISANTA FÉ I (SM)
SONATA IV (EF)

500550

APPLICATION

BOX SIDE

Ø = 21,3 mm

Ø = 74 mm

H = 86,3 mm

HYUNDAI
HYUNDAIELANTRA (XD)
TUCSON (JM)

500200

APPLICATION

WHEEL SIDE

Ø = 21,9 mm

Ø = 76 mm

H = 95 mm

HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAICOUPE (RD)
ELANTRA (XD)
LANTRA I (J-1)
LANTRA II (J-2)
MATRIX (FC)

500177

APPLICATION

BOX SIDE

Ø = 22 mm

Ø = 65,5 mm

H = 91 mm

HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
KIACOUPE (RD)
ELANTRA (XD)
LANTRA I (J-1)
LANTRA II (J-2)
SONATA IV (EF)
MAGENTIS (GD, MS)

500322T

APPLICATION

WHEEL SIDE

Ø = 22 mm

Ø = 73 mm

H = 116 mm

KIA
KIARIO (DC)
RIO (DC_)

500366

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 98 \text{ mm}$



HYUNDAI

SANTAMO

500512

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 94 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA
 KIA

i30 (FD)
 i30 (GD)
 ix35 (EL, ELH, LM)
 SPORTAGE (JE_, KM_)
 SPORTAGE (SL)

500557T

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 105 \text{ mm}$



KIA
 KIA

CEE'D (ED)
 PRO CEE'D (ED)

500395

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 77,8 \text{ mm}$
 $H = 88 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI

COUPE (GK)
 ELANTRA (XD)
 MATRIX (FC)
 SANTA FÉ I (SM)
 SONATA V (NF)
 TRAJET (FO)
 TUCSON (JM)

500192

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 96 \text{ mm}$



HYUNDAI

COUPE (GK)

500213

APPLICATION

WHEEL SIDE
 $\emptyset = 23 \text{ mm}$
 $\emptyset = 82 \text{ mm}$
 $H = 97 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI

COUPE (GK)
 COUPE (RD)
 ELANTRA (XD)
 LANTRA II (J-2)
 MATRIX (FC)
 SANTA FÉ I (SM)
 SANTAMO
 SONATA IV (EF)
 TRAJET (FO)

KIA
 KIA

JOICE
 MAGENTIS (GD, MS)

500026

APPLICATION

WHEEL SIDE
 $\emptyset = 23,2 \text{ mm}$
 $\emptyset = 82 \text{ mm}$
 $H = 99 \text{ mm}$



KIA
 KIA
 KIA
 KIA

CARENS I (FC)
 RETONA (CE)
 SHUMA (FB)
 SPORTAGE (K00)

500182

APPLICATION

BOX SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 78 \text{ mm}$
 $H = 92 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA

SONATA IV (EF)
 TRAJET (FO)
 XG (XG)
 MAGENTIS (GD, MS)

500544

APPLICATION

BOX SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 80 \text{ mm}$
 $H = 89 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI

COUPE (GK)
 COUPE (RD)
 ELANTRA (XD)
 SANTA FÉ I (SM)
 TUCSON (JM)

500240T

APPLICATION

WHEEL SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 84 \text{ mm}$
 $H = 115 \text{ mm}$



KIA

SORENTO I (JC)

500256

APPLICATION

BOX SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 81,5 \text{ mm}$
 $H = 87 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI

GALLOPER II (JK-01)
 SANTA FÉ I (SM)
 SONATA IV (EF)
 TRAJET (FO)

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



KIA
 KIA

RETONA (CE)
 SPORTAGE (K00)

500638

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 86 \text{ mm}$



HYUNDAI
 KIA
 KIA
 KIA

TERRACAN (HP)
 RETONA (CE)
 SORENTO I (JC)
 SPORTAGE (K00)

500092

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 89 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA

ELANTRA (HD)
 GETZ (TB)
 MATRIX (FC)
 JOICE

500277

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 91 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA

ELANTRA (XD)
 SANTA FÉ I (SM)
 SONATA IV (EF)
 TUCSON (JM)
 XG
 XG (XG)
 MAGENTIS (GD, MS)

500347

APPLICATION

WHEEL SIDE
 $\varnothing = 25,85 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 100 \text{ mm}$



HYUNDAI

GALLOPER II (JK-01)

500537T

APPLICATION

WHEEL SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 115 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA

SONATA V (NF)
 SONATA VI (YF)
 TUCSON (JM)
 SPORTAGE (JE_, KM_)

500106

APPLICATION

WHEEL SIDE
 $\varnothing = 26,8 \text{ mm}$
 $\varnothing = 90 \text{ mm}$
 $H = 108 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI

SANTA FÉ I (SM)
 SONATA IV (EF)
 XG (XG)

500238T

APPLICATION

WHEEL SIDE
 $\varnothing = 26,9 \text{ mm}$
 $\varnothing = 88 \text{ mm}$
 $H = 141 \text{ mm}$



HYUNDAI
 HYUNDAI
 HYUNDAI
 HYUNDAI
 KIA

SONATA IV (EF)
 TRAJET (FO)
 XG
 XG (XG)
 MAGENTIS (GD, MS)

500031

APPLICATION

WHEEL SIDE
 $\varnothing = 27,5 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 97 \text{ mm}$



KIA
 KIA

CARNIVAL I (UP)
 CARNIVAL II (GQ)

APPLICATION

WHEEL SIDE

Ø = 28 mm

Ø = 90 mm

H = 132 mm

HYUNDAI
HYUNDAI
HYUNDAICOUPE (GK)
ELANTRA (XD)
TUCSON (JM)

500130

APPLICATION

BOX SIDE



NISSAN

MICRA II (K11)

500312

APPLICATION

BOX SIDE

NISSAN
NISSAN
NISSAN
NISSANINTERSTAR (X70)
KUBISTAR (X76)
PRIMASTAR
PRIMASTAR (X83)

500391

APPLICATION

WHEEL SIDE

Ø = 16,15 mm

Ø = 63,05 mm

H = 68,7 mm

NISSAN
NISSAN
NISSAN
NISSAN
NISSANQASHQAI / QASHQAI +2
(J10, JJ10)
QASHQAI II (J11, J11_)
X-TRAIL (T30)
X-TRAIL (T31)
X-TRAIL (T32_)

500387

APPLICATION

BOX SIDE

Ø = 16,9 mm

Ø = 56,2 mm

H = 77,7 mm

NISSAN
NISSANMURANO I (Z50)
X-TRAIL (T30)

500059

APPLICATION

BOX SIDE

Ø = 17 mm

Ø = 62,15 mm

H = 110 mm



NISSAN

SUNNY I (B11)

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

ALMERA II (N16)
 ALMERA Mk II (N16)
 MICRA C+C III (K12)
 MICRA III (K12)
 NOTE (E11, NE11)

500509

APPLICATION

BOX SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 83 \text{ mm}$



NISSAN

ALMERA II (N16)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



NISSAN

MICRA I (K10)

500414

APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

ALMERA II (N16)
 ALMERA TINO (V10)
 MICRA III (K12)
 NOTE (E11, NE11)
 PRIMERA (P11)
 PRIMERA (P12)
 PRIMERA (WP11)
 PRIMERA (WP12)

500114

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 77,6 \text{ mm}$
 $H = 90 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

ALMERA I (N15)
 BLUEBIRD (T12, T72)
 BLUEBIRD (T12, T72,
 U12)
 BLUEBIRD (U11)
 BLUEBIRD (WU11)
 SUNNY I (B11)
 SUNNY II (B12)
 SUNNY III (N14)

500349
APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 93 \text{ mm}$



NISSAN

MICRA II (K11)

500118
APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 82,3 \text{ mm}$
 $H = 86 \text{ mm}$


 NISSAN
 NISSAN

 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

 BLUEBIRD (T12, T72)
 BLUEBIRD (T12, T72,
 U12)
 BLUEBIRD (U11)
 BLUEBIRD (WU11)
 PRAIRIE PRO (M11)
 PRIMERA (P10)
 PRIMERA (P11)
 PRIMERA (W10)

 NISSAN
 NISSAN

 PRIMERA (WP11)
 SUNNY I (B11)

500039
APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$


 NISSAN
 NISSAN

 PRAIRIE (M10, NM10)
 SUNNY I (B11)

500093
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 84 \text{ mm}$



NISSAN

MICRA II (K11)

500486
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 95 \text{ mm}$



NISSAN

CHERRY III (N12)

500211
APPLICATION

BOX SIDE
 $\varnothing = 21$ mm
 $\varnothing = 71$ mm
H = 85 mm



NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN

ALMERA I (N15)
BLUEBIRD (T12, T72)
SUNNY I (B11)
SUNNY II (B12)
SUNNY II (N13)
SUNNY III (N14)

500034
APPLICATION

WHEEL SIDE
 $\varnothing = 21$ mm
 $\varnothing = 76$ mm
H = 91 mm



NISSAN
NISSAN

CHERRY II (N10)
CHERRY II (VN10)

500197
APPLICATION

WHEEL SIDE
 $\varnothing = 21$ mm
 $\varnothing = 81$ mm
H = 91 mm



NISSAN
NISSAN

ALMERA I (N15)
ALMERA TINO (V10)

500069
APPLICATION

BOX SIDE
 $\varnothing = 21$ mm
 $\varnothing = 81,8$ mm
H = 92,3 mm



NISSAN

PRAIRIE PRO (M11)

500426
APPLICATION

BOX SIDE
 $\varnothing = 21,75$ mm
 $\varnothing = 74,04$ mm
H = 89,25 mm



NISSAN
NISSAN
NISSAN
NISSAN

ALMERA TINO (V10)
INTERSTAR
INTERSTAR (X70)
PRIMERA (P12)

500532
APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 80 \text{ mm}$



NISSAN
 NISSAN

PRIMERA (P12)
 PRIMERA (WP12)

500322T
APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 116 \text{ mm}$



NISSAN
 NISSAN

MICRA C+C III (K12)
 MICRA III (K12)

500285T
APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

ALMERA II (N16)
 ALMERA Mk II (N16)
 ALMERA TINO (V10)
 JUKE (F15)
 MICRA C+C III (K12)
 MICRA III (K12)
 NOTE (E11, NE11)
 PRIMERA (P11)
 PRIMERA (P12)

NISSAN
 NISSAN

PRIMERA (WP11)
 PRIMERA (WP12)

500291
APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 86 \text{ mm}$
 $H = 97 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

100 NX (B13)
 ALMERA I (N15)
 ALMERA II (N16)
 BLUEBIRD (U11)
 BLUEBIRD (WU11)
 PRAIRIE (M10, NM10)
 PRAIRIE PRO (M11)
 PRIMERA (P10)
 PRIMERA (P11)

NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

PRIMERA (WP11)
 STANZA (T11)
 SUNNY I (B11)
 SUNNY II (B12)
 SUNNY II (N13)
 SUNNY III (N14)
 SUNNY III (Y10)

500033

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 94 \text{ mm}$



NISSAN	100 NX (B13)
NISSAN	ALMERA I (N15)
NISSAN	ALMERA II (N16)
NISSAN	ALMERA TINO (V10)
NISSAN	BLUEBIRD (T12, T72)
NISSAN	BLUEBIRD (T12, T72, U12)
NISSAN	BLUEBIRD (U11)
NISSAN	BLUEBIRD (WU11)
NISSAN	CHERRY III (N12)
NISSAN	PRAIRIE (M10, NM10)
NISSAN	PRIMERA (P10)
NISSAN	PRIMERA (P11)
NISSAN	PRIMERA (W10)
NISSAN	PRIMERA (WP11)
NISSAN	STANZA (T11)
NISSAN	SUNNY II (B12)
NISSAN	SUNNY II (N13)
NISSAN	SUNNY III (N14)

500393

APPLICATION

BOX SIDE
 $\varnothing = 22,7 \text{ mm}$
 $\varnothing = 73,2 \text{ mm}$
 $H = 87,45 \text{ mm}$



NISSAN	PRAIRIE (M10, NM10)
NISSAN	SUNNY II (N13)

500300

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 104 \text{ mm}$



NISSAN	KUBISTAR (X76)
NISSAN	KUBISTAR (X80)

500513

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 92 \text{ mm}$



NISSAN	PRAIRIE PRO (M11)
--------	-------------------

500421
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 75,44 \text{ mm}$
 $H = 95 \text{ mm}$



NISSAN QASHQAI / QASHQAI +2
 (J10, JJ10)
 NISSAN X-TRAIL (T31)

500279
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 105 \text{ mm}$



NISSAN PRIMERA (P10)
 NISSAN PRIMERA (P11)
 NISSAN PRIMERA (W10)
 NISSAN PRIMERA (WP11)

500112
APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 94 \text{ mm}$
 $H = 93,7 \text{ mm}$



NISSAN	ALMERA TINO (V10)	NISSAN	VANETTE CARGO (HC 23)
NISSAN	BLUEBIRD (T12, T72)		
NISSAN	BLUEBIRD (T12, T72, U12)		
NISSAN	BLUEBIRD (U11)		
NISSAN	BLUEBIRD (WU11)		
NISSAN	CEFIRO III (A33)		
NISSAN	MAXIMA / MAXIMA QX IV (A32)		
NISSAN	MAXIMA / MAXIMA QX V (A33)		
NISSAN	MAXIMA III (J30)		
NISSAN	PATHFINDER II (R50)		
NISSAN	PICK UP (D22)		
NISSAN	PRAIRIE (M10, NM10)		
NISSAN	PRIMERA (P10)		
NISSAN	SERENA (C23)		
NISSAN	SUNNY III (N14)		
NISSAN	TERRANO I (WD21)		
NISSAN	TERRANO II (R20)		
NISSAN	VANETTE (C22)		

500239T
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 125 \text{ mm}$



NISSAN ALMERA II (N16)
 NISSAN PRIMERA (P11)
 NISSAN PRIMERA (P12)
 NISSAN PRIMERA (WP11)
 NISSAN PRIMERA (WP12)

500257
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 101 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN

PRIMERA (P11)
 PRIMERA (WP11)
 SUNNY II (N13)
 SUNNY III (N14)

500384
APPLICATION

BOX SIDE
 $\varnothing = 24,15 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 93 \text{ mm}$



NISSAN
 NISSAN
 NISSAN

JUKE (F15)
 QASHQAI II (J11, J11_)
 X-TRAIL (T32_)

500178
APPLICATION

BOX SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 103 \text{ mm}$



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

PATHFINDER II (R50)
 SERENA (C23)
 TERRANO I (WD21)
 TERRANO II (R20)
 VANETTE (C22)
 VANETTE CARGO (HC 23)

500294T
APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



NISSAN
 NISSAN

PRIMERA (P12)
 PRIMERA (WP12)

500327
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 75 \text{ mm}$
 $H = 98 \text{ mm}$



INFINITI
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

FX
 200 SX (S14)
 INTERSTAR (X70)
 LAUREL (JC32)
 NAVARA (D22_)
 NP300 (D22)
 PATHFINDER II (R50)
 PICK UP (D22)
 PRIMASTAR

NISSAN
 NISSAN

PRIMASTAR (X83)
 SERENA (C23)

500277
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 91 \text{ mm}$



INFINITI
 INFINITI
 INFINITI
 INFINITI
 NISSAN

FX
 G
 M (Y51)
 Q70 (Y51)
 350 Z (Z33)

500123
APPLICATION

WHEEL SIDE
 $\varnothing = 25,3 \text{ mm}$
 $\varnothing = 76,3 \text{ mm}$
 $H = 80 \text{ mm}$



NISSAN
 NISSAN

LAUREL (JC31)
 LAUREL (JC32)

500589
APPLICATION

BOX SIDE
 $\varnothing = 25,5 \text{ mm}$
 $\varnothing = 75 \text{ mm}$
 $H = 92,2 \text{ mm}$



NISSAN
 NISSAN
 NISSAN

NAVARA (D22_)
 NP300 NAVARA (D40)
 PATHFINDER III (R51)

500410
APPLICATION

BOX SIDE
 $\varnothing = 25,5 \text{ mm}$
 $\varnothing = 76,5 \text{ mm}$
 $H = 89 \text{ mm}$



NISSAN

QASHQAI / QASHQAI +2
 (J10, JJ10)

500494
APPLICATION

BOX SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 85,5 \text{ mm}$
 $H = 95 \text{ mm}$



NISSAN
 NISSAN

ALMERA II (N16)
 ALMERA TINO (V10)

500390T
APPLICATION

WHEEL SIDE
 $\varnothing = 26,6 \text{ mm}$
 $\varnothing = 80,2 \text{ mm}$
 $H = 109,5 \text{ mm}$



NISSAN

QASHQAI / QASHQAI +2
(J10, JJ10)

500296T
APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 119 \text{ mm}$



NISSAN
NISSAN
NISSAN

ALMERA II (N16)
ALMERA TINO (V10)
PRIMERA (P12)

500227T
APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 125 \text{ mm}$



NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN

ALMERA II (N16)
ALMERA TINO (V10)
JUKE (F15)
NP300 NAVARA (D40)
PATHFINDER III (R51)
PRIMASTAR
PRIMASTAR (X83)
PRIMERA (P12)
PRIMERA (WP12)

500031
APPLICATION

WHEEL SIDE
 $\varnothing = 27,5 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 97 \text{ mm}$



NISSAN
NISSAN
NISSAN
NISSAN

PRAIRIE PRO (M11)
SUNNY I (B11)
SUNNY II (B12)
SUNNY II (N13)

500323T
APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 135 \text{ mm}$



NISSAN
NISSAN

KUBISTAR (X76)
KUBISTAR (X80)

500502T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 110 \text{ mm}$



INFINITI	EX
INFINITI	G
INFINITI	M35
NISSAN	370 Z (Z34)
NISSAN	QASHQAI / QASHQAI +2
	(J10, JJ10)
NISSAN	X-TRAIL (T31)
NISSAN	X-TRAIL (T31)

500321T

APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 123 \text{ mm}$



NISSAN	PRIMERA (P12)
NISSAN	PRIMERA (WP12)

500440

APPLICATION

BOX SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 96 \text{ mm}$



NISSAN	QASHQAI / QASHQAI +2
	(J10, JJ10)
NISSAN	QASHQAI II (J11, J11_)
NISSAN	X-TRAIL (T32_)

500412T

APPLICATION

WHEEL SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 99 \text{ mm}$
 $H = 125 \text{ mm}$



NISSAN	MURANO II (Z51)
NISSAN	QASHQAI / QASHQAI +2
	(J10, JJ10)
NISSAN	X-TRAIL (T31)

500573T

APPLICATION

WHEEL SIDE
 $\varnothing = 30,5 \text{ mm}$
 $\varnothing = 104 \text{ mm}$
 $H = 107 \text{ mm}$



NISSAN	NP300 NAVARA (D40)
NISSAN	PATHFINDER III (R51)

500392

APPLICATION

WHEEL SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 61,75 \text{ mm}$
 $H = 96,6 \text{ mm}$



INNOCENTI

MINI

500350

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 87 \text{ mm}$



INNOCENTI

ELBA (146)

500254

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 80 \text{ mm}$



INNOCENTI

KORAL

500040

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



INNOCENTI

KORAL

500040E

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



INNOCENTI

KORAL

500034

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 91 \text{ mm}$



INNOCENTI

MINI

500158

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 74 \text{ mm}$

INNOCENTI
INNOCENTIELBA (146)
KORAL

500081

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 80 \text{ mm}$



INNOCENTI

KORAL

500080

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 80 \text{ mm}$



INNOCENTI

KORAL

500147

APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



INNOCENTI

ELBA (146)

APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



INNOCENTI
INNOCENTI

ELBA (146)
KORAL

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



ISUZU

GEMINI (JT)

500211

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 85 \text{ mm}$



ISUZU

GEMINI (JT)

500207

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 71,5 \text{ mm}$
 $H = 90 \text{ mm}$



ISUZU

GEMINI (JT)

500195

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$



ISUZU

GEMINI (JT)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



ISUZU

GEMINI (JT)

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 81,8 mm
H = 92,3 mm



ISUZU
ISUZU

GEMINI (JT)
MIDI (94000, 98000)

500031

APPLICATION

WHEEL SIDE
Ø = 27,5 mm
Ø = 85 mm
H = 97 mm



ISUZU
ISUZU

ASKA I
ASKA III

500329

APPLICATION

WHEEL SIDE
 $\emptyset = 23 \text{ mm}$
 $\emptyset = 45 \text{ mm}$
 $H = 77 \text{ mm}$



JAGUAR

X-TYPE (CF1_)

500003

APPLICATION

WHEEL SIDE
 $\emptyset = 25 \text{ mm}$
 $\emptyset = 57 \text{ mm}$
 $H = 70 \text{ mm}$

JAGUAR
JAGUARS-TYPE (CCX_)
XJ (N3_)

500227T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 89 \text{ mm}$
 $H = 125 \text{ mm}$

JAGUAR
JAGUAR
JAGUAR
JAGUARS-TYPE (CCX_)
XJ (N3_)
XK (QQ6_)
X-TYPE (CF1_)

500262

APPLICATION

WHEEL SIDE
 $\emptyset = 23,5 \text{ mm}$
 $\emptyset = 79 \text{ mm}$
 $H = 96 \text{ mm}$



JEEP

GRAND CHEROKEE I
 (ZJ)

500487T

APPLICATION

WHEEL SIDE
 $\emptyset = 25,5 \text{ mm}$
 $\emptyset = 84,5 \text{ mm}$
 $H = 115 \text{ mm}$



JEEP

JEEP

JEEP

CHEROKEE (XJ)
 GRAND CHEROKEE I
 (ZJ)
 GRAND CHEROKEE II
 (WG, WJ)

500015

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 128 \text{ mm}$



LADA

NIVA (2121)

500209

APPLICATION

BOX SIDE
 $\varnothing = 18,8 \text{ mm}$
 $\varnothing = 75,3 \text{ mm}$
 $H = 81 \text{ mm}$



LADA
 LADA
 LADA
 LADA
 LADA
 LADA

110 (2110)
 111 (2111)
 112 (2112)
 NIVA (2121)
 SAMARA (2108, 2109,
 2113, 2114, 2115)
 SAMARA (2108, 2109,
 2113, 2115)

LADA

SAMARA (2113, 2114,
 2115)

500042

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 80 \text{ mm}$



LADA
 LADA
 LADA
 LADA
 LADA
 LADA

110 (2110)
 111 (2111)
 112 (2112)
 SAMARA (2108, 2109,
 2113, 2114, 2115)
 SAMARA (2108, 2109,
 2113, 2115)
 SAMARA (2113, 2114,
 2115)

LADA

SAMARA FORMA
 (21099, 2115)

500042E

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 80 \text{ mm}$



LADA
 LADA
 LADA
 LADA
 LADA

110 (2110)
 111 (2111)
 112 (2112)
 SAMARA (2108, 2109,
 2113, 2115)
 SAMARA FORMA
 (21099, 2115)

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



LADA

LARGUS

APPLICATION

BOX SIDE
Ø = 30 mm
Ø = 75 mm
H = 83 mm



LADA

LARGUS

500492

APPLICATION

BOX SIDE
Ø = 30 mm
Ø = 75 mm
H = 83 mm



LADA

LARGUS

500509

APPLICATION

BOX SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 83 \text{ mm}$



LAND ROVER FREELANDER 2 (LF_)

500322T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 116 \text{ mm}$



LAND ROVER FREELANDER (LN_)

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



LAND ROVER FREELANDER 2 (LF_)

500232T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 138 \text{ mm}$



LAND ROVER FREELANDER (LN_)

500589

APPLICATION

WHEEL SIDE
 $\varnothing = 25,5 \text{ mm}$
 $\varnothing = 75 \text{ mm}$
 $H = 92,2 \text{ mm}$



LAND ROVER DISCOVERY III (L319)
 LAND ROVER DISCOVERY III VAN (L319)
 LAND ROVER DISCOVERY IV (L319)
 LAND ROVER DISCOVERY IV VAN (L319)
 LAND ROVER RANGE ROVER SPORT (LS_)

500227T

APPLICATION

WHEEL SIDE

Ø = 27 mm

Ø = 89 mm

H = 125 mm



LAND ROVER
LAND ROVER
LAND ROVER

DISCOVERY III (L319)
DISCOVERY IV (L319)
RANGE ROVER SPORT
(LS_)

500574T

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 80 mm

H = 122 mm



LAND ROVER
LAND ROVER
LAND ROVER
LAND ROVER

DISCOVERY III (L319)
DISCOVERY IV (L319)
FREELANDER 2 (LF_)
RANGE ROVER SPORT
(LS_)

500573T

APPLICATION

WHEEL SIDE

Ø = 30,5 mm

Ø = 104 mm

H = 107 mm



LAND ROVER
LAND ROVER

LAND ROVER
LAND ROVER

LAND ROVER
LAND ROVER

LAND ROVER

LAND ROVER

DISCOVERY III (L319)
DISCOVERY III VAN
(L319)
DISCOVERY IV (L319)
DISCOVERY IV VAN
(L319)
RANGE ROVER III (LM_)
RANGE ROVER Mk III
(LM_)
RANGE ROVER SPORT
(L320)
RANGE ROVER SPORT
(LS_)

500396T

APPLICATION

BOX SIDE

Ø = 47,7 mm

Ø = 103,65 mm

H = 124,25 mm



LAND ROVER
LAND ROVER

LAND ROVER

RANGE ROVER III (LM_)
RANGE ROVER Mk III
(LM_)
RANGE ROVER SPORT
(LS_)

500501

APPLICATION

BOX SIDE
 $\varnothing = 18,75 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 90 \text{ mm}$



TOYOTA
 TOYOTA

AVENSIS (_T22_)
 AVENSIS VERSO (_M2_)

500428

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59,25 \text{ mm}$
 $H = 90 \text{ mm}$



TOYOTA
 TOYOTA

AYGO (_B1_)
 YARIS (_P9_)

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA

AVENSIS (_T22_)
 COROLLA (_E11_)
 PICNIC (CXM1_,
 SXM1_)

500199

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



TOYOTA

YARIS (_P1_)

500266

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



TOYOTA

YARIS (_P1_)

500619T

APPLICATION

WHEEL SIDE
 $\varnothing = 19,8 \text{ mm}$
 $\varnothing = 67,6 \text{ mm}$
 $H = 98,2 \text{ mm}$



TOYOTA
 TOYOTA

AYGO (_B1_)
 YARIS (_P9_)

500414

APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

AURIS (_E15_)
 AVENSIS (_T22_)
 AVENSIS (_T25_)
 COROLLA (_E12_)
 COROLLA (E14_, E15_)

500607

APPLICATION

BOX SIDE
 $\varnothing = 20,8 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 81 \text{ mm}$



TOYOTA

YARIS (_P1_)

500218

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 86 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

PASEO (EL54_)
 TERCEL (_L5_)
 VIOS/YARIS (_P9_)
 YARIS (_P1_)
 YARIS VERSO (_P2_)

500270

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 84 \text{ mm}$



TOYOTA

AVENSIS (_T22_)

500281

APPLICATION

BOX SIDE
 $\varnothing = 21$ mm
 $\varnothing = 80$ mm
H = 89 mm



TOYOTA

AVENSIS (_T22_)

500620T

APPLICATION

WHEEL SIDE
 $\varnothing = 21,2$ mm
 $\varnothing = 70$ mm
H = 97 mm

TOYOTA
TOYOTAAYGO (_B1_)
IQ (_J1_)

500388

APPLICATION

BOX SIDE
 $\varnothing = 21,45$ mm
 $\varnothing = 76,5$ mm
H = 92,75 mm

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTAPRIUS (_W2_)
URBAN CRUISER (_P1_)
VERSO S (_P12_)
VIOS/YARIS (_P9_)
YARIS (_P1_)
YARIS VERSO (_P2_)

500351

APPLICATION

WHEEL SIDE
 $\varnothing = 21,55$ mm
 $\varnothing = 76$ mm
H = 85,8 mm

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTACARINA II (_T15_)
CELICA (_A4_, _A6_)
COROLLA (_E11_)
COROLLA (_E7_)
COROLLA (_E7_, T18)
COROLLA (_E8_)
COROLLA (AE86)
RAV 4 II (_A2_)
STARLET (_P7_)

TOYOTA

STARLET (KP6_)

500364

APPLICATION

BOX SIDE
 $\varnothing = 22$ mm
 $\varnothing = 66$ mm
H = 94 mm

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTACARINA II (_T15_)
CELICA (_A4_, _A6_)
CELICA (_T16_)
COROLLA (_E7_)
COROLLA (_E7_, T18)
COROLLA (_E8_)
COROLLA (_E9_)
COROLLA (AE86)
COROLLA FX (E8B)

TOYOTA

STARLET (_P7_)

500532

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 80 \text{ mm}$



TOYOTA
 TOYOTA

COROLLA (_E12_)
 COROLLA (R1_, ZER_,
 ZZE12_)

500359

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 86 \text{ mm}$



TOYOTA
 TOYOTA

AVENSIS (_T22_)
 COROLLA (R1_, ZER_,
 ZZE12_)

500362

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 87 \text{ mm}$



TOYOTA
 TOYOTA

AVENSIS (_T22_)
 COROLLA (R1_, ZER_,
 ZZE12_)

500503

APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 96 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA

COROLLA (_E12_)
 MR 2 III (ZZW3_)
 PRIUS (_W1_)

500409T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 114,5 \text{ mm}$



TOYOTA

YARIS (_P9_)

APPLICATION

YARIS (_P1_)

APPLICATION

AVENSIS (_T22_)
AVENSIS (_T25_)
COROLLA (_E11_)
COROLLA (_E12_)
PICNIC (CXM1_,
SXM1_)

APPLICATION

YARIS (_P1_)

APPLICATION

CAMRY (_V2_)
CARINA E (_T19_)
CARINA II (_T17_)
CELICA (_T16_)
CELICA (_T18_)
CELICA (_T20_)
COROLLA (_E10_)
COROLLA (_E10_,
AE102)
COROLLA (_E11_)
COROLLA (_E9_)
MR 2 I (AW1_)
PICNIC (_XM1_)
PICNIC (CXM1_,
SXM1_)
PRIUS (_W1_)
RAV 4 I (_A1_)
STARLET (_P7_)
STARLET (_P8_)

500280

APPLICATION

WHEEL SIDE
 $\varnothing = 22,5 \text{ mm}$
 $\varnothing = 76,5 \text{ mm}$
 $H = 83 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

 TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V2_)
 CARINA E (_T19_)
 CELICA (_T16_)
 COROLLA (_E10_)
 COROLLA (_E10_,
 AE102)
 COROLLA (_E11_)
 COROLLA (_E9_)
 CORONA (_T17_)

TOYOTA
 TOYOTA
 TOYOTA

MR 2 I (AW1_)
 RAV 4 I (_A1_)
 RAV 4 II (_A2_)

500367

APPLICATION

BOX SIDE
 $\varnothing = 22,6 \text{ mm}$
 $\varnothing = 78,5 \text{ mm}$
 $H = 101 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V1_)
 CAMRY (_V2_)
 CELICA (_T18_)
 CELICA (_T20_)
 CORONA (_T1_)
 CORONA (RT1_)

500219

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 96 \text{ mm}$



TOYOTA
 TOYOTA

 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

COROLLA (_E10_)
 COROLLA (_E10_,
 AE102)
 PASEO (EL54_)
 STARLET (_P7_)
 STARLET (_P8_)
 STARLET (_P9_)
 STARLET (KP6_)

500597

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 90 \text{ mm}$



TOYOTA
 TOYOTA

 TOYOTA
 TOYOTA

 TOYOTA
 TOYOTA

AURIS (_E18_)
 AURIS TOURING
 SPORTS (_E18_)
 YARIS (_P13_)
 YARIS (_P13_) | YARIS/
 VITZ
 YARIS (_P9_)
 YARIS/VITZ (_P13_)

500600

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 112 \text{ mm}$



LEXUS	ES (_V6_)	TOYOTA	RAV 4 III (_A3_)
LEXUS	HS (ANF10)	TOYOTA	RAV 4 IV (_A4_)
LEXUS	NX (_Z1_)		
LEXUS	NX (AGZ1_, AYZ1_, ZGZ1_)		
LEXUS	RX (GSU3_, MCU3_, MHU3_)		
TOYOTA	ALPHARD / VELLFIRE (_H2_)		
TOYOTA	AVENSIS VERSO (_M2_)		
TOYOTA	CAMRY (_V3_)		
TOYOTA	CAMRY (_V4_)		
TOYOTA	CAMRY (_V5_)		
TOYOTA	COROLLA (_E12_)		
TOYOTA	HARRIER (_U3_)		
TOYOTA	MARK X ZiO (_A1_)		
TOYOTA	PREVIA (_R3_)		
TOYOTA	PREVIA (_R3_) ESTIMA PREVIA / ESTIMA		
TOYOTA	PREVIA III (_R5_)		
TOYOTA	RAV 4 II (_A2_)		

500531

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 87 \text{ mm}$



TOYOTA	AURIS (_E15_)		
TOYOTA	AURIS (_E18_)		
TOYOTA	AURIS TOURING SPORTS (_E18_)		
TOYOTA	AVENSIS (_T25_)		
TOYOTA	COROLLA (E14_, E15_)		
TOYOTA	COROLLA (R1_, ZER_, ZZE12_)		
TOYOTA	VERSO (_R2_)		

500213

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 97 \text{ mm}$



TOYOTA	CORONA (_T17_)		
--------	----------------	--	--

500528

APPLICATION

BOX SIDE
 $\varnothing = 23,5 \text{ mm}$
 $\varnothing = 66,5 \text{ mm}$
 $H = 95 \text{ mm}$



TOYOTA	AVENSIS (_T27_)		
--------	-----------------	--	--

500133

APPLICATION

BOX SIDE
 Ø = 23,7 mm
 Ø = 71,4 mm
 H = 111 mm



TOYOTA
 TOYOTA

AVENSIS (_T25_)
 COROLLA (_E12_)

500239T

APPLICATION

WHEEL SIDE
 Ø = 24 mm
 Ø = 60 mm
 H = 125 mm



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

AVENSIS (_T22_)
 AVENSIS (_T25_)
 AVENSIS (_T27_)
 COROLLA (_E12_)

500368

APPLICATION

BOX SIDE
 Ø = 24 mm
 Ø = 72 mm
 H = 101 mm



LEXUS
 LEXUS
 LEXUS
 LEXUS
 LEXUS
 TOYOTA
 TOYOTA

ES (_V6_)
 HS (ANF10)
 NX (_Z1_)
 NX (AGZ1_, AYZ1_,
 ZGZ1_)
 RX (GSU3_, MCU3_,
 MHU3_)
 AVENSIS VERSO (_M2_)
 CAMRY (_V3_)

TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 COROLLA (_E12_)
 PREVIA (_R3_)
 RAV 4 II (_A2_)
 RAV 4 III (_A3_)
 RAV 4 IV (_A4_)

500577

APPLICATION

BOX SIDE
 Ø = 24 mm
 Ø = 75 mm
 H = 101 mm



LEXUS

RX (GSU3_, MCU3_,
 MHU3_)

500119

APPLICATION

WHEEL SIDE
 Ø = 24 mm
 Ø = 79 mm
 H = 111 mm



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CARINA E (_T19_)
 CARINA II (_T15_)
 CARINA II (_T17_)
 CELICA (_A6_)
 CELICA (_T16_)
 CELICA (_T18_)
 COROLLA (_E10_)
 COROLLA (_E10_,
 AE102)

TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 COROLLA (_E11_)
 COROLLA (_E8_)
 COROLLA (_E9_)
 COROLLA FX (E8B)
 STARLET (_P8_)
 TERCEL (_L1_, _L2_)
 TERCEL (AL2_)

500544

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 89 \text{ mm}$



TOYOTA

CAMRY (_V2_)

500340T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 105 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA

PRIUS (_W2_)
 YARIS (_P1_)
 YARIS VERSO (_P2_)

500384

APPLICATION

BOX SIDE
 $\varnothing = 24,15 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 93 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

AVENSIS (_T25_)
 AVENSIS (_T27_)
 COROLLA (_E12_)
 COROLLA (R1_, ZER_,
 ZZE12_)
 VERSO (_R2_)

500256

APPLICATION

BOX SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 81,5 \text{ mm}$
 $H = 87 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V1_)
 CAMRY (_V2_)
 CELICA (_T16_)
 MARK II
 PREVIA (_R1_, _R2_)

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



TOYOTA
 TOYOTA

AVENSIS (_T22_)
 AVENSIS (_T25_)

500500T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,6 \text{ mm}$
 $\varnothing = 80,45 \text{ mm}$
 $H = 108,4 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA

AURIS (_E15_)
 AVENSIS (_T27_)
 COROLLA (E14_, E15_)

500404

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 113 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V1_)
 CAMRY (_V2_)
 CARINA II (_T15_)
 CELICA (_A4_, _A6_)
 COROLLA (_E7_)
 MR 2 I (AW1_)
 TERCEL (AL2_)

500385

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 77,5 \text{ mm}$
 $H = 90 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V1_)
 CARINA II (_T15_)
 COROLLA (_E7_)

500511T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 110 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

COROLLA (_E12_)
 COROLLA (E14_, E15_)
 MR 2 III (ZZW3_)
 PRIUS (_W1_)

500232T

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 138 \text{ mm}$



TOYOTA

CARINA E (_T19_)

500410

APPLICATION

BOX SIDE
 $\varnothing = 25,5 \text{ mm}$
 $\varnothing = 76,5 \text{ mm}$
 $H = 89 \text{ mm}$



LEXUS
 TOYOTA

RX (GSU3_, MCU3_,
 MHU3_)
 HARRIER (_U3_)

500386

APPLICATION

WHEEL SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 88,2 \text{ mm}$
 $H = 95 \text{ mm}$



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V1_)
 CAMRY (_V2_)
 CELICA (_T16_)
 CELICA (_T18_)
 CELICA (_T20_)
 MR 2 II (SW2_)
 SUPRA (_A8_)

500106

APPLICATION

WHEEL SIDE
 $\varnothing = 26,8 \text{ mm}$
 $\varnothing = 90 \text{ mm}$
 $H = 108 \text{ mm}$



TOYOTA

COROLLA (_E9_)

500346

APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 86 \text{ mm}$
 $H = 95 \text{ mm}$



TOYOTA
 TOYOTA

 TOYOTA
 TOYOTA

 TOYOTA
 TOYOTA

CAMRY (_V2_)
 HIACE II (LH5_, LH6_,
 LH7_, YH5_, YH6_,
 YH7_)
 HIACE IV (_H1_, _H2_)
 HIACE IV (LH1_, LXH1_,
 RZH1_)
 HILUX VI (_N1_)
 LITEACE (_R2__V)

TOYOTA

 TOYOTA

LITEACE (CM3_V,
 KM3_V)
 LITEACE (CM30_G,
 KM30_G)

500234T

APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 123 \text{ mm}$



LEXUS
 TOYOTA
 TOYOTA

RX (MCU15)
 CELICA (_T23_)
 COROLLA (_E11_)

500343T

APPLICATION

WHEEL SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 90 \text{ mm}$
 $H = 115 \text{ mm}$



LEXUS

LEXUS
LEXUSTOYOTA
TOYOTA
TOYOTA
TOYOTA

ES (ASV60_, AVV60_,
 GSV60_)
 HS (ANF10)
 RX (GSU3_, MCU3_,
 MHU3_)
 AVENSIS VERSO (_M2_)
 CAMRY (_V3_)
 CAMRY (_V4_)
 CAMRY (_V5_)

TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

COROLLA (_E12_)
 HARRIER (_U3_)
 PREVIA (_R3_)
 PREVIA III (_R5_)
 RAV 4 II (_A2_)
 RAV 4 III (_A3_)
 RAV 4 IV (_A4_)

500220

APPLICATION

BOX SIDE
 $\emptyset = 27,15 \text{ mm}$
 $\emptyset = 95,2 \text{ mm}$
 $H = 118 \text{ mm}$

LEXUS
TOYOTA
TOYOTATOYOTA
TOYOTA

LX (UZJ100)
 HIACE IV (_H1_, _H2_)
 HIACE IV (LH1_, LXH1_,
 RZH1_)
 LAND CRUISER (_J7_)
 LAND CRUISER (BJ7_,
 HZJ7_, KZJ7_, LJ7_,
 PZJ7_, RJ7_)

TOYOTA
 TOYOTA
 TOYOTA

LAND CRUISER 100
 (FZJ1_, UZJ1_)
 LAND CRUISER 80
 (_J8_)
 LAND CRUISER 90
 (_J9_)

500542

APPLICATION

BOX SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 80 \text{ mm}$
 $H = 113 \text{ mm}$

LEXUS
TOYOTA
TOYOTA

GX (_J12_)
 FJ CRUISER (GSJ1_)
 LAND CRUISER
 (GRJ12_, KDJ12_,
 KZJ12_, LJ12_,
 TRJ12_)

500031

APPLICATION

WHEEL SIDE
 $\emptyset = 27,5 \text{ mm}$
 $\emptyset = 85 \text{ mm}$
 $H = 97 \text{ mm}$

TOYOTA
TOYOTA
TOYOTA

CAMRY (_V1_)
 CAMRY (_V2_)
 CELICA (_T16_)

500497T

APPLICATION

WHEEL SIDE
 $\emptyset = 30,5 \text{ mm}$
 $\emptyset = 93,5 \text{ mm}$
 $H = 120 \text{ mm}$

TOYOTA
TOYOTA
TOYOTA
TOYOTA

AVENSIS VERSO (_M2_)
 CAMRY (_V3_)
 RAV 4 III (_A3_)
 RAV 4 IV (_A4_)

500629T

APPLICATION

WHEEL SIDE
 $\emptyset = 31 \text{ mm}$
 $\emptyset = 104 \text{ mm}$
 $H = 129 \text{ mm}$



LEXUS
 LEXUS
 TOYOTA
 TOYOTA
 TOYOTA

GX (_J12_)
 GX (URJ15_)
 FJ CRUISER (GSJ1_)
 HILUX VII (_N1_, _N2_,
 N3)
 LAND CRUISER (_J12_)

TOYOTA
 TOYOTA

LAND CRUISER
 (GRJ12_, KDJ12_,
 KZJ12_, LJ12_,
 TRJ12_)
 LAND CRUISER 150
 (GDJ15_, GRJ15_,
 KDJ15_, TRJ15_)

500228T

APPLICATION

WHEEL SIDE
 $\emptyset = 31 \text{ mm}$
 $\emptyset = 110 \text{ mm}$
 $H = 138 \text{ mm}$



LEXUS
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

LX (UZJ100)
 LAND CRUISER (_J7_)
 LAND CRUISER (BJ7_,
 HZJ7_, KZJ7_, LJ7_,
 PZJ7_, RJ7_)
 LAND CRUISER 100
 (FZJ1_, UZJ1_)
 LAND CRUISER 80
 (_J8_)

TOYOTA

LAND CRUISER 90
 (_J9_)

500403T

APPLICATION

BOX SIDE
 $\emptyset = 32,05 \text{ mm}$
 $\emptyset = 70,05 \text{ mm}$
 $H = 112,55 \text{ mm}$



LEXUS
 LEXUS
 LEXUS
 LEXUS
 LEXUS

GS (JZS147_)
 GS (JZS160_, UZS160_,
 UZS161_)
 LS (UCF10)
 LS (UCF20)
 LS (UCF30)

APPLICATION

WHEEL SIDE

 $\varnothing = 17 \text{ mm}$ $\varnothing = 59 \text{ mm}$

H = 78 mm



LIGIER

AMBRA

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



MAZDA

2 (DY)

500174

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 87 \text{ mm}$



MAZDA
 MAZDA
 MAZDA
 MAZDA

121 II (DB)
 323 III (BF)
 323 S IV (BG)
 DEMIO (DW)

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



MAZDA

2 (DY)

500534

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 88 \text{ mm}$



MAZDA
 MAZDA

3 (BK)
 3 (BL)

500199

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



MAZDA

121 I (DA)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



MAZDA	323 C V (BA)
MAZDA	323 F V (BA)
MAZDA	323 F VI (BJ)
MAZDA	323 S V (BA)
MAZDA	626 III (GD)
MAZDA	626 III (GV)
MAZDA	DEMIO (DW)
MAZDA	PREMACY (CP) MPV

500198

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



MAZDA	121 II (DB)
MAZDA	MX-3 (EC)

500064

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 79,5 \text{ mm}$
 $H = 112 \text{ mm}$



MAZDA	121 III (JASM, JBSM)
-------	----------------------

500109

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



MAZDA	121 III (JASM, JBSM)
-------	----------------------

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



MAZDA	121 I (DA)	MAZDA	626 II (GC)
MAZDA	323 C IV (BG)	MAZDA	626 III (GD)
MAZDA	323 C V (BA)	MAZDA	626 III (GV)
MAZDA	323 F IV (BG)	MAZDA	E-SERIE (SR1)
MAZDA	323 F V (BA)	MAZDA	MX-3 (EC)
MAZDA	323 II (BD)	MAZDA	XEDOS 6 (CA)
MAZDA	323 III (BF)		
MAZDA	323 III (BW)		
MAZDA	323 S IV (BG)		

500489

APPLICATION

BOX SIDE
 $\varnothing = 20,5 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 90 \text{ mm}$



MAZDA	323 F IV (BG)
MAZDA	323 II (BD)
MAZDA	323 III (BF)
MAZDA	323 III (BW)
MAZDA	626 III (GD)

500546

APPLICATION

BOX SIDE
 $\varnothing = 20,5 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 91 \text{ mm}$



MAZDA	3 (BK)
MAZDA	3 (BL)

500169

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 92 \text{ mm}$



MAZDA	323 III (BF)
MAZDA	323 III (BW)
MAZDA	XEDOS 6 (CA)

500173

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 93 \text{ mm}$



MAZDA	323 C V (BA)
MAZDA	323 F V (BA)
MAZDA	323 F VI (BJ)
MAZDA	323 P V (BA)
MAZDA	323 S V (BA)
MAZDA	323 S VI (BJ)
MAZDA	5 (CR19) MPV
MAZDA	PREMACY (CP) MPV

500176

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 91 \text{ mm}$



MAZDA	626 V (GF)
-------	------------

500319

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 101 \text{ mm}$



MAZDA

121 III (JASM, JBSM)

500093

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 84 \text{ mm}$



MAZDA

2 (DY)

500116

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 88 \text{ mm}$

MAZDA
MAZDAMX-3 (EC)
XEDOS 6 (CA)

500523

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 94,5 \text{ mm}$

MAZDA
MAZDA3 (BK)
5 (CR19) MPV

500207

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 71,5 \text{ mm}$
 $H = 90 \text{ mm}$

MAZDA
MAZDA
MAZDA323 I (FA)
323 II (BD)
323 III (BF)

500195

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$



MAZDA	323 III (BF)
MAZDA	323 III (BW)
MAZDA	323 S IV (BG)
MAZDA	6 (GG)
MAZDA	6 (GY)
MAZDA	MX-5 I (NA)
MAZDA	MX-5 II (NB)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



MAZDA	121 I (DA)
MAZDA	323 C IV (BG)
MAZDA	323 C V (BA)
MAZDA	323 F IV (BG)
MAZDA	323 F V (BA)
MAZDA	323 III (BF)
MAZDA	323 III (BW)
MAZDA	323 S IV (BG)
MAZDA	323 S V (BA)

500345

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 69 \text{ mm}$



MAZDA	323 C V (BA)
MAZDA	323 F VI (BJ)
MAZDA	323 S VI (BJ)

500069

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 81,8 \text{ mm}$
 $H = 92,3 \text{ mm}$



MAZDA	626 III (GD)
MAZDA	626 III (GV)
MAZDA	626 IV (GE)
MAZDA	626 V (GF)
MAZDA	626 V (GW)
MAZDA	E-SERIE (SR1)
MAZDA	MPV II (LW) MPV
MAZDA	PREMACY (CP) MPV
MAZDA	XEDOS 6 (CA)

500037

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



MAZDA	626 III (GD)
MAZDA	626 III (GV)
MAZDA	626 IV (GE)

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 74 mm
H = 100 mm



MAZDA

MX-5 II (NB)

500025

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77 mm
H = 103 mm



MAZDA

121 III (JASM, JBSM)

500025E

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77 mm
H = 103 mm



MAZDA

121 III (JASM, JBSM)

500285T

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77,4 mm
H = 116,5 mm



MAZDA
MAZDA
MAZDA

323 F VI (BJ)
323 S VI (BJ)
PREMACY (CP) MPV

500366

APPLICATION

BOX SIDE
Ø = 23 mm
Ø = 66 mm
H = 98 mm



MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA

323 C V (BA)
323 F V (BA)
323 S IV (BG)
626 II (GC)
626 III (GD)
626 III (GV)
MPV II (LW) MPV
MX-3 (EC)

500506
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 72,75 \text{ mm}$
 $H = 92,5 \text{ mm}$



MAZDA 2 (DE)
 MAZDA 3 (BM)
 MAZDA 323 F VI (BJ)
 MAZDA 323 S VI (BJ)
 MAZDA 6 (GG)
 MAZDA 6 (GH)
 MAZDA 6 (GH, GJ)
 MAZDA 6 (GJ, GL)
 MAZDA 6 (GY)

MAZDA 626 II (GC)
 MAZDA 626 III (GD)
 MAZDA 626 III (GV)
 MAZDA 626 IV (GE)
 MAZDA 626 V (GF)
 MAZDA 626 V (GW)
 MAZDA E-SERIE (SR2)
 MAZDA PREMACY (CP) MPV
 MAZDA XEDOS 6 (CA)

500513
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 92 \text{ mm}$



MAZDA 6 (GH)
 MAZDA 626 V (GF)
 MAZDA 626 V (GW)

500421
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 75,44 \text{ mm}$
 $H = 95 \text{ mm}$



MAZDA 6 (GG)
 MAZDA 6 (GH)
 MAZDA 6 (GY)
 MAZDA CX-7 (ER)

500557T
APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 105 \text{ mm}$



MAZDA 3 (BK)

500166T
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 58 \text{ mm}$
 $H = 107 \text{ mm}$



MAZDA 121 III (JASM, JBSM)

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 79 mm
H = 135 mm



MAZDA
MAZDA

626 V (GF)
626 V (GW)

500565T

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 81 mm
H = 97 mm



MAZDA
MAZDA

626 V (GF)
626 V (GW)

500257

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 83 mm
H = 101 mm



MAZDA
MAZDA
MAZDA

323 F V (BA)
B-SERIE (UF)
B-SERIE (UN)

500178

APPLICATION

BOX SIDE
Ø = 24,5 mm
Ø = 76 mm
H = 103 mm



MAZDA

MX-6 (GE)

500256

APPLICATION

BOX SIDE
Ø = 24,5 mm
Ø = 81,5 mm
H = 87 mm



MAZDA
MAZDA
MAZDA
MAZDA

323 III (BF)
323 III (BW)
626 II (GC)
626 III (GV)

APPLICATION

WHEEL SIDE
Ø = 24,5 mm
Ø = 83 mm
H = 120 mm



MAZDA

TRIBUTE (EP) Closed

500394

APPLICATION

BOX SIDE
Ø = 24,55 mm
Ø = 81,75 mm
H = 81,5 mm



MAZDA
MAZDA
MAZDA
MAZDA

6 (GG)
6 (GY)
626 III (GD)
626 III (GV)

500500T

APPLICATION

WHEEL SIDE
Ø = 24,6 mm
Ø = 80,45 mm
H = 108,4 mm



MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA

3 (BK)
3 (BL)
5 (CR19) MPV
5 (CW) MPV
6 (GH, GJ)
6 (GJ, GL)
CX-5 (GH, KE)
CX-5 (KE, GH)

500337T

APPLICATION

WHEEL SIDE
Ø = 25 mm
Ø = 81 mm
H = 127 mm



MAZDA

XEDOS 9 (TA)

500548

APPLICATION

BOX SIDE
Ø = 25,5 mm
Ø = 85,5 mm
H = 94 mm



MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA

3 (BM)
6 (GG)
6 (GH)
6 (GH, GJ)
6 (GY)
CX-7 (ER)

APPLICATION

WHEEL SIDE
Ø = 25,6 mm
Ø = 77,15 mm
H = 117,25 mm



MAZDA 2 (DE)
MAZDA 6 (GG)
MAZDA 6 (GH)
MAZDA 6 (GY)

500347

APPLICATION

BOX SIDE
Ø = 25,85 mm
Ø = 84 mm
H = 100 mm



MAZDA MPV II (LW) MPV

500390T

APPLICATION

WHEEL SIDE
Ø = 26,6 mm
Ø = 80,2 mm
H = 109,5 mm



MAZDA 6 (GG)
MAZDA 6 (GH)
MAZDA 6 (GH, GJ)
MAZDA 6 (GJ, GL)
MAZDA 6 (GY)

500106

APPLICATION

WHEEL SIDE
Ø = 26,8 mm
Ø = 90 mm
H = 108 mm



MAZDA MPV II (LW) MPV

500234T

APPLICATION

WHEEL SIDE
Ø = 27 mm
Ø = 87 mm
H = 123 mm



MAZDA 626 V (GF)
MAZDA 626 V (GW)
MAZDA MPV II (LW) MPV

APPLICATION

WHEEL SIDE
Ø = 27 mm
Ø = 89 mm
H = 125 mm



MAZDA B-SERIE (UN)

500341T

APPLICATION

WHEEL SIDE
Ø = 27,5 mm
Ø = 84 mm
H = 116 mm



MAZDA RX 8 (SE17)
MAZDA RX-8 (SE, FE)

500031

APPLICATION

WHEEL SIDE
Ø = 27,5 mm
Ø = 85 mm
H = 97 mm



MAZDA 626 II (GC)
MAZDA 626 III (GD)
MAZDA 626 III (GV)
MAZDA 626 IV (GE)
MAZDA MX-6 (GE)
MAZDA XEDOS 6 (CA)

500321T

APPLICATION

WHEEL SIDE
Ø = 28 mm
Ø = 92 mm
H = 123 mm



MAZDA MPV II (LW) MPV

500481

APPLICATION

WHEEL SIDE
Ø = 29 mm
Ø = 87,5 mm
H = 110 mm



MAZDA 6 (GH)

APPLICATION

WHEEL SIDE
Ø = 31 mm
Ø = 74 mm
H = 111 mm



MAZDA
MAZDA

2 (DE)
2 (DY)

500132
APPLICATION

BOX SIDE


 MERCEDES-BENZ SPRINTER 3-t (903)
 MERCEDES-BENZ SPRINTER 4-t (904)
 MERCEDES-BENZ VITO (W639)

500050
APPLICATION

WHEEL SIDE

 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$

 MERCEDES-BENZ E-CLASS (S210)
 MERCEDES-BENZ E-CLASS (W210)

500050E
APPLICATION

WHEEL SIDE

 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$

 MERCEDES-BENZ E-CLASS (S210)
 MERCEDES-BENZ E-CLASS (W210)

500260
APPLICATION

BOX SIDE

 $\varnothing = 22 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 96 \text{ mm}$

 MERCEDES-BENZ 124 Coupé (C124)
 MERCEDES-BENZ 124 Saloon (W124)
 MERCEDES-BENZ 190 (W201)
 MERCEDES-BENZ C-CLASS (W202)
 MERCEDES-BENZ E-CLASS (A124)
 MERCEDES-BENZ E-CLASS (C124)
 MERCEDES-BENZ E-CLASS (S124)
 MERCEDES-BENZ E-CLASS (W124)
 MERCEDES-BENZ E-CLASS (W210)
 MERCEDES-BENZ KOMBI (S124)
 MERCEDES-BENZ S-CLASS (C126)
 MERCEDES-BENZ S-CLASS (C140)
 MERCEDES-BENZ S-CLASS (W116)
 MERCEDES-BENZ S-CLASS (W126)
 MERCEDES-BENZ S-CLASS (W140)
 MERCEDES-BENZ SL (R107)
 MERCEDES-BENZ SL (R129)

500477
APPLICATION

WHEEL SIDE
 $\varnothing = 22,5 \text{ mm}$
 $\varnothing = 56,7 \text{ mm}$
 $H = 100 \text{ mm}$



MERCEDES-BENZ 190 (W201)

500188
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 113 \text{ mm}$



MERCEDES-BENZ SPRINTER 2-t (901, 902)
 MERCEDES-BENZ SPRINTER 3-t (903)
 MERCEDES-BENZ SPRINTER 4-t (904)
 MERCEDES-BENZ V-CLASS (638/2)
 MERCEDES-BENZ VITO (638)

500010
APPLICATION

BOX SIDE
 $\varnothing = 23,15 \text{ mm}$
 $\varnothing = 56 \text{ mm}$
 $H = 100 \text{ mm}$



MERCEDES-BENZ /8 (W114)
 MERCEDES-BENZ /8 (W115)
 MERCEDES-BENZ 123 Saloon (W123)
 MERCEDES-BENZ 124 Coupé (C124)
 MERCEDES-BENZ 124 Saloon (W124)
 MERCEDES-BENZ 190 (W201)
 MERCEDES-BENZ C-CLASS (W202)
 MERCEDES-BENZ E-CLASS (W210)
 MERCEDES-BENZ KOMBI (S124)

MERCEDES-BENZ S-CLASS (W116)

500627T
APPLICATION

BOX SIDE
 $\varnothing = 23,5 \text{ mm}$
 $\varnothing = 85,8 \text{ mm}$
 $H = 97,8 \text{ mm}$



MERCEDES-BENZ GL-CLASS (X164)
 MERCEDES-BENZ M-CLASS (W164)

500278
APPLICATION
WHEEL SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 60 \text{ mm}$
 $H = 98 \text{ mm}$


MERCEDES-BENZ C-CLASS (CL203)
 MERCEDES-BENZ C-CLASS (S202)
 MERCEDES-BENZ C-CLASS (S203)
 MERCEDES-BENZ C-CLASS (W202)
 MERCEDES-BENZ C-CLASS (W203)
 MERCEDES-BENZ CLK (A208)
 MERCEDES-BENZ CLK (C208)
 MERCEDES-BENZ E-CLASS (A124)
 MERCEDES-BENZ E-CLASS (S210)
 MERCEDES-BENZ E-CLASS (W210)
 MERCEDES-BENZ S-CLASS (C140)
 MERCEDES-BENZ S-CLASS (W140)
 MERCEDES-BENZ S-CLASS (W220)
 MERCEDES-BENZ SL (R129)
 MERCEDES-BENZ SLK (R170)

500102
APPLICATION
WHEEL SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 93 \text{ mm}$
 $H = 127 \text{ mm}$


MERCEDES-BENZ 100 (631)

500447
APPLICATION
BOX SIDE
 $\emptyset = 24,64 \text{ mm}$
 $\emptyset = 64 \text{ mm}$
 $H = 98 \text{ mm}$


MERCEDES-BENZ V-CLASS (638/2)
 MERCEDES-BENZ VITO (638)

500089
APPLICATION
BOX SIDE
 $\emptyset = 25 \text{ mm}$
 $\emptyset = 57 \text{ mm}$
 $H = 99 \text{ mm}$


MERCEDES-BENZ V-CLASS (638/2)
 MERCEDES-BENZ VITO (638)

500261
APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 90 \text{ mm}$



MERCEDES-BENZ /8 (W114)
 MERCEDES-BENZ /8 (W115)
 MERCEDES-BENZ 123 Coupé (C123)
 MERCEDES-BENZ 123 Saloon (W123)
 MERCEDES-BENZ KOMBI (S123)
 MERCEDES-BENZ S-CLASS (W116)
 MERCEDES-BENZ S-CLASS (W126)
 MERCEDES-BENZ SL (C107)
 MERCEDES-BENZ SL (R107)

500326
APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 90 \text{ mm}$



MERCEDES-BENZ S-CLASS (W126)
 MERCEDES-BENZ SL (R107)

500442
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 109 \text{ mm}$



MERCEDES-BENZ A-CLASS (W169)
 MERCEDES-BENZ B-CLASS (W245)

500363
APPLICATION

BOX SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 124 \text{ mm}$



MERCEDES-BENZ 100 (631)

500402T
APPLICATION

BOX SIDE
 $\varnothing = 26,65 \text{ mm}$
 $\varnothing = 70,05 \text{ mm}$
 $H = 112,55 \text{ mm}$



MERCEDES-BENZ A-CLASS (W168)
 MERCEDES-BENZ Vaneo (414)

500011T
APPLICATION

WHEEL SIDE
 $\varnothing = 27,2 \text{ mm}$
 $\varnothing = 98,1 \text{ mm}$
 $H = 144,5 \text{ mm}$



MERCEDES-BENZ SPRINTER 2-t (901, 902)
 MERCEDES-BENZ SPRINTER 3-t (903)
 MERCEDES-BENZ SPRINTER 4-t (904)
 MERCEDES-BENZ V-CLASS (638/2)
 MERCEDES-BENZ VITO (638)

500540T
APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 123 \text{ mm}$



MERCEDES-BENZ M-CLASS (W163)

500321T
APPLICATION

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 123 \text{ mm}$



MERCEDES-BENZ M-CLASS (W163)

500259
APPLICATION

BOX SIDE
 $\varnothing = 29 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 97 \text{ mm}$



MERCEDES-BENZ 124 Saloon (W124)
 MERCEDES-BENZ E-CLASS (A124)
 MERCEDES-BENZ E-CLASS (C124)
 MERCEDES-BENZ E-CLASS (W124)
 MERCEDES-BENZ S-CLASS (C140)
 MERCEDES-BENZ S-CLASS (W140)
 MERCEDES-BENZ SL (R129)

500558T
APPLICATION

WHEEL SIDE
 $\varnothing = 29,75 \text{ mm}$
 $\varnothing = 95,5 \text{ mm}$
 $H = 125 \text{ mm}$



MERCEDES-BENZ M-CLASS (W164)
 MERCEDES-BENZ R-CLASS (V251, W251)

500616T
APPLICATION

BOX SIDE
 $\varnothing = 29,8 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 110,8 \text{ mm}$



MERCEDES-BENZ A-CLASS (W169)
 MERCEDES-BENZ B-CLASS (W245)
 MERCEDES-BENZ S-CLASS (W221)

500214
APPLICATION

WHEEL SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 98 \text{ mm}$



MERCEDES-BENZ C-CLASS (S203)
 MERCEDES-BENZ CLK (C208)
 MERCEDES-BENZ E-CLASS (W210)
 MERCEDES-BENZ S-CLASS (C215)
 MERCEDES-BENZ S-CLASS (W220)
 MERCEDES-BENZ SLK (R170)

500521T
APPLICATION

BOX SIDE
 $\varnothing = 30,6 \text{ mm}$
 $\varnothing = 64,8 \text{ mm}$
 $H = 77,4 \text{ mm}$



MERCEDES-BENZ C-CLASS (C204)	MERCEDES-BENZ SL (R230)
MERCEDES-BENZ C-CLASS (CL203)	MERCEDES-BENZ SL (R231)
MERCEDES-BENZ C-CLASS (S203)	MERCEDES-BENZ SLK (R171)
MERCEDES-BENZ C-CLASS (S204)	MERCEDES-BENZ SLK (R172)
MERCEDES-BENZ C-CLASS (S205)	
MERCEDES-BENZ C-CLASS (W203)	
MERCEDES-BENZ C-CLASS (W204)	
MERCEDES-BENZ C-CLASS (W205)	
MERCEDES-BENZ CLC-CLASS (CL203)	
MERCEDES-BENZ CLS (C218)	
MERCEDES-BENZ CLS (C219)	
MERCEDES-BENZ CLS (X218)	
MERCEDES-BENZ E-CLASS (A207)	
MERCEDES-BENZ E-CLASS (C207)	
MERCEDES-BENZ E-CLASS (S211)	
MERCEDES-BENZ E-CLASS (S212)	
MERCEDES-BENZ E-CLASS (W211)	
MERCEDES-BENZ E-CLASS (W212)	
MERCEDES-BENZ GLK-CLASS (X204)	
MERCEDES-BENZ M-CLASS (W166)	
MERCEDES-BENZ S-CLASS (W221)	

500274
APPLICATION

BOX SIDE
 $\varnothing = 31 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 100 \text{ mm}$



MERCEDES-BENZ C-CLASS (S203)
 MERCEDES-BENZ C-CLASS (W203)
 MERCEDES-BENZ CLK (A208)
 MERCEDES-BENZ CLK (C208)
 MERCEDES-BENZ S-CLASS (C215)
 MERCEDES-BENZ S-CLASS (W220)
 MERCEDES-BENZ SLK (R170)

500230T
APPLICATION

WHEEL SIDE
 $\varnothing = 32 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 109 \text{ mm}$



MERCEDES-BENZ A-CLASS (W168)

500403T
APPLICATION

BOX SIDE
 $\varnothing = 32,05 \text{ mm}$
 $\varnothing = 70,05 \text{ mm}$
 $H = 112,55 \text{ mm}$



MERCEDES-BENZ A-CLASS (W168)
 MERCEDES-BENZ A-CLASS (W169)
 MERCEDES-BENZ B-CLASS (W245)
 MERCEDES-BENZ Vaneo (414)

500561T
APPLICATION

WHEEL SIDE
 $\varnothing = 33 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 76,5 \text{ mm}$



MERCEDES-BENZ A-CLASS (W176)	MERCEDES-BENZ SL (R230)
MERCEDES-BENZ C-CLASS (C204)	MERCEDES-BENZ SL (R231)
MERCEDES-BENZ C-CLASS (CL203)	MERCEDES-BENZ SLC (R172)
MERCEDES-BENZ C-CLASS (S202)	MERCEDES-BENZ SLK (R170)
MERCEDES-BENZ C-CLASS (S203)	MERCEDES-BENZ SLK (R171)
MERCEDES-BENZ C-CLASS (S204)	MERCEDES-BENZ SLK (R172)
MERCEDES-BENZ C-CLASS (S205)	
MERCEDES-BENZ C-CLASS (W202)	
MERCEDES-BENZ C-CLASS (W203)	
MERCEDES-BENZ C-CLASS (W204)	
MERCEDES-BENZ C-CLASS (W205)	
MERCEDES-BENZ CLA (C117)	
MERCEDES-BENZ CLC-CLASS (CL203)	
MERCEDES-BENZ CLK (A208)	
MERCEDES-BENZ CLK (C208)	
MERCEDES-BENZ CLS (C218)	
MERCEDES-BENZ CLS (C219)	
MERCEDES-BENZ CLS (X218)	
MERCEDES-BENZ E-CLASS (A124)	
MERCEDES-BENZ E-CLASS (A207)	
MERCEDES-BENZ E-CLASS (C207)	
MERCEDES-BENZ E-CLASS (S210)	
MERCEDES-BENZ E-CLASS (S211)	
MERCEDES-BENZ E-CLASS (S212)	
MERCEDES-BENZ E-CLASS (W210)	
MERCEDES-BENZ E-CLASS (W211)	
MERCEDES-BENZ E-CLASS (W212)	
MERCEDES-BENZ GLA-CLASS (X156)	
MERCEDES-BENZ GLK-CLASS (X204)	
MERCEDES-BENZ M-CLASS (W166)	
MERCEDES-BENZ S-CLASS (W140)	
MERCEDES-BENZ S-CLASS (W220)	
MERCEDES-BENZ S-CLASS (W221)	
MERCEDES-BENZ SL (R129)	

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



MG

MG ZR

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



MG

MG ZR

500414

APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



MG

MG ZT

500255

APPLICATION

WHEEL SIDE
 $\varnothing = 20,5 \text{ mm}$
 $\varnothing = 84,8 \text{ mm}$
 $H = 106 \text{ mm}$

MG
MGMG ZR
MG ZS

500205

APPLICATION

WHEEL SIDE
 $\varnothing = 20,9 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 92 \text{ mm}$

MG
MG
MG
MGMG TF
MG ZR
MG ZS
MGF (RD)

500292

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



MG
 MG

MG ZS
 MG ZT

500270

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 84 \text{ mm}$



MG
 MG

MG ZR
 MG ZS

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



MG

MG ZT

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



MG

MG ZT

500518
APPLICATION

BOX SIDE



MITSUBISHI

CARISMA (DA_)

500174
APPLICATION

BOX SIDE

 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 87 \text{ mm}$


MITSUBISHI

 PAJERO II (NH, NJ, NK,
NL, V2_W, V3_W, V4_W)

500428
APPLICATION

BOX SIDE

 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59,25 \text{ mm}$
 $H = 90 \text{ mm}$

 MITSUBISHI
MITSUBISHI

 COLT CZC (RG)
COLT VI (RG, Z2_A,
Z3_A)

500170
APPLICATION

BOX SIDE

 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$


MITSUBISHI

SPACE STAR (DG_A)

500199
APPLICATION

BOX SIDE

 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$

 MITSUBISHI
MITSUBISHI

 COLT IV (CA_A)
LANCER V (CB/D_A, CC)

500266
APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



MITSUBISHI

MINICA (H2_)

500041
APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



MITSUBISHI

MINICA (H2_)

500414
APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$


 MITSUBISHI
 MITSUBISHI

 CARISMA (DA_)
 SPACE STAR (DG_A)

500273
APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 93 \text{ mm}$


 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

 COLT II (C1_A, RB, RC)
 COLT III (C5_A, RD, RE)
 COLT IV (CA_A)
 GALANT III (E1_A)
 LANCER III (C1_A,
 C6_A, RD, RE)
 LANCER III (C1_V, C3_V)

500109
APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$


 MITSUBISHI
 MITSUBISHI

 PAJERO I (L04_G)
 PAJERO I (L04_G,
 L14_G, NA, NB, NC, ND,
 NE, NF, NG)

500039
APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

COLT I (A15_A, RA)
 COLT II (C1_A, RB, RC)
 COLT III (C5_A, RD, RE)
 COLT IV (CA_A)
 CORDIA (A21_A, AA, AB)
 GALANT III (E1_A)
 GALANT IV (E3_A, HG, HH)
 LANCER F II (A17_, RC)
 LANCER I (A17_)

MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

LANCER III (C1_A, C6_A, RD, RE)
 LANCER III (C1_V, C3_V)
 LANCER IV (C6_A, C7_A, CA, CB)
 LANCER IV (C6_A, CA, CB)
 LANCER V (CB/D_A, CC)
 TREDIA (A21_)

500169
APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 92 \text{ mm}$



MITSUBISHI
 MITSUBISHI

COLT IV (CA_A)
 LANCER III (C1_V, C3_V)

500207
APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 71,5 \text{ mm}$
 $H = 90 \text{ mm}$



MITSUBISHI
 MITSUBISHI

PAJERO PININ (H6_W, H7_W, QA)
 SPACE WAGON (N8_W, N9_W, UG)

500195
APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$



MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

COLT I (A15_A, RA)
 COLT II (C1_A, RB, RC)
 CORDIA (A21_A, AA, AB)
 LANCER III (C1_A, C6_A, RD, RE)
 LANCER III (C1_V, C3_V)
 LANCER IV (C6_A, C7_A, CA, CB)

MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

LANCER IV (C6_A, CA, CB)
 SAPPORO II (A16_A)
 SPACE RUNNER (N1_W, N2_W)
 TREDIA (A21_)

500283
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

COLT I (A15_A, RA)
 CORDIA (A21_A, AA, AB)
 GALANT III (E1_A)
 LANCER F II (A17_, RC)
 SAPPORO II (A16_A)
 TREDIA (A21_)

500034
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 91 \text{ mm}$



MITSUBISHI CORDIA (A21_A, AA, AB)
 MITSUBISHI GALANT II (A16_)
 MITSUBISHI GALANT II (A16_V)
 MITSUBISHI GALANT III (E1_A)
 MITSUBISHI LANCER F II (A17_, RC)
 MITSUBISHI LANCER I (A17_)
 MITSUBISHI SPACE WAGON (D0_
 V/W, UA, UB, UC)
 MITSUBISHI TREDIA (A21_)

500069
APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 81,8 \text{ mm}$
 $H = 92,3 \text{ mm}$



MITSUBISHI	COLT II (C1_A, RB, RC)	MITSUBISHI	SPACE WAGON (D0_ V/W, UA, UB, UC)
MITSUBISHI	CORDIA (A21_A, AA, AB)	MITSUBISHI	SPACE WAGON (N3_W, N4_W, UF)
MITSUBISHI	GALANT II (A16_)	MITSUBISHI	TREDIA (A21_)
MITSUBISHI	GALANT III (E1_A)		
MITSUBISHI	GALANT IV (E3_A, HG, HH)		
MITSUBISHI	PAJERO PININ (H6_W, H7_W, QA)		
MITSUBISHI	SAPPORO II (A16_A)		

500243T
APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 146 \text{ mm}$



MITSUBISHI CARISMA (DA_)

500200
APPLICATION

WHEEL SIDE
 $\varnothing = 21,9 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 95 \text{ mm}$



MITSUBISHI COLT II (C1_A, RB, RC)
 MITSUBISHI COLT III (C5_A, RD, RE)
 MITSUBISHI COLT V (CJ_, CP_)
 MITSUBISHI GALANT III (E1_A)
 MITSUBISHI GALANT IV (E3_A, HG,
HH)
 MITSUBISHI LANCER IV (C6_A,
C7_A, CA, CB)

500177
APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 65,5 \text{ mm}$
 $H = 91 \text{ mm}$



MITSUBISHI	COLT III (C5_A, RD, RE)	MITSUBISHI	SPACE RUNNER (N1_W, N2_W)
MITSUBISHI	COLT IV (CA_A)	MITSUBISHI	SPACE RUNNER (N6_W)
MITSUBISHI	ECLIPSE II (D3_A)		
MITSUBISHI	ECLIPSE III (D5_A)		
MITSUBISHI	GALANT V (E5_A, E7_A, E8_A, HJ)		
MITSUBISHI	SIGMA (F0_W)		
MITSUBISHI	SIGMA (F1_A, F2_A)		

500221
APPLICATION

BOX SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 93 \text{ mm}$



MITSUBISHI

SPACE STAR (DG_A)

500322T
APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 116 \text{ mm}$



MITSUBISHI

 COLT VI (RG, Z2_A,
 Z3_A)

500285T
APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$


 MITSUBISHI
 MITSUBISHI

 CARISMA (DA_)
 SPACE STAR (DG_A)

500615T
APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 91,5 \text{ mm}$
 $H = 118 \text{ mm}$


 MITSUBISHI
 MITSUBISHI

 MITSUBISHI

 PAJERO II (V3_W)
 PAJERO II (V3_W) I
 SHOGUN
 PAJERO III (V6_W,
 V7_W)

500597
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 90 \text{ mm}$



MITSUBISHI

 OUTLANDER III (GG_W,
 GF_W, ZJ)

500366
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 98 \text{ mm}$



MITSUBISHI COLT II (C1_A, RB, RC)
 MITSUBISHI COLT III (C5_A, RD, RE)
 MITSUBISHI COLT IV (CA_A)
 MITSUBISHI GALANT IV (E3_A, HG, HH)
 MITSUBISHI LANCER IV (C6_A, C7_A, CA, CB)
 MITSUBISHI LANCER V (CB/D_A, CC)

MITSUBISHI LANCER V (CB_W, CC, CD_W, CE)
 MITSUBISHI LANCER VI (CJ-CP_)
 MITSUBISHI SPACE WAGON (N3_W, N4_W, UF)
 MITSUBISHI SPACE WAGON (N8_W, N9_W, UG)

500578
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 94 \text{ mm}$



MITSUBISHI LANCER (CG, CH, CJ, CS_A, CT0)

500506
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 72,75 \text{ mm}$
 $H = 92,5 \text{ mm}$



MITSUBISHI COLT V (CJ_, CP_)
 MITSUBISHI LANCER VI (CJ-CP_)

500421
APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 75,44 \text{ mm}$
 $H = 95 \text{ mm}$



MITSUBISHI OUTLANDER I (CU_W, ZE, ZF)

500213
APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 82 \text{ mm}$
 $H = 97 \text{ mm}$



MITSUBISHI COLT III (C5_A, RD, RE)
 MITSUBISHI ECLIPSE I (D2_A)
 MITSUBISHI LANCER IV (C6_A, C7_A, CA, CB)
 MITSUBISHI TREDIA (A21_)

500239T
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 125 \text{ mm}$



MITSUBISHI

SPACE STAR (DG_A)

500119
APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 79 \text{ mm}$
 $H = 111 \text{ mm}$



MITSUBISHI

GALANT IV (E3_A, HG, HH)

500539T
APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 113 \text{ mm}$



MITSUBISHI

LANCER (CG, CH, CJ, CS_A, CT0)

MITSUBISHI

LANCER (CH, CS_W)

MITSUBISHI

SPACE WAGON (N8_W, N9_W, UG)

500256
APPLICATION

BOX SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 81,5 \text{ mm}$
 $H = 87 \text{ mm}$



MITSUBISHI

GALLOPER (JK-01)

MITSUBISHI

L 200 (K0_T, K1_T, K2_T, K3_T, ME, MF, MG, MH, MJ)

MITSUBISHI

L 200 (K6_T, K7_T, MK)

MITSUBISHI

L 300 (L0_2P, L03_P/G, SA, SB, SC, SD, SE)

MITSUBISHI

L 300 (L03_P, SA, SB, SC, SD, SE)

MITSUBISHI

L 300 (P0_W, P1_W, P2_W, SD, SE, SF, SG, SH, SJ, WA)

MITSUBISHI

L 300 / DELICA II (L03_P)

MITSUBISHI

PAJERO I (L04_G)

MITSUBISHI

PAJERO I (L04_G, L14_G, NA, NB, NC, ND, NE, NF, NG)

MITSUBISHI

PAJERO II (NH, NJ, NK, NL, V2_W, V3_W, V4_W)

MITSUBISHI

PAJERO II (V2_W, V4_W)

MITSUBISHI

PAJERO II (V3_W)

MITSUBISHI

PAJERO III (V6_W, V7_W)

MITSUBISHI

STARION (A18_A, JA, JB, JD)

500294T
APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



MITSUBISHI

SPACE STAR (DG_A)

500337T
APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 81 \text{ mm}$
 $H = 127 \text{ mm}$



MITSUBISHI

GALANT V (E5_A, E7_A, E8_A, HJ)

MITSUBISHI

GALANT VI (EA_)

MITSUBISHI

SPACE RUNNER (N6_W)

MITSUBISHI

SPACE WAGON (N8_W, N9_W, UG)

500277
APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 91 \text{ mm}$



MITSUBISHI

DEBONAIR (S2_A)

500232T
APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 138 \text{ mm}$



MITSUBISHI

PAJERO II (NH, NJ, NK, NL, V2_W, V3_W, V4_W)

MITSUBISHI

PAJERO SPORT (K90, PA)

500347
APPLICATION

WHEEL SIDE
 $\varnothing = 25,85 \text{ mm}$
 $\varnothing = 84 \text{ mm}$
 $H = 100 \text{ mm}$



MITSUBISHI

DEBONAIR (S1_A)

MITSUBISHI

GALLOPER (JK-01)

MITSUBISHI

L 200 (K0_T, K1_T, K2_T, K3_T, ME, MF, MG, MH, MJ)

MITSUBISHI

L 200 (K6_T, K7_T, MK)

MITSUBISHI

L 300 (L0_2P, L03_P/G, SA, SB, SC, SD, SE)

MITSUBISHI

L 300 (L03_P, SA, SB, SC, SD, SE)

MITSUBISHI

L 300 (P0_W, P1_W, P2_W, SD, SE, SF, SG, SH, SJ, WA)

MITSUBISHI

L 300 / DELICA II (L03_P)

MITSUBISHI

PAJERO I (L04_G)

MITSUBISHI

PAJERO I (L04_G, L14_G, NA, NB, NC, ND, NE, NF, NG)

500163T
APPLICATION

WHEEL SIDE
 $\emptyset = 26 \text{ mm}$
 $\emptyset = 80 \text{ mm}$
 $H = 133 \text{ mm}$



MITSUBISHI

SPACE RUNNER (N1_W,
N2_W)

500504
APPLICATION

BOX SIDE
 $\emptyset = 26 \text{ mm}$
 $\emptyset = 81 \text{ mm}$
 $H = 102 \text{ mm}$



MITSUBISHI

ASX (GA_W_, XA, XB)

MITSUBISHI

GRANDIS (BA, NA_W)

MITSUBISHI

LANCER (CJ, CY/Z_A)

MITSUBISHI

LANCER SPORTBACK

(CJ, CX_A)

MITSUBISHI

OUTLANDER II (CW_W,
ZG, ZH)

MITSUBISHI

OUTLANDER III (GG_W,
GF_W, ZJ)

500100T
APPLICATION

WHEEL SIDE
 $\emptyset = 26,1 \text{ mm}$
 $\emptyset = 84,5 \text{ mm}$
 $H = 131 \text{ mm}$



MITSUBISHI

SPACE RUNNER (N6_W)

MITSUBISHI

SPACE WAGON (N8_W,
N9_W, UG)

500106
APPLICATION

WHEEL SIDE
 $\emptyset = 26,8 \text{ mm}$
 $\emptyset = 90 \text{ mm}$
 $H = 108 \text{ mm}$



MITSUBISHI

GALANT III (E1_A)

500234T

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 123 \text{ mm}$



MITSUBISHI DELICA / SPACE GEAR
 MITSUBISHI GALLOPER (JK-01)
 MITSUBISHI L 200 (K6_T, K7_T, MK)
 MITSUBISHI L 200 (KA_T, KB_T, ML, MN)
 MITSUBISHI L 200 / TRITON (KA_T, KB_T, ML, MN)
 MITSUBISHI L 400 (PA_V, PA_W, PB_V, PC_W, PD_W)
 MITSUBISHI L 400 / SPACE GEAR (PA_V, PA_W, PB_V, PC_W, PD_W)
 MITSUBISHI OUTLANDER I (CU_W, ZE, ZF)
 MITSUBISHI PAJERO CLASSIC (V2_W)
 MITSUBISHI PAJERO I (L04_G, L14_G, NA, NB, NC, ND, NE, NF, NG)
 MITSUBISHI PAJERO II (NH, NJ, NK, NL, V2_W, V3_W, V4_W)

APPLICATION

MITSUBISHI PAJERO III (V6_W, V7_W)
 MITSUBISHI PAJERO SPORT (K90, PA)
 MITSUBISHI SPACE WAGON (N3_W, N4_W, UF)

500227T

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 125 \text{ mm}$



MITSUBISHI PAJERO PININ (H6_W, H7_W, QA)

APPLICATION
500031

WHEEL SIDE
 $\varnothing = 27,5 \text{ mm}$
 $\varnothing = 85 \text{ mm}$
 $H = 97 \text{ mm}$



MITSUBISHI PAJERO I (L04_G)
 MITSUBISHI PAJERO I (L04_G, L14_G, NA, NB, NC, ND, NE, NF, NG)

APPLICATION
500324T

WHEEL SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 87 \text{ mm}$
 $H = 150 \text{ mm}$



MITSUBISHI DELICA / SPACE GEAR
 MITSUBISHI L 200 (K6_T, K7_T, MK)
 MITSUBISHI L 400 / SPACE GEAR (PA_V, PA_W, PB_V, PC_W, PD_W)

APPLICATION

500516T
APPLICATION

WHEEL SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 115 \text{ mm}$



MITSUBISHI
 MITSUBISHI

LANCER (CJ, CY/Z_A)
 LANCER SPORTBACK
 (CJ, CX_A)

500078
APPLICATION

BOX SIDE
 $\varnothing = 30,5 \text{ mm}$
 $\varnothing = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$



MITSUBISHI

CARISMA (DA_)

500077
APPLICATION

BOX SIDE
 $\varnothing = 30,5 \text{ mm}$
 $\varnothing = 85,44 \text{ mm}$
 $H = 88 \text{ mm}$



MITSUBISHI
 MITSUBISHI

CARISMA (DA_)
 SPACE STAR (DG_A)

500583
APPLICATION

WHEEL SIDE
 $\varnothing = 30,65 \text{ mm}$
 $\varnothing = 110 \text{ mm}$
 $H = 111,5 \text{ mm}$



MITSUBISHI
 MITSUBISHI
 MITSUBISHI

PAJERO CLASSIC
 (V2_W)
 PAJERO II (V3_W)
 PAJERO III (V6_W,
 V7_W)

APPLICATION

WHEEL SIDE
 $\varnothing = 26 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 133 \text{ mm}$



PROTON

PROTON

PERSONA 400 (C9_C,
 C9_S) | WIRA
 PERSONA 400 (C9_S)
 | WIRA

500059

APPLICATION

BOX SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 62,15 \text{ mm}$
 $H = 110 \text{ mm}$



ROVER	200 (RF)
ROVER	200 (XH)
ROVER	200 (XW)

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



ROVER	200 (RF)
ROVER	200 (XW)
ROVER	25 (RF)
ROVER	400 (RT)
ROVER	45 (RT)
ROVER	COUPE
ROVER	STREETWISE

500170

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 84 \text{ mm}$



ROVER	200 (RF)
ROVER	200 (XW)
ROVER	25 (RF)
ROVER	400 (RT)
ROVER	45 (RT)
ROVER	COUPE
ROVER	STREETWISE

500414

APPLICATION

BOX SIDE
 $\varnothing = 19,85 \text{ mm}$
 $\varnothing = 66,7 \text{ mm}$
 $H = 82,15 \text{ mm}$



ROVER	75 (RJ)
-------	---------

500063

APPLICATION

BOX SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 100 \text{ mm}$



ROVER	200 (RF)
-------	----------

500349

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 93 \text{ mm}$



ROVER	200 (RF)
ROVER	200 (XW)
ROVER	400 (RT)
ROVER	400 (XW)

500109

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



ROVER	MINI
ROVER	MINI (XN)

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



ROVER	200 (XW)
ROVER	800 (XS)

500255

APPLICATION

WHEEL SIDE
 $\varnothing = 20,5 \text{ mm}$
 $\varnothing = 84,8 \text{ mm}$
 $H = 106 \text{ mm}$



ROVER	800
ROVER	200 (RF)
ROVER	200 (XW)
ROVER	25 (RF)
ROVER	400 (RT)
ROVER	400 (XW)
ROVER	45 (RT)
ROVER	800 (XS)
ROVER	MONTEGO

ROVER	MONTEGO (XE)
ROVER	STREETWISE

500205

APPLICATION

WHEEL SIDE
 $\varnothing = 20,9 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 92 \text{ mm}$



ROVER	200 (RF)
ROVER	200 (XW)
ROVER	25 (RF)
ROVER	400 (RT)
ROVER	400 (XW)
ROVER	45 (RT)
ROVER	COUPE
ROVER	STREETWISE

500292

APPLICATION

BOX SIDE
 $\varnothing = 21$ mm
 $\varnothing = 70$ mm
H = 88 mm



ROVER 45 (RT)
ROVER 75 (RJ)

500215

APPLICATION

BOX SIDE
 $\varnothing = 21$ mm
 $\varnothing = 74$ mm
H = 94 mm



ROVER 400 (RT)
ROVER 45 (RT)

500034

APPLICATION

WHEEL SIDE
 $\varnothing = 21$ mm
 $\varnothing = 76$ mm
H = 91 mm



ROVER	100 / METRO (XP)	ROVER	MAESTRO
ROVER	200 (RF)	ROVER	MONTEGO (XE)
ROVER	200 (XH)	ROVER	STREETWISE
ROVER	200 (XW)		
ROVER	25 (RF)		
ROVER	400 (RT)		
ROVER	400 (XW)		
ROVER	45 (RT)		
ROVER	COUPE		

500270

APPLICATION

BOX SIDE
 $\varnothing = 21$ mm
 $\varnothing = 80$ mm
H = 84 mm



ROVER	800	ROVER	STREETWISE
ROVER	200 (RF)		
ROVER	200 (XW)		
ROVER	25 (RF)		
ROVER	400 (RT)		
ROVER	400 (XW)		
ROVER	45 (RT)		
ROVER	600 (RH)		
ROVER	800 (XS)		

500221

APPLICATION

BOX SIDE
 $\varnothing = 22$ mm
 $\varnothing = 66$ mm
H = 93 mm



ROVER 75 (RJ)

500025

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 103 \text{ mm}$



ROVER
 ROVER
 ROVER
 ROVER

100 / METRO (XP)
 200 (XH)
 200 (XW)
 MONTEGO

500025E

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 103 \text{ mm}$



ROVER
 ROVER
 ROVER
 ROVER

100 / METRO (XP)
 200 (XH)
 200 (XW)
 MONTEGO

500285T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77,4 \text{ mm}$
 $H = 116,5 \text{ mm}$



ROVER

75 (RJ)

500275

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 78 \text{ mm}$
 $H = 91,5 \text{ mm}$



ROVER
 ROVER

200 (RF)
 400 (XW)

500239T

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 125 \text{ mm}$



ROVER

75 (RJ)

APPLICATION

WHEEL SIDE
Ø = 24,5 mm
Ø = 83 mm
H = 120 mm



ROVER

75 (RJ)

500092

APPLICATION

BOX SIDE
Ø = 25 mm
Ø = 83 mm
H = 89 mm



ROVER

600 (RH)

APPLICATION

BOX SIDE
Ø = 19,3 mm
Ø = 62 mm
H = 83 mm



SAAB

9-5 (YS3G)

500414

APPLICATION

BOX SIDE
Ø = 19,85 mm
Ø = 66,7 mm
H = 82,15 mm



SAAB

9-5 (YS3G)

500270

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 80 mm
H = 84 mm



SAAB
SAAB
SAAB

9000
9-3 (YS3D)
9-5 (YS3E)

500066

APPLICATION

BOX SIDE
Ø = 22 mm
Ø = 66,6 mm
H = 99 mm



SAAB

900 II

500272

APPLICATION

BOX SIDE
Ø = 22 mm
Ø = 75 mm
H = 125 mm



SAAB
SAAB
SAAB
SAAB

9000
900 I
900 I (AC4, AM4)
9-3 (YS3D)

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77,4 mm
H = 116,5 mm



SAAB 9-5 (YS3G)

500121

APPLICATION

WHEEL SIDE
Ø = 23,9 mm
Ø = 92 mm
H = 83 mm



SAAB 9000

500239T

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 60 mm
H = 125 mm



SAAB 9-5 (YS3G)

500267

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 64 mm
H = 101 mm



SAAB 9-3 (YS3F)

500175

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 70 mm
H = 116 mm



SAAB 9-5 (YS3E)

500294T

APPLICATION

WHEEL SIDE
 $\varnothing = 24,5 \text{ mm}$
 $\varnothing = 83 \text{ mm}$
 $H = 120 \text{ mm}$



SAAB

9-3 (YS3F)

500089

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 57 \text{ mm}$
 $H = 99 \text{ mm}$



SAAB

9-3 (YS3F)

500216

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 75 \text{ mm}$
 $H = 113 \text{ mm}$



SAAB

9-3 (YS3D)

500107

APPLICATION

WHEEL SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 90 \text{ mm}$
 $H = 104 \text{ mm}$



SAAB

90

SAAB

99

SAAB

900 I

SAAB

900 I (AC4, AM4)

500342T

APPLICATION

WHEEL SIDE
 $\varnothing = 25,1 \text{ mm}$
 $\varnothing = 86,75 \text{ mm}$
 $H = 110 \text{ mm}$



SAAB

9-3 (YS3F)

500238T

APPLICATION

WHEEL SIDE
 $\varnothing = 26,9 \text{ mm}$
 $\varnothing = 88 \text{ mm}$
 $H = 141 \text{ mm}$



SAAB
 SAAB

900 II
 9-3 (YS3D)

500526T

APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 71 \text{ mm}$
 $H = 107 \text{ mm}$



SAAB

9-5 (YS3G)

500612T

APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 87,5 \text{ mm}$
 $H = 107 \text{ mm}$



SAAB

9-3 (YS3F)

500227T

APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 125 \text{ mm}$



SAAB
 SAAB

9-3 (YS3F)
 9-5 (YS3G)

500527T

APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 95 \text{ mm}$



SAAB

9-5 (YS3G)

500011T

APPLICATION

WHEEL SIDE
Ø = 27,2 mm
Ø = 98,1 mm
H = 144,5 mm



SAAB
SAAB
SAAB

9000
9-3 (YS3D)
9-5 (YS3E)

500336T

APPLICATION

WHEEL SIDE
Ø = 28,5 mm
Ø = 99,1 mm
H = 122,8 mm



SAAB

9-5 (YS3G)

APPLICATION

BOX SIDE
Ø = 25 mm
Ø = 68 mm
H = 70 mm



SMART
SMART
SMART
SMART
SMART

CABRIO (450)
CITY- (450)
CROSSBLADE (450)
FORTWO (450)
ROADSTER (452)

500628

APPLICATION

BOX SIDE

 $\emptyset = 24,95 \text{ mm}$ $\emptyset = 79,6 \text{ mm}$ $H = 95,5 \text{ mm}$ 

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

ACTYON I

ACTYON SPORTS I (QJ)

KYRON

REXTON (GAB_)

REXTON W

RODIUS II

500493T

APPLICATION

WHEEL SIDE

 $\emptyset = 28 \text{ mm}$ $\emptyset = 90 \text{ mm}$ $H = 115 \text{ mm}$ 

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

SSANGYONG

ACTYON I

ACTYON SPORTS I (QJ)

ACTYON SPORTS II

KYRON

REXTON (GAB_)

REXTON W

RODIUS II

500172

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 55,5 \text{ mm}$
 $H = 90 \text{ mm}$



SUBARU	JUSTY II (JMA, MS)
SUBARU	FORESTER (SG)
SUBARU	IMPREZA (GD)
SUBARU	IMPREZA (GF)
SUBARU	IMPREZA (GG)
SUBARU	LEGACY III (BE)
SUBARU	LEGACY III (BH)
SUBARU	OUTBACK (BE, BH)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



SUBARU	JUSTY I (KAD)
SUBARU	REX III
SUBARU	VIVIO

500584

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 65 \text{ mm}$



SUBARU	FORESTER (SF)
--------	---------------

500198

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



SUBARU	FORESTER (SF)
SUBARU	IMPREZA (GC)
SUBARU	IMPREZA (GF)
SUBARU	JUSTY I (KAD)
SUBARU	LEGACY II (BD)
SUBARU	LEGACY II (BG)

500273

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 93 \text{ mm}$



SUBARU	FORESTER (SF)
SUBARU	LEGACY I (BC)

500109

APPLICATION

WHEEL SIDE
 $\emptyset = 20,2 \text{ mm}$
 $\emptyset = 65 \text{ mm}$
 $H = 97,4 \text{ mm}$



SUBARU
 SUBARU
 SUBARU

LEGACY II (BG)
 LEONE II
 XT (XT)

500609

APPLICATION

BOX SIDE
 $\emptyset = 20,5 \text{ mm}$
 $\emptyset = 65 \text{ mm}$
 $H = 97 \text{ mm}$



SUBARU
 SUBARU
 SUBARU
 SUBARU

FORESTER (SG_)
 IMPREZA (G3, GE, GH,
 GR)
 IMPREZA (GR)
 IMPREZA (GR, GH, G3)
 I B3

500601

APPLICATION

BOX SIDE
 $\emptyset = 20,5 \text{ mm}$
 $\emptyset = 66,5 \text{ mm}$
 $H = 94 \text{ mm}$



SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

IMPREZA (GD)
 IMPREZA (GG)
 IMPREZA (GR)
 LEGACY IV (BL)
 LEGACY IV (BP)
 OUTBACK (BL, BP)
 TRIBECA (B9)

500580

APPLICATION

WHEEL SIDE
 $\emptyset = 21 \text{ mm}$
 $\emptyset = 66 \text{ mm}$
 $H = 70 \text{ mm}$



SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

FORESTER (SF)
 FORESTER (SG_)
 FORESTER (SH)
 FORESTER (SH_)
 FORESTER (SJ_)
 IMPREZA (G3, GE, GH,
 GR)
 IMPREZA (GD)
 IMPREZA (GG)
 IMPREZA (GJ)
 IMPREZA (GP)
 IMPREZA (GR)
 IMPREZA (GR, GH, G3)
 I B3
 IMPREZA (GT_)
 LEGACY IV (BL)
 LEGACY IV (BP)
 LEGACY V (BM)
 LEGACY V (BR)
 LEGACY VI (BN, BS)
 LEVORG

SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

OUTBACK (BL, BP)
 OUTBACK (BR)
 OUTBACK (BS)
 WRX (GJ)
 XV
 XV (GP)
 XV (GT)

500116

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 88 \text{ mm}$



SUBARU
 SUBARU

JUSTY II (JMA, MS)
 JUSTY III (G3X)

500207

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 71,5 \text{ mm}$
 $H = 90 \text{ mm}$



SUBARU
 SUBARU
 SUBARU

LEONE I
 LEONE I (AB)
 LEONE II

500195

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$



SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

FORESTER (SF)
 IMPREZA (GC)
 IMPREZA (GD)
 IMPREZA (GF)
 IMPREZA (GFC)
 IMPREZA (GG)
 JUSTY I (KAD)
 LEGACY I (BC)
 LEGACY II (BD)

SUBARU
 SUBARU
 SUBARU
 SUBARU

LEGACY II (BG)
 LEGACY III (BE)
 LEGACY III (BH)
 OUTBACK (BE, BH)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



SUBARU
 SUBARU
 SUBARU
 SUBARU

JUSTY I (KAD)
 LEONE I
 LEONE I (AB)
 LEONE II

500345

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 69 \text{ mm}$



SUBARU

OUTBACK (BE, BH)

500034

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 91 \text{ mm}$



SUBARU
 SUBARU
 SUBARU

LEONE I
 LEONE I (AB)
 LEONE II

500388

APPLICATION

BOX SIDE
 $\varnothing = 21,45 \text{ mm}$
 $\varnothing = 76,5 \text{ mm}$
 $H = 92,75 \text{ mm}$



SUBARU

TREZIA

500200

APPLICATION

WHEEL SIDE
 $\varnothing = 21,9 \text{ mm}$
 $\varnothing = 76 \text{ mm}$
 $H = 95 \text{ mm}$



SUBARU

SVX (CX)

500634T

APPLICATION

WHEEL SIDE
 $\varnothing = 22,5 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 99 \text{ mm}$



SUBARU

JUSTY III (G3X)

500275

APPLICATION

WHEEL SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 78 \text{ mm}$
 $H = 91,5 \text{ mm}$



SUBARU

LEONE II

500614T

APPLICATION

WHEEL SIDE

Ø = 24 mm

Ø = 74 mm

H = 98 mm



SUBARU	FORESTER (SF)
SUBARU	IMPREZA (GD)
SUBARU	IMPREZA (GG)
SUBARU	LEGACY III (BE)
SUBARU	LEGACY III (BH)
SUBARU	LEGACY IV (BL)
SUBARU	LEGACY IV (BP)
SUBARU	OUTBACK (BE, BH)
SUBARU	OUTBACK (BL, BP)

SUBARU

TRIBECA (B9)

500565T

APPLICATION

WHEEL SIDE

Ø = 24 mm

Ø = 81 mm

H = 97 mm



SUBARU	FORESTER (SF)
SUBARU	IMPREZA (GD)
SUBARU	IMPREZA (GG)
SUBARU	IMPREZA (GR)
SUBARU	LEGACY III (BE)
SUBARU	LEGACY III (BH)
SUBARU	OUTBACK (BE, BH)

500172

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 55,5 \text{ mm}$
 $H = 90 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

ALTO (EF)
 BALENO (EG)
 IGNIS (FH)
 WAGON R+ (EM)
 WAGON R+ (MM)

500375

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 84 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI

ALTO (FF)
 WAGON R
 WAGON R+ (MM)

500206

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 66 \text{ mm}$
 $H = 83 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

ALTO
 ALTO (OS)
 ALTO (EF)
 ALTO (FF)
 ALTO (HA12, HA23)
 SWIFT II (AH, AJ)
 SWIFT II (EA, MA)

500501

APPLICATION

BOX SIDE
 $\varnothing = 18,75 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 90 \text{ mm}$



SUZUKI

GRAND VITARA II (JT, TD, TE)

500174

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 87 \text{ mm}$



SUZUKI

BALENO (EG)

500199

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

ALTO (0S)
 IGNIS (FH)
 SWIFT (SF413)
 SWIFT II (AH, AJ)
 SWIFT II (EA, MA)
 WAGON R+ (EM)
 WAGON R+ (MM)

500266

APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 65 \text{ mm}$
 $H = 87 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

ALTO
 ALTO (EF)
 ALTO (FF)
 SUPER CARRY (ED)
 WAGON R+ (EM)

500212

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 84 \text{ mm}$



SUZUKI

BALENO (EG)

500041

APPLICATION

WHEEL SIDE
 $\varnothing = 19,6 \text{ mm}$
 $\varnothing = 67,2 \text{ mm}$
 $H = 83 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

ALTO
 ALTO (0S)
 SAMURAI (SJ)
 SJ 410
 SJ 410 (0S)
 SWIFT I (AA)

500180

APPLICATION

BOX SIDE
 $\varnothing = 19,82 \text{ mm}$
 $\varnothing = 57,83 \text{ mm}$
 $H = 89,6 \text{ mm}$



SUZUKI

ALTO (FF)

500273

APPLICATION

WHEEL SIDE
 $\varnothing = 20 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 93 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI

BALENO (EG)
 SWIFT I (AA)
 SWIFT II (EA, MA)

500039

APPLICATION

WHEEL SIDE
 $\varnothing = 20,2 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 87,85 \text{ mm}$



SUZUKI

BALENO (EG)

500498

APPLICATION

BOX SIDE
 $\varnothing = 20,75 \text{ mm}$
 $\varnothing = 58,2 \text{ mm}$
 $H = 88,2 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI

SWIFT II (AH, AJ)
 SWIFT II (EA, MA)
 SWIFT Mk II (AH, AJ)

500116

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 88 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

ALTO (OS)
 BALENO (EG)
 CARRY (OS)
 IGNIS (FH)
 SWIFT I (AA)
 SWIFT II (AH, AJ)
 WAGON R
 WAGON R+ (EM)

500636T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 69,13 \text{ mm}$
 $H = 105 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI

WAGON R
 WAGON R+ (MM)
 WAGON R+ (MM) I
 WAGON R SORIO

500195

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 95 \text{ mm}$



SUZUKI
 SUZUKI

GRAND VITARA I (FT, HT)
 VITARA (ET, TA)

500283

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 91 \text{ mm}$



SUZUKI

VITARA (ET, TA)

500264

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 88 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI

GRAND VITARA I (FT, HT)
 GRAND VITARA I (GT)
 VITARA (ET, TA)

500069

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 81,8 \text{ mm}$
 $H = 92,3 \text{ mm}$



SUZUKI

VITARA (ET, TA)

500517T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 109 \text{ mm}$



SUZUKI
 SUZUKI
 SUZUKI
 SUZUKI

BALENO (EG)
 LIANA (ER)
 LIANA (ER, RH_)
 SWIFT III (EZ, MZ)

500037

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 88 \text{ mm}$



SUZUKI
 SUZUKI

BALENO (EG)
 X-90 (EL)

500322T

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 116 \text{ mm}$



SUZUKI

SPLASH (EX)

500271

APPLICATION

WHEEL SIDE
 $\varnothing = 22 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 94 \text{ mm}$



SUZUKI

VITARA (ET, TA)

500634T

APPLICATION

WHEEL SIDE
 $\varnothing = 22,5 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 99 \text{ mm}$



SUZUKI

IGNIS II (MH)

500513

APPLICATION

BOX SIDE
 $\varnothing = 23 \text{ mm}$
 $\varnothing = 74 \text{ mm}$
 $H = 92 \text{ mm}$



SUZUKI
 SUZUKI

GRAND VITARA I (FT, HT)
 VITARA (ET, TA)

500131

APPLICATION

BOX SIDE

TALBOT
TALBOTSAMBA (51A)
SAMBA (51E)

500108

APPLICATION

WHEEL SIDE

Ø = 17,3 mm

Ø = 70,8 mm

H = 101,5 mm

TALBOT
TALBOT
TALBOT
TALBOT1307-1510
HORIZON
SAMBA (51A)
SOLARA

500108E

APPLICATION

WHEEL SIDE

Ø = 17,3 mm

Ø = 70,8 mm

H = 101,5 mm

TALBOT
TALBOT
TALBOT
TALBOT1307-1510
HORIZON
SAMBA (51A)
SOLARA

500287

APPLICATION

WHEEL SIDE

Ø = 20,4 mm

Ø = 76 mm

H = 113 mm



TALBOT

SAMBA (51A)

500287E

APPLICATION

WHEEL SIDE

Ø = 20,4 mm

Ø = 76 mm

H = 113 mm



TALBOT

SAMBA (51A)

500360

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 94 \text{ mm}$



TALBOT	1307-1510
TALBOT	HORIZON
TALBOT	SIMCA 1100
TALBOT	SOLARA

500060

APPLICATION

BOX SIDE
 $\varnothing = 28 \text{ mm}$
 $\varnothing = 62 \text{ mm}$
 $H = 114 \text{ mm}$



TALBOT	1307-1510
TALBOT	HORIZON
TALBOT	SIMCA 1100
TALBOT	SIMCA 1609/1610
TALBOT	SOLARA

500018

APPLICATION

WHEEL SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 116 \text{ mm}$



TALBOT	1307-1510
TALBOT	HORIZON
TALBOT	MATRA BAGHEERA (X)
TALBOT	RANCHO
TALBOT	SIMCA 1100
TALBOT	SIMCA 1609/1610
TALBOT	SOLARA

500018E

APPLICATION

WHEEL SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 73,5 \text{ mm}$
 $H = 116 \text{ mm}$



TALBOT	HORIZON
TALBOT	MATRA BAGHEERA (X)
TALBOT	RANCHO
TALBOT	SIMCA 1100
TALBOT	SIMCA 1609/1610
TALBOT	SOLARA

500061

APPLICATION

BOX SIDE
 $\varnothing = 37 \text{ mm}$
 $\varnothing = 59 \text{ mm}$
 $H = 104 \text{ mm}$



TALBOT	1307-1510
TALBOT	HORIZON
TALBOT	SIMCA 1100
TALBOT	SIMCA 1301
TALBOT	SIMCA 1609/1610
TALBOT	SOLARA

APPLICATION

WHEEL SIDE
Ø = 37 mm
Ø = 83 mm
H = 112 mm



TALBOT
TALBOT
TALBOT
TALBOT

1307-1510
HORIZON
SIMCA 1100
SOLARA

APPLICATION

BOX SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 62,15 \text{ mm}$
 $H = 110 \text{ mm}$



TRIUMPH

ACCLAIM

500132

APPLICATION

WHEEL SIDE



AUDI	100 (43, C2)	VOLKSWAGEN	TRANSPORTER III
AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	TRANSPORTER IV
AUDI	100 (44, 44W, C3)		(70XA)
AUDI	100 (4A, C4)	VOLKSWAGEN	TRANSPORTER IV
AUDI	200 (43)		(70XB, 70XC, 7DB, 7DK,
AUDI	200 (44, 44Q)		7DW)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	TRANSPORTER IV
AUDI	80 (89, 89Q, 8A, B3)		(70XD)
AUDI	80 (8C, B4)		
AUDI	90 (81, 85, B2)		
AUDI	90 (89, 89Q, 8A, B3)		
AUDI	A4 (8D2, B5)		
AUDI	A4 (8D5, B5)		
AUDI	A4 (8E2, B6)		
AUDI	A4 (8E5, B6)		
AUDI	A6 (4A, C4)		
AUDI	A6 (4B2, C5)		
AUDI	A6 (4B5, C5)		
AUDI	A8 (4D2, 4D8)		
AUDI	ALLROAD (4BH, C5)		
AUDI	CABRIOLET (8G7, B4)		
AUDI	COUPE B2 (81, 855,		
	856)		
AUDI	COUPE B3 (89, 8B3)		
AUDI	QUATTRO (85)		
AUDI	V8 (44_, 4C_)		
SKODA	SUPERB (3U4)		
VOLKSWAGEN	PASSAT (32B)		
VOLKSWAGEN	PASSAT (3B2)		
VOLKSWAGEN	PASSAT (3B3)		
VOLKSWAGEN	PASSAT (3B5)		
VOLKSWAGEN	PASSAT (3B6)		
VOLKSWAGEN	TRANSPORTER III		

500029

APPLICATION

BOX SIDE



AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	GOLF III (1E7)
AUDI	50 (86)	VOLKSWAGEN	GOLF III (1H1)
AUDI	80 (80, 82, B1)	VOLKSWAGEN	GOLF III (1H5)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	GOLF IV (1E7)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	80 (8C, B4)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	GOLF Mk III (1H1)
AUDI	90 (89, 89Q, 8A, B3)	VOLKSWAGEN	JETTA I (16)
AUDI	A3 (8L1)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	PASSAT (32)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	PASSAT (32B)
AUDI	CABRIOLET (8G7, B4)	VOLKSWAGEN	PASSAT (33)
AUDI	COUPE B2 (81, 855, 856)	VOLKSWAGEN	PASSAT (3A2, 35I)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	PASSAT (3A5, 35I)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	POLO (6KV2)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	POLO (6KV5)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	POLO (6NF)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	SANTANA (32B)
SEAT	INCA (6K9)	VOLKSWAGEN	SCIROCCO (53)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	SCIROCCO (53B)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	VENTO (1H2)
SKODA	OCTAVIA (1U5)		
VOLKSWAGEN	411, 412		
VOLKSWAGEN	412		
VOLKSWAGEN	1500, 1600 (31)		
VOLKSWAGEN	1500, 1600 (36)		
VOLKSWAGEN	CADDY I (14)		
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		
VOLKSWAGEN	GOLF I (155)		
VOLKSWAGEN	GOLF I (17)		
VOLKSWAGEN	GOLF II (19E, 1G1)		

500356

APPLICATION

WHEEL SIDE

Ø = 17 mm

Ø = 69 mm

H = 97 mm



SEAT	PANDA (141A)
------	--------------

500053

APPLICATION

WHEEL SIDE

Ø = 17,8 mm

Ø = 77 mm

H = 80 mm



SEAT	IBIZA II (6K1)
VOLKSWAGEN	DERBY (80, 86C)
VOLKSWAGEN	GOLF I (155)
VOLKSWAGEN	GOLF II (19E, 1G1)
VOLKSWAGEN	JETTA II (165, 19E, 1G2)
VOLKSWAGEN	POLO (80, 86C)
VOLKSWAGEN	POLO (86CF)
VOLKSWAGEN	SCIROCCO (53B)

500053E

APPLICATION

WHEEL SIDE
 $\varnothing = 17,8 \text{ mm}$
 $\varnothing = 77 \text{ mm}$
 $H = 80 \text{ mm}$



SEAT
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

IBIZA II (6K1)
GOLF I (155)
GOLF II (19E, 1G1)
SCIROCCO (53B)

500355

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 97 \text{ mm}$



SEAT

PANDA (141A)

500248

APPLICATION

BOX SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 100 \text{ mm}$
 $H = 114 \text{ mm}$



AUDI	A3 (8L1)
SEAT	ALHAMBRA (7V8, 7V9)
SEAT	CORDOBA (6K1, 6K2)
SEAT	CORDOBA (6K5)
SEAT	IBIZA II (6K1)
SEAT	LEON (1M1)
SEAT	TOLEDO I (1L)
SEAT	TOLEDO II (1M2)
SKODA	OCTAVIA (1U2)
SKODA	OCTAVIA (1U5)
VOLKSWAGEN	BORA (1J2)
VOLKSWAGEN	BORA (1J6)
VOLKSWAGEN	CADDY II (9K9A)
VOLKSWAGEN	CADDY II (9K9B)
VOLKSWAGEN	CADDY II (9U7)
VOLKSWAGEN	CORRADO (53I)
VOLKSWAGEN	GOLF III (1E7)
VOLKSWAGEN	GOLF III (1H1)
VOLKSWAGEN	GOLF III (1H5)
VOLKSWAGEN	GOLF IV (1E7)
VOLKSWAGEN	GOLF IV (1J1)

VOLKSWAGEN	GOLF IV (1J5)
VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
VOLKSWAGEN	NEW BEETLE (1Y7)
VOLKSWAGEN	PASSAT (3A2, 35I)
VOLKSWAGEN	PASSAT (3A5, 35I)
VOLKSWAGEN	PASSAT (3B2)
VOLKSWAGEN	PASSAT (3B5)
VOLKSWAGEN	POLO (6KV2)
VOLKSWAGEN	POLO (6KV5)
VOLKSWAGEN	VENTO (1H2)

500428

APPLICATION

BOX SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 59,25 \text{ mm}$
 $H = 90 \text{ mm}$



SEAT
SKODA
VOLKSWAGEN
VOLKSWAGEN

Mii (KF1_)
CITIGO
LOAD UP
UP

500005

APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 94 \text{ mm}$



AUDI
 VOLKSWAGEN
 VOLKSWAGEN

50 (86)
 POLO (80, 86C)
 POLO (86)

500258

APPLICATION

WHEEL SIDE
 $\varnothing = 19 \text{ mm}$
 $\varnothing = 78 \text{ mm}$
 $H = 83 \text{ mm}$



SKODA
 SKODA
 SKODA
 VOLKSWAGEN

FELICIA I (6U1)
 FELICIA I (6U5)
 FELICIA I (797)
 CADDY II (9U7)

500282

APPLICATION

BOX SIDE
 $\varnothing = 19,25 \text{ mm}$
 $\varnothing = 67,7 \text{ mm}$
 $H = 93 \text{ mm}$



SKODA
 SKODA
 SKODA
 SKODA
 SKODA
 SKODA
 SKODA
 VOLKSWAGEN

FAVORIT (781)
 FAVORIT (785)
 FAVORIT (787)
 FELICIA I (6U1)
 FELICIA I (6U5)
 FELICIA I (797)
 FELICIA II (6U1)
 FELICIA II (6U5)
 CADDY II (9U7)

500137

APPLICATION

BOX SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 54,5 \text{ mm}$
 $H = 100,8 \text{ mm}$



AUDI

100 (4A, C4)

500194

APPLICATION

WHEEL SIDE
 $\varnothing = 19,3 \text{ mm}$
 $\varnothing = 64,7 \text{ mm}$
 $H = 82 \text{ mm}$



SEAT
 SEAT
 SEAT
 SEAT

MARBELLA (028A)
 MARBELLA (28)
 TERRA (024A)
 TERRA (24)

500254

APPLICATION

WHEEL SIDE

Ø = 20 mm

Ø = 70 mm

H = 80 mm



SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT

FURA (025A)
IBIZA I (021A)
MALAGA (023A)
MARBELLA (28)
PANDA (141A)
RONDA (022A)
TERRA (024A)
TERRA (24)

500052

APPLICATION

WHEEL SIDE

Ø = 20 mm

Ø = 74,2 mm

H = 79 mm



AUDI
AUDI
AUDI
VOLKSWAGEN

80 (89, 89Q, 8A, B3)
80 (8C, B4)
90 (89, 89Q, 8A, B3)
DERBY (80, 86C)

500052E

APPLICATION

WHEEL SIDE

Ø = 20 mm

Ø = 74,2 mm

H = 79 mm



AUDI
AUDI
AUDI
VOLKSWAGEN

80 (89, 89Q, 8A, B3)
80 (8C, B4)
90 (89, 89Q, 8A, B3)
DERBY (80, 86C)

500042

APPLICATION

WHEEL SIDE

Ø = 20 mm

Ø = 76 mm

H = 80 mm



AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	PASSAT (32)
AUDI	100 (4A, C4)	VOLKSWAGEN	PASSAT (32B)
AUDI	200 (44, 44Q)	VOLKSWAGEN	PASSAT (33)
AUDI	50 (86)	VOLKSWAGEN	PASSAT (3A2, 35I)
AUDI	80 (80, 82, B1)	VOLKSWAGEN	PASSAT (3A5, 35I)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	POLO (6KV2)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	POLO (6KV5)
AUDI	80 (8C, B4)	VOLKSWAGEN	POLO (6NF)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	POLO (80, 86C)
AUDI	90 (89, 89Q, 8A, B3)	VOLKSWAGEN	POLO (86)
AUDI	COUPE B2 (81, 855, 856)	VOLKSWAGEN	POLO (86CF)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	SANTANA (32B)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	SCIROCCO (53)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	SCIROCCO (53B)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	VENTO (1H2)
SEAT	IBIZA III (6K1)		
SEAT	INCA (6K9)		
SEAT	TOLEDO I (1L)		
VOLKSWAGEN	CADDY I (14)		
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		
VOLKSWAGEN	DERBY (80, 86C)		
VOLKSWAGEN	DERBY (86)		
VOLKSWAGEN	GOLF I (155)		
VOLKSWAGEN	GOLF I (17)		
VOLKSWAGEN	GOLF II (19E, 1G1)		
VOLKSWAGEN	GOLF III (1H1)		
VOLKSWAGEN	GOLF III (1H5)		
VOLKSWAGEN	GOLF IV (1E7)		
VOLKSWAGEN	GOLF Mk III (1H1)		
VOLKSWAGEN	ILTIS (183)		
VOLKSWAGEN	JETTA I (16)		
VOLKSWAGEN	JETTA II (165, 19E, 1G2)		

500042E

APPLICATION

WHEEL SIDE

Ø = 20 mm

Ø = 76 mm

H = 80 mm



AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	PASSAT (3A5, 35I)
AUDI	100 (4A, C4)	VOLKSWAGEN	POLO (6KV2)
AUDI	200 (44, 44Q)	VOLKSWAGEN	POLO (6KV5)
AUDI	50 (86)	VOLKSWAGEN	POLO (80, 86C)
AUDI	80 (80, 82, B1)	VOLKSWAGEN	POLO (86)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	SANTANA (32B)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	SCIROCCO (53)
AUDI	80 (8C, B4)	VOLKSWAGEN	SCIROCCO (53B)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	VENTO (1H2)
AUDI	90 (89, 89Q, 8A, B3)		
AUDI	COUPE B2 (81, 855, 856)		
SEAT	CORDOBA (6K1, 6K2)		
SEAT	CORDOBA (6K5)		
SEAT	IBIZA II (6K1)		
SEAT	INCA (6K9)		
SEAT	TOLEDO I (1L)		
VOLKSWAGEN	CADDY I (14)		
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		
VOLKSWAGEN	DERBY (80, 86C)		
VOLKSWAGEN	DERBY (86)		
VOLKSWAGEN	GOLF I (155)		
VOLKSWAGEN	GOLF I (17)		
VOLKSWAGEN	GOLF II (19E, 1G1)		
VOLKSWAGEN	GOLF III (1H1)		
VOLKSWAGEN	GOLF III (1H5)		
VOLKSWAGEN	GOLF Mk III (1H1)		
VOLKSWAGEN	JETTA I (16)		
VOLKSWAGEN	JETTA II (165, 19E, 1G2)		
VOLKSWAGEN	PASSAT (32)		
VOLKSWAGEN	PASSAT (32B)		
VOLKSWAGEN	PASSAT (33)		
VOLKSWAGEN	PASSAT (3A2, 35I)		

500064

APPLICATION

BOX SIDE

Ø = 20 mm

Ø = 79,5 mm

H = 112 mm



AUDI	100 (4A, C4)
------	--------------

500032

APPLICATION

WHEEL SIDE

Ø = 20,4 mm

Ø = 72,6 mm

H = 97,3 mm



SEAT	FURA (025A)
SEAT	MARBELLA (028A)
SEAT	MARBELLA (28)
SEAT	RONDA (022A)

500032E

APPLICATION

WHEEL SIDE
 $\varnothing = 20,4 \text{ mm}$
 $\varnothing = 72,6 \text{ mm}$
 $H = 97,3 \text{ mm}$



SEAT	FURA (025A)
SEAT	MARBELLA (028A)
SEAT	MARBELLA (28)
SEAT	RONDA (022A)

500068

APPLICATION

BOX SIDE
 $\varnothing = 20,5 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 95 \text{ mm}$



AUDI	50 (86)	VOLKSWAGEN	POLO (6KV5)
SEAT	AROSA (6H)	VOLKSWAGEN	POLO (6N1)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	POLO (6N2)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	POLO (6NF)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	POLO (80, 86C)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	POLO (86)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	POLO (86CF)
SEAT	INCA (6K9)	VOLKSWAGEN	SCIROCCO (53)
SEAT	TERRA (024A)	VOLKSWAGEN	SCIROCCO (53B)
SEAT	TERRA (24)	VOLKSWAGEN	VENTO (1H2)
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		
VOLKSWAGEN	DERBY (80, 86C)		
VOLKSWAGEN	DERBY (86)		
VOLKSWAGEN	GOLF I (17)		
VOLKSWAGEN	GOLF II (19E, 1G1)		
VOLKSWAGEN	GOLF III (1H1)		
VOLKSWAGEN	GOLF III (1H5)		
VOLKSWAGEN	JETTA I (16)		
VOLKSWAGEN	JETTA II (165, 19E, 1G2)		
VOLKSWAGEN	POLO (6KV2)		

500186

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 63 \text{ mm}$
 $H = 100 \text{ mm}$



AUDI	A2 (8Z0)	VOLKSWAGEN	BORA (1J6)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	GOLF IV (1J1)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	LEON (1M1)	VOLKSWAGEN	LUPO (6E1, 6X1)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	POLO (6N1)
SKODA	FABIA (6Y2)	VOLKSWAGEN	POLO (6N2)
SKODA	FABIA (6Y3)	VOLKSWAGEN	POLO (9A4)
SKODA	FABIA (6Y5)	VOLKSWAGEN	POLO (9N_)
VOLKSWAGEN	BORA (1J2)		

500263

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 84 \text{ mm}$



SEAT	MARBELLA (028A)
------	-----------------

500165T

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 67 \text{ mm}$
 $H = 102 \text{ mm}$



AUDI
AUDI
VOLKSWAGEN

A2 (8Z0)
R8
LUP0 (6E1, 6X1)

500187

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 113 \text{ mm}$



AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SKODA
SKODA
SKODA
SKODA
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

A2 (8Z0)
A3 (8L1)
A4 (8E2, B6)
A4 (8E5, B6)
TT (8N3)
TT (8N9)
AROSA (6H)
CORDOBA (6L2)
IBIZA IV (6L1)
IBIZA V (6J1, 6P5)
IBIZA V (6J5, 6P1)
LEON (1M1)
TOLEDO II (1M2)
FABIA (6Y2)
OCTAVIA (1U2)
OCTAVIA (1U5)
ROOMSTER (5J)
ROOMSTER Praktik (5J)
BORA (1J2)
BORA (1J6)
CADDY II (9K9A)

VOLKSWAGEN	CADDY II (9K9B)
VOLKSWAGEN	CADDY II (9U7)
VOLKSWAGEN	GOLF IV (1J1)
VOLKSWAGEN	GOLF IV (1J5)
VOLKSWAGEN	GOLF Mk IV (1J1)
VOLKSWAGEN	LUPO (6E1, 6X1)
VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
VOLKSWAGEN	NEW BEETLE (1Y7)
VOLKSWAGEN	PASSAT (3B2)
VOLKSWAGEN	POLO (6KV2)
VOLKSWAGEN	POLO (6KV5)
VOLKSWAGEN	POLO (6N1)
VOLKSWAGEN	POLO (6N2)
VOLKSWAGEN	POLO (6NF)
VOLKSWAGEN	POLO (86CF)
VOLKSWAGEN	POLO (9A4)
VOLKSWAGEN	POLO (9N)

500040

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT

FURA (025A)
IBIZA I (021A)
MALAGA (023A)
MARBELLA (028A)
MARBELLA (28)
RONDA (022A)
TERRA (024A)
TERRA (24)

500040E

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



SEAT
SEAT
SEAT
SEAT
SEAT
SEAT

FURA (025A)
IBIZA I (021A)
MALAGA (023A)
MARBELLA (028A)
RONDA (022A)
TERRA (24)

500129

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 77,5 \text{ mm}$
 $H = 76 \text{ mm}$



SKODA	FAVORIT (781)
SKODA	FAVORIT (785)
SKODA	FELICIA I (6U1)
SKODA	FELICIA I (6U5)
SKODA	FELICIA I (797)
VOLKSWAGEN	CADDY II (9U7)

500129E

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 77,5 \text{ mm}$
 $H = 76 \text{ mm}$



SKODA	FAVORIT (781)
SKODA	FAVORIT (785)
SKODA	FELICIA I (6U1)
VOLKSWAGEN	CADDY II (9U7)

500270

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 80 \text{ mm}$
 $H = 84 \text{ mm}$



AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	GOLF Mk IV (1J1)
AUDI	100 (4A, C4)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
AUDI	80 (8C, B4)	VOLKSWAGEN	PASSAT (3A5, 35I)
AUDI	A3 (8L1)	VOLKSWAGEN	PASSAT (3B2)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A4 (8E2, B6)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	PASSAT Variant (3B6)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	PHAETON (3D_)
AUDI	A4 (8H7, 8HE, B6, B7)	VOLKSWAGEN	POLO (6KV2)
AUDI	A6 (4A, C4)	VOLKSWAGEN	POLO (6KV5)
AUDI	A6 (4B2)	VOLKSWAGEN	SHARAN (7M6, 7M8, 7M9)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	VENTO (1H2)
AUDI	A6 (4B5, C5)		
AUDI	A8 (4D2, 4D8)		
AUDI	CABRIOLET (8G7, B4)		
SEAT	ALHAMBRA (7V8, 7V9)		
SEAT	CORDOBA (6K1, 6K2)		
SEAT	CORDOBA (6K2)		
SEAT	CORDOBA (6K5)		
SEAT	IBIZA II (6K1)		
SEAT	TOLEDO I (1L)		
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
SKODA	SUPERB (3U4)		
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	BORA (1J6)		
VOLKSWAGEN	GOLF III (1E7)		
VOLKSWAGEN	GOLF III (1H1)		
VOLKSWAGEN	GOLF III (1H5)		
VOLKSWAGEN	GOLF IV (1E7)		
VOLKSWAGEN	GOLF IV (1J1)		
VOLKSWAGEN	GOLF IV (1J5)		
VOLKSWAGEN	GOLF Mk III (1H1)		

500110

APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 82,7 mm
 H = 98 mm



AUDI	90 (89, 89Q, 8A, B3)
AUDI	COUPE B3 (89, 8B3)
SEAT	TOLEDO I (1L)
VOLKSWAGEN	PASSAT (32B)
VOLKSWAGEN	PASSAT (3A5, 35I)

500110E

APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 82,7 mm
 H = 98 mm



AUDI	80 (89, 89Q, 8A, B3)
AUDI	COUPE B3 (89, 8B3)
SEAT	TOLEDO I (1L)
VOLKSWAGEN	PASSAT (32B)
VOLKSWAGEN	PASSAT (3A5, 35I)

500332

APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 83 mm
 H = 75 mm



AUDI	80 (8C, B4)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	PASSAT Variant (3B6)
AUDI	A4 (8ED, B7)		
AUDI	A4 (8H7, 8HE, B6, B7)		
AUDI	A4 (8K2, B8)		
AUDI	A4 (8K5, B8)		
AUDI	A4 Allroad (8KH, B8)		
AUDI	A5 (8F7)		
AUDI	A5 (8T3)		
AUDI	A5 (8TA)		
AUDI	A6 (4A, C4)		
AUDI	A6 (4B2, C5)		
AUDI	A6 (4B5, C5)		
AUDI	A6 (4F2, C6)		
AUDI	A6 (4F5, C6)		
AUDI	A6 Allroad (4FH, C6)		
AUDI	A8 (4E_)		
VOLKSWAGEN	PASSAT (3B2)		
VOLKSWAGEN	PASSAT (3B3)		

500562

APPLICATION

WHEEL SIDE
 Ø = 21 mm
 Ø = 90 mm
 H = 76 mm



AUDI	A4 (8K2, B8)	AUDI	A8 (4E_)
AUDI	A4 (8K5, B8)	AUDI	ALLROAD (4BH, C5)
AUDI	A4 Allroad (8KH, B8)	AUDI	R8
AUDI	A5 (8F7)	VOLKSWAGEN	PHAETON (3D_)
AUDI	A5 (8T3)		
AUDI	A5 (8TA)		
AUDI	A6 (4F2, C6)		
AUDI	A6 (4F5, C6)		
AUDI	A8 (4D2, 4D8)		

500073

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 99 \text{ mm}$
 $H = 90 \text{ mm}$



AUDI	80 (81, 85, B2)	VOLKSWAGEN	CADDY II (9K9A)
AUDI	80 (8C, B4)	VOLKSWAGEN	CORRADO (53I)
AUDI	A3 (8L1)	VOLKSWAGEN	GOLF I (155)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	GOLF II (19E, 1G1)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	GOLF III (1E7)
AUDI	A6 (4A, C4)	VOLKSWAGEN	GOLF III (1H1)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	GOLF III (1H5)
AUDI	A6 (4B5, C5)	VOLKSWAGEN	GOLF IV (1E7)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	PASSAT (32B)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	PASSAT (3A2, 35I)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	PASSAT (3A5, 35I)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	PASSAT (3B3)
SEAT	INCA (6K9)	VOLKSWAGEN	PASSAT (3B6)
SEAT	LEON (1M1)	VOLKSWAGEN	POLO (6KV2)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	POLO (6KV5)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	SCIROCCO (53B)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	VENTO (1H2)
SKODA	OCTAVIA (1U5)		
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	BORA (1J6)		

500096

APPLICATION

BOX SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 99 \text{ mm}$
 $H = 99 \text{ mm}$



AUDI	100 (43, C2)
AUDI	100 (44, 44Q, C3)
AUDI	100 (44, 44W, C3)
AUDI	100 (4A, C4)
AUDI	80 (80, 82, B1)
AUDI	80 (81, 85, B2)
VOLKSWAGEN	SANTANA (32B)
VOLKSWAGEN	TRANSPORTER II

500365

BOX SIDE
 Ø = 21,5 mm
 Ø = 70 mm
 H = 85 mm



APPLICATION

AUDI	A3 (8P1)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	A3 (8P7)	VOLKSWAGEN	GOLF V (1K1)
AUDI	A3 (8PA)	VOLKSWAGEN	GOLF V (1K5)
AUDI	A4 (8E2, B6)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	GOLF VI (AJ5)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	JETTA III (1K2)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	JETTA IV (162, 163)
AUDI	A4 (8H7, 8HE, B6, B7)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
AUDI	A6 (4F2, C6)	VOLKSWAGEN	NEW BEETLE (1Y7)
AUDI	A6 (4F5, C6)	VOLKSWAGEN	PASSAT (3C2)
AUDI	A6 Allroad (4FH, C6)	VOLKSWAGEN	PASSAT (3C5)
AUDI	A8 (4E_)	VOLKSWAGEN	PASSAT CC (357)
AUDI	TT (8N3)	VOLKSWAGEN	SCIROCCO (137, 138)
AUDI	TT (8N9)	VOLKSWAGEN	SHARAN (7M6, 7M8, 7M9)
SEAT	ALHAMBRA (7V8, 7V9)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SEAT	ALTEA (5P1)		
SEAT	ALTEA XL (5P5, 5P8)		
SEAT	EXEO (3R2)		
SEAT	EXEO (3R5)		
SEAT	LEON (1P1)		
SEAT	TOLEDO III (5P2)		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	BORA (1J6)		
VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)		
VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)		
VOLKSWAGEN	EOS (1F7, 1F8)		
VOLKSWAGEN	GOLF IV (1J1)		
VOLKSWAGEN	GOLF IV (1J5)		

500050

WHEEL SIDE
 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$



APPLICATION

AUDI	100 (43, C2)	VOLKSWAGEN	CORRADO (53I)
AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	GOLF I (155)
AUDI	100 (4A, C4)	VOLKSWAGEN	GOLF II (19E, 1G1)
AUDI	100 (C1)	VOLKSWAGEN	GOLF III (1E7)
AUDI	200 (43)	VOLKSWAGEN	GOLF III (1H1)
AUDI	200 (44, 44Q)	VOLKSWAGEN	GOLF III (1H5)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	PASSAT (32B)
AUDI	80 (8C, B4)	VOLKSWAGEN	PASSAT (3A2, 35I)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	PASSAT (3A5, 35I)
AUDI	90 (89, 89Q, 8A, B3)	VOLKSWAGEN	PASSAT (3B2)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A6 (4A, C4)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	POLO (6KV2)
AUDI	A6 (4B5, C5)	VOLKSWAGEN	POLO (6KV5)
AUDI	ALLROAD (4BH, C5)	VOLKSWAGEN	SANTANA (32B)
AUDI	CABRIOLET (8G7, B4)	VOLKSWAGEN	SCIROCCO (53B)
AUDI	COUPE B2 (81, 855, 856)	VOLKSWAGEN	VENTO (1H2)
AUDI	COUPE B3 (89, 8B3)		
AUDI	QUATTRO (85)		
PORSCHE	911 (964)		
PORSCHE	911 (964) Targa		
PORSCHE	911 (993)		
SEAT	CORDOBA (6K1, 6K2)		
SEAT	CORDOBA (6K2)		
SEAT	CORDOBA (6K5)		
SEAT	IBIZA II (6K1)		
SEAT	IBIZA III (6K1)		
SEAT	INCA (6K9)		
SEAT	TOLEDO I (1L)		
SKODA	SUPERB (3U4)		
VOLKSWAGEN	CADDY II (9K9A)		

500050E

APPLICATION

WHEEL SIDE
 $\varnothing = 21,8 \text{ mm}$
 $\varnothing = 82,4 \text{ mm}$
 $H = 81,6 \text{ mm}$



AUDI	100 (43, C2)	VOLKSWAGEN	CORRADO (53I)
AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	GOLF I (155)
AUDI	100 (4A, C4)	VOLKSWAGEN	GOLF II (19E, 1G1)
AUDI	100 (C1)	VOLKSWAGEN	GOLF III (1E7)
AUDI	200 (43)	VOLKSWAGEN	GOLF III (1H1)
AUDI	200 (44, 44Q)	VOLKSWAGEN	GOLF III (1H5)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	GOLF Mk III (1H1)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
AUDI	80 (8C, B4)	VOLKSWAGEN	PASSAT (32B)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	PASSAT (3A2, 35I)
AUDI	90 (89, 89Q, 8A, B3)	VOLKSWAGEN	PASSAT (3A5, 35I)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	PASSAT (3B2)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A6 (4A, C4)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A6 (4B5, C5)	VOLKSWAGEN	POLO (6KV2)
AUDI	ALLROAD (4BH, C5)	VOLKSWAGEN	POLO (6KV5)
AUDI	CABRIOLET (8G7, B4)	VOLKSWAGEN	SANTANA (32B)
AUDI	COUPE B2 (81, 855, 856)	VOLKSWAGEN	SCIROCCO (53B)
AUDI	COUPE B3 (89, 8B3)	VOLKSWAGEN	VENTO (1H2)
AUDI	QUATTRO (85)		
PORSCHE	911 (964)		
PORSCHE	911 (964) Targa		
PORSCHE	911 (993)		
SEAT	CORDOBA (6K1, 6K2)		
SEAT	CORDOBA (6K2)		
SEAT	CORDOBA (6K5)		
SEAT	IBIZA II (6K1)		
SEAT	IBIZA III (6K1)		
SEAT	INCA (6K9)		
SEAT	TOLEDO I (1L)		
SKODA	SUPERB (3U4)		
VOLKSWAGEN	CADDY II (9K9A)		

500190

APPLICATION

WHEEL SIDE
 $\varnothing = 22,2 \text{ mm}$
 $\varnothing = 75,7 \text{ mm}$
 $H = 112 \text{ mm}$



AUDI	ALLROAD (4BH, C5)
------	-------------------

500483

APPLICATION

BOX SIDE

Ø = 22,9 mm

Ø = 69,15 mm

H = 86 mm



AUDI	A3 (8P1)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	A3 (8PA)	VOLKSWAGEN	GOLF V (1K1)
AUDI	TT (8J3)	VOLKSWAGEN	GOLF V (1K5)
AUDI	TT (8J9)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	ALTEA (5P1)	VOLKSWAGEN	JETTA III (1K2)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	JETTA IV (162, 163)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	PASSAT (3C2)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	PASSAT (3C5)
SEAT	LEON (1P1)	VOLKSWAGEN	PASSAT CC (357)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	POLO (9N_)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SKODA	FABIA (545, 5J)		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		
SKODA	ROOMSTER (5J)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		
SKODA	YETI (5L)		
VOLKSWAGEN	CC (358)		

500085

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 71 mm

H = 78 mm



SEAT	FURA (025A)
SEAT	MARBELLA (28)
SEAT	PANDA (141A)
SEAT	RONDA (022A)

500158

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 73 mm

H = 74 mm



SEAT	FURA (025A)
SEAT	MARBELLA (028A)
SEAT	PANDA (141A)
SEAT	RONDA (022A)

500081

APPLICATION

BOX SIDE

Ø = 23 mm

Ø = 80 mm

H = 80 mm



SEAT	PANDA (141A)
------	--------------

500046

APPLICATION

WHEEL SIDE
 $\varnothing = 23,1 \text{ mm}$
 $\varnothing = 75,9 \text{ mm}$
 $H = 82 \text{ mm}$



SEAT

RONDA (022A)

500067

APPLICATION

BOX SIDE
 $\varnothing = 23,2 \text{ mm}$
 $\varnothing = 56,2 \text{ mm}$
 $H = 99 \text{ mm}$



AUDI A3 (8L1)
 AUDI A4 (8E2, B6)
 AUDI A4 (8E5, B6)
 AUDI A4 (8EC, B7)
 AUDI A4 (8ED, B7)
 AUDI A4 (8H7, 8HE, B6, B7)
 AUDI R8
 AUDI TT (8N3)
 AUDI TT (8N9)
 SEAT ALHAMBRA (7V8, 7V9)
 SEAT CORDOBA (6L2)
 SEAT IBIZA IV (6L1)
 SEAT LEON (1M1)
 SEAT TOLEDO II (1M2)
 SKODA FABIA (6Y2)
 SKODA OCTAVIA (1U2)
 SKODA OCTAVIA (1U5)
 VOLKSWAGEN BORA (1J2)
 VOLKSWAGEN BORA (1J6)
 VOLKSWAGEN GOLF IV (1J1)
 VOLKSWAGEN GOLF IV (1J5)
 VOLKSWAGEN GOLF IV Van (1J1)
 VOLKSWAGEN GOLF VAN IV Variant (1J5)
 VOLKSWAGEN MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)
 VOLKSWAGEN NEW BEETLE (1C1, 9C1)
 VOLKSWAGEN PASSAT (3B2)
 VOLKSWAGEN PHAETON (3D_)
 VOLKSWAGEN SHARAN (7M6, 7M8, 7M9)
 VOLKSWAGEN TRANSPORTER IV (70A, 70H, 7DA, 7DH)

VOLKSWAGEN TRANSPORTER IV (70XA)
 VOLKSWAGEN TRANSPORTER IV (70XB, 70XC, 7DB, 7DK, 7DW)
 VOLKSWAGEN TRANSPORTER IV (70XD)
 VOLKSWAGEN TRANSPORTER V (7EA, 7EH, 7HA, 7HH)
 VOLKSWAGEN TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
 VOLKSWAGEN TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
 VOLKSWAGEN TRANSPORTER V (7JD, 7JE, 7JL, 7JY, 7JZ, 7FD)

500079

APPLICATION

BOX SIDE
 $\varnothing = 23,5 \text{ mm}$
 $\varnothing = 60 \text{ mm}$
 $H = 82,4 \text{ mm}$



AUDI 100 (43, C2)
 AUDI 100 (4A, C4)
 AUDI 100 (C1)
 VOLKSWAGEN TRANSPORTER III

500121

APPLICATION

WHEEL SIDE
 $\emptyset = 23,9 \text{ mm}$
 $\emptyset = 92 \text{ mm}$
 $H = 83 \text{ mm}$



AUDI	100 (44, 44Q, C3)
AUDI	100 (4A, C4)
AUDI	200 (44, 44Q)
AUDI	80 (81, 85, B2)
AUDI	A6 (4A, C4)
AUDI	QUATTRO (85)
AUDI	V8 (44_, 4C_)

500175

APPLICATION

BOX SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 70 \text{ mm}$
 $H = 116 \text{ mm}$



AUDI	A3 (8L1)	AUDI	ALLROAD (4BH, C5)
AUDI	A4 (8E2, B6)	SEAT	ALHAMBRA (7V8, 7V9)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	BORA (1J2)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	BORA (1J6)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A4 (8H7, 8HE, B6, B7)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	A6 (4B2)	VOLKSWAGEN	PHAETON (3D_)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	SHARAN (7M6, 7M8, 7M9)
AUDI	A6 (4B5, C5)		

500240T

APPLICATION

WHEEL SIDE
 $\emptyset = 24 \text{ mm}$
 $\emptyset = 84 \text{ mm}$
 $H = 115 \text{ mm}$



AUDI	A4 (8D2, B5)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A4 (8E2, B6)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	PASSAT Variant (3B6)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	POLO (6N1)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	POLO (6N2)
AUDI	A4 (8H7, 8HE, B6, B7)		
AUDI	A4 (8K5, B8)		
AUDI	A4 Allroad (8KH, B8)		
AUDI	A5 (8F7)		
AUDI	A5 (8T3)		
AUDI	A5 (8TA)		
AUDI	A6 (4B2, C5)		
AUDI	A6 (4B5, C5)		
AUDI	Q5 (8R)		
SEAT	AROSA (6H)		
SEAT	EXEO (3R2)		
SEAT	EXEO (3R5)		
SKODA	SUPERB (3U4)		
VOLKSWAGEN	LUPO (6E1, 6X1)		
VOLKSWAGEN	PASSAT (3B2)		

500036

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 90,5 \text{ mm}$
 $H = 88 \text{ mm}$



AUDI 100 (4A, C4)
 AUDI 80 (8C, B4)
 AUDI 90 (89, 89Q, 8A, B3)
 AUDI A4 (8D2, B5)
 AUDI A4 (8D5, B5)
 AUDI A4 (8E2, B6)
 AUDI A6 (4A, C4)
 AUDI A6 (4B2, C5)
 AUDI A6 (4B5, C5)
 AUDI A8 (4D2, 4D8)
 AUDI ALLROAD (4BH, C5)
 AUDI CABRIOLET (8G7, B4)
 AUDI COUPE B3 (89, 8B3)
 AUDI V8 (44_, 4C_)
 SKODA SUPERB (3U4)
 VOLKSWAGEN PASSAT (3B2)
 VOLKSWAGEN PASSAT (3B3)
 VOLKSWAGEN PASSAT (3B5)
 VOLKSWAGEN PASSAT (3B6)
 VOLKSWAGEN TRANSPORTER III

VOLKSWAGEN TRANSPORTER IV (70XA)
 VOLKSWAGEN TRANSPORTER IV (70XB, 70XC, 7DB, 7DK, 7DW)
 VOLKSWAGEN TRANSPORTER IV (70XD)

500633

APPLICATION

WHEEL SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 92 \text{ mm}$
 $H = 85 \text{ mm}$



AUDI 100 (43, C2)
 AUDI 100 (44, 44Q, C3)
 AUDI 200 (43)
 AUDI 200 (44, 44Q)

500058

APPLICATION

BOX SIDE
 $\varnothing = 24 \text{ mm}$
 $\varnothing = 99 \text{ mm}$
 $H = 120 \text{ mm}$



AUDI 100 (44, 44Q, C3)
 AUDI 100 (4A, C4)
 AUDI 80 (8C, B4)
 AUDI 90 (81, 85, B2)
 AUDI A4 (8D2, B5)
 AUDI A4 (8D5, B5)
 AUDI A4 (8E2, B6)
 AUDI A4 (8E5, B6)
 AUDI A6 (4A, C4)

AUDI A6 (4B2, C5)
 AUDI A6 (4B5, C5)
 AUDI A8 (4D2, 4D8)
 VOLKSWAGEN PASSAT (3B2)
 VOLKSWAGEN PASSAT (3B3)
 VOLKSWAGEN PASSAT (3B5)
 VOLKSWAGEN PASSAT (3B6)
 VOLKSWAGEN PASSAT Variant (3B6)

500076

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 64 \text{ mm}$
 $H = 86 \text{ mm}$



SEAT FURA (025A)
 SEAT PANDA (141A)

500168T

APPLICATION

WHEEL SIDE
 $\emptyset = 25,5 \text{ mm}$
 $\emptyset = 83 \text{ mm}$
 $H = 110 \text{ mm}$



AUDI	A2 (8Z0)	VOLKSWAGEN	FOX (5Z1, 5Z3)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	POLO (60, 61, 6C, 6R)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	POLO (9A4)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	POLO (9N_)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	POLO Van (6R)
SEAT	IBIZA V (6J1, 6P5)		
SEAT	IBIZA V (6J5, 6P1)		
SEAT	IBIZA V (6J8, 6P8)		
SEAT	TOLEDO IV (KG3)		
SKODA	FABIA		
SKODA	FABIA (542, 5J)		
SKODA	FABIA (545, 5J)		
SKODA	FABIA (6Y2)		
SKODA	FABIA (6Y3)		
SKODA	FABIA (6Y5)		
SKODA	FABIA (NJ3)		
SKODA	FABIA (NJ5)		
SKODA	RAPID (NH1)		
SKODA	RAPID (NH3)		
SKODA	ROOMSTER (5J)		
SKODA	ROOMSTER Praktik (5J)		

500515T

WHEEL SIDE
 Ø = 25,8 mm
 Ø = 86,5 mm
 H = 114 mm



APPLICATION

AUDI	A1 (8X1, 8XK)	VOLKSWAGEN	BEETLE (5C7, 5C8)
AUDI	A1 Sportback (8XA, 8XF)	VOLKSWAGEN	BORA (1J2)
AUDI	A2 (8Z0)	VOLKSWAGEN	BORA (1J6)
AUDI	A3 (8L1)	VOLKSWAGEN	CADDY II (9K9A)
AUDI	A3 (8P1)	VOLKSWAGEN	CADDY II (9K9B)
AUDI	A3 (8P7)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A3 (8PA)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	A3 (8VA, 8VF)	VOLKSWAGEN	CADDY IV (SAA, SAH)
AUDI	A3 (8VM, 8VS)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
AUDI	Q3 (8U)	VOLKSWAGEN	CC (358)
AUDI	TT (8J3)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	TT (8J9)	VOLKSWAGEN	GOLF III (1E7)
AUDI	TT (8N3)	VOLKSWAGEN	GOLF III (1H1)
AUDI	TT (8N9)	VOLKSWAGEN	GOLF III (1H5)
AUDI	TT (FV3)	VOLKSWAGEN	GOLF IV (1E7)
AUDI	TT (FV9)	VOLKSWAGEN	GOLF IV (1J1)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	GOLF V (1K1)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF V (1K5)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	GOLF VI (517)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	GOLF VII (5G1, BE1)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	GOLF VII (BA5)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	JETTA III (1K2)
SEAT	IBIZA V (6J8, 6P8)	VOLKSWAGEN	JETTA IV (162, 163)
SEAT	INCA (6K9)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	LEON (1M1)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	LEON (1P1)	VOLKSWAGEN	PASSAT (362)
SEAT	LEON (5F1)	VOLKSWAGEN	PASSAT (365)
SEAT	LEON (5F8)	VOLKSWAGEN	PASSAT (3A5, 35I)
SEAT	LEON SC (5F5)	VOLKSWAGEN	PASSAT (3B2)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	PASSAT (3B5)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	PASSAT (3C2)
SEAT	TOLEDO IV (KG3)	VOLKSWAGEN	PASSAT (3C5)
SKODA	FABIA	VOLKSWAGEN	PASSAT CC (357)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	POLO (60, 61, 6C, 6R)
SKODA	FABIA (6Y2)	VOLKSWAGEN	POLO (60_, 61_)
SKODA	FABIA (6Y3)	VOLKSWAGEN	POLO (6KV2)
SKODA	FABIA (6Y5)	VOLKSWAGEN	POLO (6KV5)
SKODA	FABIA (NJ3)	VOLKSWAGEN	POLO (6NF)
SKODA	FABIA (NJ5)	VOLKSWAGEN	POLO (9A4)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	POLO (9N_)
SKODA	OCTAVIA (1U5)	VOLKSWAGEN	POLO Van (6R)
SKODA	OCTAVIA (1Z3)	VOLKSWAGEN	SCIROCCO (137, 138)
SKODA	OCTAVIA (1Z5)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SKODA	OCTAVIA (5E3)	VOLKSWAGEN	TOURAN (1T3)
SKODA	OCTAVIA (5E5)		
SKODA	RAPID (NH1)		
SKODA	RAPID (NH3)		
SKODA	ROOMSTER (5J)		
SKODA	ROOMSTER Praktik (5J)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		
SKODA	YETI (5L)		
VOLKSWAGEN	BEETLE (5C1, 5C2)		

500075

APPLICATION

BOX SIDE

Ø = 26 mm

Ø = 61 mm

H = 88 mm



SEAT

RONDA (022A)

500020T

APPLICATION

WHEEL SIDE

Ø = 26 mm

Ø = 78,5 mm

H = 110 mm



AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	GOLF III (1E7)
AUDI	100 (4A, C4)	VOLKSWAGEN	GOLF III (1H1)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	GOLF III (1H5)
AUDI	80 (8C, B4)	VOLKSWAGEN	GOLF IV (1E7)
AUDI	90 (89, 89Q, 8A, B3)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A3 (8L1)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	TT (8N3)	VOLKSWAGEN	GOLF Mk III (1H1)
AUDI	TT (8N9)	VOLKSWAGEN	GOLF Mk IV (1J1)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF V (1K1)
SEAT	AROSA (6H)	VOLKSWAGEN	GOLF V (1K5)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	JETTA I (16)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	LUPO (6E1, 6X1)
SEAT	INCA (6K9)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	LEON (1M1)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	LEON (1P1)	VOLKSWAGEN	PASSAT (32B)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	PASSAT (3A2, 35I)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	PASSAT (3A5, 35I)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	PASSAT (3B2)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	PASSAT (3B5)
SKODA	OCTAVIA (1U5)	VOLKSWAGEN	POLO (6KV2)
SKODA	OCTAVIA (1Z3)	VOLKSWAGEN	POLO (6KV5)
SKODA	OCTAVIA (1Z5)	VOLKSWAGEN	POLO (6N1)
VOLKSWAGEN	BORA (1J2)	VOLKSWAGEN	POLO (6N2)
VOLKSWAGEN	BORA (1J6)	VOLKSWAGEN	POLO (6NF)
VOLKSWAGEN	CADDY I (14)	VOLKSWAGEN	POLO (80, 86C)
VOLKSWAGEN	CADDY II (9K9A)	VOLKSWAGEN	POLO (86CF)
VOLKSWAGEN	CADDY II (9K9B)	VOLKSWAGEN	SANTANA (32B)
VOLKSWAGEN	GOLF I (155)	VOLKSWAGEN	SCIROCCO (53)
VOLKSWAGEN	GOLF I (17)	VOLKSWAGEN	SCIROCCO (53B)
VOLKSWAGEN	GOLF II (19E, 1G1)	VOLKSWAGEN	VENTO (1H2)

500104T

APPLICATION

WHEEL SIDE
 $\emptyset = 26,3 \text{ mm}$
 $\emptyset = 83 \text{ mm}$
 $H = 122 \text{ mm}$



AUDI	A1 (8X1, 8XK)	VOLKSWAGEN	CORRADO (53I)
AUDI	A1 Sportback (8XA, 8XF)	VOLKSWAGEN	GOLF III (1E7)
AUDI	A2 (8Z0)	VOLKSWAGEN	GOLF III (1H1)
AUDI	A3 (8L1)	VOLKSWAGEN	GOLF III (1H5)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF IV (1J1)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	PASSAT (3A2, 35I)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	PASSAT (3A5, 35I)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	POLO (6KV2)
SEAT	LEON (1M1)	VOLKSWAGEN	POLO (6KV5)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	POLO (6N1)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	POLO (9N_)
SKODA	FABIA (6Y2)	VOLKSWAGEN	VENTO (1H2)
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	BORA (1J6)		
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		

500526T

APPLICATION

BOX SIDE
 $\emptyset = 27 \text{ mm}$
 $\emptyset = 71 \text{ mm}$
 $H = 107 \text{ mm}$



AUDI	A4 (8K2, B6)	VOLKSWAGEN	PASSAT (3G2)
AUDI	A4 (8K2, B8)	VOLKSWAGEN	PASSAT (3G5)
AUDI	A4 (8K5, B8)	VOLKSWAGEN	SHARAN (7M6, 7M8, 7M9)
AUDI	A4 Allroad (8KH, B8)	VOLKSWAGEN	SHARAN (7N1, 7N2)
AUDI	A5 (8F7)		
AUDI	A5 (8T3)		
AUDI	A5 (8TA)		
AUDI	A6 (4G2, 4GC, C7)		
AUDI	A6 (4G5, 4GD, C7)		
AUDI	A6 Allroad (4GH, 4GJ)		
AUDI	A6 Sportwagon (4G5, 4GD, C7)		
AUDI	A7 (4GA, 4GF)		
AUDI	A8 (4H_)		
AUDI	Q5 (8R)		
SEAT	ALHAMBRA (7V8, 7V9)		
SKODA	SUPERB (3T5)		
VOLKSWAGEN	GOLF SPORTSVAN (AM1)		
VOLKSWAGEN	PASSAT (3C2)		
VOLKSWAGEN	PASSAT (3C5)		

500612T

APPLICATION

BOX SIDE

Ø = 27 mm

Ø = 87,5 mm

H = 107 mm



AUDI	A1 (8X1, 8XK)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
AUDI	A1 Sportback (8XA, 8XF)	VOLKSWAGEN	GOLF VI (517)
AUDI	A3 (8P1)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	A3 (8P7)	VOLKSWAGEN	GOLF VI Van (5K1_)
AUDI	A3 (8PA)	VOLKSWAGEN	GOLF VII (5G1, BE1)
AUDI	A3 (8V1, 8VK)	VOLKSWAGEN	GOLF VII (BA5)
AUDI	A3 (8V7, 8VE)	VOLKSWAGEN	JETTA III (1K2)
AUDI	A3 (8VA, 8VF)	VOLKSWAGEN	JETTA IV (162, 163)
AUDI	A3 (8VM, 8VS)	VOLKSWAGEN	PASSAT (362)
AUDI	A4 (8K2, B6)	VOLKSWAGEN	PASSAT (365)
AUDI	A4 (8K2, B8)	VOLKSWAGEN	PASSAT (3C2)
AUDI	A4 (8K5, B8)	VOLKSWAGEN	PASSAT (3C5)
AUDI	A4 Allroad (8KH, B8)	VOLKSWAGEN	PASSAT ALLTRACK (365)
AUDI	A5 (8F7)	VOLKSWAGEN	PASSAT CC (357)
AUDI	A5 (8T3)	VOLKSWAGEN	SCIROCCO (137, 138)
AUDI	A5 (8TA)	VOLKSWAGEN	SCIROCCO Van (137)
AUDI	A6 (4G2, 4GC, C7)	VOLKSWAGEN	TIGUAN (5N_)
AUDI	A6 (4G5, 4GD, C7)	VOLKSWAGEN	TOURAN (1T1, 1T2)
AUDI	A6 Allroad (4GH, 4GJ)	VOLKSWAGEN	TOURAN (1T3)
AUDI	A6 Sportwagon (4G5, 4GD, C7)		
AUDI	A7 (4GA, 4GF)		
AUDI	A8 (4H_)		
AUDI	Q3 (8U)		
AUDI	Q5 (8R)		
AUDI	TT (8J3)		
AUDI	TT (8J9)		
SEAT	ALTEA (5P1)		
SEAT	ALTEA XL (5P5, 5P8)		
SEAT	LEON (1P1)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		
VOLKSWAGEN	BEETLE (5C1, 5C2)		
VOLKSWAGEN	BEETLE (5C7, 5C8)		
VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)		
VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)		
VOLKSWAGEN	CC (358)		
VOLKSWAGEN	EOS (1F7, 1F8)		
VOLKSWAGEN	GOLF PLUS (521, 5M1)		
VOLKSWAGEN	GOLF PLUS Van (521)		

500345T

APPLICATION

WHEEL SIDE

Ø = 27 mm

Ø = 88 mm

H = 100 mm



AUDI	A4 (8E5, B6)
------	--------------

500249T

APPLICATION

BOX SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 108 \text{ mm}$



SEAT	AROSA (6H)	VOLKSWAGEN	POLO (6N2)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	POLO (6NF)
SEAT	CORDOBA (6K2)		
SEAT	CORDOBA (6K5)		
SEAT	IBIZA II (6K1)		
SEAT	IBIZA III (6K1)		
SEAT	INCA (6K9)		
SEAT	LEON (1M1)		
SKODA	FABIA		
SKODA	FABIA (6Y2)		
SKODA	FABIA (6Y3)		
SKODA	FABIA (6Y5)		
SKODA	OCTAVIA (1U2)		
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		
VOLKSWAGEN	CADDY II (9U7)		
VOLKSWAGEN	GOLF III (1H1)		
VOLKSWAGEN	LUPO (6E1, 6X1)		
VOLKSWAGEN	POLO (6KV2)		
VOLKSWAGEN	POLO (6KV5)		
VOLKSWAGEN	POLO (6N1)		

500227T

APPLICATION

WHEEL SIDE
 $\varnothing = 27 \text{ mm}$
 $\varnothing = 89 \text{ mm}$
 $H = 125 \text{ mm}$



SKODA	OCTAVIA (1U2)
SKODA	OCTAVIA (1U5)

500246T

BOX SIDE

Ø = 27 mm

Ø = 94 mm

H = 108 mm



APPLICATION

AUDI	100 (44, 44Q, C3)	VOLKSWAGEN	FOX (5Z1, 5Z3)
AUDI	A1 (8X1, 8XK)	VOLKSWAGEN	GOLF ALLTRACK (BA5)
AUDI	A1 Sportback (8XA, 8XF)	VOLKSWAGEN	GOLF III (1E7)
AUDI	A2 (8Z0)	VOLKSWAGEN	GOLF III (1H1)
AUDI	A3 (8L1)	VOLKSWAGEN	GOLF III (1H5)
AUDI	A3 (8V1, 8VK)	VOLKSWAGEN	GOLF IV (1E7)
AUDI	A3 (8V7, 8VE)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A3 (8VA, 8VF)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	A3 (8VM, 8VS)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	Q2 (GA)	VOLKSWAGEN	GOLF V (1K1)
AUDI	TT (FV3)	VOLKSWAGEN	GOLF V (1K5)
AUDI	TT (FV9)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	TT Roadster (FV9)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF VII (5G1, BE1)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF VII (5G1, BQ1, BE1, BE2)
SEAT	AROSA (6H)	VOLKSWAGEN	GOLF VII (BA5)
SEAT	ATECA (KH7)	VOLKSWAGEN	GOLF VII Variant (BA5, BV5)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	LUPO (6E1, 6X1)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	PASSAT (3G2)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	PASSAT (3G5)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	PASSAT ALLTRACK (3G5)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	POLO (60, 61, 6C, 6R)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	POLO (6KV2)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	POLO (6KV5)
SEAT	IBIZA V (6J8, 6P8)	VOLKSWAGEN	POLO (6N1)
SEAT	INCA (6K9)	VOLKSWAGEN	POLO (6N2)
SEAT	LEON (1M1)	VOLKSWAGEN	POLO (6NF)
SEAT	LEON (1P1)	VOLKSWAGEN	POLO (9A4)
SEAT	LEON (5F8)	VOLKSWAGEN	POLO (9N_)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	TIGUAN (AD1)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	TIGUAN ALLSPACE (BW2)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SEAT	TOLEDO IV (KG3)	VOLKSWAGEN	VENTO (1H2)
SKODA	FABIA		
SKODA	FABIA (545, 5J)		
SKODA	FABIA (6Y2)		
SKODA	FABIA (6Y3)		
SKODA	FABIA (6Y5)		
SKODA	KODIAQ		
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		
SKODA	RAPID (NH1)		
SKODA	RAPID (NH3)		
SKODA	ROOMSTER (5J)		
SKODA	ROOMSTER Praktik (5J)		
SKODA	SUPERB (3V3)		
SKODA	SUPERB (3V5)		
VOLKSWAGEN	ARTEON		
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	BORA (1J6)		
VOLKSWAGEN	CADDY II (9K9A)		
VOLKSWAGEN	CADDY II (9K9B)		

500559T

APPLICATION

BOX SIDE

Ø = 27 mm

Ø = 100 mm

H = 115 mm



AUDI	A1 (8X1, 8XK)	SKODA	OCTAVIA III (5E3, NL3, NR3)
AUDI	A1 Sportback (8XA, 8XF)	SKODA	OCTAVIA III (5E5)
AUDI	A2 (8Z0)	SKODA	RAPID (NH1)
AUDI	A3 (8L1)	SKODA	RAPID (NH3)
AUDI	A3 (8P1)	SKODA	ROOMSTER (5J)
AUDI	A3 (8P7)	SKODA	ROOMSTER Praktik (5J)
AUDI	A3 (8PA)	SKODA	SUPERB (3T4)
AUDI	A3 (8V1, 8VK)	SKODA	SUPERB (3T5)
AUDI	A3 (8V7, 8VE)	SKODA	YETI (5L)
AUDI	A3 (8VA, 8VF)	VOLKSWAGEN	ARTEON
AUDI	A3 (8VM, 8VS)	VOLKSWAGEN	BEETLE (5C1, 5C2)
AUDI	A3 (8VS, 8VM)	VOLKSWAGEN	BEETLE (5C7, 5C8)
AUDI	A3 Limousine (8VS, 8VM)	VOLKSWAGEN	BORA (1J2)
AUDI	A3 Sportback (8VA, 8VF)	VOLKSWAGEN	BORA (1J6)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	CADDY ALLTRACK (SAA)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	CADDY ALLTRACK (SAB)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	CADDY II (9K9A)
AUDI	Q2 (GA)	VOLKSWAGEN	CADDY II (9K9B)
AUDI	Q3 (8U)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	Q5 (8R)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	TT (8J3)	VOLKSWAGEN	CADDY IV (SAA, SAH)
AUDI	TT (8J9)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
AUDI	TT (8N3)	VOLKSWAGEN	CC (358)
AUDI	TT (8N9)	VOLKSWAGEN	EOS (1F7, 1F8)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF IV (1E7)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF IV (1J1)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	GOLF V (1K1)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	GOLF V (1K5)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	GOLF VI (517)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	GOLF VII (5G1, BE1)
SEAT	IBIZA V (6J8, 6P8)	VOLKSWAGEN	GOLF VII (5G1, BQ1, BE1, BE2)
SEAT	INCA (6K9)	VOLKSWAGEN	GOLF VII (5G1, BQ1, BE2)
SEAT	LEON (1M1)	VOLKSWAGEN	GOLF VII (BA5)
SEAT	LEON (1P1)	VOLKSWAGEN	GOLF VII (BA5, BV5)
SEAT	LEON (5F1)	VOLKSWAGEN	JETTA III (1K2)
SEAT	LEON (5F8)	VOLKSWAGEN	JETTA IV (162, 163)
SEAT	LEON SC (5F5)	VOLKSWAGEN	LUPO (6E1, 6X1)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	TOLEDO IV (KG3)	VOLKSWAGEN	PASSAT (362)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	PASSAT (365)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	PASSAT (3B2)
SKODA	FABIA (6Y2)	VOLKSWAGEN	PASSAT (3B5)
SKODA	FABIA (NJ3)		
SKODA	FABIA (NJ5)		
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		

500559T

APPLICATION

BOX SIDE

Ø = 27 mm

Ø = 100 mm

H = 115 mm



VOLKSWAGEN	PASSAT (3C2)
VOLKSWAGEN	PASSAT (3C5)
VOLKSWAGEN	PASSAT (3G2)
VOLKSWAGEN	PASSAT (3G5)
VOLKSWAGEN	PASSAT ALLTRACK (365)
VOLKSWAGEN	PASSAT ALLTRACK (3G5)
VOLKSWAGEN	PASSAT CC (357)
VOLKSWAGEN	POLO (60, 61, 6C, 6R)
VOLKSWAGEN	POLO (60_, 61_)
VOLKSWAGEN	POLO (6KV2)
VOLKSWAGEN	POLO (6KV5)
VOLKSWAGEN	POLO (6N2)
VOLKSWAGEN	POLO (9N_)
VOLKSWAGEN	POLO (AW1, BZ1)
VOLKSWAGEN	POLO Van (6R)
VOLKSWAGEN	SCIROCCO (137, 138)
VOLKSWAGEN	TIGUAN (5N_)
VOLKSWAGEN	TIGUAN (AD1)

VOLKSWAGEN	TIGUAN ALLSPACE (BW2)
VOLKSWAGEN	TOURAN (1T1, 1T2)
VOLKSWAGEN	TOURAN (1T3)

500011T

APPLICATION

WHEEL SIDE

Ø = 27,2 mm

Ø = 98,1 mm

H = 144,5 mm



SEAT	ALHAMBRA (7V8, 7V9)
VOLKSWAGEN	SHARAN (7M6, 7M8, 7M9)
VOLKSWAGEN	TRANSPORTER IV (70XA)
VOLKSWAGEN	TRANSPORTER IV (70XB, 70XC, 7DB, 7DK, 7DW)

VOLKSWAGEN	TRANSPORTER IV (70XD)
------------	-----------------------

500252T

BOX SIDE

Ø = 27,4 mm

Ø = 100,4 mm

H = 114 mm



APPLICATION

AUDI	100 (4A, C4)	VOLKSWAGEN	CADDY II (9K9A)
AUDI	A2 (8Z0)	VOLKSWAGEN	CADDY II (9K9B)
AUDI	A3 (8L1)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A3 (8P1)		CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	A3 (8P7)	VOLKSWAGEN	CC (358)
AUDI	A3 (8PA)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	A3 (8V1, 8VK)	VOLKSWAGEN	GOLF IV (1E7)
AUDI	A3 (8V7, 8VE)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A3 (8VA, 8VF)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	A3 (8VM, 8VS)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	GOLF V (1K1)
AUDI	A4 (8K2, B8)	VOLKSWAGEN	GOLF V (1K5)
AUDI	A4 (8K5, B8)	VOLKSWAGEN	GOLF VI (517)
AUDI	A4 Allroad (8KH, B8)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	A5 (8F7)	VOLKSWAGEN	GOLF VI (AJ5)
AUDI	A5 (8T3)	VOLKSWAGEN	GOLF VII (5G1, BE1)
AUDI	A5 (8TA)	VOLKSWAGEN	GOLF VII (BA5)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	JETTA III (1K2)
AUDI	Q3 (8U)	VOLKSWAGEN	JETTA IV (162, 163)
AUDI	TT (8J3)	VOLKSWAGEN	LUPO (6E1, 6X1)
AUDI	TT (8J9)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
AUDI	TT (8N3)	VOLKSWAGEN	NEW BEETLE (1Y7)
AUDI	TT (8N9)	VOLKSWAGEN	PASSAT (362)
SEAT	ALHAMBRA (710, 711)	VOLKSWAGEN	PASSAT (365)
SEAT	ALTEA (5P1)	VOLKSWAGEN	PASSAT (3C2)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	PASSAT (3C5)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	PASSAT ALLTRACK (365)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	PASSAT CC (357)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	POLO (6KV2)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	POLO (6KV5)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	POLO (6N2)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	POLO (9N_)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	SCIROCCO (137, 138)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	TIGUAN (5N_)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SEAT	INCA (6K9)	VOLKSWAGEN	TOURAN (1T3)
SEAT	LEON (1M1)		
SEAT	LEON (1P1)		
SEAT	LEON (5F1)		
SEAT	LEON (5F8)		
SEAT	LEON SC (5F5)		
SEAT	TOLEDO II (1M2)		
SEAT	TOLEDO III (5P2)		
SKODA	FABIA (6Y2)		
SKODA	FABIA (6Y3)		
SKODA	FABIA (6Y5)		
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		
SKODA	ROOMSTER (5J)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		
SKODA	YETI (5L)		
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	BORA (1J6)		

500488T

APPLICATION

BOX SIDE

Ø = 27,5 mm

Ø = 70,9 mm

H = 107,5 mm



AUDI	A2 (8Z0)	SKODA	ROOMSTER Praktik (5J)
AUDI	A3 (8L1)	VOLKSWAGEN	BORA (1J2)
AUDI	A4 (8E2, B6)	VOLKSWAGEN	BORA (1J6)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	TT (8N3)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	TT (8N9)	VOLKSWAGEN	LUPO (6E1, 6X1)
SEAT	AROSA (6H)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	POLO (6N1)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	POLO (6N2)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	POLO (9A4)
SEAT	LEON (1M1)	VOLKSWAGEN	POLO (9N_)
SEAT	TOLEDO II (1M2)		
SKODA	FABIA (542, 5J)		
SKODA	FABIA (545, 5J)		
SKODA	FABIA (6Y2)		
SKODA	FABIA (6Y3)		
SKODA	FABIA (6Y5)		
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
SKODA	ROOMSTER (5J)		

500510T

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 67 mm

H = 102 mm



AUDI	A1 (8X1, 8XK)	SKODA	FABIA (6Y2)
AUDI	A1 Sportback (8XA, 8XF)	SKODA	FABIA (NJ3)
AUDI	A3 (8L1)	SKODA	FABIA (NJ5)
AUDI	A3 (8P1)	SKODA	KODIAQ
AUDI	A3 (8P7)	SKODA	OCTAVIA (1U5)
AUDI	A3 (8PA)	SKODA	OCTAVIA (1Z3)
AUDI	A3 (8V1, 8VK)	SKODA	OCTAVIA (1Z5)
AUDI	A3 (8V7, 8VE)	SKODA	OCTAVIA (5E3)
AUDI	A3 (8VA, 8VF)	SKODA	OCTAVIA (5E5)
AUDI	A3 (8VM, 8VS)	SKODA	OCTAVIA III (5E3, NL3, NR3)
AUDI	A3 Limousine (8VS, 8VM)	SKODA	OCTAVIA III (5E5)
AUDI	A3 Sportback (8VA, 8VF)	SKODA	RAPID (NH1)
AUDI	A4 (8K2, B8)	SKODA	RAPID (NH3)
AUDI	A4 (8K5, B8)	SKODA	SUPERB (3T4)
AUDI	A4 Allroad (8KH, B8)	SKODA	SUPERB (3T5)
AUDI	A5 (8F7)	SKODA	SUPERB (3V3)
AUDI	A5 (8T3)	SKODA	SUPERB (3V5)
AUDI	A5 (8TA)	SKODA	YETI (5L)
AUDI	A6 (4F2, C6)	VOLKSWAGEN	AMAROK (2H_, S1B)
AUDI	A6 (4F5, C6)	VOLKSWAGEN	AMAROK (2HA, 2HB, S1B, S6B, S7A, S7B)
AUDI	A6 (4G2, 4GC, C7)	VOLKSWAGEN	AMAROK (S1B)
AUDI	A6 (4G5, 4GD, C7)	VOLKSWAGEN	ARTEON
AUDI	A6 Allroad (4FH, C6)	VOLKSWAGEN	BEETLE (5C1, 5C2)
AUDI	A6 Allroad (4GH, 4GJ)	VOLKSWAGEN	BEETLE (5C7, 5C8)
AUDI	A6 Sportwagon (4G5, 4GD, C7)	VOLKSWAGEN	BORA (1J2)
AUDI	A7 (4GA, 4GF)	VOLKSWAGEN	BORA (1J6)
AUDI	A8 (4H_)	VOLKSWAGEN	CADDY ALLTRACK (SAA)
AUDI	Q2 (GA)	VOLKSWAGEN	CADDY ALLTRACK (SAB)
AUDI	Q3 (8U)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	Q5 (8R)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	Q7 (4L)	VOLKSWAGEN	CADDY IV (SAA, SAH)
AUDI	TT (8J3)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
AUDI	TT (8J9)	VOLKSWAGEN	CC (358)
AUDI	TT (8N3)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	TT (8N9)	VOLKSWAGEN	GOLF ALLTRACK (BA5)
PORSCHE	CAYENNE (92A)	VOLKSWAGEN	GOLF IV (1J1)
PORSCHE	CAYENNE (9PA)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
SEAT	ATECA (KH7)	VOLKSWAGEN	GOLF V (1K1)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	GOLF V (1K5)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	GOLF VI (517)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	IBIZA V (6J8, 6P8)	VOLKSWAGEN	GOLF VII (5G1, BE1)
SEAT	LEON (1M1)	VOLKSWAGEN	GOLF VII (5G1, BQ1, BE1, BE2)
SEAT	LEON (1P1)	VOLKSWAGEN	GOLF VII (BA5)
SEAT	LEON (5F1)	VOLKSWAGEN	GOLF VII (BA5, BV5)
SEAT	LEON (5F8)		
SEAT	LEON SC (5F5)		
SEAT	LEON ST (5F8)		
SEAT	TOLEDO II (1M2)		
SEAT	TOLEDO III (5P2)		
SEAT	TOLEDO IV (KG3)		
SKODA	FABIA (542, 5J)		
SKODA	FABIA (545, 5J)		

500510T

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 67 mm

H = 102 mm



VOLKSWAGEN	GOLF VII Variant (BA5, BV5)
VOLKSWAGEN	JETTA III (1K2)
VOLKSWAGEN	JETTA IV (162, 163)
VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)
VOLKSWAGEN	MULTIVAN VI (SGF, SGM, SGN)
VOLKSWAGEN	PASSAT (362)
VOLKSWAGEN	PASSAT (365)
VOLKSWAGEN	PASSAT (3C2)
VOLKSWAGEN	PASSAT (3C5)
VOLKSWAGEN	PASSAT (3G2)
VOLKSWAGEN	PASSAT (3G5)
VOLKSWAGEN	PASSAT ALLTRACK (365)
VOLKSWAGEN	PASSAT ALLTRACK (3G5)
VOLKSWAGEN	PASSAT CC (357)
VOLKSWAGEN	POLO (60, 61, 6C, 6R)
VOLKSWAGEN	POLO (60_, 61_)
VOLKSWAGEN	POLO (9N_)
VOLKSWAGEN	POLO Van (6R)
VOLKSWAGEN	SCIROCCO (137, 138)
VOLKSWAGEN	TIGUAN (5N_)
VOLKSWAGEN	TIGUAN (AD1)
VOLKSWAGEN	TOUAREG (7L6, 7L7, 7LA)
VOLKSWAGEN	TOUAREG (7P5)
VOLKSWAGEN	TOURAN (1T1, 1T2)
VOLKSWAGEN	TOURAN (1T3)
VOLKSWAGEN	TOURAN (5T1)
VOLKSWAGEN	TRANSPORTER Mk VI (SFD, SFE, SFL, SFZ)

VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)
VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
VOLKSWAGEN	TRANSPORTER VI (SFD, SFE, SFL, SFZ)
VOLKSWAGEN	TRANSPORTER VI (SGA, SGH)
VOLKSWAGEN	TRANSPORTER VI (SGB, SGG, SGJ)

500574T

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 80 mm

H = 122 mm



VOLKSWAGEN	CRAFTER (SY_)
VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)
VOLKSWAGEN	MULTIVAN VI (SGF, SGM, SGN)
VOLKSWAGEN	TRANSPORTER Mk VI (SFD, SFE, SFL, SFZ)
VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)
VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
VOLKSWAGEN	TRANSPORTER VI (SFD, SFE, SFL, SFZ)
VOLKSWAGEN	TRANSPORTER VI (SGA, SGH)
VOLKSWAGEN	TRANSPORTER VI (SGB, SGG, SGJ)

500138

APPLICATION

BOX SIDE

Ø = 28 mm

Ø = 99 mm

H = 100 mm



AUDI	100 (4A, C4)	AUDI	COUPE B3 (89, 8B3)
AUDI	80 (81, 85, B2)	SKODA	OCTAVIA (1U2)
AUDI	80 (89, 89Q, 8A, B3)	SKODA	OCTAVIA (1U5)
AUDI	80 (8C, B4)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	PASSAT (32B)
AUDI	90 (89, 89Q, 8A, B3)	VOLKSWAGEN	PASSAT (3B3)
AUDI	CABRIOLET (8G7, B4)	VOLKSWAGEN	PASSAT (3B6)
AUDI	COUPE B2 (81, 855, 856)	VOLKSWAGEN	SANTANA (32B)

500571T

APPLICATION

WHEEL SIDE

Ø = 28,5 mm

Ø = 62,5 mm

H = 86 mm



AUDI	A4 (8K2, B8)
AUDI	A4 (8K5, B8)
AUDI	A4 Allroad (8KH, B8)
AUDI	A5 (8F7)
AUDI	A5 (8T3)
AUDI	A5 (8TA)
AUDI	A8 (4E_)
AUDI	A8 (4E2, 4E8)
AUDI	Q7 (4L)
AUDI	Q7 (4LB)
AUDI	R8
VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)
VOLKSWAGEN	MULTIVAN VI (SGF, SGM, SGN)
VOLKSWAGEN	PHAETON (3D_)
VOLKSWAGEN	TOUAREG (7L6, 7L7, 7LA)
VOLKSWAGEN	TRANSPORTER Mk VI (SFD, SFE, SFL, SFZ)
VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)
VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)

500571T

APPLICATION

WHEEL SIDE
 $\emptyset = 28,5 \text{ mm}$
 $\emptyset = 62,5 \text{ mm}$
 $H = 86 \text{ mm}$



VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
VOLKSWAGEN	TRANSPORTER V (7HA, 7HH, 7EA, 7EH)
VOLKSWAGEN	TRANSPORTER V (7HB, 7HJ, 7EB, 7EJ, 7EF, 7EG, 7HF, 7EC) I TRANSPORTER / CARAVELLE I CARAVELLE
VOLKSWAGEN	TRANSPORTER VI (SFD, SFE, SFL, SFZ)
VOLKSWAGEN	TRANSPORTER VI (SGA, SGH)
VOLKSWAGEN	TRANSPORTER VI (SGB, SGG, SGJ)
VOLKSWAGEN	TRANSPORTER VI (SGB, SGG, SGJ) I TRANSPORTER / CARAVELLE

500336T

WHEEL SIDE

Ø = 28,5 mm

Ø = 99,1 mm

H = 122,8 mm



APPLICATION

AUDI	A3 (8P1)	SKODA	SUPERB (3T5)
AUDI	A3 (8P7)	SKODA	SUPERB (3V3)
AUDI	A3 (8PA)	SKODA	SUPERB (3V5)
AUDI	A3 (8V1, 8VK)	SKODA	YETI (5L)
AUDI	A3 (8V7, 8VE)	VOLKSWAGEN	AMAROK (2H_, S1B)
AUDI	A3 (8VA, 8VF)	VOLKSWAGEN	AMAROK (2HA, 2HB, S1B, S6B, S7A, S7B)
AUDI	A3 (8VM, 8VS)		AMAROK (S1B)
AUDI	A3 Limousine (8VS, 8VM)	VOLKSWAGEN	ARTEON
AUDI	A3 Sportback (8VA, 8VF)	VOLKSWAGEN	BEETLE (5C1, 5C2)
AUDI	A4 (8E2, B6)	VOLKSWAGEN	BEETLE (5C7, 5C8)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	CADDY ALLTRACK (SAA)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	CADDY ALLTRACK (SAB)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A4 (8H7, 8HE, B6, B7)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	A4 (8K2, B8)		CADDY IV (SAA, SAH)
AUDI	A4 (8K5, B8)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
AUDI	A4 Allroad (8KH, B8)	VOLKSWAGEN	CC (358)
AUDI	A5 (8F7)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	A5 (8T3)	VOLKSWAGEN	GOLF ALLTRACK (BA5)
AUDI	A5 (8TA)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	A6 (4F2, C6)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
AUDI	A6 (4F5, C6)		GOLF V (1K1)
AUDI	A6 (4G2, 4GC, C7)	VOLKSWAGEN	GOLF VI (517)
AUDI	A6 (4G5, 4GD, C7)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	A6 Allroad (4FH, C6)	VOLKSWAGEN	GOLF VII (5G1, BE1)
AUDI	A7 (4GA, 4GF)	VOLKSWAGEN	GOLF VII (5G1, BQ1, BE1, BE2)
AUDI	A8 (4E_)	VOLKSWAGEN	GOLF VII (BA5)
AUDI	A8 (4H_)	VOLKSWAGEN	GOLF VII (BA5, BV5)
AUDI	Q2 (GA)	VOLKSWAGEN	JETTA III (1K2)
AUDI	Q3 (8U)	VOLKSWAGEN	JETTA IV (162, 163)
AUDI	Q5 (8R)	VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)
AUDI	Q7 (4L)		PASSAT (362)
AUDI	TT (8J3)	VOLKSWAGEN	PASSAT (365)
AUDI	TT (8J9)	VOLKSWAGEN	PASSAT (3C2)
AUDI	TT (FV3)	VOLKSWAGEN	PASSAT (3C5)
AUDI	TT (FV9)	VOLKSWAGEN	PASSAT (3G2)
AUDI	TT Roadster (FV9)	VOLKSWAGEN	PASSAT (3G5)
PORSCHE	CAYENNE (9PA)	VOLKSWAGEN	PASSAT ALLTRACK (365)
SEAT	ALTEA (5P1)	VOLKSWAGEN	PASSAT ALLTRACK (3G5)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	PASSAT CC (357)
SEAT	ATECA (KH7)	VOLKSWAGEN	PHAETON (3D_)
SEAT	EXEO (3R2)	VOLKSWAGEN	SCIROCCO (137, 138)
SEAT	EXEO (3R5)	VOLKSWAGEN	TIGUAN (5N_)
SEAT	LEON (1P1)	VOLKSWAGEN	TIGUAN (AD1)
SEAT	LEON (5F1)	VOLKSWAGEN	TIGUAN ALLSPACE (BW2)
SEAT	LEON (5F8)		
SEAT	LEON SC (5F5)		
SEAT	LEON ST (5F8)		
SEAT	TOLEDO III (5P2)		
SKODA	KODIAQ		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		
SKODA	OCTAVIA III (5E3, NL3, NR3)		
SKODA	OCTAVIA III (5E5)		
SKODA	SUPERB (3T4)		

500336T

WHEEL SIDE
 $\varnothing = 28,5 \text{ mm}$
 $\varnothing = 99,1 \text{ mm}$
 $H = 122,8 \text{ mm}$



APPLICATION

VOLKSWAGEN	TOUAREG (7L6, 7L7, 7LA)	VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
VOLKSWAGEN	TOURAN (1T1, 1T2)	VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
VOLKSWAGEN	TOURAN (1T3)		
VOLKSWAGEN	TOURAN (5T1)		
VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)		

500306T

WHEEL SIDE
 $\varnothing = 29 \text{ mm}$
 $\varnothing = 98 \text{ mm}$
 $H = 115 \text{ mm}$



APPLICATION

AUDI	A1 (8X1, 8XK)	VOLKSWAGEN	BEETLE (5C1, 5C2)
AUDI	A1 Sportback (8XA, 8XF)	VOLKSWAGEN	BEETLE (5C7, 5C8)
AUDI	A3 (8L1)	VOLKSWAGEN	BORA (1J2)
AUDI	A3 (8P1)	VOLKSWAGEN	BORA (1J6)
AUDI	A3 (8P7)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A3 (8PA)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	A4 (8D2, B5)	VOLKSWAGEN	CC (358)
AUDI	A4 (8D5, B5)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A6 (4B5, C5)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	Q3 (8U)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	TT (8J3)	VOLKSWAGEN	GOLF V (1K1)
AUDI	TT (8J9)	VOLKSWAGEN	GOLF V (1K5)
AUDI	TT (8N3)	VOLKSWAGEN	GOLF VI (517)
AUDI	TT (8N9)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	JETTA III (1K2)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	JETTA IV (162, 163)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	PASSAT (362)
SEAT	IBIZA V (6J8, 6P8)	VOLKSWAGEN	PASSAT (365)
SEAT	LEON (1M1)	VOLKSWAGEN	PASSAT (3B2)
SEAT	LEON (1P1)	VOLKSWAGEN	PASSAT (3B3)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	PASSAT (3B5)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	PASSAT (3B6)
SEAT	TOLEDO IV (KG3)	VOLKSWAGEN	PASSAT (3C2)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	PASSAT (3C5)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	PASSAT ALLTRACK (365)
SKODA	FABIA (6Y2)	VOLKSWAGEN	PASSAT CC (357)
SKODA	FABIA (NJ3)	VOLKSWAGEN	POLO (60, 61, 6C, 6R)
SKODA	FABIA (NJ5)	VOLKSWAGEN	POLO (60_, 61_)
SKODA	FABIA III (NJ3)	VOLKSWAGEN	POLO (9N_)
SKODA	FABIA III (NJ5)	VOLKSWAGEN	POLO Van (6R)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	SCIROCCO (137, 138)
SKODA	OCTAVIA (1U5)	VOLKSWAGEN	TIGUAN (5N_)
SKODA	OCTAVIA (1Z3)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SKODA	OCTAVIA (1Z5)	VOLKSWAGEN	TOURAN (1T3)
SKODA	RAPID (NH1)		
SKODA	RAPID (NH3)		
SKODA	RAPID Spaceback (NH1)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		
SKODA	SUPERB (3U4)		
SKODA	YETI (5L)		

500490T

APPLICATION

WHEEL SIDE
 Ø = 29,5 mm
 Ø = 95 mm
 H = 120 mm



AUDI	A1 (8X1, 8XK)	SKODA	SUPERB (3U4)
AUDI	A1 Sportback (8XA, 8XF)	SKODA	SUPERB (3V3)
AUDI	A3 (8L1)	SKODA	SUPERB (3V5)
AUDI	A3 (8P1)	SKODA	YETI (5L)
AUDI	A3 (8P7)	VOLKSWAGEN	BEETLE (5C1, 5C2)
AUDI	A3 (8PA)	VOLKSWAGEN	BEETLE (5C7, 5C8)
AUDI	A4 (8E2, B6)	VOLKSWAGEN	BORA (1J2)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	BORA (1J6)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	A4 (8H7, 8HE, B6, B7)	VOLKSWAGEN	CC (358)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	A6 (4B5, C5)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A6 (4F2, C6)	VOLKSWAGEN	GOLF IV (1J5)
AUDI	A6 (4F5, C6)	VOLKSWAGEN	GOLF PLUS (521, 5M1)
AUDI	A6 Allroad (4FH, C6)	VOLKSWAGEN	GOLF SPORTSVAN (AM1)
AUDI	A8 (4E_)	VOLKSWAGEN	GOLF V (1K1)
AUDI	Q3 (8U)	VOLKSWAGEN	GOLF V (1K5)
AUDI	TT (8J3)	VOLKSWAGEN	GOLF VI (517)
AUDI	TT (8J9)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	TT (8N3)	VOLKSWAGEN	GOLF VI (AJ5)
AUDI	TT (8N9)	VOLKSWAGEN	JETTA III (1K2)
AUDI	TT (FV3)	VOLKSWAGEN	JETTA IV (162, 163)
AUDI	TT (FV9)	VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)
SEAT	ALTEA (5P1)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	PASSAT (362)
SEAT	EXEO (3R2)	VOLKSWAGEN	PASSAT (365)
SEAT	EXEO (3R5)	VOLKSWAGEN	PASSAT (3B3)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	PASSAT (3B6)
SEAT	IBIZA V (6J1, 6P5)	VOLKSWAGEN	PASSAT (3C2)
SEAT	IBIZA V (6J5, 6P1)	VOLKSWAGEN	PASSAT (3C5)
SEAT	IBIZA V (6J8, 6P8)	VOLKSWAGEN	PASSAT ALLTRACK (365)
SEAT	LEON (1M1)	VOLKSWAGEN	PASSAT CC (357)
SEAT	LEON (1P1)	VOLKSWAGEN	PHAETON (3D_)
SEAT	LEON (5F1)	VOLKSWAGEN	POLO (60, 61, 6C, 6R)
SEAT	LEON (5F8)	VOLKSWAGEN	POLO (60_, 61_)
SEAT	LEON SC (5F5)	VOLKSWAGEN	POLO (9N_)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	POLO Van (6R)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	SCIROCCO (137, 138)
SEAT	TOLEDO IV (KG3)	VOLKSWAGEN	TIGUAN (5N_)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	TOURAN (1T3)
SKODA	FABIA (NJ3)	VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)
SKODA	FABIA (NJ5)	VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
SKODA	FABIA III (NJ3)	VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
SKODA	FABIA III (NJ5)		
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)		
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	OCTAVIA (5E3)		
SKODA	OCTAVIA (5E5)		
SKODA	RAPID (NH1)		
SKODA	RAPID (NH3)		
SKODA	RAPID Spaceback (NH1)		
SKODA	SUPERB (3T4)		
SKODA	SUPERB (3T5)		

500145

APPLICATION

BOX SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 92 \text{ mm}$



SEAT
 SEAT
 SEAT
 SEAT

IBIZA I (021A)
 MALAGA (023A)
 RONDA (022A)
 TERRA (024A)

500070

APPLICATION

BOX SIDE
 $\varnothing = 30 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 92 \text{ mm}$



SEAT

MARBELLA (28)

500147

APPLICATION

BOX SIDE
 $\varnothing = 30,2 \text{ mm}$
 $\varnothing = 78,3 \text{ mm}$
 $H = 90 \text{ mm}$



SEAT

MARBELLA (28)

500570T

APPLICATION

WHEEL SIDE
 $\varnothing = 30,5 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 76,5 \text{ mm}$



AUDI
 AUDI
 AUDI
 AUDI
 AUDI
 AUDI
 AUDI
 PORSCHE
 VOLKSWAGEN

A4 (8K2, B8)
 A4 (8K5, B8)
 A4 Allroad (8KH, B8)
 A5 (8F7)
 A5 (8T3)
 A5 (8TA)
 Q7 (4L)
 CAYENNE (9PA)
 TOUAREG (7L6, 7L7,
 7LA)

500630T

APPLICATION

BOX SIDE
 Ø = 30,5 mm
 Ø = 77,5 mm
 H = 111,5 mm



AUDI	Q7 (4L)	VOLKSWAGEN	TRANSPORTER VI (SGB, SGG, SGJ)
VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)		
VOLKSWAGEN	MULTIVAN VI (SGF, SGM, SGN)		
VOLKSWAGEN	TOUAREG (7L6, 7L7, 7LA)		
VOLKSWAGEN	TRANSPORTER Mk VI (SFD, SFE, SFL, SFZ)		
VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)		
VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)		
VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)		
VOLKSWAGEN	TRANSPORTER VI (SFD, SFE, SFL, SFZ)		
VOLKSWAGEN	TRANSPORTER VI (SGA, SGH)		

500631T

APPLICATION

WHEEL SIDE
 Ø = 30,5 mm
 Ø = 103 mm
 H = 143 mm



AUDI	A4 (8K2, B8)	AUDI	A7 (4GA, 4GF)
AUDI	A4 (8K5, B8)	AUDI	A8 (4H_)
AUDI	A5 (8F7)	AUDI	Q5 (8R)
AUDI	A5 (8T3)		
AUDI	A5 (8TA)		
AUDI	A6 (4F2, C6)		
AUDI	A6 (4F5, C6)		
AUDI	A6 (4G2, 4GC, C7)		
AUDI	A6 (4G5, 4GD, C7)		

500491T

APPLICATION

WHEEL SIDE
 Ø = 31,3 mm
 Ø = 104 mm
 H = 130 mm



AUDI	Q7 (4L)	VOLKSWAGEN	TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)
VOLKSWAGEN	MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)	VOLKSWAGEN	TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)
VOLKSWAGEN	PHAETON (3D_)		
VOLKSWAGEN	TOUAREG (7L6, 7L7, 7LA)		
VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)		

500331

APPLICATION

BOX SIDE
 Ø = 33 mm
 Ø = 54 mm
 H = 78 mm



PORSCHE	911 (996)
PORSCHE	BOXSTER (987)
PORSCHE	CAYMAN (981)
PORSCHE	CAYMAN (987)

500632

APPLICATION

BOX SIDE
 $\emptyset = 34 \text{ mm}$
 $\emptyset = 80 \text{ mm}$
 $H = 83 \text{ mm}$



AUDI	200 (44, 44Q)
AUDI	A4 (8D2, B5)
AUDI	A4 (8D5, B5)
VOLKSWAGEN	PASSAT (3B2)
VOLKSWAGEN	PASSAT (3B3)
VOLKSWAGEN	PASSAT (3B5)
VOLKSWAGEN	PASSAT (3B6)

500143

APPLICATION

BOX SIDE
 $\emptyset = 35 \text{ mm}$
 $\emptyset = 99 \text{ mm}$
 $H = 115 \text{ mm}$



AUDI	A3 (8L1)	VOLKSWAGEN	GOLF III (1H5)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF IV (1E7)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	GOLF IV (1J1)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	LUPO (6E1, 6X1)
SEAT	INCA (6K9)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	LEON (1M1)	VOLKSWAGEN	NEW BEETLE (1Y7)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	PASSAT (32B)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	PASSAT (3A2, 35I)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	PASSAT (3A5, 35I)
SKODA	OCTAVIA (1U5)	VOLKSWAGEN	PASSAT (3B2)
VOLKSWAGEN	BORA (1J2)	VOLKSWAGEN	PASSAT (3B5)
VOLKSWAGEN	BORA (1J6)	VOLKSWAGEN	POLO (6KV2)
VOLKSWAGEN	CADDY II (9K9A)	VOLKSWAGEN	POLO (6KV5)
VOLKSWAGEN	CADDY II (9K9B)	VOLKSWAGEN	POLO (6N1)
VOLKSWAGEN	CORRADO (53I)	VOLKSWAGEN	POLO (6N2)
VOLKSWAGEN	GOLF I (155)	VOLKSWAGEN	SCIROCCO (53B)
VOLKSWAGEN	GOLF II (19E, 1G1)	VOLKSWAGEN	VENTO (1H2)
VOLKSWAGEN	GOLF III (1E7)		
VOLKSWAGEN	GOLF III (1H1)		

APPLICATION

BOX SIDE



VOLVO
VOLVO

S40 I (VS)
V40 (VW)

500549

APPLICATION

BOX SIDE

Ø = 19 mm
Ø = 67,4 mm
H = 87 mm



VOLVO
VOLVO
VOLVO

C30
S40 II (MS)
V50 (MW)

500348

APPLICATION

WHEEL SIDE

Ø = 20 mm
Ø = 74 mm
H = 110 mm



VOLVO
VOLVO
VOLVO

440 K (445)
460 L (464)
480 E

500349

APPLICATION

WHEEL SIDE

Ø = 20 mm
Ø = 80 mm
H = 93 mm



VOLVO
VOLVO
VOLVO

C30
S40 II (MS)
V50 (MW)

500523

APPLICATION

BOX SIDE

Ø = 21 mm
Ø = 69 mm
H = 94,5 mm



VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO

C30
C70 II
S60 I
S70 (LS)
S80 I (TS, XY)
V50 (MW)
V70 II (SW)

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 70 mm
H = 88 mm



VOLVO	C70 I
VOLVO	S40 I (VS)
VOLVO	S60 I
VOLVO	S70 (LS)
VOLVO	S80 I (TS, XY)
VOLVO	V40 (VW)
VOLVO	V70 I (LV)
VOLVO	V70 II (SW)

500195

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 72 mm
H = 95 mm



VOLVO	S40 I (VS)
VOLVO	V40 (VW)

500270

APPLICATION

BOX SIDE
Ø = 21 mm
Ø = 80 mm
H = 84 mm



VOLVO	850 (LS)
VOLVO	850 (LW)
VOLVO	C70 I
VOLVO	S70 (LS)
VOLVO	V70 I (LV)

500243T

APPLICATION

WHEEL SIDE
Ø = 21 mm
Ø = 82 mm
H = 146 mm



VOLVO	S40 I (VS)
-------	------------

500426

APPLICATION

BOX SIDE
Ø = 21,75 mm
Ø = 74,04 mm
H = 89,25 mm



VOLVO	C30
VOLVO	C70 II
VOLVO	S40 II (MS)
VOLVO	V50 (MW)

APPLICATION

WHEEL SIDE
Ø = 21,8 mm
Ø = 82,4 mm
H = 81,6 mm



VOLVO 440 K (445)
VOLVO 460 L (464)
VOLVO 480 E
VOLVO 850 (LS)
VOLVO 850 (LW)
VOLVO C70 I
VOLVO S70 (LS)
VOLVO S80 I (TS, XY)
VOLVO V70 I (LV)

500050E

APPLICATION

WHEEL SIDE
Ø = 21,8 mm
Ø = 82,4 mm
H = 81,6 mm



VOLVO 440 K (445)
VOLVO 460 L (464)
VOLVO 480 E
VOLVO 850 (LS)
VOLVO 850 (LW)
VOLVO C70 I
VOLVO S70 (LS)
VOLVO S80 I (TS, XY)
VOLVO V70 I (LV)

500025

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77 mm
H = 103 mm



VOLVO 440 K (445)
VOLVO 460 L (464)
VOLVO 480 E

500025E

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77 mm
H = 103 mm



VOLVO 440 K (445)
VOLVO 460 L (464)
VOLVO 480 E

500285T

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 77,4 mm
H = 116,5 mm



VOLVO S40 I (VS)

APPLICATION

WHEEL SIDE
Ø = 22 mm
Ø = 87 mm
H = 94 mm



VOLVO C30
VOLVO C70 II
VOLVO S40 II (MS)
VOLVO V50 (MW)

500002

APPLICATION

WHEEL SIDE
Ø = 22,4 mm
Ø = 52,2 mm
H = 77 mm



VOLVO 66
VOLVO 340-360 (343, 345)
VOLVO 340-360 (344)

500300

APPLICATION

BOX SIDE
Ø = 23 mm
Ø = 65 mm
H = 104 mm



VOLVO S40 I (VS)
VOLVO V40 (VW)

500121

APPLICATION

WHEEL SIDE
Ø = 23,9 mm
Ø = 92 mm
H = 83 mm



VOLVO 850 (LS)
VOLVO 850 (LW)
VOLVO C70 I
VOLVO S70 (LS)
VOLVO V70 I (LV)
VOLVO XC70 CROSS COUNTRY

500175

APPLICATION

BOX SIDE
Ø = 24 mm
Ø = 70 mm
H = 116 mm



VOLVO	C70 I	VOLVO	V70 II (SW)
VOLVO	S40 I (VS)	VOLVO	XC70 CROSS COUNTRY
VOLVO	S40 II (MS)		(295) I V70 XC
VOLVO	S60 I	VOLVO	XC90 I
VOLVO	S70 (LS)		
VOLVO	S80 I (TS, XY)		
VOLVO	V40 (VW)		
VOLVO	V50 (MW)		
VOLVO	V70 I (LV)		

APPLICATION

WHEEL SIDE
Ø = 24 mm
Ø = 84 mm
H = 115 mm



VOLVO C70 I
VOLVO S40 I (VS)
VOLVO S60 I
VOLVO S70 (LS)
VOLVO S80 I (TS, XY)
VOLVO V40 (VW)
VOLVO V70 I (LV)
VOLVO V70 II (SW)

500294T

APPLICATION

WHEEL SIDE
Ø = 24,5 mm
Ø = 83 mm
H = 120 mm



VOLVO S40 II (MS)
VOLVO V50 (MW)

500533

APPLICATION

BOX SIDE
Ø = 25,5 mm
Ø = 70,5 mm
H = 92 mm



VOLVO C30
VOLVO C70 II
VOLVO S40 II (MS)
VOLVO S60 II
VOLVO S80 II (AS)
VOLVO V40
VOLVO V50 (MW)
VOLVO V60
VOLVO V70 III (BW)

500545T

APPLICATION

WHEEL SIDE
Ø = 26 mm
Ø = 91 mm
H = 127 mm



VOLVO S80 II (AS)
VOLVO V70 III (BW)
VOLVO XC60

500227T

APPLICATION

WHEEL SIDE
Ø = 27 mm
Ø = 89 mm
H = 125 mm



VOLVO C30
VOLVO C70 II
VOLVO S40 II (MS)
VOLVO V50 (MW)

APPLICATION

WHEEL SIDE
Ø = 27,2 mm
Ø = 98,1 mm
H = 144,5 mm



VOLVO	C70 I
VOLVO	S40 I (VS)
VOLVO	S60 I
VOLVO	S70 (LS)
VOLVO	S80 I (TS, XY)
VOLVO	V40 (VW)
VOLVO	V70 I (LV)
VOLVO	V70 II (SW)
VOLVO	XC70 CROSS COUNTRY

500252T

APPLICATION

BOX SIDE
Ø = 27,4 mm
Ø = 100,4 mm
H = 114 mm



VOLVO	V50 (MW)
-------	----------

500397

APPLICATION

BOX SIDE
Ø = 28 mm
Ø = 70 mm
H = 98 mm



VOLVO	850 (LS)
VOLVO	850 (LW)
VOLVO	C70 I
VOLVO	S70 (LS)
VOLVO	V70 I (LV)

500574T

APPLICATION

BOX SIDE
Ø = 28 mm
Ø = 80 mm
H = 122 mm



VOLVO	S60 II
VOLVO	S80 II (AS)
VOLVO	V60
VOLVO	V70 III (BW)
VOLVO	XC60

500336T

APPLICATION

WHEEL SIDE
Ø = 28,5 mm
Ø = 99,1 mm
H = 122,8 mm



VOLVO	XC90 I
-------	--------

APPLICATION

BOX SIDE
Ø = 30,5 mm
Ø = 85,44 mm
H = 88 mm



VOLVO	440 K (445)
VOLVO	460 L (464)
VOLVO	480 E
VOLVO	S40 I (VS)
VOLVO	V40 (VW)

500356

APPLICATION

WHEEL SIDE
 $\varnothing = 17 \text{ mm}$
 $\varnothing = 69 \text{ mm}$
 $H = 97 \text{ mm}$



ZASTAVA
 ZASTAVA
 ZASTAVA

101 (1100)
 YUGO
 YUGO FLORIDA

500355

APPLICATION

WHEEL SIDE
 $\varnothing = 18 \text{ mm}$
 $\varnothing = 68 \text{ mm}$
 $H = 97 \text{ mm}$



ZASTAVA
 ZASTAVA
 ZASTAVA

101 (1100)
 YUGO
 YUGO FLORIDA

500040

APPLICATION

WHEEL SIDE
 $\varnothing = 21 \text{ mm}$
 $\varnothing = 70,5 \text{ mm}$
 $H = 80 \text{ mm}$



ZASTAVA
 ZASTAVA

YUGO
 YUGO FLORIDA

500155

APPLICATION

BOX SIDE
 $\varnothing = 25 \text{ mm}$
 $\varnothing = 73 \text{ mm}$
 $H = 71 \text{ mm}$



ZASTAVA
 ZASTAVA

YUGO
 YUGO FLORIDA

ert

STEERING BOOT KITS



510141
LEFT - 510140

$\varnothing = 9 \text{ mm}$
 $\varnothing = 40 \text{ mm}$
 $H = 130 \text{ mm}$


RIGHT - 510140

$\varnothing = 9 \text{ mm}$
 $\varnothing = 40 \text{ mm}$
 $H = 130 \text{ mm}$

APPLICATION

FIAT	CINQUECENTO (170_)
FIAT	SEICENTO / 600 (187_)

101657
LEFT - 101658

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 25,4 \text{ mm}$
 $H = 182 \text{ mm}$


RIGHT - 101612

$\varnothing = 10 \text{ mm}$
 $\varnothing = 42,3 \text{ mm}$
 $H = 119,5 \text{ mm}$

APPLICATION

FIAT	147	FIAT	PANDA (141_)
FIAT	126 (126_)	FIAT	PENNY (257_)
FIAT	127 (127_)	FIAT	REGATA (138_)
FIAT	128 (128_)	FIAT	RITMO (138_)
FIAT	DUNA (146_)	FIAT	UNO (146_)
FIAT	FIORINO (127_)	FIAT	X 1/9 (128_)
FIAT	FIORINO (146_)	LANCIA	A 112
FIAT	FIORINO (147_)	LANCIA	DELTA I (831_)
FIAT	FIORINO Pick up (146_)	LANCIA	PRISMA (831_)
FIAT	FIORINO Pick up (147_)	LANCIA	Y10 (156_)

102004
LEFT - 102003

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 50 \text{ mm}$
 $H = 194 \text{ mm}$


RIGHT - 102003

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 50 \text{ mm}$
 $H = 194 \text{ mm}$

APPLICATION

FIAT	CROMA (154_)
LANCIA	THEMA (834_)

102101
LEFT - 101612

$\varnothing = 10 \text{ mm}$
 $\varnothing = 42,3 \text{ mm}$
 $H = 119,5 \text{ mm}$


RIGHT - 101612

$\varnothing = 10 \text{ mm}$
 $\varnothing = 42,3 \text{ mm}$
 $H = 119,5 \text{ mm}$

APPLICATION

FIAT	PANDA (141_)
LANCIA	DELTA I (831_)
LANCIA	PRISMA (831_)

102024

LEFT - 102020

$\varnothing$ = 10 mm
 $\varnothing$ = 44 mm
H = 205 mm



FIAT
LANCIA

CROMA (154_)
THEMA (834_)

APPLICATION

RIGHT - 102023

$\varnothing$ = 10,15 mm
 $\varnothing$ = 44 mm
H = 165 mm

102006

LEFT - 102005

$\varnothing$ = 10,5 mm
 $\varnothing$ = 44,3 mm
H = 164 mm



FIAT
FIAT
FIAT
LANCIA
LANCIA

126 (126_)
TEMPRA (159_)
TIPO (160_)
Y (840_)
Y10 (156_)

APPLICATION

RIGHT - 102005

$\varnothing$ = 10,5 mm
 $\varnothing$ = 44,3 mm
H = 164 mm

102015

LEFT - 101545

$\varnothing$ = 11 mm
 $\varnothing$ = 38 mm
H = 215 mm



FIAT
FIAT
FIAT
FIAT

242-SERIE (242_)
DUCATO (280_)
DUCATO (290_)
TALENTO (290_)

APPLICATION

RIGHT - 102012

$\varnothing$ = 10,17 mm
 $\varnothing$ = 47,55 mm
H = 154 mm

510057

LEFT - 510056

$\varnothing$ = 12 mm
 $\varnothing$ = 47 mm
H = 180 mm



ALFA ROMEO
ALFA ROMEO
ALFA ROMEO
ALFA ROMEO
ALFA ROMEO

6 (119_)
75 (162B_)
ALFETTA (116_)
ALFETTA GT (116_)
GIULIETTA (116_)

APPLICATION

RIGHT - 510056

$\varnothing$ = 12 mm
 $\varnothing$ = 47 mm
H = 180 mm

102392

LEFT - 102391

Ø = 12 mm
 Ø = 55 mm
 H = 170 mm



FIAT
 FIAT
 FIAT

PALIO (178_)
 PALIO (178BX)
 SIENA (178_)

APPLICATION

RIGHT - 102391

Ø = 12 mm
 Ø = 55 mm
 H = 170 mm

102375

LEFT - 102374

Ø = 12,3 mm
 Ø = 54,2 mm
 H = 200,95 mm



ABARTH

 ABARTH
 ALFA ROMEO
 FIAT
 FIAT
 FIAT

GRANDE PUNTO
 (199_)
 PUNTO EVO (199_)
 MITO (955_)
 500L (199_)
 FIORINO (225_)
 FIORINO Van / Wagon
 (225_)
 GRANDE PUNTO
 (199_)

FIAT

 FIAT
 FIAT
 FIAT
 FIAT

 FIAT

 GRANDE PUNTO Van
 (199_)
 LINEA (323_)
 PUNTO (199_)
 PUNTO EVO (199_)
 PUNTO EVO Van
 (199_)
 QUBO (225_)

RIGHT - 102374

Ø = 12,3 mm
 Ø = 54,2 mm
 H = 200,95 mm

510013

LEFT - 510012

Ø = 12,5 mm
 Ø = 55 mm
 H = 205 mm



ALFA ROMEO
 ALFA ROMEO
 ALFA ROMEO
 FIAT

145 (930_)
 146 (930_)
 GTV (916_)
 STILO (192_)

APPLICATION

RIGHT - 510012

Ø = 12,5 mm
 Ø = 55 mm
 H = 205 mm

101771

LEFT - 101504

Ø = 12,5 mm
 Ø = 61,3 mm
 H = 213,8 mm



FIAT
 FIAT
 LANCIA
 LANCIA

SCUDO (220_)
 ULYSSE (220_)
 THESIS (841_)
 ZETA (22_)

APPLICATION

RIGHT - 101504

Ø = 12,5 mm
 Ø = 61,3 mm
 H = 213,8 mm

510139

APPLICATION

LEFT - 101504

$\emptyset$ = 12,5 mm
 $\emptyset$ = 61,3 mm
H = 213,8 mm



FIAT
FIAT
FIAT
LANCIA

DUCATO (230_)
SCUDO (220_)
ULYSSE (220_)
ZETA (22_)

RIGHT - 510121

$\emptyset$ = 15 mm
 $\emptyset$ = 55 mm
H = 280 mm

510112

APPLICATION

LEFT - 510111

$\emptyset$ = 13 mm
 $\emptyset$ = 44 mm
H = 175 mm



FIAT
FIAT

SEDICI
SEDICI (FY_)

RIGHT - 510111

$\emptyset$ = 13 mm
 $\emptyset$ = 44 mm
H = 175 mm

510254

APPLICATION

LEFT - 510253

$\emptyset$ = 13,5 mm
 $\emptyset$ = 50 mm
H = 200 mm



FIAT

DOBLO (263_)

RIGHT - 510253

$\emptyset$ = 13,5 mm
 $\emptyset$ = 50 mm
H = 200 mm

101745

APPLICATION

LEFT - 101599

$\emptyset$ = 13,5 mm
 $\emptyset$ = 52 mm
H = 187,5 mm



LANCIA

DELTA I (831_)

RIGHT - 101599

$\emptyset$ = 13,5 mm
 $\emptyset$ = 52 mm
H = 187,5 mm

510051

APPLICATION

LEFT - 510050

FIAT

CROMA (194_)

Ø = 13,5 mm
Ø = 56 mm
H = 218 mm



RIGHT - 510050

Ø = 13,5 mm
Ø = 56 mm
H = 218 mm

102075

APPLICATION

LEFT - 101801

FIAT

DUCATO (230_)

Ø = 13,7 mm
Ø = 53,6 mm
H = 250,2 mm



RIGHT - 101801

Ø = 13,7 mm
Ø = 53,6 mm
H = 250,2 mm

101980

APPLICATION

LEFT - 101979

FIAT

DUCATO (230_)

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm



RIGHT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm

102030

APPLICATION

LEFT - 102029

FIAT
FIAT

DUCATO (250_, 290_)
DUCATO Van (250_,
290_)

Ø = 15 mm
Ø = 55 mm
H = 225 mm



RIGHT - 102029

Ø = 15 mm
Ø = 55 mm
H = 225 mm

101691

APPLICATION

LEFT - 101468

$\varnothing$ = 15 mm
 $\varnothing$ = 55,1 mm
H = 250 mm



FIAT
FIAT
FIAT

DUCATO (280_)
DUCATO (290_)
TALENTO (290_)

RIGHT - 101468

$\varnothing$ = 15 mm
 $\varnothing$ = 55,1 mm
H = 250 mm

510089

APPLICATION

LEFT - 510088

$\varnothing$ = 19,5 mm
 $\varnothing$ = 51 mm
H = 175 mm



ALFA ROMEO
ALFA ROMEO
ALFA ROMEO

159 (939_)
BRERA (939_)
SPIDER (939_)

RIGHT - 510088

$\varnothing$ = 19,5 mm
 $\varnothing$ = 51 mm
H = 175 mm

510208

APPLICATION

LEFT - 510207

$\varnothing$ = 34 mm
 $\varnothing$ = 51 mm
H = 198 mm



ALFA ROMEO
ALFA ROMEO
ALFA ROMEO

159 (939_)
BRERA (939_)
SPIDER (939_)

RIGHT - 510207

$\varnothing$ = 34 mm
 $\varnothing$ = 51 mm
H = 198 mm

510171

APPLICATION

LEFT - 510170

$\varnothing$ = 37,5 mm
 $\varnothing$ = 61 mm
H = 210 mm



ALFA ROMEO
ALFA ROMEO
ALFA ROMEO
ALFA ROMEO

147 (937_)
156 (932_)
166 (936_)
GT (937_)

RIGHT - 510170

$\varnothing$ = 37,5 mm
 $\varnothing$ = 61 mm
H = 210 mm

APPLICATION

LEFT - 510022

Ø = 10 mm
Ø = 44 mm
H = 120 mm



AUSTIN

MINI

RIGHT - 510022

Ø = 10 mm
Ø = 44 mm
H = 120 mm



APPLICATION

LEFT - 101709

Ø = 11 mm
Ø = 46,75 mm
H = 145 mm



AUSTIN

AMBASSADOR

RIGHT - 101709

Ø = 11 mm
Ø = 46,75 mm
H = 145 mm



101657

LEFT - 101658

Ø = 9,5 mm
Ø = 25,4 mm
H = 182 mm



AUTOBIANCHI
AUTOBIANCHI

A 112
Y10

APPLICATION

RIGHT - 101612

Ø = 10 mm
Ø = 42,3 mm
H = 119,5 mm

102102

APPLICATION

LEFT - 101709

BEDFORD

BLITZ (CF97)

$\emptyset = 11 \text{ mm}$
 $\emptyset = 46,75 \text{ mm}$
 $H = 145 \text{ mm}$



RIGHT - 101709

$\emptyset = 11 \text{ mm}$
 $\emptyset = 46,75 \text{ mm}$
 $H = 145 \text{ mm}$

510003C

APPLICATION

LEFT - 510003

BEDFORD

ASTRA VAN

$\emptyset = 39 \text{ mm}$
 $\emptyset = 50 \text{ mm}$
 $H = 162 \text{ mm}$



RIGHT - 510003

$\emptyset = 39 \text{ mm}$
 $\emptyset = 50 \text{ mm}$
 $H = 162 \text{ mm}$

101980

LEFT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm



BMW
BMW
BMW
BMW
BMW

5 (E60)
5 (E61)
7 (E65, E66, E67)
X3 (E83)
X5 (E53)

APPLICATION

RIGHT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm

102061

LEFT - 101501

Ø = 14,5 mm
Ø = 50,5 mm
H = 189 mm



BMW

3 (E91)

APPLICATION

RIGHT - 101501

Ø = 14,5 mm
Ø = 50,5 mm
H = 189 mm

102140

LEFT - 102139

Ø = 15 mm
Ø = 54 mm
H = 170 mm



BMW
BMW

3 (E36)
3 (E46)

APPLICATION

RIGHT - 102139

Ø = 15 mm
Ø = 54 mm
H = 170 mm

510210

LEFT - 510209

Ø = 15,5 mm
Ø = 64 mm
H = 195 mm



BMW
BMW
BMW
BMW
BMW
BMW
BMW
BMW
BMW

1 (E81)
1 (E82)
1 (E87)
1 (E88)
3 (E90)
3 (E91)
3 (E92)
3 (E93)
X1 (E84)

APPLICATION

BMW

Z4 (E89)

RIGHT - 510209

Ø = 15,5 mm
Ø = 64 mm
H = 195 mm

510069

LEFT - 510068

Ø = 15,5 mm
Ø = 66 mm
H = 195 mm



RIGHT - 510068

Ø = 15,5 mm
Ø = 66 mm
H = 195 mm

BMW 5 (E60)
BMW 5 (E61)
BMW 5 (F07)
BMW 5 (F10)
BMW 5 (F11)
BMW 6 (E63)
BMW 6 (E64)
BMW 6 (F06)
BMW 6 (F12)

APPLICATION

BMW 6 (F13)
BMW 7 (F01, F02, F03, F04)
BMW X3 (E83)

102333

LEFT - 102331

Ø = 15,5 mm
Ø = 66 mm
H = 198 mm



RIGHT - 102331

Ø = 15,5 mm
Ø = 66 mm
H = 198 mm

BMW 5 (E60)
BMW 5 (E61)
BMW 7 (E65, E66, E67)
BMW X3 (E83)
BMW X5 (E53)

APPLICATION

510077

LEFT - 510076

Ø = 16 mm
Ø = 63 mm
H = 204 mm



RIGHT - 510076

Ø = 16 mm
Ø = 63 mm
H = 204 mm

BMW 1 (F20)
BMW 1 (F21)
BMW 2 (F22, F87)
BMW 2 (F23)
BMW 3 (F30, F80)
BMW 3 (F31)
BMW 3 (F34)
BMW X3 (F25)
BMW X4 (F26)

APPLICATION

BMW X5 (E70)
BMW X5 (F15, F85)
BMW X6 (E71, E72)
BMW X6 (F16, F86)

510250

LEFT - 101653

Ø = 37,35 mm
Ø = 54,4 mm
H = 171,65 mm



RIGHT - 101653

Ø = 37,35 mm
Ø = 54,4 mm
H = 171,65 mm

BMW 3 (E30)
BMW 3 (E46)
BMW 5 (E39)
BMW Z4 (E85)
BMW Z8 (E52)

APPLICATION

102027

LEFT - 102026

Ø = 38 mm
 Ø = 43,5 mm
 H = 165 mm



BMW

3 (E21)

APPLICATION

RIGHT - 102026

Ø = 38 mm
 Ø = 43,5 mm
 H = 165 mm

102028

LEFT - 102026

Ø = 38 mm
 Ø = 43,5 mm
 H = 165 mm

BMW
BMW3 (E21)
3 (E30)

APPLICATION

RIGHT - 101647

Ø = 52,65 mm
 Ø = 52,65 mm
 H = 125,25 mm

101842

LEFT - 101664

Ø = 38 mm
 Ø = 44 mm
 H = 165 mm

BMW
BMW
BMW
BMW
BMW3 (E30)
3 (E36)
3 (E46)
Z1
Z3 (E36)

APPLICATION

RIGHT - 101664

Ø = 38 mm
 Ø = 44 mm
 H = 165 mm

101741

LEFT - 101664

Ø = 38 mm
 Ø = 44 mm
 H = 165 mm

BMW
BMW
BMW3 (E21)
3 (E30)
Z1

APPLICATION

RIGHT - 101647

Ø = 52,65 mm
 Ø = 52,65 mm
 H = 125,25 mm

102125

LEFT - 101670

Ø = 38 mm
 Ø = 51 mm
 H = 184,96 mm



RIGHT - 101670

Ø = 38 mm
 Ø = 51 mm
 H = 184,96 mm

BMW	3 (E36)
BMW	3 (E46)
BMW	5 (E34)
BMW	5 (E39)
BMW	Z3 (E36)
BMW	Z4 (E85)
BMW	Z8 (E52)

APPLICATION

102068

LEFT - 101656

Ø = 43 mm
 Ø = 55 mm
 H = 175 mm



RIGHT - 101656

Ø = 43 mm
 Ø = 55 mm
 H = 175 mm

BMW	3 (E30)
BMW	3 (E36)
BMW	3 (E46)
BMW	5 (E34)
BMW	Z3 (E36)
BMW	Z4 (E85)
BMW	Z8 (E52)

APPLICATION

101750

LEFT - 101144

Ø = 7,9 mm
 Ø = 37,95 mm
 H = 165 mm



OPEL
 OPEL
 VAUXHALL

 VAUXHALL
 VAUXHALL

MOVANO (E9, U9)
 MOVANO (J9)
 MOVANO Mk I (A) (ED,
 HD, UD)
 MOVANO Mk I (A) (FD)
 MOVANO Mk I (A) (JD)

APPLICATION**RIGHT - 101144**

Ø = 7,9 mm
 Ø = 37,95 mm
 H = 165 mm

510047

LEFT - 510046

Ø = 9,5 mm
 Ø = 42 mm
 H = 165 mm



OPEL
 OPEL
 OPEL
 OPEL

MOVANO (E9, U9)
 MOVANO (F9)
 MOVANO (H9)
 MOVANO (J9)

APPLICATION**RIGHT - 510046**

Ø = 9,5 mm
 Ø = 42 mm
 H = 165 mm

510002C

LEFT - 510002

Ø = 10 mm
 Ø = 37,5 mm
 H = 140 mm



OPEL
 OPEL
 VAUXHALL

ARENA (TB, TF)
 ARENA (THB)
 ARENA

APPLICATION**RIGHT - 510002**

Ø = 10 mm
 Ø = 37,5 mm
 H = 140 mm

102433

LEFT - 102432

Ø = 11 mm
 Ø = 45 mm
 H = 197 mm



CHEVROLET
 DAEWOO

MATIZ (M200, M250)
 MATIZ (KLYA)

APPLICATION**RIGHT - 102432**

Ø = 11 mm
 Ø = 45 mm
 H = 197 mm

101693

LEFT - 101674

Ø = 11 mm
 Ø = 46 mm
 H = 206,35 mm



CHEVROLET
 DAEWOO
 DAEWOO

MATIZ (M200, M250)
 MATIZ (KLYA)
 TICO (KLY3)

APPLICATION

RIGHT - 101674

Ø = 11 mm
 Ø = 46 mm
 H = 206,35 mm

510175

LEFT - 510174

Ø = 12 mm
 Ø = 48 mm
 H = 200 mm



OPEL
 OPEL

VIVARO (F7)
 VIVARO (J7)

APPLICATION

RIGHT - 510174

Ø = 12 mm
 Ø = 48 mm
 H = 200 mm

510212

LEFT - 510211

Ø = 12 mm
 Ø = 49 mm
 H = 190 mm



OPEL
 OPEL
 OPEL

COMBO (71_)
 CORSA A
 CORSA A (91_, 92_,
 96_, 97_)
 CORSA A (93_, 94_,
 98_, 99_)
 CORSA B (73_)
 CORSA B (73_, 78_,
 79_)

OPEL
 VAUXHALL
 VAUXHALL
 VAUXHALL
 VAUXHALL

TIGRA (95_)
 COMBO Mk I (B)
 CORSA Mk I (B)
 CORSAVAN Mk I (B)
 TIGRA Mk I (F07)

RIGHT - 510211

Ø = 12 mm
 Ø = 49 mm
 H = 190 mm

510021

LEFT - 510020

Ø = 12 mm
 Ø = 50 mm
 H = 175 mm



OPEL
 OPEL
 OPEL

COMBO (71_)
 CORSA A
 CORSA A (91_, 92_,
 96_, 97_)
 CORSA A (93_, 94_,
 98_, 99_)
 CORSA B (73_, 78_,
 79_)

APPLICATION

RIGHT - 510020

Ø = 12 mm
 Ø = 50 mm
 H = 175 mm

OPEL

510027

APPLICATION

LEFT - 510026

Ø = 12 mm
 Ø = 50 mm
 H = 195 mm



OPEL
 OPEL
 OPEL
 OPEL

COMBO
 CORSA C (F08, F68)
 CORSA C (F08, W5L)
 TIGRA

RIGHT - 510026

Ø = 12 mm
 Ø = 50 mm
 H = 195 mm

102375

APPLICATION

LEFT - 102374

Ø = 12,3 mm
 Ø = 54,2 mm
 H = 200,95 mm



OPEL
 OPEL
 OPEL

ADAM
 CORSA D
 CORSA E

RIGHT - 102374

Ø = 12,3 mm
 Ø = 54,2 mm
 H = 200,95 mm

510009

APPLICATION

LEFT - 510008

Ø = 13 mm
 Ø = 49 mm
 H = 158 mm



CHEVROLET
 DAEWOO
 DAEWOO

REZZO
 NUBIRA (KLAJ)
 REZZO (KLAU, U100)

RIGHT - 510008

Ø = 13 mm
 Ø = 49 mm
 H = 158 mm

102394

APPLICATION

LEFT - 102393

Ø = 13 mm
 Ø = 49 mm
 H = 170 mm



CHEVROLET
 CHEVROLET
 DAEWOO
 DAEWOO
 DAEWOO
 DAEWOO

AVEO (T250, T255)
 LACETTI (J200)
 GENTRA
 LACETTI
 LACETTI (KLAN)
 NUBIRA (KLAN)

RIGHT - 102393

Ø = 13 mm
 Ø = 49 mm
 H = 170 mm

510032

LEFT - 510031

Ø = 13 mm
Ø = 53 mm
H = 185 mm



CHEVROLET
OPEL

CAPTIVA (C100, C140)
ANTARA

APPLICATION

RIGHT - 510031

Ø = 13 mm
Ø = 53 mm
H = 185 mm

510087

LEFT - 510086

Ø = 13 mm
Ø = 54,5 mm
H = 215 mm



OPEL
OPEL
OPEL

VIVARO (E7)
VIVARO (F7)
VIVARO (J7)

APPLICATION

RIGHT - 510086

Ø = 13 mm
Ø = 54,5 mm
H = 215 mm

510193

LEFT - 510192

Ø = 13,5 mm
Ø = 48,6 mm
H = 175 mm



OPEL
VAUXHALL

MERIVA
MERIVA Mk I (A)

APPLICATION

RIGHT - 510192

Ø = 13,5 mm
Ø = 48,6 mm
H = 175 mm

101745

LEFT - 101599

Ø = 13,5 mm
Ø = 52 mm
H = 187,5 mm



OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL

ASTRA G (F07_)
ASTRA G (F08_, F48_)
ASTRA G (F35_)
ASTRA G (F67)
ASTRA G (F69_)
ASTRA G (F70)
ASTRA G CLASSIC
(F08, F48)
ASTRA G CLASSIC
(F69)
ASTRA G CLASSIC
Caravan (F35)

APPLICATION

OPEL ASTRA H (L08)
OPEL ASTRA H (L35)
OPEL ASTRA H (L48)
OPEL ASTRA H (L67)
OPEL ASTRA H (L69)
OPEL ASTRA H (L70)
OPEL ZAFIRA A (F75_)
OPEL ZAFIRA B (A05)
VAUXHALL ASTRA Mk IV (G)
VAUXHALL ZAFIRA Mk I (A) (F75)

RIGHT - 101599

Ø = 13,5 mm
Ø = 52 mm
H = 187,5 mm

OPEL
OPEL

510051

APPLICATION

LEFT - 510050

$\varnothing$ = 13,5 mm
 $\varnothing$ = 56 mm
H = 218 mm



OPEL
OPEL

SIGNUM
VECTRA C

RIGHT - 510050

$\varnothing$ = 13,5 mm
 $\varnothing$ = 56 mm
H = 218 mm

102371

APPLICATION

LEFT - 102370

$\varnothing$ = 13,8 mm
 $\varnothing$ = 46,4 mm
H = 186 mm



CHEVROLET
CHEVROLET
CHEVROLET
OPEL

AVEO (T300)
COBALT
TRAX
MOKKA

RIGHT - 102370

$\varnothing$ = 13,8 mm
 $\varnothing$ = 46,4 mm
H = 186 mm

101806

APPLICATION

LEFT - 101601

$\varnothing$ = 14 mm
 $\varnothing$ = 48,5 mm
H = 158,45 mm



OPEL

VECTRA B (36_)

RIGHT - 101601

$\varnothing$ = 14 mm
 $\varnothing$ = 48,5 mm
H = 158,45 mm

102065

APPLICATION

LEFT - 102007

$\varnothing$ = 14,5 mm
 $\varnothing$ = 48,45 mm
H = 169,7 mm



DAEWOO
DAEWOO
OPEL
OPEL
OPEL
VAUXHALL

LEGANZA (KLAV)
NUBIRA (KLAJ)
VECTRA B (31_)
VECTRA B (36_)
VECTRA B (38_)
VECTRA (B)

RIGHT - 102007

$\varnothing$ = 14,5 mm
 $\varnothing$ = 48,45 mm
H = 169,7 mm

102061

LEFT - 101501

Ø = 14,5 mm
 Ø = 50,5 mm
 H = 189 mm



CHEVROLET
 OPEL

CRUZE (J300)
 ASTRA J

APPLICATION**RIGHT - 101501**

Ø = 14,5 mm
 Ø = 50,5 mm
 H = 189 mm

101749

LEFT - 101640

Ø = 15,15 mm
 Ø = 51 mm
 H = 175 mm



OPEL
 OPEL
 OPEL
 VAUXHALL

FRONTERA B (6B_)
 MONTEREY A (UBS_)
 MONTEREY B
 FRONTERA Mk II (B)

APPLICATION**RIGHT - 101640**

Ø = 15,15 mm
 Ø = 51 mm
 H = 175 mm

510110

LEFT - 510109

Ø = 15,5 mm
 Ø = 52 mm
 H = 210 mm



OPEL

ASTRA GTC J

APPLICATION**RIGHT - 510109**

Ø = 15,5 mm
 Ø = 52 mm
 H = 210 mm

101697

LEFT - 101607

Ø = 38,15 mm
 Ø = 50,95 mm
 H = 134 mm



OPEL

KADETT E (35_, 36_,
 45_, 46_)
 KADETT E (39_, 49_)
 KADETT E (43B_)

APPLICATION**RIGHT - 101607**

Ø = 38,15 mm
 Ø = 50,95 mm
 H = 134 mm

510003C

LEFT - 510003

Ø = 39 mm
 Ø = 50 mm
 H = 162 mm



RIGHT - 510003

Ø = 39 mm
 Ø = 50 mm
 H = 162 mm

APPLICATION

OPEL	ASCONA C (81_, 86_, 87_, 88_)	OPEL	KADETT E (39_, 49_)
OPEL	ASCONA C (84_, 89_)	OPEL	KADETT E (43B_)
OPEL	KADETT D (_42, 32_, 37_, 39)	OPEL	MANTA A (58_, 59_)
OPEL	KADETT D (31_-34_, 41_-44_)	OPEL	MANTA B (53_, 55_)
OPEL	KADETT E (33_, 34_, 43_, 44_)	OPEL	MANTA B (58_, 59_)
OPEL	KADETT E (37_, 47_)	VAUXHALL	ASTRA
		VAUXHALL	ASTRA Mk II
		VAUXHALL	CAVALIER Mk II
		VAUXHALL	CAVALIER Mk III
		VAUXHALL	CAVALIER Mk III (87)

510132

LEFT - 510131

Ø = 42,15 mm
 Ø = 51,5 mm
 H = 165,05 mm



RIGHT - 510131

Ø = 42,15 mm
 Ø = 51,5 mm
 H = 165,05 mm

APPLICATION

DAEWOO	ESPERO (KLEJ)	OPEL	KADETT E (33_, 34_, 43_, 44_)
DAEWOO	NEXIA (KLETN)	OPEL	KADETT E (35_, 36_, 45_, 46_)
OPEL	ASCONA C (81_, 86_, 87_, 88_)	OPEL	KADETT E (37_, 47_)
OPEL	ASCONA C (84_, 89_)	OPEL	KADETT E (38_, 48_)
OPEL	KADETT D (31_-34_, 41_-44_)	OPEL	KADETT E (39_, 49_)
OPEL	KADETT D (35_, 36_, 45_, 46_)	OPEL	KADETT E (43B_)
		OPEL	VECTRA A (J89)

101657

LEFT - 101658

Ø = 9,5 mm
 Ø = 25,4 mm
 H = 182 mm



CHRYSLER
 CHRYSLER

VOYAGER III (GS)
 VOYAGER IV (RG, RS)

APPLICATION

RIGHT - 101612

Ø = 10 mm
 Ø = 42,3 mm
 H = 119,5 mm

101680

LEFT - 101143

Ø = 9,5 mm
 Ø = 41,9 mm
 H = 199,5 mm



CHRYSLER
 CHRYSLER

VOYAGER II (ES)
 VOYAGER III (GS)

APPLICATION

RIGHT - 101143

Ø = 9,5 mm
 Ø = 41,9 mm
 H = 199,5 mm

102161

LEFT - 101611

Ø = 9,3 mm
Ø = 46,7 mm
H = 132,05 mm



CITROEN
CITROEN

2 CV
MEHARI

APPLICATION

RIGHT - 101611

Ø = 9,3 mm
Ø = 46,7 mm
H = 132,05 mm

101609

LEFT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

BERLINGO (MF)
C15 (VD-_)
LNA
VISA
ZX (N2)
104
205 I (741A/C)
205 II (20A/C)
205 Mk II (20A/C)
305 I (581A)
305 II (581M)

APPLICATION

PEUGEOT 306 (7B, N3, N5)
PEUGEOT 309 I (10A, 10C)
PEUGEOT 309 II (3A, 3C)
PEUGEOT 405 II (4B)
PEUGEOT 405 Mk II (4B)
PEUGEOT 504 (A_, M_)
PEUGEOT 505 (551A)
PEUGEOT 604 (561A_)
PEUGEOT PARTNER (5)
PEUGEOT PARTNER (5F)

RIGHT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm

101634

LEFT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm



PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

205 I (20D, 741B)
205 I (741A/C)
205 II (20A/C)
205 Mk II (20A/C)
305 I (581A)
305 II (581M)
306 (7A, 7C, N3, N5)
309 I (10A, 10C)
309 II (3A, 3C)

APPLICATION

PEUGEOT 406 (8B)
PEUGEOT PARTNER (5)
PEUGEOT PARTNER (5F)

RIGHT - 101600

Ø = 39,45 mm
Ø = 44 mm
H = 120 mm

510215

LEFT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm



PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

205 I (20D, 741B)
205 I (741A/C)
205 II (20A/C)
205 Mk II (20A/C)
306 (7A, 7C, N3, N5)
306 (7B, N3, N5)
309 I (10A, 10C)
309 II (3A, 3C)
PARTNER (5)

APPLICATION

PEUGEOT PARTNER (5F)

RIGHT - 101467

Ø = 40 mm
Ø = 40 mm
H = 110,7 mm

3rd BOOT - 510148

Ø = 11 mm
Ø = 39 mm
H = 66 mm

510053

LEFT - 101608

Ø = 10 mm
 Ø = 40 mm
 H = 171,9 mm



RIGHT - 510052

Ø = 39 mm
 Ø = 39 mm
 H = 130 mm

PEUGEOT	504
PEUGEOT	504 (A_, M_)
PEUGEOT	504 (D_, F_)
PEUGEOT	504 (E_)
PEUGEOT	505 (551A)
PEUGEOT	505 (551D)

APPLICATION

102015

LEFT - 101545

Ø = 11 mm
 Ø = 38 mm
 H = 215 mm



RIGHT - 102012

Ø = 10,17 mm
 Ø = 47,55 mm
 H = 154 mm

CITROEN	C25 (280_, 290_)
PEUGEOT	J5 (280L)
PEUGEOT	J5 (280P)
PEUGEOT	J5 (290L)
PEUGEOT	J5 (290P)

APPLICATION

101743

LEFT - 101353

Ø = 11 mm
 Ø = 42 mm
 H = 150 mm



RIGHT - 101547

Ø = 11 mm
 Ø = 42 mm
 H = 180 mm

CITROEN	BERLINGO (M_)
CITROEN	BERLINGO (MF)
CITROEN	XSARA (N1)
PEUGEOT	306 (7B, N3, N5)
PEUGEOT	PARTNER (5)
PEUGEOT	PARTNER (5F)

APPLICATION

510216

LEFT - 101353

Ø = 11 mm
 Ø = 42 mm
 H = 150 mm



RIGHT - 101467

Ø = 40 mm
 Ø = 40 mm
 H = 110,7 mm

3rd BOOT - 510148

A3 = 11 mm
 Ø = 39 mm
 H = 66 mm

CITROEN	XSARA (N0)
CITROEN	XSARA (N1)
CITROEN	XSARA (N2)
PEUGEOT	306 (7D, N3, N5)
PEUGEOT	306 (7E, N3, N5)

APPLICATION

102032

LEFT - 510226

Ø = 11 mm
 Ø = 44 mm
 H = 110 mm



CITROEN

AX (ZA-_)

APPLICATION

RIGHT - 101969

Ø = 38 mm
 Ø = 17,5 mm
 H = 141,75 mm

102128

LEFT - 510226

Ø = 11 mm
 Ø = 44 mm
 H = 110 mm



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT

AX (ZA-_)
 SAXO (S0, S1)
 106 (1A)
 106 I (1A, 1C)
 106 II (1)

APPLICATION

RIGHT - 101628

Ø = 11,75 mm
 Ø = 44,55 mm
 H = 186,25 mm

510114

LEFT - 510113

Ø = 11 mm
 Ø = 45 mm
 H = 240 mm



PEUGEOT
 PEUGEOT

405 I (15B)
 405 I (15E)

APPLICATION

RIGHT - 510113

Ø = 11 mm
 Ø = 45 mm
 H = 240 mm

510094

LEFT - 510113

Ø = 11 mm
 Ø = 45 mm
 H = 240 mm



PEUGEOT
 PEUGEOT

405 I (15B)
 405 I (15E)

APPLICATION

RIGHT - 510093

Ø = 45 mm
 Ø = 45 mm
 H = 180 mm

101678

LEFT - 101546

Ø = 11 mm
Ø = 47 mm
H = 200 mm



CITROEN

BX (XB-_)

APPLICATION

RIGHT - 101546

Ø = 11 mm
Ø = 47 mm
H = 200 mm

102122

LEFT - 101803

Ø = 11,55 mm
Ø = 47,95 mm
H = 201,65 mm

CITROEN
CITROENXANTIA (X1)
XANTIA (X2)

APPLICATION

RIGHT - 101803

Ø = 11,55 mm
Ø = 47,95 mm
H = 201,65 mm

510138

LEFT - 101803

Ø = 11,55 mm
Ø = 47,95 mm
H = 201,65 mm



PEUGEOT

605 (6B)

APPLICATION

RIGHT - 510125

Ø = 49 mm
Ø = 50 mm
H = 129 mm

3rd BOOT - 101791

Ø = 9,8 mm
Ø = 36,4 mm
H = 46,5 mm

102123

LEFT - 101803

Ø = 11,55 mm
Ø = 47,95 mm
H = 201,65 mm

CITROEN
PEUGEOT
PEUGEOT
PEUGEOTXANTIA (X1)
405 II (4B)
405 II (4E)
405 Mk II (4B)

APPLICATION

RIGHT - 101803

Ø = 11,55 mm
Ø = 47,95 mm
H = 201,65 mm

3rd BOOT - 101791

Ø = 9,8 mm
Ø = 36,4 mm
H = 46,5 mm

102076

LEFT - 101628

Ø = 11,75 mm
 Ø = 44,55 mm
 H = 186,25 mm



PEUGEOT
 PEUGEOT

106 I (1A, 1C)
 106 II (1)

APPLICATION

RIGHT - 101628

Ø = 11,75 mm
 Ø = 44,55 mm
 H = 186,25 mm

102375

LEFT - 102374

Ø = 12,3 mm
 Ø = 54,2 mm
 H = 200,95 mm



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT

NEMO
 NEMO (AA_)
 BIPPER (AA_)
 BIPPER Tepee

APPLICATION

RIGHT - 102374

Ø = 12,3 mm
 Ø = 54,2 mm
 H = 200,95 mm

101771

LEFT - 101504

Ø = 12,5 mm
 Ø = 61,3 mm
 H = 213,8 mm



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT

EVASION (22, U6)
 JUMPY (U6U)
 806 (221)
 EXPERT (224)

APPLICATION

RIGHT - 101504

Ø = 12,5 mm
 Ø = 61,3 mm
 H = 213,8 mm

102075

LEFT - 101801

Ø = 13,7 mm
 Ø = 53,6 mm
 H = 250,2 mm



PEUGEOT
 PEUGEOT

J5 (290L)
 J5 (290P)

APPLICATION

RIGHT - 101801

Ø = 13,7 mm
 Ø = 53,6 mm
 H = 250,2 mm

510154

LEFT - 101801

Ø = 13,7 mm
 Ø = 53,6 mm
 H = 250,2 mm



RIGHT - 510214

Ø = 15 mm
 Ø = 62 mm
 H = 270 mm

CITROEN
 CITROEN
 CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

JUMPER (230)
 JUMPER (230L)
 JUMPER (244)
 JUMPER (244, Z_)
 BOXER (230P)
 BOXER (244)
 BOXER (244, Z_)
 BOXER (ZCT_)
 ER (230L)

PEUGEOT

ER (244)

APPLICATION

102420

LEFT - 102419

Ø = 14 mm
 Ø = 47 mm
 H = 175 mm



RIGHT - 102419

Ø = 14 mm
 Ø = 47 mm
 H = 175 mm

CITROEN
 CITROEN
 PEUGEOT

C-CROSSER (EP_)
 C-CROSSER ENTER-
 PRISE
 4007 (GP_)

APPLICATION

510231

LEFT - 510230

Ø = 14 mm
 Ø = 60,5 mm
 H = 182 mm



RIGHT - 510230

Ø = 14 mm
 Ø = 60,5 mm
 H = 182 mm

PEUGEOT

BIPPER Tepee

APPLICATION

510187

LEFT - 510186

Ø = 14,95 mm
 Ø = 49,7 mm
 H = 163,1 mm



RIGHT - 510186

Ø = 14,95 mm
 Ø = 49,7 mm
 H = 163,1 mm

CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 CITROEN
 PEUGEOT

C2 (JM_)
 C2 ENTERPRISE
 C2 ENTERPRISE (JG_)
 C3 (HB_)
 C3 I (FC_)
 C3 I (FC_, FN_)
 1007 (KM_)

APPLICATION

102030

LEFT - 102029

Ø = 15 mm
 Ø = 55 mm
 H = 225 mm



PEUGEOT
 PEUGEOT

BOXER
 ER

APPLICATION

RIGHT - 102029

Ø = 15 mm
 Ø = 55 mm
 H = 225 mm

101691

LEFT - 101468

Ø = 15 mm
 Ø = 55,1 mm
 H = 250 mm



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

C25 (280_, 290_)
 C35
 J5 (280L)
 J5 (280P)
 J5 (290L)
 J5 (290P)
 J9

APPLICATION

RIGHT - 101468

Ø = 15 mm
 Ø = 55,1 mm
 H = 250 mm

510071

LEFT - 510070

Ø = 15,5 mm
 Ø = 51,5 mm
 H = 185 mm



CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

C3 Picasso
 207
 207 (WA_, WC_)
 207 CC (WD_)
 207 SW (WK_)

APPLICATION

RIGHT - 510070

Ø = 15,5 mm
 Ø = 51,5 mm
 H = 185 mm

510189

LEFT - 510188

Ø = 15,5 mm
 Ø = 64 mm
 H = 168 mm



CITROEN
 PEUGEOT

C8 (EA_, EB_)
 807 (E)

APPLICATION

RIGHT - 510188

Ø = 15,5 mm
 Ø = 64 mm
 H = 168 mm

101744

LEFT - 101595

Ø = 16,5 mm
 Ø = 55 mm
 H = 207,5 mm



PEUGEOT
 PEUGEOT

206 (2A/C)
 206 (2E/K)

APPLICATION**RIGHT - 101595**

Ø = 16,5 mm
 Ø = 55 mm
 H = 207,5 mm

101773

LEFT - 101502

Ø = 17 mm
 Ø = 59 mm
 H = 184 mm



PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

206 (2A/C)
 206 (2E/K)
 307 (3A/C)
 307 (3B)

APPLICATION**RIGHT - 101502**

Ø = 17 mm
 Ø = 59 mm
 H = 184 mm

510244

LEFT - 101503

Ø = 18 mm
 Ø = 46,5 mm
 H = 211 mm



CITROEN

XANTIA (X2)

APPLICATION**RIGHT - 101503**

Ø = 18 mm
 Ø = 46,5 mm
 H = 211 mm

510137

LEFT - 101503

Ø = 18 mm
 Ø = 46,5 mm
 H = 211 mm



CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT

XANTIA (X1)
 406 (8B)
 406 (8E/F)
 406 Break (8E/F)

APPLICATION**RIGHT - 101600**

Ø = 39,45 mm
 Ø = 44 mm
 H = 120 mm

3rd BOOT - 101791

Ø = 9,8 mm
 Ø = 36,4 mm
 H = 46,5 mm

CITROEN - PEUGEOT - DS

STEERING BOOT KITS

102062

LEFT - 101548

Ø = 21 mm
Ø = 58 mm
H = 170 mm



PEUGEOT	406 (8B)
PEUGEOT	406 (8C)
PEUGEOT	406 (8E/F)

APPLICATION

RIGHT - 101548

Ø = 21 mm
Ø = 58 mm
H = 170 mm

102108

LEFT - 101548

Ø = 21 mm
Ø = 58 mm
H = 170 mm



PEUGEOT	406 (8B)
---------	----------

APPLICATION

RIGHT - 101548

Ø = 21 mm
Ø = 58 mm
H = 170 mm

3rd BOOT - 101791

Ø = 9,8 mm
Ø = 36,4 mm
H = 46,5 mm

102034

LEFT - 102033

Ø = 21,25 mm
Ø = 57 mm
H = 172 mm



CITROEN	C5 I (DC_)
CITROEN	C5 I (DE_)
PEUGEOT	607 (9D, 9U)

APPLICATION

RIGHT - 102033

Ø = 21,25 mm
Ø = 57 mm
H = 172 mm

102010

LEFT - 102011

Ø = 24,5 mm
Ø = 52,6 mm
H = 200,5 mm



CITROEN	C6 (TD_)
PEUGEOT	407 (6C_)
PEUGEOT	407 (6D_)
PEUGEOT	407 (6E_)

APPLICATION

RIGHT - 102009

Ø = 26,7 mm
Ø = 48 mm
H = 195 mm

102067

LEFT - 102011

Ø = 24,5 mm
 Ø = 52,6 mm
 H = 200,5 mm



CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT

C6 (TD_)
 407 (6C_)
 407 (6D_)
 407 (6E_)

APPLICATION**RIGHT - 102011**

Ø = 24,5 mm
 Ø = 52,6 mm
 H = 200,5 mm

510245

LEFT - 101706

Ø = 26 mm
 Ø = 44 mm
 H = 105 mm



PEUGEOT

404

APPLICATION**RIGHT - 101706**

Ø = 26 mm
 Ø = 44 mm
 H = 105 mm

102022

LEFT - 101969

Ø = 38 mm
 Ø = 17,5 mm
 H = 141,75 mm



CITROEN
 PEUGEOT

SAXO (S0, S1)
 106 II (1)

APPLICATION**RIGHT - 101969**

Ø = 38 mm
 Ø = 17,5 mm
 H = 141,75 mm

510096

LEFT - 510095

Ø = 38 mm
 Ø = 39 mm
 H = 138 mm



CITROEN
 CITROEN

AX (ZA-_)
 SAXO (S0, S1)

APPLICATION**RIGHT - 510095**

Ø = 38 mm
 Ø = 39 mm
 H = 138 mm

510229

LEFT - 510228

Ø = 38 mm
 Ø = 39 mm
 H = 138 mm



CITROEN
 PEUGEOT

SAXO (S0, S1)
 106 II (1)

APPLICATION

RIGHT - 510228

Ø = 38 mm
 Ø = 39 mm
 H = 138 mm

510233

LEFT - 510232

Ø = 38 mm
 Ø = 39 mm
 H = 138 mm



CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT

SAXO (S0, S1)
 106 (1A)
 106 I (1A, 1C)
 106 II (1)

APPLICATION

RIGHT - 510232

Ø = 38 mm
 Ø = 39 mm
 H = 138 mm

101772

LEFT - 101467

Ø = 40 mm
 Ø = 40 mm
 H = 110,7 mm



CITROEN
 CITROEN
 CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

BERLINGO (MF)
 XSARA (N1)
 XSARA PICASSO (N68)
 ZX (N2)
 205 I (20D, 741B)
 205 I (741A/C)
 205 II (20A/C)
 205 Mk II (20A/C)
 305 I (581A)
 305 II (581M)

APPLICATION

PEUGEOT 306 (7B, N3, N5)
 PEUGEOT 306 (7D, N3, N5)
 PEUGEOT 306 (7E, N3, N5)
 PEUGEOT 309 I (10A, 10C)
 PEUGEOT 309 II (3A, 3C)
 PEUGEOT 406 (8B)
 PEUGEOT 406 (8C)
 PEUGEOT PARTNER (5)
 PEUGEOT PARTNER (5F)

RIGHT - 101467

Ø = 40 mm
 Ø = 40 mm
 H = 110,7 mm

101761

LEFT - 101467

Ø = 40 mm
 Ø = 40 mm
 H = 110,7 mm



CITROEN
 CITROEN
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT
 PEUGEOT

BERLINGO (M_)
 BERLINGO (MF)
 205 I (741A/C)
 205 II (20A/C)
 205 Mk II (20A/C)
 305 I (581A)
 305 II (581M)

APPLICATION

PEUGEOT 306 (7B, N3, N5)
 PEUGEOT 309 I (10A, 10C)
 PEUGEOT 309 II (3A, 3C)
 PEUGEOT 406 (8B)
 PEUGEOT PARTNER (5)
 PEUGEOT PARTNER (5F)

RIGHT - 101608

Ø = 10 mm
 Ø = 40 mm
 H = 171,9 mm

APPLICATION

LEFT - 101967

Ø = 44,5 mm
Ø = 38,5 mm
H = 121,5 mm



CITROEN
PEUGEOT

SAXO (S0, S1)
106 II (1)

RIGHT - 101967

Ø = 44,5 mm
Ø = 38,5 mm
H = 121,5 mm

101750

LEFT - 101144

Ø = 7,9 mm
 Ø = 37,95 mm
 H = 165 mm



RIGHT - 101144

Ø = 7,9 mm
 Ø = 37,95 mm
 H = 165 mm

RENAULT
 RENAULT

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

AVANTIME (DE0_)
 CLIO II (BB0/1/2_,
 CB0/1/2_)
 CLIO II (SB0/1/2_)
 ESPACE III (JE0_)
 ESPACE IV (JK0/1_)
 KANGOO (KC0/1_)
 LAGUNA I (556_,
 B56_)

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

MASTER II (ED/HD/UD)
 MASTER II (FD)
 MASTER II (JD)
 MEGANE (JA0/1_)
 MEGANE I (BA0/1_)
 SCÉNIC I (JA0/1_)
 THALIA I (LB0/1/2_)

APPLICATION

102082

LEFT - 101543

Ø = 9 mm
 Ø = 38 mm
 H = 170 mm



RENAULT

RENAULT
 RENAULT
 RENAULT
 RENAULT

CLIO II (BB0/1/2_,
 CB0/1/2_)
 CLIO II (SB0/1/2_)
 KANGOO (FC0/1_)
 KANGOO (KC0/1_)
 SAFRANE I (B54_)

RIGHT - 101543

Ø = 9 mm
 Ø = 38 mm
 H = 170 mm

APPLICATION

101777

LEFT - 101543

Ø = 9 mm
 Ø = 38 mm
 H = 170 mm



RENAULT

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

CLIO II (BB0/1/2_,
 CB0/1/2_)
 KANGOO (FC0/1_)
 KANGOO (KC0/1_)
 SAFRANE I (B54_)
 SAFRANE II (B54_)
 THALIA I (LB0/1/2_)

RIGHT - 101799

Ø = 9 mm
 Ø = 39 mm
 H = 195 mm

APPLICATION

102073

LEFT - 101799

Ø = 9 mm
 Ø = 39 mm
 H = 195 mm



RENAULT

SAFRANE I (B54_)

RIGHT - 101799

Ø = 9 mm
 Ø = 39 mm
 H = 195 mm

APPLICATION

101657

LEFT - 101658

Ø = 9,5 mm
Ø = 25,4 mm
H = 182 mm



RIGHT - 101612

Ø = 10 mm
Ø = 42,3 mm
H = 119,5 mm

APPLICATION

RENAULT	TRAFIC (PXX)
RENAULT	TRAFIC (TXW)
RENAULT	TRAFIC (TXX)

101687

LEFT - 101507

Ø = 9,5 mm
Ø = 31 mm
H = 196 mm



RIGHT - 101507

Ø = 9,5 mm
Ø = 31 mm
H = 196 mm

APPLICATION

RENAULT	18	RENAULT	FUEGO (136_)
RENAULT	11 (B/C37_)	RENAULT	TRAFIC (P6)
RENAULT	11 (S37_)	RENAULT	TRAFIC (PXX)
RENAULT	18 (134_)	RENAULT	TRAFIC (T1, T3, T4)
RENAULT	18 (135_)	RENAULT	TRAFIC (T5, T6, T7)
RENAULT	20 (127_)	RENAULT	TRAFIC (TXW)
RENAULT	25 (B29_)	RENAULT	TRAFIC (TXX)
RENAULT	30 (127_)		
RENAULT	9 (L42_)		

102145

LEFT - 101507

Ø = 9,5 mm
Ø = 31 mm
H = 196 mm



RIGHT - 101509

Ø = 10 mm
Ø = 40 mm
H = 100 mm

APPLICATION

RENAULT	TRAFIC (P6)
RENAULT	TRAFIC (PXX)
RENAULT	TRAFIC (T1, T3, T4)
RENAULT	TRAFIC (T5, T6, T7)
RENAULT	TRAFIC (TXW)
RENAULT	TRAFIC (TXX)

510047

LEFT - 510046

Ø = 9,5 mm
Ø = 42 mm
H = 165 mm



RIGHT - 510046

Ø = 9,5 mm
Ø = 42 mm
H = 165 mm

APPLICATION

DACIA	LOGAN (FS_)	RENAULT	LOGAN I (KS_)
DACIA	LOGAN (LS_)	RENAULT	LOGAN I (LS_)
DACIA	LOGAN (US_)	RENAULT	MASTER II (ED/HD/UD)
DACIA	LOGAN MCV (KS_)	RENAULT	MASTER II (FD)
DACIA	SANDERO	RENAULT	MASTER II (JD)
RENAULT	AVANTIME (DEO_)	RENAULT	SANDERO/STEPWAY
RENAULT	ESPACE III (JEO_)		I (BS_)
RENAULT	LOGAN EXPRESS		
	(US_)		

510130

LEFT - 510129

Ø = 10 mm
Ø = 27,5 mm
H = 155 mm



RIGHT - 510129

Ø = 10 mm
Ø = 27,5 mm
H = 155 mm

RENAULT 11 (B/C37_)
RENAULT 19 I (B/C53_)
RENAULT 19 I (D53_)
RENAULT 19 I (L53_)
RENAULT 19 II (853_, D53_)
RENAULT 19 II (B/C53_)
RENAULT 19 II (L53_)
RENAULT 19 II (S53_)
RENAULT 21 (B48_)

APPLICATION

RENAULT 21 (K48_)
RENAULT 21 (L48_)
RENAULT 9 (L42_)
RENAULT CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT CLIO II (SB0/1/2_)
RENAULT RAPID (F40_, G40_)
RENAULT SUPER 5 (B/C40_)
RENAULT TWINGO I (C06_)

101677

LEFT - 101469

Ø = 10 mm
Ø = 33 mm
H = 163 mm



RIGHT - 101469

Ø = 10 mm
Ø = 33 mm
H = 163 mm

RENAULT 14 (121_)
RENAULT 16 (115_)
RENAULT 4 (112_)
RENAULT 4 (R21_, R23_)
RENAULT 5 (122_)
RENAULT 5 (238_)
RENAULT 6 (118_)
RENAULT RODEO 4 (ACL_)
RENAULT RODEO 6 (ACL_)

APPLICATION

510002C

LEFT - 510002

Ø = 10 mm
Ø = 37,5 mm
H = 140 mm



RIGHT - 510002

Ø = 10 mm
Ø = 37,5 mm
H = 140 mm

RENAULT 18
RENAULT 11 (B/C37_)
RENAULT 18 (134_)
RENAULT 18 (135_)
RENAULT 19 I (B/C53_)
RENAULT 19 I (L53_)
RENAULT 19 II (B/C53_)
RENAULT 19 II (L53_)
RENAULT 20 (127_)
RENAULT 21 (B48_)
RENAULT 25 (B29_)
RENAULT 30 (127_)
RENAULT CLIO I (5/357_, B/C57_)

APPLICATION

RENAULT CLIO I (S57_)
RENAULT CLIO II (BB0/1/2_, CB0/1/2_)
RENAULT ESPACE I (J11_)
RENAULT ESPACE II (J/S63_)
RENAULT SUPER 5 (B/C40_)
RENAULT SUPER 5 (S40_)
RENAULT TRAFIC (PXX)
RENAULT TRAFIC (TXW)
RENAULT TRAFIC (TXX)
RENAULT TWINGO I (C06_)
RENAULT TWINGO I (S06_)

510235

LEFT - 510234

Ø = 10 mm
Ø = 37,75 mm
H = 152 mm



RIGHT - 510234

Ø = 10 mm
Ø = 37,75 mm
H = 152 mm

APPLICATION

RENAULT	LAGUNA I (556_, B56_)
RENAULT	LAGUNA I (K56_)

510001C

LEFT - 510001

Ø = 10,55 mm
Ø = 31,5 mm
H = 152 mm



RIGHT - 510001

Ø = 10,55 mm
Ø = 31,5 mm
H = 152 mm

APPLICATION

RENAULT	11 (B/C37_)	RENAULT	SUPER 5 (B/C40_)
RENAULT	19 I (B/C53_)	RENAULT	SUPER 5 (S40_)
RENAULT	19 I (L53_)	RENAULT	TWINGO I (C06_)
RENAULT	19 II (B/C53_)	RENAULT	TWINGO I (S06_)
RENAULT	19 II (L53_)		
RENAULT	21 (B48_)		
RENAULT	9 (L42_)		
RENAULT	CLIO II (BB0/1/2_, CB0/1/2_)		

101692

LEFT - 101508

Ø = 11 mm
Ø = 39 mm
H = 160 mm



RIGHT - 101508

Ø = 11 mm
Ø = 39 mm
H = 160 mm

APPLICATION

RENAULT	18	RENAULT	FUEGO (136_)
RENAULT	11 (B/C37_)		
RENAULT	11 (S37_)		
RENAULT	18 (134_)		
RENAULT	18 (135_)		
RENAULT	20 (127_)		
RENAULT	25 (B29_)		
RENAULT	30 (127_)		
RENAULT	9 (L42_)		

101704

LEFT - 101508

Ø = 11 mm
Ø = 39 mm
H = 160 mm



RIGHT - 101507

Ø = 9,5 mm
Ø = 31 mm
H = 196 mm

APPLICATION

RENAULT	18	RENAULT	FUEGO (136_)
RENAULT	11 (B/C37_)		
RENAULT	11 (S37_)		
RENAULT	18 (134_)		
RENAULT	18 (135_)		
RENAULT	20 (127_)		
RENAULT	25 (B29_)		
RENAULT	30 (127_)		
RENAULT	9 (L42_)		

101678

LEFT - 101546

Ø = 11 mm
 Ø = 47 mm
 H = 200 mm



DACIA	1210
DACIA	1310
DACIA	1410
DACIA	1310 (U, X)

APPLICATION

RIGHT - 101546

Ø = 11 mm
 Ø = 47 mm
 H = 200 mm

102162

LEFT - 101562

Ø = 11,5 mm
 Ø = 40 mm
 H = 170 mm



RENAULT	MEGANE I (BA0/1_)
RENAULT	MEGANE I (DA0/1_)
RENAULT	MEGANE I (EA0/1_)
RENAULT	MEGANE I (KA0/1_)
RENAULT	MEGANE I (LA0/1_)

APPLICATION

RIGHT - 101562

Ø = 11,5 mm
 Ø = 40 mm
 H = 170 mm

102158

LEFT - 101798

Ø = 11,67 mm
 Ø = 45,65 mm
 H = 169,45 mm



RENAULT	SAFRANE I (B54_)
---------	------------------

APPLICATION

RIGHT - 101628

Ø = 11,75 mm
 Ø = 44,55 mm
 H = 186,25 mm

102076

LEFT - 101628

Ø = 11,75 mm
 Ø = 44,55 mm
 H = 186,25 mm



RENAULT	SAFRANE I (B54_)
---------	------------------

APPLICATION

RIGHT - 101628

Ø = 11,75 mm
 Ø = 44,55 mm
 H = 186,25 mm

101794

LEFT - 160380

Ø = 12 mm
 Ø = 44 mm
 H = 170 mm

**RIGHT - 160380**

Ø = 12 mm
 Ø = 44 mm
 H = 170 mm

RENAULT
 RENAULT
 RENAULT
 RENAULT

RENAULT
 RENAULT

MEGANE (JA0/1_)
 MEGANE I (BA0/1_)
 MEGANE I (LA0/1_)
 MEGANE II (BM0/1_,
 CM0/1_)
 MEGANE II (EM0/1_)
 SCÉNIC I (JA0/1_)

APPLICATION

201107

LEFT - 102429

Ø = 12 mm
 Ø = 54 mm
 H = 200 mm

**RIGHT - 102429**

Ø = 12 mm
 Ø = 54 mm
 H = 200 mm

RENAULT
 RENAULT
 RENAULT

RENAULT
 RENAULT
 RENAULT
 RENAULT

FLUENCE (L3_)
 FLUENCE (L30_)
 GRAND SCÉNIC III
 (JZ0/1_)
 MEGANE CC (EZ0/1_)
 MEGANE III (BZ0_)
 MEGANE III (DZ0/1_)
 MEGANE III (KZ0/1_)
 SCÉNIC III (JZ0/1_)

APPLICATION

510025

LEFT - 510024

Ø = 13 mm
 Ø = 54 mm
 H = 205 mm

**RIGHT - 510024**

Ø = 13 mm
 Ø = 54 mm
 H = 205 mm

RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

TRAFIC II (EL)
 TRAFIC II (FL)
 TRAFIC II (JL)
 TRAFIC III (EG_)
 TRAFIC III (FG_)
 TRAFIC III (JG_)

APPLICATION

510087

LEFT - 510086

Ø = 13 mm
 Ø = 54,5 mm
 H = 215 mm

**RIGHT - 510086**

Ø = 13 mm
 Ø = 54,5 mm
 H = 215 mm

RENAULT
 RENAULT
 RENAULT
 RENAULT

TRAFIC (TXX)
 TRAFIC II (EL)
 TRAFIC II (FL)
 TRAFIC II (JL)

APPLICATION

DACIA - RENAULT

STEERING BOOT KITS

102066

LEFT - 102008

Ø = 13,5 mm
Ø = 42,32 mm
H = 164,5 mm



RENAULT

RENAULT

APPLICATION

CLIO III (BR0/1,
CR0/1_)
MODUS / GRAND
MODUS (F/JPO_)

RIGHT - 102008

Ø = 13,5 mm
Ø = 42,32 mm
H = 164,5 mm

101980

LEFT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm



RENAULT

RENAULT

RENAULT

APPLICATION

LAGUNA II (BG0/1_)
LAGUNA II (KG0/1_)
MEGANE II (LM0/1_)

RIGHT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm

102424

LEFT - 102423

Ø = 14 mm
Ø = 50 mm
H = 168 mm



RENAULT

KOLEOS (HY_)

APPLICATION

RIGHT - 102423

Ø = 14 mm
Ø = 50 mm
H = 168 mm

510258

LEFT - 510257

Ø = 14 mm
Ø = 53 mm
H = 195 mm



RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

RENAULT

APPLICATION

GRAND SCÉNIC II
(JM0/1_)
MEGANE II (BM0/1_,
CM0/1_)
MEGANE II (EM0/1_)
MEGANE II (KM_)
MEGANE II (KM0/1_)
MEGANE II (KM0/2_)
MEGANE II (LM0/1_)

RENAULT

RENAULT

MEGANE II Box Body
(KM_)
SCÉNIC II (JM0/1_)

RIGHT - 510257

Ø = 14 mm
Ø = 53 mm
H = 195 mm

510231

LEFT - 510230

Ø = 14 mm
 Ø = 60,5 mm
 H = 182 mm



RENAULT
 RENAULT
 RENAULT

LAGUNA (DT0/1)
 LAGUNA III (BT0/1)
 LAGUNA III (KT0/1)

APPLICATION

RIGHT - 510230

Ø = 14 mm
 Ø = 60,5 mm
 H = 182 mm

101676

LEFT - 101505

Ø = 24,4 mm
 Ø = 34,5 mm
 H = 96,5 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT
 RENAULT

4 (112_)
 5 (122_)
 5 (238_)
 6 (118_)
 RODEO 4 (ACL_)
 RODEO 6 (ACL_)

APPLICATION

RIGHT - 101505

Ø = 24,4 mm
 Ø = 34,5 mm
 H = 96,5 mm

101688

LEFT - 101506

Ø = 26 mm
 Ø = 36 mm
 H = 78 mm



RENAULT
 RENAULT
 RENAULT
 RENAULT

12
 17
 12 (117_)
 15 (130_)

APPLICATION

RIGHT - 101506

Ø = 26 mm
 Ø = 36 mm
 H = 78 mm

APPLICATION

LEFT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm

DAF

85 CF



RIGHT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm

101789

APPLICATION

LEFT - 101661

Ø = 13,6 mm
 Ø = 57 mm
 H = 178,5 mm



DAIHATSU

CHARADE IV (G200,
G202)

DAIHATSU

GRAN MOVE (G3)

RIGHT - 101661

Ø = 13,6 mm
 Ø = 57 mm
 H = 178,5 mm

101749

APPLICATION

LEFT - 101640

Ø = 15,15 mm
 Ø = 51 mm
 H = 175 mm



DAIHATSU

SIRION (M1)

RIGHT - 101640

Ø = 15,15 mm
 Ø = 51 mm
 H = 175 mm

LEFT - 101611

FORD

ESCORT III (GAA)



RIGHT - 101610

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 29,35 \text{ mm}$
 $H = 160 \text{ mm}$

510015

APPLICATION

LEFT - 510014

$\varnothing = 10 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 147,5 \text{ mm}$



FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

CAPRI (ECJ)
CAPRI II (GECF)
CAPRI III (GECF)
ESCORT (AFH, ATH)
ESCORT I (ADH, AF)
ESCORT I (AFH, ATH)
ESCORT II
ESCORT II (ATH)

RIGHT - 510014

$\varnothing = 10 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 147,5 \text{ mm}$

101790

APPLICATION

LEFT - 101646

$\varnothing = 10,01 \text{ mm}$
 $\varnothing = 36 \text{ mm}$
 $H = 200,1 \text{ mm}$



FORD
FORD
FORD
FORD

ESCORT CLASSIC
(AAL, ABL)
ESCORT III (ALD)
ESCORT III (AWA)
ESCORT III (GAA)
ESCORT IV (ABFT,
AWF, GAF)
ESCORT IV (ALF)
ESCORT IV (AVF, AWF)
ESCORT V (ALL)
ESCORT V (AVL, GAL)
ESCORT V (GAL)
ESCORT VI (ALL)
ESCORT VI (GAL)

| FORD

ESCORT VII (AAL, ABL,
GAL)
ESCORT VII (AFL, GAL)
ESCORT VII (ALL)
ESCORT VII (ANL, GAL)
FIESTA II (FBD)
FIESTA III (GFJ)
P 100 II
SCORPIO I (GAE, GGE)
SCORPIO I (GGE)
SIERRA (BNG)
SIERRA (GB4, CBG)
SIERRA (GB4, GBG)
SIERRA (GBC, GBG)

RIGHT - 101646

$\varnothing = 10,01 \text{ mm}$
 $\varnothing = 36 \text{ mm}$
 $H = 200,1 \text{ mm}$

FORD
FORD
FORD
FORD
FORD
FORD
FORD

FORD
FORD
FORD
FORD
FORD
FORD
FORD

LEFT - 510119

Ø = 10,1 mm
Ø = 54,5 mm
H = 197,25 mm



FORD
FORD
FORD
FORD

SIERRA (BNG)
SIERRA (GB4, GBG)
SIERRA (GBC, GBG)
SIERRA (GBG, GB4)

APPLICATION

RIGHT - 510119

Ø = 10,1 mm
Ø = 54,5 mm
H = 197,25 mm

101635

LEFT - 101605

Ø = 10,45 mm
Ø = 35,15 mm
H = 219 mm



FORD
FORD
FORD
FORD

ESCORT III (ALD)
ESCORT III (AWA)
ESCORT III (GAA)
FIESTA II (FBD)

APPLICATION

RIGHT - 101605

Ø = 10,45 mm
Ø = 35,15 mm
H = 219 mm

101694

LEFT - 101604

Ø = 11 mm
Ø = 48 mm
H = 234 mm



FORD
FORD
FORD
FORD

ESCORT III (ALD)
ESCORT III (AWA)
ESCORT III (GAA)
ESCORT IV (ABFT, AWF, GAF)
ESCORT IV (ALF)
ESCORT IV (AVF, AWF)
ESCORT V (ALL)
ESCORT V (AVL, GAL)
ESCORT V (GAL)
ESCORT VI (GAL)

APPLICATION

FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT VII (AAL, ABL, GAL)
FIESTA II (FBD)
P 100 II
SIERRA (BNC)
SIERRA (BNG)
SIERRA (GB4, CBG)
SIERRA (GB4, GBG)
SIERRA (GBC)
SIERRA (GBC, GBG)

RIGHT - 101604

Ø = 11 mm
Ø = 48 mm
H = 234 mm

102077

LEFT - 101597

Ø = 11,5 mm
Ø = 52 mm
H = 170 mm



FORD

GALAXY (WGR)

APPLICATION

RIGHT - 101597

Ø = 11,5 mm
Ø = 52 mm
H = 170 mm

LEFT - 101659

Ø = 12 mm
Ø = 45,5 mm
H = 185 mm



FORD

GALAXY (WGR)

APPLICATION

RIGHT - 101659

Ø = 12 mm
Ø = 45,5 mm
H = 185 mm

101771

LEFT - 101504

Ø = 12,5 mm
Ø = 61,3 mm
H = 213,8 mm



FORD

FORD

FORD

FORD

FORD

FORD

SIERRA (BNC)

SIERRA (GBC)

TRANSIT (FA__)

TRANSIT (FB__, FC__,
FD__, FS__, FZ__)

TRANSIT (FM__,

FN__)

TRANSIT Van (FA__)

APPLICATION

RIGHT - 101504

Ø = 12,5 mm
Ø = 61,3 mm
H = 213,8 mm

510139

LEFT - 101504

Ø = 12,5 mm
Ø = 61,3 mm
H = 213,8 mm



FORD

FORD

FORD

FORD

TRANSIT (FA__)

TRANSIT (FB__, FC__,
FD__, FS__, FZ__)

TRANSIT (FM__,

FN__)

TRANSIT Van (FA__)

APPLICATION

RIGHT - 510121

Ø = 15 mm
Ø = 55 mm
H = 280 mm

101802

LEFT - 101596

Ø = 13,5 mm
Ø = 47 mm
H = 200 mm



FORD

FOCUS (DAW, DBW)

APPLICATION

RIGHT - 101596

Ø = 13,5 mm
Ø = 47 mm
H = 200 mm

101789

LEFT - 101661

Ø = 13,6 mm
Ø = 57 mm
H = 178,5 mm



RIGHT - 101661

Ø = 13,6 mm
Ø = 57 mm
H = 178,5 mm

FORD
FORD
FORD

FORD
FORD
FORD
FORD
FORD
FORD
FORD

FORD

ESCORT '91 (AVL)
ESCORT '95 (AVL)
ESCORT CLASSIC
(AAL, ABL)
ESCORT CLASSIC (ANL)
ESCORT V (ALL)
ESCORT V (AVL, GAL)
ESCORT V (GAL)
ESCORT VI (ALL)
ESCORT VI (GAL)
ESCORT VII (AAL, ABL,
GAL)
ESCORT VII (AFL, GAL)

FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT VII (ALL)
ESCORT VII (ANL, GAL)
FIESTA (J3_, J5_)
FIESTA III (GFJ)
FIESTA IV (JA_, JB_)
FIESTA V (JD_, JH_)
FOCUS (DAW, DBW)
FOCUS (DFW)
FOCUS (DNW)
KA (RB_)
ORION III (GAL)
PUMA (EC_)
STREET KA (RL2)

101805

LEFT - 101804

Ø = 13,8 mm
Ø = 36,8 mm
H = 227,7 mm



RIGHT - 101804

Ø = 13,8 mm
Ø = 36,8 mm
H = 227,7 mm

FORD
FORD
FORD
FORD

FORD
FORD
FORD
FORD

ESCORT '86 (AVF)
ESCORT '91 (AVL)
ESCORT '95 (AVL)
ESCORT CLASSIC
(AAL, ABL)
ESCORT IV (ABFT,
AWF, GAF)
ESCORT V (GAL)
ESCORT VI (GAL)

FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT VII (AAL, ABL,
GAL)
FIESTA III (GFJ)
FIESTA IV (JA_, JB_)
KA (RB_)
ORION I (AFD)
ORION II (AFF)
ORION III (GAL)

101980

LEFT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm



RIGHT - 101979

Ø = 13,9 mm
Ø = 50 mm
H = 198 mm

FORD
FORD
FORD
FORD

FORD
FORD

TRANSIT
TRANSIT (E_ _)
TRANSIT (FA_ _)
TRANSIT (FB_ _, FC_ _
, FD _, FS_ _, FZ_ _)
TRANSIT (FM_ _,
FN_ _)
TRANSIT CONNECT
(P65_, P70_, P80_)

FORD

TRANSIT TOURNEO

101806

LEFT - 101601

Ø = 14 mm
Ø = 48,5 mm
H = 158,45 mm



RIGHT - 101601

Ø = 14 mm
Ø = 48,5 mm
H = 158,45 mm

FORD

ESCORT VII (AAL, ABL,
GAL)

APPLICATION

LEFT - 101598

Ø = 14 mm
Ø = 49,5 mm
H = 182 mm



FORD
FORD

TRANSIT (E_)
TRANSIT (T_)

APPLICATION

RIGHT - 101598

Ø = 14 mm
Ø = 49,5 mm
H = 182 mm

510201

LEFT - 510200

Ø = 14 mm
Ø = 55 mm
H = 192 mm



FORD
FORD

COURIER
ESCORT VII (AAL, ABL,
GAL)
ESCORT VII (AFL, GAL)
ESCORT VII (ALL)
ESCORT VII (ANL, GAL)
ESCORT VII Turnier
(GAL, ANL) | ESCORT
NOMADE

FORD
FORD

FIESTA (JV_)
FIESTA (JV_) | COU-
RIER
FIESTA IV (JA_ , JB_)
FOCUS (DAW, DBW)
KA (RB_)
PUMA (EC_)
STREET KA (RL2)

RIGHT - 510200

Ø = 14 mm
Ø = 55 mm
H = 192 mm

102017

LEFT - 102016

Ø = 14 mm
Ø = 55 mm
H = 196 mm



FORD
FORD

FIESTA V (JD_ , JH_)
FUSION (JU_)

APPLICATION

RIGHT - 102016

Ø = 14 mm
Ø = 55 mm
H = 196 mm

102065

LEFT - 102007

Ø = 14,5 mm
Ø = 48,45 mm
H = 169,7 mm



FORD

ESCORT VII (AAL, ABL,
GAL)

APPLICATION

RIGHT - 102007

Ø = 14,5 mm
Ø = 48,45 mm
H = 169,7 mm

LEFT - 102385

Ø = 14,7 mm
Ø = 53,65 mm
H = 206,95 mm



FORD
FORD
FORD
FORD
FORD

C-MAX (DM2)
FOCUS C-MAX
FOCUS II (DA_)
FOCUS III
KUGA I

APPLICATION

RIGHT - 102385

Ø = 14,7 mm
Ø = 53,65 mm
H = 206,95 mm

102390

LEFT - 102389

Ø = 15 mm
Ø = 53 mm
H = 193 mm



FORD
FORD

FOCUS II
FOCUS II (DA_)

APPLICATION

RIGHT - 102389

Ø = 15 mm
Ø = 53 mm
H = 193 mm

510275

LEFT - 510274

Ø = 15 mm
Ø = 60 mm
H = 205 mm



FORD

TRANSIT (E_ _)

APPLICATION

RIGHT - 510274

Ø = 15 mm
Ø = 60 mm
H = 205 mm

101778

LEFT - 101603

Ø = 16,2 mm
Ø = 54,25 mm
H = 208,35 mm



FORD
FORD
FORD
FORD
FORD

COUGAR (EC_)
MAVERICK
MONDEO I (GBP)
MONDEO II (BAP)
MONDEO III (B5Y)

APPLICATION

RIGHT - 101603

Ø = 16,2 mm
Ø = 54,25 mm
H = 208,35 mm

LEFT - 102425

Ø = 16,5 mm
Ø = 52 mm
H = 195 mm



FORD
FORD
FORD

GALAXY (WA6)
MONDEO IV (BA7)
S-MAX (WA6)

APPLICATION

RIGHT - 102425

Ø = 16,5 mm
Ø = 52 mm
H = 195 mm

101696

LEFT - 101602

Ø = 9 mm
Ø = 39,15 mm
H = 147 mm



RIGHT - 101602

Ø = 9 mm
Ø = 39,15 mm
H = 147 mm

HONDA
HONDA
HONDA
HONDA

HONDA
HONDA
HONDA
HONDA

APPLICATION

ACCORD I (SJ, SY)
CIVIC I (AN, AR)
CIVIC I (SB)
CIVIC III (AG, AH, AJ, AL)
CIVIC III (AK, AM, AU)
JAZZ I (AA)
PRELUDE I (SN)
QUINTET (SU)

102060

LEFT - 101675

Ø = 9 mm
Ø = 45,5 mm
H = 161 mm



HONDA
HONDA
HONDA

APPLICATION

CIVIC IV (EC, ED, EE)
CIVIC IV (ED)
CRX III (EG, EH) Targa

RIGHT - 101675

Ø = 9 mm
Ø = 45,5 mm
H = 161 mm

101698

LEFT - 101637

Ø = 9,5 mm
Ø = 38,7 mm
H = 170 mm



HONDA
HONDA
HONDA
HONDA
HONDA

APPLICATION

ACCORD II (AC, AD)
CRX I (AF, AS)
CRX II (ED, EE)
INTEGRA (DA)
PRELUDE II (AB)

RIGHT - 101637

Ø = 9,5 mm
Ø = 38,7 mm
H = 170 mm

510144

LEFT - 510143

Ø = 9,5 mm
Ø = 39 mm
H = 184 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

APPLICATION

ACCORD I (SJ, SY)
ACCORD II (AC, AD)
ACCORD III (CA)
ACCORD V (CC, CD)
CITY
CITY (3A_, SX8)
CITY (CG_)
CIVIC I (AN, AR)
CIVIC I (SF)
CIVIC III (AG, AH, AJ, AL)
CIVIC III (AK, AM, AU)
CIVIC IV (EC, ED, EE)

HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

CONCERTO (HW, MA)
CONCERTO (HWW)
CRX I (AF, AS)
CRX II (ED, EE)
LEGEND I (HS, KA)
LEGEND I (KA_)
LEGEND II (KA)
PRELUDE II (AB)
PRELUDE III (BA)
PRELUDE IV (BB)

RIGHT - 510143

Ø = 9,5 mm
Ø = 39 mm
H = 184 mm

510007

APPLICATION

LEFT - 510006

Ø = 9,5 mm
Ø = 44 mm
H = 143 mm



HONDA
HONDA
HONDA
HONDA
HONDA
HONDA

ACCORD V (CE)
CR-V I (RD)
CR-V II (RD_)
INTEGRA (DC2, DC4)
PRELUDE V (BB)
SHUTTLE (RA)

RIGHT - 101625

Ø = 9,75 mm
Ø = 45 mm
H = 184 mm

102107

APPLICATION

LEFT - 101625

Ø = 9,75 mm
Ø = 45 mm
H = 184 mm



HONDA
HONDA
HONDA
HONDA

CIVIC VI (EJ, EK)
CIVIC VI (MA, MB)
CR-V I (RD)
INTEGRA (DC2, DC4)

RIGHT - 101675

Ø = 9 mm
Ø = 45,5 mm
H = 161 mm

510084

APPLICATION

LEFT - 510083

Ø = 10 mm
Ø = 43 mm
H = 156 mm



HONDA
HONDA
HONDA

ACCORD VI (CG)
ACCORD VI (CG, CH, CK)
ACCORD VI (CH, CL)

RIGHT - 510083

Ø = 10 mm
Ø = 43 mm
H = 156 mm

510247

APPLICATION

LEFT - 101636

Ø = 10,2 mm
Ø = 55 mm
H = 172,2 mm



HONDA
HONDA
HONDA

CIVIC VII (EM2)
CIVIC VII (EP, EU, EV)
CIVIC VII (ES)

RIGHT - 101636

Ø = 10,2 mm
Ø = 55 mm
H = 172,2 mm

510091

APPLICATION

LEFT - 510090

Ø = 11 mm
 Ø = 44 mm
 H = 150 mm



HONDA
 HONDA
 HONDA

CIVIC VI (EJ, EK)
 CIVIC VI (MA, MB)
 CIVIC VI (MB, MC)

RIGHT - 510090

Ø = 11 mm
 Ø = 44 mm
 H = 150 mm

510100

APPLICATION

LEFT - 510099

Ø = 12,5 mm
 Ø = 45 mm
 H = 175 mm



HONDA
 HONDA

ACCORD VII (CL, CN)
 ACCORD VII (CM, CN)

RIGHT - 510099

Ø = 12,5 mm
 Ø = 45 mm
 H = 175 mm

102396

APPLICATION

LEFT - 102395

Ø = 12,5 mm
 Ø = 50,5 mm
 H = 162 mm



HONDA
 HONDA
 HONDA

ACCORD VIII (CU)
 ACCORD VIII (CW)
 CROSSTOUR

RIGHT - 102395

Ø = 12,5 mm
 Ø = 50,5 mm
 H = 162 mm

102133

APPLICATION

LEFT - 101584

Ø = 13 mm
 Ø = 42,6 mm
 H = 184,1 mm



HONDA

HR-V (GH)

RIGHT - 101668

Ø = 13,5 mm
 Ø = 42,5 mm
 H = 165 mm

510206

APPLICATION

LEFT - 510205

HONDA

CIVIC VIII (FK, FN)

$\varnothing = 13 \text{ mm}$
 $\varnothing = 52 \text{ mm}$
 $H = 163 \text{ mm}$



RIGHT - 510204

$\varnothing = 13 \text{ mm}$
 $\varnothing = 46,41 \text{ mm}$
 $H = 185 \text{ mm}$

510118

APPLICATION

LEFT - 101662

HONDA
 HONDA
 HONDA
 HONDA

CIVIC VII (EM2)
 CIVIC VII (EP, EU, EV)
 CIVIC VII (ES)
 CR-V II (RD_)

$\varnothing = 60 \text{ mm}$
 $\varnothing = 72 \text{ mm}$
 $H = 445 \text{ mm}$



3rd BOOT - 510117

$\varnothing = 12,9 \text{ mm}$
 $\varnothing = 54,7 \text{ mm}$
 $H = 140,5 \text{ mm}$

LEFT - 101602

Ø = 9 mm
Ø = 39,15 mm
H = 147 mm



HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI

ACCENT (X-3)
ACCENT I (X-3)
COUPE (RD)
PONY (X-1)
S (SLC)

APPLICATION

RIGHT - 101602

Ø = 9 mm
Ø = 39,15 mm
H = 147 mm

510082

LEFT - 510081

Ø = 11,5 mm
Ø = 36 mm
H = 195 mm



KIA
KIA

PRIDE
PRIDE (DA)

APPLICATION

RIGHT - 510081

Ø = 11,5 mm
Ø = 36 mm
H = 195 mm

510036

LEFT - 510035

Ø = 12,5 mm
Ø = 44 mm
H = 215 mm



KIA

SHUMA II (FB)

APPLICATION

RIGHT - 510035

Ø = 12,5 mm
Ø = 44 mm
H = 215 mm

102132

LEFT - 101663

Ø = 13 mm
Ø = 43 mm
H = 173,5 mm



HYUNDAI
HYUNDAI

ATOS (IL44, MX)
ATOS PRIME (MX)

APPLICATION

RIGHT - 101663

Ø = 13 mm
Ø = 43 mm
H = 173,5 mm

102369

LEFT - 102368

Ø = 13 mm
Ø = 50 mm
H = 170 mm



HYUNDAI
HYUNDAI
KIA

i10 (PA)
i30 (FD)
RIO II (JB)

APPLICATION

RIGHT - 102368

Ø = 13 mm
Ø = 50 mm
H = 170 mm

102431

LEFT - 102430

Ø = 13,5 mm
Ø = 51 mm
H = 180 mm



HYUNDAI
HYUNDAI

SANTA FÉ I (SM)
TRAJET (FO)

APPLICATION

RIGHT - 102430

Ø = 13,5 mm
Ø = 51 mm
H = 180 mm

101806

LEFT - 101601

Ø = 14 mm
Ø = 48,5 mm
H = 158,45 mm



HYUNDAI
HYUNDAI
KIA

SONATA IV (EF)
XG (XG)
MAGENTIS (GD, MS)

APPLICATION

RIGHT - 101601

Ø = 14 mm
Ø = 48,5 mm
H = 158,45 mm

102135

LEFT - 101669

Ø = 14,4 mm
Ø = 47,2 mm
H = 165,15 mm



HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI

ACCENT II (LC)
COUPE (GK)
COUPE (RD)
GETZ (TB)
MATRIX (FC)

APPLICATION

RIGHT - 101669

Ø = 14,4 mm
Ø = 47,2 mm
H = 165,15 mm

102382

LEFT - 102367

Ø = 14,7 mm
Ø = 46 mm
H = 167 mm



HYUNDAI
HYUNDAI
KIA
KIA
KIA

i20 (PB, PBT)
ix20 (JC)
RIO III (UB)
SOUL (AM)
VENGA (YN)

APPLICATION

RIGHT - 102367

Ø = 14,7 mm
Ø = 46 mm
H = 167 mm

102377

LEFT - 102376

Ø = 15 mm
Ø = 51,09 mm
H = 235,4 mm



KIA
KIA
KIA

CARNIVAL I (UP)
CARNIVAL II (GQ)
SORENTO I (JC)

APPLICATION

RIGHT - 102376

Ø = 15 mm
Ø = 51,09 mm
H = 235,4 mm

101749

LEFT - 101640

Ø = 15,15 mm
Ø = 51 mm
H = 175 mm



KIA
KIA

CERATO (LD)
OPIRUS (GH)

APPLICATION

RIGHT - 101640

Ø = 15,15 mm
Ø = 51 mm
H = 175 mm

510110

LEFT - 510109

Ø = 15,5 mm
Ø = 52 mm
H = 210 mm



HYUNDAI

SANTA FÉ II (CM)

APPLICATION

RIGHT - 510109

Ø = 15,5 mm
Ø = 52 mm
H = 210 mm

510116

APPLICATION

LEFT - 510115

Ø = 16 mm
Ø = 48 mm
H = 186 mm



KIA
KIA

RIO (DC)
RIO (DC_)

RIGHT - 510115

Ø = 16 mm
Ø = 48 mm
H = 186 mm

102330

APPLICATION

LEFT - 102329

Ø = 16 mm
Ø = 48,5 mm
H = 208 mm



HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI

ACCENT I (X-3)
ACCENT II (LC)
COUPE (RD)
LANTRA I (J-1)
LANTRA II (J-2)

RIGHT - 102329

Ø = 16 mm
Ø = 48,5 mm
H = 208 mm

102246

APPLICATION

LEFT - 102245

Ø = 16 mm
Ø = 50,9 mm
H = 186 mm



HYUNDAI
KIA

TUCSON (JM)
SPORTAGE (JE_, KM_)

RIGHT - 102245

Ø = 16 mm
Ø = 50,9 mm
H = 186 mm

102422

APPLICATION

LEFT - 102421

Ø = 16 mm
Ø = 54,5 mm
H = 183 mm



HYUNDAI
HYUNDAI
KIA

ix35 (EL, ELH, LM)
ix55
SPORTAGE (SL)

RIGHT - 102421

Ø = 16 mm
Ø = 54,5 mm
H = 183 mm

510029

APPLICATION

LEFT - 510028

Ø = 16,2 mm
Ø = 54,25 mm
H = 175 mm



HYUNDAI
KIA

SANTA FÉ III (DM)
SORENTO II (XM)

RIGHT - 510028

Ø = 16,2 mm
Ø = 54,25 mm
H = 175 mm

101750

APPLICATION

LEFT - 101144

NISSAN

INTERSTAR (X70)

$\varnothing = 7,9 \text{ mm}$
 $\varnothing = 37,95 \text{ mm}$
 $H = 165 \text{ mm}$



RIGHT - 101144

$\varnothing = 7,9 \text{ mm}$
 $\varnothing = 37,95 \text{ mm}$
 $H = 165 \text{ mm}$

102110

APPLICATION

LEFT - 101671

NISSAN

SUNNY III (N14)

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 42 \text{ mm}$
 $H = 142 \text{ mm}$



RIGHT - 101651

$\varnothing = 9,55 \text{ mm}$
 $\varnothing = 40,65 \text{ mm}$
 $H = 153 \text{ mm}$

510047

APPLICATION

LEFT - 510046

NISSAN
NISSANINTERSTAR
INTERSTAR (X70)

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 42 \text{ mm}$
 $H = 165 \text{ mm}$



RIGHT - 510046

$\varnothing = 9,5 \text{ mm}$
 $\varnothing = 42 \text{ mm}$
 $H = 165 \text{ mm}$

102087

APPLICATION

LEFT - 101651

NISSAN

SUNNY III (N14)

$\varnothing = 9,55 \text{ mm}$
 $\varnothing = 40,65 \text{ mm}$
 $H = 153 \text{ mm}$



RIGHT - 101651

$\varnothing = 9,55 \text{ mm}$
 $\varnothing = 40,65 \text{ mm}$
 $H = 153 \text{ mm}$

510091

APPLICATION

LEFT - 510090

Ø = 11 mm
 Ø = 44 mm
 H = 150 mm



NISSAN
 NISSAN

MICRA II (K11)
 SERENA (C23)

RIGHT - 510090

Ø = 11 mm
 Ø = 44 mm
 H = 150 mm

102428

APPLICATION

LEFT - 102427

Ø = 11,5 mm
 Ø = 51 mm
 H = 155 mm



NISSAN
 NISSAN
 NISSAN
 NISSAN

CUBE (Z12)
 MICRA C+C III (K12)
 MICRA III (K12)
 NOTE (E11, NE11)

RIGHT - 102427

Ø = 11,5 mm
 Ø = 51 mm
 H = 155 mm

102366

APPLICATION

LEFT - 102365

Ø = 12,5 mm
 Ø = 55 mm
 H = 200 mm



NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN
 NISSAN

ALMERA II (N16)
 MICRA II (K11)
 PRIMERA (P11)
 PRIMERA (P12)
 PRIMERA (WP12)
 TEANA II (J32)

RIGHT - 102365

Ø = 12,5 mm
 Ø = 55 mm
 H = 200 mm

510087

APPLICATION

LEFT - 510086

Ø = 13 mm
 Ø = 54,5 mm
 H = 215 mm



NISSAN

PRIMASTAR (X83)

RIGHT - 510086

Ø = 13 mm
 Ø = 54,5 mm
 H = 215 mm

102066

APPLICATION

LEFT - 102008

Ø = 13,5 mm
 Ø = 42,32 mm
 H = 164,5 mm



NISSAN

MICRA III (K12)

RIGHT - 102008

Ø = 13,5 mm
 Ø = 42,32 mm
 H = 164,5 mm

102424

APPLICATION

LEFT - 102423

Ø = 14 mm
 Ø = 50 mm
 H = 168 mm



NISSAN

NISSAN

NISSAN

NISSAN

JUKE (F15)

LEAF (ZE0)

QASHQAI / QASHQAI

+2 (J10, JJ10)

X-TRAIL (T31)

RIGHT - 102423

Ø = 14 mm
 Ø = 50 mm
 H = 168 mm

102379

APPLICATION

LEFT - 102378

Ø = 14,85 mm
 Ø = 49 mm
 H = 185 mm



NISSAN

ALMERA TINO (V10)

RIGHT - 102378

Ø = 14,85 mm
 Ø = 49 mm
 H = 185 mm

102381

APPLICATION

LEFT - 102378

Ø = 14,85 mm
 Ø = 49 mm
 H = 185 mm



NISSAN

ALMERA TINO (V10)

RIGHT - 102380

Ø = 14,5 mm
 Ø = 46 mm
 H = 197 mm

101657

LEFT - 101658

Ø = 9,5 mm
Ø = 25,4 mm
H = 182 mm



INNOCENTI
INNOCENTI
INNOCENTI

ELBA (146)
KORAL
MINI

APPLICATION

RIGHT - 101612

Ø = 10 mm
Ø = 42,3 mm
H = 119,5 mm

510091

LEFT - 510090

Ø = 11 mm
Ø = 44 mm
H = 150 mm



INNOCENTI

MINI

APPLICATION

RIGHT - 510090

Ø = 11 mm
Ø = 44 mm
H = 150 mm

LEFT - 510048

Ø = 9 mm
Ø = 44 mm
H = 190 mm



ISUZU

CAMPO (KB)

APPLICATION

RIGHT - 510048

Ø = 9 mm
Ø = 44 mm
H = 190 mm

101749

LEFT - 101640

Ø = 15,15 mm
Ø = 51 mm
H = 175 mm



ISUZU
ISUZU

TROOPER II (UB)
TROOPER III

APPLICATION

RIGHT - 101640

Ø = 15,15 mm
Ø = 51 mm
H = 175 mm

LEFT - 510061

Ø = 16 mm
Ø = 61 mm
H = 215 mm



IVECO
IVECO
IVECO

DAILY III
DAILY IV
DAILY V

APPLICATION

RIGHT - 510061

Ø = 16 mm
Ø = 61 mm
H = 215 mm

APPLICATION

LEFT - 510063

Ø = 16 mm
Ø = 67 mm
H = 218 mm



JEEP

COMANCHE (MJ)

RIGHT - 510063

Ø = 16 mm
Ø = 67 mm
H = 218 mm

LEFT - 510046

Ø = 9,5 mm
Ø = 42 mm
H = 165 mm

RIGHT - 510046

Ø = 9,5 mm
Ø = 42 mm
H = 165 mm



LADA

LARGUS

APPLICATION

510203

LEFT - 510202

Ø = 14,4 mm
Ø = 68 mm
H = 226 mm



RIGHT - 510202

Ø = 14,4 mm
Ø = 68 mm
H = 226 mm

LAND ROVER
LAND ROVER

LAND ROVER
LAND ROVER

APPLICATION

DISCOVERY III (L319)
DISCOVERY III VAN
(L319)
DISCOVERY IV (L319)
DISCOVERY IV VAN
(L319)

510240

LEFT - 510239

Ø = 15,5 mm
Ø = 59 mm
H = 190 mm



RIGHT - 510239

Ø = 15,5 mm
Ø = 59 mm
H = 190 mm

LAND ROVER

RANGE ROVER SPORT
(LS_)

APPLICATION

102333

LEFT - 102331

Ø = 15,5 mm
Ø = 66 mm
H = 198 mm



RIGHT - 102331

Ø = 15,5 mm
Ø = 66 mm
H = 198 mm

LAND ROVER

LAND ROVER

RANGE ROVER III
(LM_)
RANGE ROVER Mk III
(LM_)

APPLICATION

102426

LEFT - 102425

Ø = 16,5 mm
Ø = 52 mm
H = 195 mm



RIGHT - 102425

Ø = 16,5 mm
Ø = 52 mm
H = 195 mm

LAND ROVER

FREELANDER 2 (LF_)

APPLICATION

510044

LEFT - 510043

Ø = 9,5 mm
Ø = 47 mm
H = 145 mm



TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA

CELICA (_A4_, _A6_)
CELICA (_A6_)
CELICA (_T16_)
CELICA (_T18_)
CELICA (_T20_)

APPLICATION

RIGHT - 510043

Ø = 9,5 mm
Ø = 47 mm
H = 145 mm

510045

LEFT - 510043

Ø = 9,5 mm
Ø = 47 mm
H = 145 mm



TOYOTA
TOYOTA

CAMRY (_V1_)
CAMRY (_V2_)

APPLICATION

RIGHT - 510030

Ø = 9 mm
Ø = 49,2 mm
H = 142 mm

510248

LEFT - 101638

Ø = 9,75 mm
Ø = 41,35 mm
H = 145,35 mm



TOYOTA
TOYOTA

TOYOTA
TOYOTA
TOYOTA

CRESSIDA (_X6_)
CRESSIDA (_X6_,
MX62)
CRESSIDA (_X7_)
CRESSIDA (_X8_)
CRESSIDA (_X8_,
MX83)

APPLICATION

RIGHT - 101638

Ø = 9,75 mm
Ø = 41,35 mm
H = 145,35 mm

102070

LEFT - 101652

Ø = 9,75 mm
Ø = 49,1 mm
H = 139 mm



TOYOTA
TOYOTA
TOYOTA

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA

CELICA (_T18_)
COROLLA (_E10_)
COROLLA (_E10_,
AE102)
COROLLA (_E11_)
COROLLA (_E8_)
COROLLA (_E9_)
COROLLA (AE86)
COROLLA FX (E8B)

APPLICATION

TOYOTA
TOYOTA
TOYOTA

RAV 4 I (_A1_)
RAV 4 II (_A2_)
TERCEL (_L1_, _L2_)

RIGHT - 101652

Ø = 9,75 mm
Ø = 49,1 mm
H = 139 mm

510249

APPLICATION

LEFT - 101639

Ø = 10 mm
 Ø = 32 mm
 H = 115 mm



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CARINA II (_T15_)
 CARINA II (_T17_)
 COROLLA (_E7_)
 COROLLA (_E7_, T18)
 COROLLA (_E8_)
 COROLLA (_E9_)
 COROLLA (AE86)
 COROLLA (KE, TE)
 COROLLA FX (E8B)

RIGHT - 101648

Ø = 10,5 mm
 Ø = 45 mm
 H = 136 mm

102069

APPLICATION

LEFT - 101654

Ø = 10 mm
 Ø = 46 mm
 H = 129 mm



TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

CAMRY (_V1_)
 CAMRY (_V2_)
 CARINA II (_T15_)
 CARINA II (_T17_)
 CELICA (_T16_)
 COROLLA (_E9_)

RIGHT - 101654

Ø = 10 mm
 Ø = 46 mm
 H = 129 mm

102132

APPLICATION

LEFT - 101663

Ø = 13 mm
 Ø = 43 mm
 H = 173,5 mm



TOYOTA
 TOYOTA

PASEO (EL54_)
 STARLET (_P8_)

RIGHT - 101663

Ø = 13 mm
 Ø = 43 mm
 H = 173,5 mm

102065

APPLICATION

LEFT - 102007

Ø = 14,5 mm
 Ø = 48,45 mm
 H = 169,7 mm



TOYOTA
 TOYOTA

AVENSIS (_T22_)
 PICNIC (CXM1_,
 SXM1_)

RIGHT - 102007

Ø = 14,5 mm
 Ø = 48,45 mm
 H = 169,7 mm

102379

LEFT - 102378

Ø = 14,85 mm
Ø = 49 mm
H = 185 mm



LEXUS
TOYOTA

RX (MCU15)
CAMRY (_V2_)

APPLICATION

RIGHT - 102378

Ø = 14,85 mm
Ø = 49 mm
H = 185 mm

102328

LEFT - 102327

Ø = 15 mm
Ø = 48 mm
H = 150 mm



TOYOTA
TOYOTA
TOYOTA

CARINA E (_T19_)
COROLLA (_E10_)
COROLLA (_E10_,
AE102)

APPLICATION

RIGHT - 102327

Ø = 15 mm
Ø = 48 mm
H = 150 mm

TOYOTA
TOYOTA
TOYOTA
TOYOTA

COROLLA (_E11_)
COROLLA (_E9_)
RAV 4 I (_A1_)
RAV 4 II (_A2_)

510040

LEFT - 510039

Ø = 15 mm
Ø = 49 mm
H = 156 mm



TOYOTA

RAV 4 III (_A3_)

APPLICATION

RIGHT - 510039

Ø = 15 mm
Ø = 49 mm
H = 156 mm

510104

LEFT - 510103

Ø = 15 mm
Ø = 49 mm
H = 188 mm



TOYOTA

COROLLA (_E12_)

APPLICATION

RIGHT - 510103

Ø = 15 mm
Ø = 49 mm
H = 188 mm

102058

LEFT - 101665

Ø = 15 mm
 Ø = 50 mm
 H = 172 mm



RIGHT - 101665

Ø = 15 mm
 Ø = 50 mm
 H = 172 mm

TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

TOYOTA
 TOYOTA

AURIS (_E15_)
 AVANZA (F60_)
 AVENSIS (_T27_)
 COROLLA (_E12_)
 COROLLA (R1_, ZER_,
 ZZE12_)
 RAV 4 II (_A2_)
 YARIS (_P9_)

APPLICATION

510221

LEFT - 510220

Ø = 15 mm
 Ø = 52 mm
 H = 201 mm



RIGHT - 510220

Ø = 15 mm
 Ø = 52 mm
 H = 201 mm

LEXUS

RX (GSU3_, MCU3_,
 MHU3_)

APPLICATION

101749

LEFT - 101640

Ø = 15,15 mm
 Ø = 51 mm
 H = 175 mm



RIGHT - 101640

Ø = 15,15 mm
 Ø = 51 mm
 H = 175 mm

TOYOTA

TOYOTA

TOYOTA

HIACE III (LH5_, LH6_,
 LH7_, YH5_, YH6_,
 YH7_)
 HIACE IV (_H1_, _H2_)
 HIACE IV (LH1_,
 LXH1_, RZH1_)

TOYOTA

LAND CRUISER
 (GRJ12_, KDJ12_,
 KZJ12_, LJ12_,
 TRJ12_)

APPLICATION

510102

LEFT - 510101

Ø = 16 mm
 Ø = 51 mm
 H = 182 mm



RIGHT - 510101

Ø = 16 mm
 Ø = 51 mm
 H = 182 mm

TOYOTA
 TOYOTA
 TOYOTA

AVENSIS (_T25_)
 COROLLA (_E12_)
 COROLLA (R1_, ZER_,
 ZZE12_)

APPLICATION

510034

LEFT - 510033

Ø = 16 mm
 Ø = 60 mm
 H = 157 mm

**RIGHT - 510033**

Ø = 16 mm
 Ø = 60 mm
 H = 157 mm

TOYOTA
 TOYOTA
 TOYOTA

TOYOTA
 TOYOTA

APPLICATION

AURIS (_E15_)
 AURIS (_E18_)
 AURIS TOURING
 SPORTS (_E18_)
 AVENSIS (_T27_)
 COROLLA (_E18_,
 ZRE17_)

102072

LEFT - 101643

Ø = 16,5 mm
 Ø = 54,5 mm
 H = 159,5 mm

**RIGHT - 101643**

Ø = 16,5 mm
 Ø = 54,5 mm
 H = 159,5 mm

TOYOTA
 TOYOTA
 TOYOTA

APPLICATION

AVENSIS (_T25_)
 COROLLA (_E12_)
 COROLLA (R1_, ZER_,
 ZZE12_)

102059

LEFT - 101667

Ø = 20,15 mm
 Ø = 53,85 mm
 H = 198,95 mm

**RIGHT - 101667**

Ø = 20,15 mm
 Ø = 53,85 mm
 H = 198,95 mm

TOYOTA
 TOYOTA

TOYOTA

APPLICATION

LAND CRUISER (_J7_)
 LAND CRUISER (BJ7_,
 HZJ7_, KZJ7_, LJ7_,
 PZJ7_, RJ7_)
 LAND CRUISER
 (GRJ12_, KDJ12_,
 KZJ12_, LJ12_,
 TRJ12_)

TOYOTA

TOYOTA

TOYOTA

LAND CRUISER 100
 (FZJ1_, UZJ1_)
 LAND CRUISER 80
 (_J8_)
 LAND CRUISER 90
 (_J9_)

102124

LEFT - 101649

Ø = 47 mm
 Ø = 67 mm
 H = 126 mm

**RIGHT - 101655**

Ø = 10,55 mm
 Ø = 46,3 mm
 H = 149,15 mm

TOYOTA
 TOYOTA
 TOYOTA
 TOYOTA

TOYOTA

APPLICATION

CARINA II (_T15_)
 CARINA II (_T17_)
 COROLLA (_E7_)
 CRESSIDA (_X6_,
 MX62)
 TERCEL (AL2_)

101790

APPLICATION

LEFT - 101646

MAZDA

121 III (JASM, JBSM)

Ø = 10,01 mm
 Ø = 36 mm
 H = 200,1 mm



RIGHT - 101646

Ø = 10,01 mm
 Ø = 36 mm
 H = 200,1 mm

102105

APPLICATION

LEFT - 101641

MAZDA

323 I (FA)

Ø = 11 mm
 Ø = 40 mm
 H = 177 mm



RIGHT - 510242

Ø = 11,3 mm
 Ø = 32,55 mm
 H = 185 mm

101693

APPLICATION

LEFT - 101674

MAZDA

323 C IV (BG)

MAZDA

323 S IV (BG)

Ø = 11 mm
 Ø = 46 mm
 H = 206,35 mm



MAZDA

323 C V (BA)

MAZDA

323 S Mk V (BA)

MAZDA

323 F IV (BG)

MAZDA

323 S V (BA)

MAZDA

323 F V (BA)

MAZDA

626 II (GC)

MAZDA

323 I (FA)

MAZDA

626 III (GD)

MAZDA

323 II (BD)

MAZDA

626 III (GV)

MAZDA

323 III (BF)

MAZDA

929 I (LA)

MAZDA

323 III (BW)

MAZDA

929 II (HB)

MAZDA

323 P V (BA)

RIGHT - 101674

Ø = 11 mm
 Ø = 46 mm
 H = 206,35 mm

510082

APPLICATION

LEFT - 510081

MAZDA

121 I (DA)

Ø = 11,5 mm
 Ø = 36 mm
 H = 195 mm



RIGHT - 510081

Ø = 11,5 mm
 Ø = 36 mm
 H = 195 mm

102396

LEFT - 102395

Ø = 12,5 mm
 Ø = 50,5 mm
 H = 162 mm



MAZDA 6 (GG)
 MAZDA 6 (GH)
 MAZDA 6 (GY)

APPLICATION

RIGHT - 102395

Ø = 12,5 mm
 Ø = 50,5 mm
 H = 162 mm

510219

LEFT - 510218

Ø = 13,15 mm
 Ø = 53 mm
 H = 139,8 mm



MAZDA CX-7 (ER)

APPLICATION

RIGHT - 510218

Ø = 13,15 mm
 Ø = 53 mm
 H = 139,8 mm

101789

LEFT - 101661

Ø = 13,6 mm
 Ø = 57 mm
 H = 178,5 mm



MAZDA 121 III (JASM, JBSM)

APPLICATION

RIGHT - 101661

Ø = 13,6 mm
 Ø = 57 mm
 H = 178,5 mm

101805

LEFT - 101804

Ø = 13,8 mm
 Ø = 36,8 mm
 H = 227,7 mm



MAZDA 121 III (JASM, JBSM)

APPLICATION

RIGHT - 101804

Ø = 13,8 mm
 Ø = 36,8 mm
 H = 227,7 mm

510201

APPLICATION

LEFT - 510200

MAZDA

121 III (JASM, JBSM)

Ø = 14 mm
 Ø = 55 mm
 H = 192 mm



RIGHT - 510200

Ø = 14 mm
 Ø = 55 mm
 H = 192 mm

510177

APPLICATION

LEFT - 510176

MAZDA

6 (GG)

Ø = 15 mm
 Ø = 49 mm
 H = 156 mm



RIGHT - 510176

Ø = 15 mm
 Ø = 49 mm
 H = 156 mm

102418

APPLICATION

LEFT - 102415

MAZDA

3 (BK)
 3 (BL)
 5 (CR19) MPV
 5 (CW) MPV

Ø = 15,5 mm
 Ø = 51 mm
 H = 170 mm



RIGHT - 102415

Ø = 15,5 mm
 Ø = 51 mm
 H = 170 mm

510080

APPLICATION

LEFT - 510078

MAZDA

6 (GH)

Ø = 15,5 mm
 Ø = 54 mm
 H = 187 mm



RIGHT - 510079

Ø = 15,5 mm
 Ø = 79 mm
 H = 201 mm

LEFT - 510037

Ø = 16 mm
Ø = 61 mm
H = 203 mm

RIGHT - 510037

Ø = 16 mm
Ø = 61 mm
H = 203 mm



MAZDA

6 (GH)

APPLICATION

102004

APPLICATION

LEFT - 102003

MERCEDES-BENZ A-CLASS (W168)

Ø = 9,5 mm
Ø = 50 mm
H = 194 mm



RIGHT - 102003

Ø = 9,5 mm
Ø = 50 mm
H = 194 mm

510164

APPLICATION

LEFT - 510163

MERCEDES-BENZ A-CLASS (W168)

Ø = 12 mm
Ø = 85 mm
H = 223 mm



RIGHT - 510163

Ø = 12 mm
Ø = 85 mm
H = 223 mm

101771

APPLICATION

LEFT - 101504

MERCEDES-BENZ E-CLASS (S210)
MERCEDES-BENZ E-CLASS (W210)

Ø = 12,5 mm
Ø = 61,3 mm
H = 213,8 mm



RIGHT - 101504

Ø = 12,5 mm
Ø = 61,3 mm
H = 213,8 mm

510055

APPLICATION

LEFT - 510054

MERCEDES-BENZ SPRINTER 2-t (901, 902)
MERCEDES-BENZ SPRINTER 3-t (903)
MERCEDES-BENZ SPRINTER 4-t (904)
MERCEDES-BENZ V-CLASS (638/2)
MERCEDES-BENZ VITO (638)

Ø = 14 mm
Ø = 56 mm
H = 195 mm



RIGHT - 510054

Ø = 14 mm
Ø = 56 mm
H = 195 mm

510042
APPLICATION
LEFT - 510041

$\varnothing = 14 \text{ mm}$
 $\varnothing = 63 \text{ mm}$
 $H = 230 \text{ mm}$



MERCEDES-BENZ E-CLASS (A207)
 MERCEDES-BENZ E-CLASS (C207)
 MERCEDES-BENZ E-CLASS (S212)
 MERCEDES-BENZ E-CLASS (W212)

RIGHT - 510041

$\varnothing = 14 \text{ mm}$
 $\varnothing = 63 \text{ mm}$
 $H = 230 \text{ mm}$

510017
APPLICATION
LEFT - 510016

$\varnothing = 14 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 237 \text{ mm}$



MERCEDES-BENZ S-CLASS (C215)
 MERCEDES-BENZ S-CLASS (W220)
 MERCEDES-BENZ SL (R230)

RIGHT - 510016

$\varnothing = 14 \text{ mm}$
 $\varnothing = 70 \text{ mm}$
 $H = 237 \text{ mm}$

101774
APPLICATION
LEFT - 101666

$\varnothing = 15,25 \text{ mm}$
 $\varnothing = 60,35 \text{ mm}$
 $H = 214 \text{ mm}$



MERCEDES-BENZ C-CLASS (CL203)
 MERCEDES-BENZ C-CLASS (S202)
 MERCEDES-BENZ C-CLASS (S203)
 MERCEDES-BENZ C-CLASS (W202)
 MERCEDES-BENZ C-CLASS (W203)
 MERCEDES-BENZ CLC-CLASS (CL203)
 MERCEDES-BENZ CLK (A208)
 MERCEDES-BENZ CLK (A209)
 MERCEDES-BENZ CLK (C208)

MERCEDES-BENZ CLK (C209)
 MERCEDES-BENZ E-CLASS (S210)
 MERCEDES-BENZ E-CLASS (S211)
 MERCEDES-BENZ E-CLASS (W210)
 MERCEDES-BENZ E-CLASS (W211)
 MERCEDES-BENZ SLK (R171)

RIGHT - 101666

$\varnothing = 15,25 \text{ mm}$
 $\varnothing = 60,35 \text{ mm}$
 $H = 214 \text{ mm}$

510062
APPLICATION
LEFT - 510061

$\varnothing = 16 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 215 \text{ mm}$



MERCEDES-BENZ E-CLASS (S210)
 MERCEDES-BENZ E-CLASS (W210)

RIGHT - 510061

$\varnothing = 16 \text{ mm}$
 $\varnothing = 61 \text{ mm}$
 $H = 215 \text{ mm}$

510064
APPLICATION
LEFT - 510063

$\emptyset$ = 16 mm
 $\emptyset$ = 67 mm
 H = 218 mm


RIGHT - 510063

$\emptyset$ = 16 mm
 $\emptyset$ = 67 mm
 H = 218 mm

MERCEDES-BENZ GL-CLASS (X164)
 MERCEDES-BENZ M-CLASS (W164)
 MERCEDES-BENZ R-CLASS (V251,
 W251)
 MERCEDES-BENZ SPRINTER 3,5-t (906)
 MERCEDES-BENZ SPRINTER 3-t (906)
 MERCEDES-BENZ SPRINTER 4,6-t (906)
 MERCEDES-BENZ SPRINTER 5-t (906)

101744
APPLICATION
LEFT - 101595

$\emptyset$ = 16,5 mm
 $\emptyset$ = 55 mm
 H = 207,5 mm


RIGHT - 101595

$\emptyset$ = 16,5 mm
 $\emptyset$ = 55 mm
 H = 207,5 mm

MERCEDES-BENZ SPRINTER 2-t (901,
 902)

510060
APPLICATION
LEFT - 510059

$\emptyset$ = 16,5 mm
 $\emptyset$ = 64,5 mm
 H = 187 mm


RIGHT - 510059

$\emptyset$ = 16,5 mm
 $\emptyset$ = 64,5 mm
 H = 187 mm

MERCEDES-BENZ M-CLASS (W163)

510091

LEFT - 510090

Ø = 11 mm
 Ø = 44 mm
 H = 150 mm



MG

MG ZR

APPLICATION

RIGHT - 510090

Ø = 11 mm
 Ø = 44 mm
 H = 150 mm

101802

LEFT - 101596

Ø = 13,5 mm
 Ø = 47 mm
 H = 200 mm



MG

MG ZT

APPLICATION

RIGHT - 101596

Ø = 13,5 mm
 Ø = 47 mm
 H = 200 mm

510075

LEFT - 510074

Ø = 19 mm
 Ø = 63 mm
 H = 250 mm



MG

MG ZR

APPLICATION

RIGHT - 510074

Ø = 19 mm
 Ø = 63 mm
 H = 250 mm

102074
APPLICATION
LEFT - 101800

$\varnothing = 10,9 \text{ mm}$
 $\varnothing = 41,3 \text{ mm}$
 $H = 184 \text{ mm}$



MITSUBISHI
 MITSUBISHI

CARISMA (DA_)
 SPACE STAR (DG_A)

RIGHT - 101800

$\varnothing = 10,9 \text{ mm}$
 $\varnothing = 41,3 \text{ mm}$
 $H = 184 \text{ mm}$

101765
APPLICATION
LEFT - 101642

$\varnothing = 11 \text{ mm}$
 $\varnothing = 41 \text{ mm}$
 $H = 183,7 \text{ mm}$



MITSUBISHI

CARISMA (DA_)

RIGHT - 101642

$\varnothing = 11 \text{ mm}$
 $\varnothing = 41 \text{ mm}$
 $H = 183,7 \text{ mm}$

101699
APPLICATION
LEFT - 101708

$\varnothing = 11 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 185 \text{ mm}$



MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI
 MITSUBISHI

3000 GT (Z1_A)
 COLT I (A15_A, RA)
 COLT II (C1_A, RB, RC)
 COLT III (C5_A, RD, RE)
 COLT IV (CA_A)
 COLT V (CJ_, CP_)
 CORDIA (A21_A, AA, AB)
 ECLIPSE I (D2_A)
 ECLIPSE II (D3_A)
 GALANT II (A16_)
 GALANT II (A16_V)
 GALANT III (E1_A)
 GALANT IV (E3_A, HG, HH)
 GALANT V (E5_A, E7_A, E8_A)
 GALANT V (E5_A, E7_A, E8_A, HJ)
 GALANT VI (EA_)

MITSUBISHI LANCER III (C1_A, C6_A, RD, RE)
 MITSUBISHI LANCER III (C1_V, C3_V)
 MITSUBISHI LANCER IV (C6_A, C7_A, CA, CB)
 MITSUBISHI LANCER IV (C6_A, CA, CB)
 MITSUBISHI LANCER V (CB/D_A, CC)
 MITSUBISHI LANCER VI (CJ-CP_)
 MITSUBISHI SAPPORO II (A16_A)
 MITSUBISHI SIGMA (F1_A, F2_A)
 MITSUBISHI SPACE RUNNER (N1_W, N2_W)
 MITSUBISHI SPACE STAR (DG_A)
 MITSUBISHI SPACE WAGON (D0_V/W, UA, UB, UC)
 MITSUBISHI TREDIA (A21_)

RIGHT - 101708

$\varnothing = 11 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 185 \text{ mm}$

510224
LEFT - 510223

$\varnothing = 13,4 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 194 \text{ mm}$


RIGHT - 510223

$\varnothing = 13,4 \text{ mm}$
 $\varnothing = 46 \text{ mm}$
 $H = 194 \text{ mm}$

MITSUBISHI

LANCER (CG, CH, CJ, CS_A, CT0)

APPLICATION
101745
LEFT - 101599

$\varnothing = 13,5 \text{ mm}$
 $\varnothing = 52 \text{ mm}$
 $H = 187,5 \text{ mm}$


RIGHT - 101599

$\varnothing = 13,5 \text{ mm}$
 $\varnothing = 52 \text{ mm}$
 $H = 187,5 \text{ mm}$

MITSUBISHI
 MITSUBISHI

MITSUBISHI

SPACE STAR (DG_A)
 SPACE WAGON (D0_V/W, UA, UB, UC)
 SPACE WAGON (N3_W, N4_W, UF)

APPLICATION
102420
LEFT - 102419

$\varnothing = 14 \text{ mm}$
 $\varnothing = 47 \text{ mm}$
 $H = 175 \text{ mm}$


RIGHT - 102419

$\varnothing = 14 \text{ mm}$
 $\varnothing = 47 \text{ mm}$
 $H = 175 \text{ mm}$

MITSUBISHI

MITSUBISHI
 MITSUBISHI

MITSUBISHI

LANCER (CG, CH, CJ, CS_A, CT0)
 LANCER (CJ, CY/Z_A)
 LANCER SPORTBACK (CJ, CX_A)
 OUTLANDER II (CW_W, ZG, ZH)

APPLICATION
102436
LEFT - 102435

$\varnothing = 14 \text{ mm}$
 $\varnothing = 51 \text{ mm}$
 $H = 166 \text{ mm}$


RIGHT - 102435

$\varnothing = 14 \text{ mm}$
 $\varnothing = 51 \text{ mm}$
 $H = 166 \text{ mm}$

MITSUBISHI
 MITSUBISHI
 MITSUBISHI

MITSUBISHI

ASX (GA_W_, XA, XB)
 LANCER (CJ, CY/Z_A)
 LANCER SPORTBACK (CJ, CX_A)
 OUTLANDER III (GG_W, GF_W, ZJ)

APPLICATION

LEFT - 102383

Ø = 17 mm
Ø = 53,5 mm
H = 200,3 mm



mitsubishi

PAJERO III (V6_W,
V7_W)

APPLICATION

RIGHT - 102383

Ø = 17 mm
Ø = 53,5 mm
H = 200,3 mm

510105

LEFT - 102383

Ø = 17 mm
Ø = 53,5 mm
H = 200,3 mm



mitsubishi

PAJERO II (NH, NJ,
NK, NL, V2_W, V3_W,
V4_W)

mitsubishi

PAJERO II (V2_W,
V4_W)

mitsubishi

PAJERO III (V6_W,
V7_W)

APPLICATION

RIGHT - 510085

Ø = 17 mm
Ø = 51 mm
H = 240 mm

LEFT - 102385

$\varnothing = 14,7 \text{ mm}$
 $\varnothing = 53,65 \text{ mm}$
 $H = 206,95 \text{ mm}$



RENAULT TRUCKS FR1

APPLICATION
RIGHT - 102385

$\varnothing = 14,7 \text{ mm}$
 $\varnothing = 53,65 \text{ mm}$
 $H = 206,95 \text{ mm}$

510023

LEFT - 510022

Ø = 10 mm
Ø = 44 mm
H = 120 mm



ROVER

MINI

APPLICATION

RIGHT - 510022

Ø = 10 mm
Ø = 44 mm
H = 120 mm

101790

LEFT - 101646

Ø = 10,01 mm
Ø = 36 mm
H = 200,1 mm



ROVER
ROVER
ROVER
ROVER
ROVER

200 (XW)
25 (RF)
400 (XW)
MINI
MINI (XN)

APPLICATION

RIGHT - 101646

Ø = 10,01 mm
Ø = 36 mm
H = 200,1 mm

510091

LEFT - 510090

Ø = 11 mm
Ø = 44 mm
H = 150 mm



ROVER
ROVER
ROVER
ROVER

200 (RF)
200 (XW)
400 (RT)
400 (XW)

APPLICATION

RIGHT - 510090

Ø = 11 mm
Ø = 44 mm
H = 150 mm

510092

LEFT - 510090

Ø = 11 mm
Ø = 44 mm
H = 150 mm



ROVER

25 (RF)

APPLICATION

RIGHT - 101646

Ø = 10,01 mm
Ø = 36 mm
H = 200,1 mm

102102

APPLICATION

LEFT - 101709

ROVER

2000-3500 (P6)

$\emptyset = 11 \text{ mm}$
 $\emptyset = 46,75 \text{ mm}$
 $H = 145 \text{ mm}$



RIGHT - 101709

$\emptyset = 11 \text{ mm}$
 $\emptyset = 46,75 \text{ mm}$
 $H = 145 \text{ mm}$

101802

APPLICATION

LEFT - 101596

ROVER

75 (RJ)

$\emptyset = 13,5 \text{ mm}$
 $\emptyset = 47 \text{ mm}$
 $H = 200 \text{ mm}$



RIGHT - 101596

$\emptyset = 13,5 \text{ mm}$
 $\emptyset = 47 \text{ mm}$
 $H = 200 \text{ mm}$

101789

APPLICATION

LEFT - 101661

ROVER

75 (RJ)

$\emptyset = 13,6 \text{ mm}$
 $\emptyset = 57 \text{ mm}$
 $H = 178,5 \text{ mm}$



RIGHT - 101661

$\emptyset = 13,6 \text{ mm}$
 $\emptyset = 57 \text{ mm}$
 $H = 178,5 \text{ mm}$

LEFT - 510050

Ø = 13,5 mm
Ø = 56 mm
H = 218 mm



SAAB

9-3 (YS3F)

APPLICATION

RIGHT - 510050

Ø = 13,5 mm
Ø = 56 mm
H = 218 mm

101749

LEFT - 101640

Ø = 15,15 mm
Ø = 51 mm
H = 175 mm



SAAB

9-3 (YS3D)

APPLICATION

RIGHT - 101640

Ø = 15,15 mm
Ø = 51 mm
H = 175 mm

APPLICATION

LEFT - 510072

Ø = 13 mm
Ø = 49 mm
H = 215 mm



SMART
SMART

FORTWO (450)
FORTWO (451)

RIGHT - 510072

Ø = 13 mm
Ø = 49 mm
H = 215 mm

510049

LEFT - 510048

Ø = 9 mm
 Ø = 44 mm
 H = 190 mm



SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

LEGACY I (BC)
 LEGACY I (BC, BJF)
 LEONE I
 LEONE I (AB)
 LEONE II
 XT (XT)

APPLICATION**RIGHT - 510048**

Ø = 9 mm
 Ø = 44 mm
 H = 190 mm

102074

LEFT - 101800

Ø = 10,9 mm
 Ø = 41,3 mm
 H = 184 mm



SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

FORESTER (SF)
 IMPREZA (GD)
 LEGACY II (BD)
 LEGACY III (BE)
 OUTBACK (BE, BH)

APPLICATION**RIGHT - 101800**

Ø = 10,9 mm
 Ø = 41,3 mm
 H = 184 mm

510082

LEFT - 510081

Ø = 11,5 mm
 Ø = 36 mm
 H = 195 mm



SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU
 SUBARU

IMPREZA (GC)
 IMPREZA (GF)
 IMPREZA (GFC)
 LEGACY I (BC)
 LEGACY I (BC, BJF)
 LEGACY II (BD)
 LEGACY II (BG)
 LEONE II

APPLICATION**RIGHT - 510081**

Ø = 11,5 mm
 Ø = 36 mm
 H = 195 mm

LEFT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm



TALBOT
TALBOT

SAMBA (51A)
TAGORA

APPLICATION

RIGHT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm

510053

LEFT - 510052

Ø = 39 mm
Ø = 39 mm
H = 130 mm



TALBOT

TAGORA

APPLICATION

RIGHT - 101608

Ø = 10 mm
Ø = 40 mm
H = 171,9 mm

LEFT - 101709

Ø = 11 mm
Ø = 46,75 mm
H = 145 mm

RIGHT - 101709

Ø = 11 mm
Ø = 46,75 mm
H = 145 mm



TRIUMPH

TR 7

APPLICATION

101657

LEFT - 101658

Ø = 9,5 mm
Ø = 25,4 mm
H = 182 mm



RIGHT - 101612

Ø = 10 mm
Ø = 42,3 mm
H = 119,5 mm

APPLICATION

SEAT	FURA (025A)	SKODA	FELICIA I (6U1)
SEAT	IBIZA I (021A)	SKODA	FELICIA II (6U1)
SEAT	MALAGA (023A)	SKODA	RAPID (120G, 130G, 135G)
SEAT	MARBELLA (28)	VOLKSWAGEN	GOLF II (19E, 1G1)
SEAT	PANDA (141A)	VOLKSWAGEN	GOLF III (1H1)
SEAT	RONDA (022A)	VOLKSWAGEN	GOLF Mk III (1H1)
SEAT	TERRA (24)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
SKODA	105,120 (742)	VOLKSWAGEN	POLO (6N1)
SKODA	FAVORIT (781)	VOLKSWAGEN	POLO (6N2)
SKODA	FAVORIT (785)		
SKODA	FAVORIT (787)		

101680

LEFT - 101143

Ø = 9,5 mm
Ø = 41,9 mm
H = 199,5 mm



RIGHT - 101143

Ø = 9,5 mm
Ø = 41,9 mm
H = 199,5 mm

APPLICATION

SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF III (1H5)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	GOLF Mk III (1H1)
SEAT	INCA (6K9)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
VOLKSWAGEN	CORRADO (53I)	VOLKSWAGEN	PASSAT (3A2, 35I)
VOLKSWAGEN	GOLF I (155)	VOLKSWAGEN	SCIROCCO (53B)
VOLKSWAGEN	GOLF I (17)		
VOLKSWAGEN	GOLF II (19E, 1G1)		
VOLKSWAGEN	GOLF III (1E7)		
VOLKSWAGEN	GOLF III (1H1)		

102024

LEFT - 102020

Ø = 10 mm
Ø = 44 mm
H = 205 mm



RIGHT - 102023

Ø = 10,15 mm
Ø = 44 mm
H = 165 mm

APPLICATION

SEAT	131
SEAT	132
SEAT	MALAGA (023A)

102014

LEFT - 102013

Ø = 11 mm
Ø = 42 mm
H = 208 mm



RIGHT - 102013

Ø = 11 mm
Ø = 42 mm
H = 208 mm

APPLICATION

AUDI	A2 (8Z0)
SEAT	AROSA (6H)
SKODA	FELICIA I (6U1)
SKODA	FELICIA I (797)
VOLKSWAGEN	FOX (5Z1, 5Z3)
VOLKSWAGEN	LUPO (6E1, 6X1)
VOLKSWAGEN	POLO (6N1)
VOLKSWAGEN	POLO (6NF)

102077

LEFT - 101597

Ø = 11,5 mm
Ø = 52 mm
H = 170 mm



SEAT
VOLKSWAGEN

ALHAMBRA (7V8, 7V9)
SHARAN (7M6, 7M8,
7M9)

APPLICATION

RIGHT - 101597

Ø = 11,5 mm
Ø = 52 mm
H = 170 mm

101763

LEFT - 101659

Ø = 12 mm
Ø = 45,5 mm
H = 185 mm



RIGHT - 101659

Ø = 12 mm
Ø = 45,5 mm
H = 185 mm

SEAT ALHAMBRA (7V8, 7V9)
SEAT CORDOBA (6K1, 6K2)
SEAT IBIZA II (6K1)
SEAT IBIZA III (6K1)
SEAT INCA (6K9)
SEAT TOLEDO I (1L)
VOLKSWAGEN CADDY II (9K9A)
VOLKSWAGEN CADDY II (9K9B)
VOLKSWAGEN CORRADO (53I)
VOLKSWAGEN GOLF I (155)
VOLKSWAGEN GOLF I (17)
VOLKSWAGEN GOLF II (19E, 1G1)
VOLKSWAGEN GOLF III (1E7)
VOLKSWAGEN GOLF III (1H5)
VOLKSWAGEN GOLF IV (1J1)
VOLKSWAGEN GOLF Mk IV (1J1)

APPLICATION

VOLKSWAGEN JETTA I (16)
VOLKSWAGEN JETTA II (165, 19E,
1G2)
VOLKSWAGEN PASSAT (32B)
VOLKSWAGEN PASSAT (33)
VOLKSWAGEN PASSAT (3A2, 35I)
VOLKSWAGEN PASSAT (3A5, 35I)
VOLKSWAGEN PASSAT (3B2)
VOLKSWAGEN POLO (6KV2)
VOLKSWAGEN POLO (6KV5)
VOLKSWAGEN POLO (6N1)
VOLKSWAGEN SCIROCCO (53)
VOLKSWAGEN SCIROCCO (53B)
VOLKSWAGEN SHARAN (7M6, 7M8,
7M9)
VOLKSWAGEN VENTO (1H2)

510175

LEFT - 510174

Ø = 12 mm
Ø = 48 mm
H = 200 mm



AUDI A2 (8Z0)
SEAT IBIZA IV (6L1)
SKODA FABIA (6Y2)
SKODA FABIA (6Y3)
SKODA FABIA (6Y5)
VOLKSWAGEN FOX (5Z1, 5Z3)
VOLKSWAGEN LUPO (6E1, 6X1)
VOLKSWAGEN POLO (9N_)

APPLICATION

RIGHT - 510174

Ø = 12 mm
Ø = 48 mm
H = 200 mm

102019

LEFT - 102018

Ø = 13 mm
 Ø = 45,5 mm
 H = 210 mm



SEAT
 SEAT
 SKODA
 VOLKSWAGEN

CORDOBA (6L2)
 IBIZA IV (6L1)
 FABIA (6Y2)
 POLO (9N_)

APPLICATION

RIGHT - 102018

Ø = 13 mm
 Ø = 45,5 mm
 H = 210 mm

101796

LEFT - 101795

Ø = 13,7 mm
 Ø = 45,9 mm
 H = 150,4 mm



VOLKSWAGEN GOLF I (155)
 VOLKSWAGEN GOLF I (17)
 VOLKSWAGEN GOLF II (19E, 1G1)
 VOLKSWAGEN GOLF III (1H1)
 VOLKSWAGEN GOLF III (1H5)
 VOLKSWAGEN GOLF IV (1J1)
 VOLKSWAGEN GOLF Mk III (1H1)
 VOLKSWAGEN GOLF Mk IV (1J1)
 VOLKSWAGEN PASSAT (3A2, 35I)

VOLKSWAGEN VENTO (1H2)

APPLICATION

RIGHT - 101795

Ø = 13,7 mm
 Ø = 45,9 mm
 H = 150,4 mm

510055

LEFT - 510054

Ø = 14 mm
 Ø = 56 mm
 H = 195 mm



VOLKSWAGEN LT 28-35 II (2DB, 2DE, 2DK)
 VOLKSWAGEN LT 28-46 II (2DA, 2DD, 2DH)
 VOLKSWAGEN LT 28-46 II (2DC, 2DF, 2DG, 2DL, 2DM)

APPLICATION

RIGHT - 510054

Ø = 14 mm
 Ø = 56 mm
 H = 195 mm

102373

LEFT - 102372

Ø = 14,5 mm
 Ø = 48 mm
 H = 205 mm



AUDI
 SEAT
 SEAT
 SKODA
 VOLKSWAGEN

A2 (8Z0)
 CORDOBA (6L2)
 IBIZA IV (6L1)
 FABIA (6Y2)
 POLO (9N_)

APPLICATION

RIGHT - 102372

Ø = 14,5 mm
 Ø = 48 mm
 H = 205 mm

102061

LEFT - 101501

Ø = 14,5 mm
 Ø = 50,5 mm
 H = 189 mm



RIGHT - 101501

Ø = 14,5 mm
 Ø = 50,5 mm
 H = 189 mm

APPLICATION

AUDI	A3 (8L1)	VOLKSWAGEN	GOLF VI (5K1)
AUDI	TT (8N3)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SEAT	LEON (1M1)	VOLKSWAGEN	PASSAT (362)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	PASSAT (3C2)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	TIGUAN (5N_)
VOLKSWAGEN	BORA (1J2)		
VOLKSWAGEN	GOLF IV (1J1)		
VOLKSWAGEN	GOLF Mk IV (1J1)		
VOLKSWAGEN	GOLF V (1K1)		

510080

LEFT - 510078

Ø = 15,5 mm
 Ø = 54 mm
 H = 187 mm



RIGHT - 510079

Ø = 15,5 mm
 Ø = 79 mm
 H = 201 mm

APPLICATION

AUDI	A4 (8K2, B6)	AUDI	A6 Allroad (4GH, 4GJ)
AUDI	A4 (8K2, B8)	AUDI	A7 (4GA, 4GF)
AUDI	A4 (8K5, B8)	AUDI	A8 (4H_)
AUDI	A4 Allroad (8KH, B8)	AUDI	Q5 (8R)
AUDI	A5 (8F7)		
AUDI	A5 (8T3)		
AUDI	A5 (8TA)		
AUDI	A6 (4G2, 4GC, C7)		
AUDI	A6 (4G5, 4GD, C7)		

510069

LEFT - 510068

Ø = 15,5 mm
 Ø = 66 mm
 H = 195 mm



RIGHT - 510068

Ø = 15,5 mm
 Ø = 66 mm
 H = 195 mm

APPLICATION

AUDI	Q7 (4L)
PORSCHE	CAYENNE (92A)
PORSCHE	CAYENNE (9PA)
VOLKSWAGEN	AMAROK (2H_, S1B)
VOLKSWAGEN	TOUAREG (7L6, 7L7, 7LA)
VOLKSWAGEN	TOUAREG (7P5)

510038

LEFT - 510037

Ø = 16 mm
 Ø = 61 mm
 H = 203 mm



RIGHT - 510037

Ø = 16 mm
 Ø = 61 mm
 H = 203 mm

APPLICATION

AUDI	A4 (8K2, B6)
AUDI	A4 (8K2, B8)
AUDI	A4 (8K5, B8)
AUDI	A4 Allroad (8KH, B8)
AUDI	A5 (8F7)
AUDI	A5 (8T3)
AUDI	A5 (8TA)
AUDI	A8 (4H_)
AUDI	Q5 (8R)

510195

LEFT - 510194

Ø = 16 mm
 Ø = 61,5 mm
 H = 205 mm



RIGHT - 510194

Ø = 16 mm
 Ø = 61,5 mm
 H = 205 mm

VOLKSWAGEN

MULTIVAN V (7EF,
 7EM, 7EN, 7HF, 7HM,
 7HN)

VOLKSWAGEN

TRANSPORTER Mk VI
 (SFD, SFE, SFL, SFZ)

VOLKSWAGEN

TRANSPORTER V (7EA,
 7EH, 7HA, 7HH)

VOLKSWAGEN

TRANSPORTER V (7EB,
 7EC, 7EF, 7EG, 7EJ,
 7HB, 7HF, 7HJ)

APPLICATION

VOLKSWAGEN

TRANSPORTER V
 (7HA, 7HH, 7EA, 7EH)

VOLKSWAGEN

TRANSPORTER VI
 (SFD, SFE, SFL, SFZ)

VOLKSWAGEN

TRANSPORTER VI
 (SGA, SGH)

VOLKSWAGEN

TRANSPORTER VI
 (SGB, SGG, SGJ)

510064

LEFT - 510063

Ø = 16 mm
 Ø = 67 mm
 H = 218 mm



RIGHT - 510063

Ø = 16 mm
 Ø = 67 mm
 H = 218 mm

VOLKSWAGEN

CRAFTER 30-35 (2E_)

VOLKSWAGEN

CRAFTER 30-50 (2E_)

VOLKSWAGEN

CRAFTER 30-50 (2F_)

APPLICATION

101744

LEFT - 101595

Ø = 16,5 mm
 Ø = 55 mm
 H = 207,5 mm



RIGHT - 101595

Ø = 16,5 mm
 Ø = 55 mm
 H = 207,5 mm

VOLKSWAGEN

LT 28-35 II (2DB, 2DE,
 2DK)

VOLKSWAGEN

LT 28-46 II (2DA, 2DD,
 2DH)

VOLKSWAGEN

LT 28-46 II (2DC, 2DF,
 2DG, 2DL, 2DM)

APPLICATION

101738

LEFT - 101626

Ø = 17 mm
 Ø = 48 mm
 H = 180 mm



RIGHT - 101626

Ø = 17 mm
 Ø = 48 mm
 H = 180 mm

AUDI

A3 (8L1)

AUDI

TT (8N3)

SEAT

LEON (1M1)

SEAT

TOLEDO II (1M2)

SKODA

OCTAVIA (1U2)

VOLKSWAGEN

BORA (1J2)

VOLKSWAGEN

GOLF IV (1J1)

VOLKSWAGEN

GOLF Mk IV (1J1)

APPLICATION

VOLKSWAGEN

NEW BEETLE (1C1,
 9C1)

510128

LEFT - 101613

Ø = 18,5 mm
 Ø = 52,5 mm
 H = 201 mm



AUDI	A4 (8D2, B5)
AUDI	A4 (8D5, B5)
AUDI	A8 (4D2, 4D8)
VOLKSWAGEN	PASSAT (3B2)
VOLKSWAGEN	PASSAT (3B5)

APPLICATION

RIGHT - 101613

Ø = 18,5 mm
 Ø = 52,5 mm
 H = 201 mm

510222

LEFT - 101613

Ø = 18,5 mm
 Ø = 52,5 mm
 H = 201 mm



AUDI	A4 (8D2, B5)
AUDI	A4 (8D5, B5)
VOLKSWAGEN	PASSAT (3B2)
VOLKSWAGEN	PASSAT (3B5)

APPLICATION

RIGHT - 510058

Ø = 17,5 mm
 Ø = 63 mm
 H = 255 mm

510259

LEFT - 101613

Ø = 18,5 mm
 Ø = 52,5 mm
 H = 201 mm



AUDI	A4 (8D2, B5)
AUDI	A4 (8D5, B5)

APPLICATION

RIGHT - 510058

Ø = 17,5 mm
 Ø = 63 mm
 H = 255 mm

3rd BOOT - 510168

Ø = 64 mm
 Ø = 64 mm
 H = 142,7 mm

510260

LEFT - 101613

Ø = 18,5 mm
 Ø = 52,5 mm
 H = 201 mm



AUDI	A4 (8D5, B5)
------	--------------

APPLICATION

RIGHT - 510065

Ø = 20 mm
 Ø = 54 mm
 H = 205 mm

3rd BOOT - 510168

Ø = 64 mm
 Ø = 64 mm
 H = 142,7 mm

510098

LEFT - 510097

Ø = 19 mm
Ø = 61 mm
H = 222 mm



AUDI
AUDI
AUDI

A6 (4F2, C6)
A6 (4F5, C6)
A6 Allroad (4FH, C6)

APPLICATION

RIGHT - 510097

Ø = 19 mm
Ø = 61 mm
H = 222 mm

510075

LEFT - 510074

Ø = 19 mm
Ø = 63 mm
H = 250 mm



AUDI
AUDI
AUDI
SEAT
SEAT

A4 (8E2, B6)
A4 (8E5, B6)
A4 (8H7, 8HE, B6, B7)
EXEO (3R2)
EXEO (3R5)

APPLICATION

RIGHT - 510074

Ø = 19 mm
Ø = 63 mm
H = 250 mm

510066

LEFT - 510065

Ø = 20 mm
Ø = 54 mm
H = 205 mm



AUDI
AUDI

A4 (8D2, B5)
A4 (8D5, B5)

APPLICATION

RIGHT - 510065

Ø = 20 mm
Ø = 54 mm
H = 205 mm

510256

LEFT - 510065

Ø = 20 mm
Ø = 54 mm
H = 205 mm



AUDI
AUDI
AUDI
AUDI
AUDI
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

A4 (8D5, B5)
A6 (4B2, C5)
A6 (4B5, C5)
A8 (4D2, 4D8)
ALLROAD (4BH, C5)
SUPERB (3U4)
PASSAT (3B3)
PASSAT (3B6)
PASSAT Variant (3B6)

APPLICATION

RIGHT - 510157

Ø = 20 mm
Ø = 61 mm
H = 255 mm

510067

APPLICATION

LEFT - 510065

Ø = 20 mm
Ø = 54 mm
H = 205 mm

VOLKSWAGEN

PASSAT (3B6)



RIGHT - 510058

Ø = 17,5 mm
Ø = 63 mm
H = 255 mm

510255

APPLICATION

LEFT - 510157

Ø = 20 mm
Ø = 61 mm
H = 255 mm

VOLKSWAGEN
VOLKSWAGENPASSAT (3B3)
PASSAT (3B6)

RIGHT - 510058

Ø = 17,5 mm
Ø = 63 mm
H = 255 mm

510108

APPLICATION

LEFT - 510106

Ø = 20,5 mm
Ø = 52,5 mm
H = 200 mm

AUDI
AUDI
AUDI
AUDI
AUDI
VOLKSWAGENA4 (8E2, B6)
A4 (8E5, B6)
A4 (8EC, B7)
A4 (8ED, B7)
A4 (8H7, 8HE, B6, B7)
GOLF V (1K1)

RIGHT - 510107

Ø = 21 mm
Ø = 62,5 mm
H = 254 mm

101679

APPLICATION

LEFT - 101544

Ø = 24,3 mm
Ø = 41,55 mm
H = 119 mm

PORSCHE

944

VOLKSWAGEN

GOLF III (1E7)

SEAT

CORDOBA (6K1, 6K2)

VOLKSWAGEN

GOLF III (1H1)

SEAT

CORDOBA (6K2)

VOLKSWAGEN

GOLF III (1H5)

SEAT

CORDOBA (6K5)

VOLKSWAGEN

GOLF Mk III (1H1)

SEAT

IBIZA II (6K1)

VOLKSWAGEN

JETTA I (16)

SEAT

IBIZA III (6K1)

VOLKSWAGEN

JETTA II (165, 19E, 1G2)

SEAT

INCA (6K9)

VOLKSWAGEN

PASSAT (3A2, 35I)

SEAT

TOLEDO I (1L)

VOLKSWAGEN

PASSAT (3A5, 35I)

VOLKSWAGEN

CADDY I (14)

VOLKSWAGEN

SCIROCCO (53)

VOLKSWAGEN

GOLF I (155)

VOLKSWAGEN

SCIROCCO (53B)

VOLKSWAGEN

GOLF I (17)

VOLKSWAGEN

VENTO (1H2)

VOLKSWAGEN

GOLF II (19E, 1G1)

VOLKSWAGEN

VENTO (1H2)

RIGHT - 101544

Ø = 24,3 mm
Ø = 41,55 mm
H = 119 mm



510243

LEFT - 101303

Ø = 25 mm
Ø = 39 mm
H = 126 mm



RIGHT - 101303

Ø = 25 mm
Ø = 39 mm
H = 126 mm

VOLKSWAGEN

TRANSPORTER II

APPLICATION

101843

LEFT - 101303

Ø = 25 mm
Ø = 39 mm
H = 126 mm



RIGHT - 101707

Ø = 25 mm
Ø = 35 mm
H = 144 mm

PORSCHE
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

944
CADDY I (14)
GOLF I (17)
GOLF II (19E, 1G1)
JETTA I (16)
JETTA II (165, 19E,
1G2)
SCIROCCO (53)

APPLICATION

VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

TRANSPORTER I (21,
23)
TRANSPORTER I (22,
24, 25, 28)
TRANSPORTER I (26)
TRANSPORTER II
TRANSPORTER III

510152

LEFT - 510151

Ø = 25 mm
Ø = 39,5 mm
H = 135 mm



RIGHT - 510151

Ø = 25 mm
Ø = 39,5 mm
H = 135 mm

VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

LUPO (6E1, 6X1)
POLO (6KV5)
POLO (6N1)
POLO (6N2)

APPLICATION

510127

LEFT - 510126

Ø = 25 mm
Ø = 51,7 mm
H = 128,5 mm



RIGHT - 510126

Ø = 25 mm
Ø = 51,7 mm
H = 128,5 mm

VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

TRANSPORTER IV
(70XA)
TRANSPORTER IV
(70XB, 70XC, 7DB,
7DK, 7DW)
TRANSPORTER IV
(70XD)

APPLICATION

101764

APPLICATION

LEFT - 101627

Ø = 25,6 mm
 Ø = 47,1 mm
 H = 127,8 mm



VOLKSWAGEN	TRANSPORTER IV (70XA)
VOLKSWAGEN	TRANSPORTER IV (70XB, 70XC, 7DB, 7DK, 7DW)
VOLKSWAGEN	TRANSPORTER IV (70XD)

RIGHT - 101627

Ø = 25,6 mm
 Ø = 47,1 mm
 H = 127,8 mm

102071

APPLICATION

LEFT - 101645

Ø = 26 mm
 Ø = 41 mm
 H = 160 mm



VOLKSWAGEN	TRANSPORTER III
VOLKSWAGEN	TRANSPORTER IV (70XA)
VOLKSWAGEN	TRANSPORTER IV (70XB, 70XC, 7DB, 7DK, 7DW)
VOLKSWAGEN	TRANSPORTER IV (70XD)

RIGHT - 101645

Ø = 26 mm
 Ø = 41 mm
 H = 160 mm

510124

APPLICATION

LEFT - 510123

Ø = 26 mm
 Ø = 45 mm
 H = 150 mm



AUDI	100 (44, 44Q, C3)	AUDI	COUPE B2 (81, 855, 856)
AUDI	100 (C1)	AUDI	COUPE B3 (89, 8B3)
AUDI	80 (80, 82, B1)	AUDI	QUATTRO (85)
AUDI	80 (81, 85, B2)	VOLKSWAGEN	PASSAT (32)
AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	PASSAT (32B)
AUDI	80 (8C, B4)	VOLKSWAGEN	PASSAT (33)
AUDI	90 (81, 85, B2)	VOLKSWAGEN	SANTANA (32B)
AUDI	90 (89, 89Q, 8A, B3)		

RIGHT - 510123

Ø = 26 mm
 Ø = 45 mm
 H = 150 mm

LEFT - 101507

Ø = 9,5 mm
Ø = 31 mm
H = 196 mm



VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO

850 (LS)
850 (LW)
C70 I
S70 (LS)
V70 I (LV)
XC70 CROSS COUNTRY

APPLICATION

RIGHT - 101507

Ø = 9,5 mm
Ø = 31 mm
H = 196 mm

102002

LEFT - 102000

Ø = 10 mm
Ø = 52 mm
H = 156 mm



VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO

780
240 (P242, P244)
260 (P262, P264)
740 (744)
760 (704, 764)
940 (944)
960 (964)

APPLICATION

RIGHT - 102001

Ø = 10 mm
Ø = 44 mm
H = 185 mm

101765

LEFT - 101642

Ø = 11 mm
Ø = 41 mm
H = 183,7 mm



VOLVO
VOLVO

S40 I (VS)
V40 (VW)

APPLICATION

RIGHT - 101642

Ø = 11 mm
Ø = 41 mm
H = 183,7 mm

510011

LEFT - 510010

Ø = 13 mm
Ø = 46 mm
H = 225 mm



VOLVO
VOLVO
VOLVO
VOLVO

C70 I
S70 (LS)
V70 I (LV)
XC70 CROSS COUNTRY

APPLICATION

RIGHT - 510010

Ø = 13 mm
Ø = 46 mm
H = 225 mm

LEFT - 510018

Ø = 14 mm
Ø = 50 mm
H = 204 mm



VOLVO
VOLVO
VOLVO
VOLVO

S60 I
S80 I (TS, XY)
V70 II (SW)
XC70 CROSS COUN-
TRY

APPLICATION

RIGHT - 510018

Ø = 14 mm
Ø = 50 mm
H = 204 mm

102386

LEFT - 102385

Ø = 14,7 mm
Ø = 53,65 mm
H = 206,95 mm



VOLVO
VOLVO
VOLVO
VOLVO

C30
C70 II
S40 II (MS)
V50 (MW)

APPLICATION

RIGHT - 102385

Ø = 14,7 mm
Ø = 53,65 mm
H = 206,95 mm

102426

LEFT - 102425

Ø = 16,5 mm
Ø = 52 mm
H = 195 mm



VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO

S60 II
S80 II (AS)
V60
V70 III (BW)
XC60
XC70 II

APPLICATION

RIGHT - 102425

Ø = 16,5 mm
Ø = 52 mm
H = 195 mm

LEFT - 101658

Ø = 9,5 mm
Ø = 25,4 mm
H = 182 mm



ZASTAVA
ZASTAVA
ZASTAVA

101 (1100)
YUGO
YUGO FLORIDA

APPLICATION

RIGHT - 101612

Ø = 10 mm
Ø = 42,3 mm
H = 119,5 mm

ert

SHOCK ABSORBER PROTECTION KITS



ert

520005
APPLICATION
FRONT


ALFA ROMEO	33 (905_)
ALFA ROMEO	33 (905A_)
ALFA ROMEO	33 (907A_)
ALFA ROMEO	33 (907B_)
FIAT	PANDA (141_)

520014
APPLICATION
FRONT


FIAT	FIORINO (146_)
FIAT	REGATA (138_)
FIAT	RITMO (138_)
FIAT	UNO (146_)
LANCIA	DELTA I (831_)
LANCIA	PRISMA (831_)
LANCIA	Y10 (156_)

520021
APPLICATION
REAR


LANCIA	DELTA I (831_)
LANCIA	PRISMA (831_)

520034
APPLICATION
FRONT


FIAT	CROMA (194_)
FIAT	DOBLO (263_)
FIAT	FIORINO (225_)
FIAT	FIORINO Van / Wagon (225_)

520036
APPLICATION
FRONT


FIAT	BRAVA (182_)
FIAT	BRAVO I (182_)
FIAT	MAREA (185_)
FIAT	STILO (192_)
FIAT	STILO VAN (192_)
FIAT	TEMPRA (159_)
FIAT	TIPO (160_)

ABARTH - ALFA ROMEO - FIAT - LANCIA

SHOCK ABSORBER PROTECTION KITS

520049

APPLICATION

FRONT



FIAT	500 (312_)
FIAT	500 C (312_)
FIAT	IDEA (350_)
FIAT	PANDA (169_)
FIAT	PUNTO (188_)
FIAT	PUNTO Van (188_)
LANCIA	MUSA (350_)
LANCIA	YPSILON (843_)

520050

APPLICATION

REAR



ALFA ROMEO	147 (937_)
ALFA ROMEO	156 (932_)
ALFA ROMEO	GT (937_)

520051

APPLICATION

REAR



ABARTH	GRANDE PUNTO (199_)
ALFA ROMEO	MITO (955_)
FIAT	GRANDE PUNTO (199_)

520056

APPLICATION

REAR



ALFA ROMEO	145 (930_)
ALFA ROMEO	146 (930_)
ALFA ROMEO	155 (167_)

520066

APPLICATION

FRONT



FIAT	DUCATO (230_)
FIAT	DUCATO (244_)
FIAT	DUCATO (280_)
FIAT	DUCATO (290_)
FIAT	TALENTO (290_)

520086
APPLICATION

FRONT


 FIAT
FIAT
FIAT

 500 (312_)
500 C (312_)
PANDA (169_)

520099
APPLICATION

FRONT


 FIAT
FIAT
FIAT

 DOBLO (263_)
FIORINO (225_)
FIORINO Van / Wagon
(225_)

520101
APPLICATION

FRONT


 ABARTH
ALFA ROMEO
FIAT
FIAT
FIAT

FIAT
FIAT

 GRANDE PUNTO (199_)
MITO (955_)
500L (199_)
FIORINO (225_)
FIORINO Van / Wagon
(225_)
GRANDE PUNTO (199_)
GRANDE PUNTO Van
(199_)

 FIAT
FIAT
FIAT
FIAT
FIAT

LINEA (323_)
PUNTO (199_)
PUNTO EVO (199_)
PUNTO EVO Van (199_)
QUBO (225_)

520122
APPLICATION

FRONT


 FIAT
FIAT
LANCIA

 SCUDO (220_)
ULYSSE (220_)
ZETA (22_)

520134
APPLICATION

FRONT


 FIAT
LANCIA

 PUNTO (176_)
Y (840_)

ABARTH - ALFA ROMEO - FIAT - LANCIA

SHOCK ABSORBER PROTECTION KITS

520138

APPLICATION

FRONT


FIAT
FIAT
LANCIA

SCUDO (220_)
ULYSSE (220_)
ZETA (22_)

520141

APPLICATION

FRONT


ABARTH
FIAT
FIAT
FIAT

RITMO (138A_)
REGATA (138_)
RITMO (138_)
UNO (146_)

520142

APPLICATION

FRONT


FIAT
FIAT

SEDICI
SEDICI (FY_)

520144

APPLICATION

REAR


ALFA ROMEO
ALFA ROMEO
ALFA ROMEO
FIAT
FIAT
FIAT
FIAT
FIAT
LANCIA

145 (930_)
146 (930_)
155 (167_)
BRAVA (182_)
BRAVO I (182_)
PUNTO (176_)
TEMPRA (159_)
TIPO (160_)
DEDRA (835_)

LANCIA
LANCIA

DELTA II (836_)
Y (840_)

520167

APPLICATION

FRONT



FIAT

DUCATO (250_, 290_)

520184

APPLICATION

REAR


FIAT
FIAT

CINQUECENTO (170_)
SEICENTO / 600 (187_)

520190

APPLICATION

FRONT



FIAT

BRAVO II (198_)

520217

APPLICATION

FRONT



FIAT

FIORINO (225_)

520232

APPLICATION

FRONT


FIAT
FIAT

500 (312_)
PANDA (169_)

APPLICATION

REAR



ASTON MARTIN CYGNET

APPLICATION

FRONT



AUTOBIANCHI

Y10

BMW - MINI

SHOCK ABSORBER PROTECTION KITS

520005

APPLICATION

FRONT



BMW 2500-3.3 (E3)
 BMW 3 (E21)
 BMW 3 (E30)
 BMW 3 (E36)
 BMW 5 (E12)
 BMW 5 (E28)
 BMW 5 (E34)
 BMW 6 (E24)
 BMW 7 (E23)

BMW 7 (E32)

520008

APPLICATION

FRONT



MINI MINI (R50, R53)

520010

APPLICATION

REAR



BMW 3 (E36)
 BMW 3 (E46)

520015

APPLICATION

FRONT



BMW 5 (E39)

520021

APPLICATION

FRONT



BMW 5 (E39)
 BMW 7 (E65, E66, E67)

520022

APPLICATION

REAR



BMW

3 (E46)

520040

APPLICATION

REAR

BMW
BMW
BMW3 (E91)
3 (E93)
3 Touring (E91)

520051

APPLICATION

REAR



BMW

3 (E21)

520060

APPLICATION

FRONT

BMW
BMW
BMW
BMW3 (E91)
5 (E60)
5 (E61)
X1 (E84)

520120

APPLICATION

REAR



BMW

X3 (E83)

BMW - MINI

SHOCK ABSORBER PROTECTION KITS

520123

APPLICATION

FRONT

BMW
BMW7 (E65, E66, E67)
X5 (E53)

520129

APPLICATION

REAR

BMW
BMW5 (E60)
5 (E61)

520131

APPLICATION

REAR

BMW
BMW
BMW
BMW
BMW
BMW1 (E81)
1 (E82)
1 (E88)
3 (E90)
3 (E91)
3 (E92)

520140

APPLICATION

FRONT

BMW
BMW
BMW
BMW
BMW
BMW3 (E90)
3 (E90)
3 (E91)
3 (E92)
3 (E93)
3 Touring (E91)

520170

APPLICATION

REAR



BMW

3 (E21)

520175

APPLICATION

REAR



BMW 3 (E36)
 BMW 3 (E46)
 BMW 6 (E24)
 BMW Z3 (E36)

520179

APPLICATION

FRONT



BMW 1 (E81)
 BMW 1 (E82)
 BMW 1 (E87)
 BMW 3 (E90)
 BMW 3 (E91)
 BMW 3 (E92)
 BMW 3 (E93)

520182

APPLICATION

FRONT



BMW X3 (E83)
 BMW X5 (E53)

520188

APPLICATION

FRONT



BMW 3 (E46)
 BMW 3 (E91)

520189

APPLICATION

FRONT



BMW 3 (E91)
 BMW 5 (E60)
 BMW 5 (E61)

BMW - MINI

SHOCK ABSORBER PROTECTION KITS

520191

APPLICATION

FRONT



BMW	1 (E81)
BMW	1 (E82)
BMW	1 (E87)
BMW	1 (E88)
BMW	3 (E46)
BMW	3 (E91)
BMW	3 (E93)

520206

APPLICATION

REAR



BMW	5 (E61)
-----	---------

520210

APPLICATION

FRONT



BMW	3 (E46)
BMW	3 (E91)

520220

APPLICATION

REAR



BMW	3 (E46)
-----	---------

520227

APPLICATION

REAR



BMW	1 (E81)
BMW	1 (E82)
BMW	1 (E87)
BMW	3 (E90)
BMW	3 (E91)
BMW	3 (E92)
BMW	3 (E93)
BMW	X1 (E84)

APPLICATION

REAR

BMW
BMW
BMW
BMW5 (E60)
5 (E61)
6 (E64)
7 (E65, E66, E67)

CHEVROLET - DAEWOO - OPEL - VAUXHALL

SHOCK ABSORBER PROTECTION KITS

520008

FRONT



DAEWOO
DAEWOO
DAEWOO
DAEWOO
OPEL

OPEL
OPEL

OPEL
OPEL
OPEL
OPEL

OPEL
OPEL

ESPERO (KLEJ)
LANOS (KLAT)
MATIZ (KLYA)
NEXIA (KLETN)
ASCONA C (81_, 86_,
87_, 88_)
ASCONA C (84_, 89_)
ASTRA F (53_, 54_,
58_, 59_)
CALIBRA A (85_)
COMBO (71_)
CORSA A
CORSA A (91_, 92_,
96_, 97_)
CORSA A (93_, 94_,
98_, 99_)
CORSA B (73_)

APPLICATION

OPEL CORSA B (73_, 78_,
79_)
OPEL KADETT D (31_-34_,
41_-44_)
OPEL KADETT D (35_, 36_,
45_, 46_)
OPEL KADETT E (33_, 34_,
43_, 44_)
OPEL KADETT E (35_, 36_,
45_, 46_)
OPEL KADETT E (37_, 47_)
OPEL KADETT E (38_, 48_)
OPEL KADETT E (39_, 49_)
OPEL KADETT E (43B_)
OPEL TIGRA (95_)
OPEL VECTRA A (J89)
VAUXHALL ASTRA Mk III (F)

520014

FRONT



OPEL
OPEL

OPEL
OPEL
OPEL

ASTRA F (51_, 52_)
ASTRA F (53_, 54_,
58_, 59_)
ASTRA F (53_B)
ASTRA F (56_, 57_)
COMMODORE C (14_,
19_)

APPLICATION

OPEL COMMODORE C (61)
OPEL MONZA A (22_)
OPEL REKORD E (11_, 14_,
16_, 17_-19_)
OPEL REKORD E (61_, 66_,
67_)
OPEL SENATOR A (29_)

520048

FRONT



OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL

ASTRA G (F07_)
ASTRA G (F08_, F48_)
ASTRA G (F35_)
ASTRA G (F69_)
ASTRA G (F70)
VECTRA B (31_)
VECTRA B (36_)
VECTRA B (38_)
ZAFIRA A (F75_)

APPLICATION

520034

FRONT



OPEL
OPEL
OPEL

OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL
OPEL

ASTRA CLASSIC
ASTRA CLASSIC (L48)
ASTRA CLASSIC (L48) I
ASTRA FAMILY
ASTRA CLASSIC Wagon
ASTRA H (A04)
ASTRA H (L08)
ASTRA H (L35)
ASTRA H (L48)
ASTRA H (L69)
ASTRA H (L70)
MERIVA B
SIGNUM

APPLICATION

OPEL VECTRA C
OPEL ZAFIRA B
OPEL ZAFIRA B (A05)
OPEL ZAFIRA B Van (A05)
VAUXHALL ASTRA Mk V (H)
VAUXHALL ASTRA Mk V (H) Wagon
(A04)
VAUXHALL ASTRAMAN Mk V (H)
VAUXHALL MERIVA Mk II (B)
VAUXHALL SIGNUM
VAUXHALL VECTRA Mk II (C)
VAUXHALL ZAFIRA Mk II (B) (M75)

520038

APPLICATION

FRONT



OPEL
OPEL
OPEL
OPEL
OPEL
VAUXHALL
VAUXHALL

COMBO
CORSA C (F08, F68)
CORSA C (F08, W5L)
MERIVA
TIGRA
COMBO Mk II (C) (F25)
CORSA Mk II (C) (F08, W5L)

520049

APPLICATION

FRONT



OPEL

CORSA B (73_)

520051

APPLICATION

REAR



OPEL
OPEL

CORSA D
VECTRA A (J89)

520054

APPLICATION

REAR



OPEL
OPEL
OPEL
VAUXHALL

VECTRA B (31_)
VECTRA B (36_)
VECTRA B (38_)
VECTRA (B)

520078

APPLICATION

REAR



CHEVROLET
CHEVROLET
CHEVROLET
DAEWOO
DAEWOO
DAEWOO
DAEWOO

LACETTI
LACETTI (J200)
NUBIRA
GENTRA
LACETTI
LACETTI (KLAN)
NUBIRA (KLAN)

CHEVROLET - DAEWOO - OPEL - VAUXHALL

SHOCK ABSORBER PROTECTION KITS

520079

APPLICATION

FRONT



CHEVROLET
CHEVROLET
CHEVROLET
DAEWOO

AVEO (T200)
AVEO (T250, T255)
KALOS
KALOS (KLAS)

520098

APPLICATION

FRONT



OPEL
OPEL
VAUXHALL

CORSA D
VECTRA C
VECTRA Mk II (C)

520099

APPLICATION

FRONT



OPEL
OPEL
OPEL
OPEL

ASTRA CLASSIC
ASTRA CLASSIC (L48)
ASTRA CLASSIC Wagon
ZAFIRA B (A05)

520100

APPLICATION

FRONT



DAEWOO
OPEL

OPEL
OPEL

OPEL
OPEL
OPEL
OPEL

OPEL

OPEL
OPEL

OPEL

ESPERO (KLEJ)
ASCONA C (81_, 86_,
87_, 88_)
ASCONA C (84_, 89_)
ASTRA F (53_, 54_,
58_, 59_)
CALIBRA A (85_)
COMBO (71_)
CORSA A
CORSA A (91_, 92_,
96_, 97_)
CORSA A (93_, 94_,
98_, 99_)
CORSA B (73_)
CORSA B (73_, 78_,
79_)
KADETT D (_42,
32_,37_,39)

OPEL KADETT D (31_-34_,
41_-44_)
OPEL KADETT D (35_, 36_,
45_, 46_)
OPEL KADETT E (33_, 34_,
43_, 44_)
OPEL KADETT E (35_, 36_,
45_, 46_)
OPEL KADETT E (37_, 47_)
OPEL KADETT E (38_, 48_)
OPEL KADETT E (39_, 49_)
OPEL KADETT E (43B_)
OPEL TIGRA (95_)
OPEL VECTRA A (J89)
VAUXHALL ASTRA Mk II

520101

APPLICATION

FRONT



OPEL

CORSA D

520102

APPLICATION

FRONT



OPEL

OMEGA B (21_, 22_, 23_)

OPEL

OMEGA B (25_, 26_, 27_)

OPEL

SENATOR B (29_)

520104

APPLICATION

FRONT



OPEL

VIVARO

OPEL

VIVARO (E7)

OPEL

VIVARO (F7)

OPEL

VIVARO (J7)

OPEL

VIVARO B (X82)

VAUXHALL

VIVARO

VAUXHALL

VIVARO (E7)

VAUXHALL

VIVARO (F7)

VAUXHALL

VIVARO (J7)

520128

APPLICATION

FRONT



OPEL

ADAM

OPEL

CORSA D

OPEL

CORSA E

520137

APPLICATION

FRONT



OPEL

INSIGNIA

OPEL

INSIGNIA A

VAUXHALL

INSIGNIA

VAUXHALL

INSIGNIA MK I (A) (G09)

VAUXHALL

INSIGNIA Mk II (B)

CHEVROLET - DAEWOO - OPEL - VAUXHALL

SHOCK ABSORBER PROTECTION KITS

520171

APPLICATION

FRONT


OPEL
OPEL

OPEL
OPEL
OPEL
OPEL

ASTRA F (51_, 52_)
ASTRA F (53_, 54_,
58_, 59_)
ASTRA F (53_B)
ASTRA F (55_)
ASTRA F (56_, 57_)
KADETT E (33_, 34_,
43_, 44_)

OPEL

OPEL
OPEL
OPEL
OPEL

KADETT E (35_, 36_,
45_, 46_)
KADETT E (37_, 47_)
KADETT E (38_, 48_)
KADETT E (39_, 49_)
KADETT E (43B_)

520153

APPLICATION

FRONT


CHEVROLET
CHEVROLET
CHEVROLET
DAEWOO
DAEWOO
DAEWOO
DAEWOO
DAEWOO

LACETTI
LACETTI (J200)
NUBIRA
GENTRA
LACETTI
LACETTI (KLAN)
NUBIRA (KLAJ)
NUBIRA (KLAN)

520170

APPLICATION

REAR



VAUXHALL

CAVALIER Mk III (87)

520178

APPLICATION

FRONT


OPEL
VAUXHALL

AGILA (A) (H00)
AGILA Mk I (A)

520180

APPLICATION

REAR


CHEVROLET
CHEVROLET
CHEVROLET

CHEVROLET
DAEWOO

AVEO (T200)
AVEO (T250, T255)
AVEO (T250, T255) I
KALOS
KALOS
KALOS (KLAS)

520075

APPLICATION

FRONT

CHRYSLER
CHRYSLERVOYAGER III (GS)
VOYAGER IV (RG, RS)

520190

APPLICATION

FRONT



CHRYSLER

DELTA

520023

APPLICATION

REAR



CITROEN	C4	PEUGEOT	307 (3B)
CITROEN	C4 (LA_)	PEUGEOT	307 (3E)
CITROEN	C4 I (LC_)	PEUGEOT	307 (3H)
CITROEN	C4 I (LR_)	PEUGEOT	307 SW (3E_, 3H_)
CITROEN	C4 II (B7)	PEUGEOT	308 (4A_, 4C_)
CITROEN	C4 II (NC_)	PEUGEOT	308 CC
CITROEN	DS4	PEUGEOT	308 SW
DS	DS 4 / DS 4 CROSS-	PEUGEOT	308 SW (4E_)
	BACK	PEUGEOT	RCZ
PEUGEOT	3008		
PEUGEOT	3008 MPV (0U_)		
PEUGEOT	307 (3A/C)		

520027

APPLICATION

FRONT



CITROEN	BERLINGO (B9)	PEUGEOT	307 (3B)
CITROEN	BERLINGO (M_)	PEUGEOT	307 (3E)
CITROEN	BERLINGO (MF)	PEUGEOT	307 (3H)
CITROEN	C4	PEUGEOT	307 SW (3E_, 3H_)
CITROEN	C4 (LA_)	PEUGEOT	308 (4A_, 4C_)
CITROEN	C4 Grand Picasso I	PEUGEOT	308 CC
	(UA_)	PEUGEOT	308 SW
CITROEN	C4 I (LC_)	PEUGEOT	308 SW (4E_)
CITROEN	C4 I (LR_)	PEUGEOT	PARTNER
CITROEN	C4 II (B7)	PEUGEOT	PARTNER ORIGIN (G_)
CITROEN	C4 II (NC_)	PEUGEOT	PARTNER Tepee
CITROEN	C4 Picasso I (UD_)	PEUGEOT	PARTNER Van
CITROEN	DS4		
DS	DS 4 / DS 4 CROSS- BACK		
PEUGEOT	3008		
PEUGEOT	5008		
PEUGEOT	307 (3A/C)		

520036

APPLICATION

FRONT



CITROEN AX (ZA-_)
 CITROEN BERLINGO (M_)
 CITROEN BERLINGO (MF)
 CITROEN C15
 CITROEN C15 (VD-_)
 CITROEN LNA
 CITROEN SAXO (S0, S1)
 CITROEN VISA
 CITROEN XSARA (N0)
 CITROEN XSARA (N1)
 CITROEN XSARA (N2)
 CITROEN XSARA PICASSO (N68)
 CITROEN ZX (N2)
 PEUGEOT 104
 PEUGEOT 205
 PEUGEOT 106 (1A)
 PEUGEOT 106 I (1A, 1C)
 PEUGEOT 106 II (1)
 PEUGEOT 205 I (20D, 741B)
 PEUGEOT 205 I (741A/C)
 PEUGEOT 205 II (20A/C)

PEUGEOT 205 Mk II (20A/C)
 PEUGEOT 304 (_04D_)
 PEUGEOT 304 (_04M_)
 PEUGEOT 305 I (581A)
 PEUGEOT 305 I (581D)
 PEUGEOT 305 II (581E)
 PEUGEOT 305 II (581M)
 PEUGEOT 306 (7A, 7C, N3, N5)
 PEUGEOT 306 (7B, N3, N5)
 PEUGEOT 306 (7D, N3, N5)
 PEUGEOT 306 (7E, N3, N5)
 PEUGEOT 309 I (10A, 10C)
 PEUGEOT 309 II (3A, 3C)
 PEUGEOT 405 I (15B)
 PEUGEOT 405 I (15E)
 PEUGEOT 405 II (4B)
 PEUGEOT 405 II (4E)
 PEUGEOT 405 Mk II (4B)
 PEUGEOT PARTNER (5)
 PEUGEOT PARTNER (5F)

520055

APPLICATION

FRONT



PEUGEOT 207
 PEUGEOT 207 (WA_, WC_)
 PEUGEOT 207 CC (WD_)
 PEUGEOT 207 SW (WK_)

520056

APPLICATION

FRONT



CITROEN XSARA (N0)
 CITROEN XSARA (N1)
 CITROEN XSARA (N2)
 CITROEN XSARA PICASSO (N68)
 PEUGEOT 504
 PEUGEOT 504 (A_, M_)
 PEUGEOT 504 (D_, F_)
 PEUGEOT 505 (551A)
 PEUGEOT 505 (551D)

PEUGEOT 604 (561A_)

520056

APPLICATION

REAR



PEUGEOT 505 (551A)

CITROEN - PEUGEOT - DS

SHOCK ABSORBER PROTECTION KITS

520060

APPLICATION

PEUGEOT 307 (3H)



520063

APPLICATION

FRONT



CITROEN	BERLINGO (M_)	PEUGEOT	406 (8E/F)
CITROEN	BERLINGO (MF)	PEUGEOT	605 (6B)
CITROEN	MEHARI	PEUGEOT	PARTNER
CITROEN	XSARA	PEUGEOT	PARTNER (5)
CITROEN	XSARA (N0)	PEUGEOT	PARTNER (5F)
CITROEN	XSARA (N1)	PEUGEOT	PARTNER ORIGIN (G_)
CITROEN	XSARA (N2)		
PEUGEOT	406 (8B)		
PEUGEOT	406 (8C)		

520066

APPLICATION

FRONT



CITROEN	C25 (280_, 290_)	PEUGEOT	BOXER (ZCT_)
CITROEN	JUMPER (230)	PEUGEOT	ER (230L)
CITROEN	JUMPER (230L)	PEUGEOT	ER (244)
CITROEN	JUMPER (230P)	PEUGEOT	J5 (280L)
CITROEN	JUMPER (244)	PEUGEOT	J5 (280P)
CITROEN	JUMPER (244, Z_)	PEUGEOT	J5 (290L)
PEUGEOT	BOXER (230P)	PEUGEOT	J5 (290P)
PEUGEOT	BOXER (244)		
PEUGEOT	BOXER (244, Z_)		

520087

APPLICATION

REAR



CITROEN	C4 AIRCROSS
CITROEN	C-CROSSER (EP_)
CITROEN	C-CROSSER ENTER-PRISE
PEUGEOT	4008
PEUGEOT	4007 (GP_)

520099

APPLICATION

FRONT



CITROEN	BERLINGO (M_)	PEUGEOT	PARTNER (5F)
CITROEN	BERLINGO (MF)		
PEUGEOT	206		
PEUGEOT	206 (2A/C)		
PEUGEOT	206 (2D)		
PEUGEOT	206 (2E/K)		
PEUGEOT	206 Van		
PEUGEOT	206+ (T3E)		
PEUGEOT	PARTNER (5)		

520101

APPLICATION

FRONT



CITROEN
CITROEN
PEUGEOT
PEUGEOT

NEMO
NEMO (AA_)
BIPPER (AA_)
BIPPER Tepee

520108

APPLICATION

FRONT



CITROEN
CITROEN
CITROEN
CITROEN
CITROEN

C2 (JM_)
C2 ENTERPRISE
C2 ENTERPRISE (JG_)
C3 (HB_)
C3 I (FC_)

520122

APPLICATION

FRONT



CITROEN
CITROEN
CITROEN
CITROEN

CITROEN

CITROEN
CITROEN

C8 (EA_, EB_)
EVASION (22, U6)
JUMPY
JUMPY (BS_, BT_, BY_,
BZ_)
JUMPY (BU_, BV_, BW_,
BX_)
JUMPY (U6U)
JUMPY I DISPATCH

PEUGEOT 806 (221)
PEUGEOT 807 (E)
PEUGEOT EXPERT
PEUGEOT EXPERT (222)
PEUGEOT EXPERT (223)
PEUGEOT EXPERT (224)
PEUGEOT EXPERT (VF3A_, VF3U_,
VF3X_)
PEUGEOT EXPERT Tepee (VF3V_)

520138

APPLICATION

FRONT



CITROEN
CITROEN
CITROEN

CITROEN

CITROEN

C8 (EA_, EB_)
EVASION (22, U6)
EVASION MPV (22, U6) I
SYNERGIE
JUMPY (BS_, BT_, BY_,
BZ_)
JUMPY (BU_, BV_, BW_,
BX_)

CITROEN JUMPY (BU_, BV_, BW_,
BX_) I DISPATCH
CITROEN JUMPY (U6U)
PEUGEOT 806 (221)
PEUGEOT EXPERT (222)
PEUGEOT EXPERT (223)
PEUGEOT EXPERT (224)

520160

APPLICATION

REAR



CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT

C5 III (RD_)
C5 III (TD_)
508
407 (6C_)
407 (6D_)
407 (6E_)
508 SW

CITROEN - PEUGEOT - DS

SHOCK ABSORBER PROTECTION KITS

520167

APPLICATION

FRONT

CITROEN
PEUGEOTJUMPER
BOXER

520185

APPLICATION

FRONT

CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOTC5 III (RD_)
C5 III (TD_)
407 (6C_)
407 (6D_)
407 (6E_)

520187

APPLICATION

FRONT

CITROEN
CITROEN
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOTBERLINGO (M_)
BERLINGO (MF)
206
206 (2A/C)
206 Van
206+ (T3E)
PARTNER (5)
PARTNER (5F)

520207

APPLICATION

FRONT

PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT
PEUGEOT207
1007 (KM_)
207 (WA_, WC_)
207 CC (WD_)
207 SW (WK_)

520211

APPLICATION

FRONT

CITROEN
CITROEN
CITROEN
CITROENC2 (JM_)
C3 (HB_)
C3 I (FC_)
C3 I (FC_, FN_)

520219

APPLICATION

FRONT

CITROEN
CITROENC5 III (RD_)
C5 III (TD_)

520221

APPLICATION

REAR

CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOTC1 (PM_, PN_)
C1 II
C1 II (PA_, PS_)
107
108

520222

APPLICATION

REAR



PEUGEOT

406 (8B)

520230

APPLICATION

FRONT

CITROEN
CITROEN
CITROEN
PEUGEOT
PEUGEOTC1 (PM_, PN_)
C1 II
C1 II (PA_, PS_)
107
108

DACIA - RENAULT

SHOCK ABSORBER PROTECTION KITS

520003

APPLICATION

REAR



RENAULT

12

520006

APPLICATION

FRONT



DACIA
DACIA
RENAULT
RENAULT

RENAULT
RENAULT
RENAULT

LOGAN (LS_)
LOGAN MCV (KS_)
CLIO I (5/357_, B/C57_)
CLIO II (BB0/1/2_,
CB0/1/2_)
CLIO II (SB0/1/2_)
KANGOO (FC0/1_)
KANGOO (KC0/1_)

RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

KANGOO / GRAND
KANGOO (KW0/1_)
LOGAN I (KS_)
LOGAN I (LS_)
THALIA I (LB0/1/2_)
TWINGO I (C06_)
TWINGO II (CN0_)

520016

APPLICATION

FRONT



RENAULT
RENAULT
RENAULT

RAPID (F40_, G40_)
SUPER 5 (B/C40_)
SUPER 5 (S40_)

520017

APPLICATION

FRONT



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

GRAND SCÉNIC II
(JM0/1_)
MEGANE II (BM0/1_,
CM0/1_)
MEGANE II (EM0/1_)
MEGANE II (KM_)
MEGANE II (KM0/1_)
MEGANE II (KM0/2_)
MEGANE II (LM0/1_)

RENAULT
RENAULT

MEGANE II Box Body
(KM_)
SCÉNIC II (JM0/1_)

520029

APPLICATION

FRONT



RENAULT
RENAULT

RENAULT
RENAULT
RENAULT

CLIO (KR0/1_)
CLIO Grandtour
(KR0/1_)
CLIO III (BR0/1, CR0/1_)
CLIO III (SB_, SR_)
MODUS / GRAND MO-
DUS (F/JPO_)

520033

APPLICATION

FRONT



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

11 (B/C37_)
19 I (B/C53_)
19 I (D53_)
19 I (L53_)
19 II (853_, D53_)
19 II (B/C53_)
19 II (L53_)
19 II (S53_)
9 (L42_)
ESPACE III (JE0_)

RENAULT LAGUNA I (556_, B56_)
RENAULT LAGUNA I (K56_)
RENAULT MEGANE (JA0/1_)
RENAULT MEGANE I (BA0/1_)
RENAULT MEGANE I (DA0/1_)
RENAULT MEGANE I (EA0/1_)
RENAULT MEGANE I (KA0/1_)
RENAULT MEGANE I (LA0/1_)
RENAULT SAFRANE I (B54_)
RENAULT SAFRANE II (B54_)

520037

APPLICATION

FRONT



RENAULT
RENAULT
RENAULT

LAGUNA II (BG0/1_)
LAGUNA II (KG0/1_)
LAGUNA II Grandtour
(KG0/1_)

520062

APPLICATION

REAR



RENAULT
RENAULT
RENAULT

CLIO II (BB0/1/2_,
CB0/1/2_)
CLIO II (SB0/1/2_)
THALIA I (LB0/1/2_)

520081

APPLICATION

REAR



RENAULT

KANGOO (FC0/1_)

520093

APPLICATION

FRONT



RENAULT
RENAULT

ESPACE IV (JK0/1_)
VEL SATIS (BJ0_)

DACIA - RENAULT

SHOCK ABSORBER PROTECTION KITS

520096

APPLICATION

FRONT



DACIA
DACIA
DACIA
DACIA
DACIA
DACIA
DACIA
DACIA
DACIA

DUSTER
LOGAN (FS_)
LOGAN (LS_)
LOGAN (US_)
LOGAN II
LOGAN MCV (KS_)
LOGAN MCV II
SANDERO
SANDERO II

RENAULT
RENAULT

LOGAN I (KS_)
LOGAN I (LS_)

520096

APPLICATION

REAR



DACIA

DUSTER

520104

APPLICATION

FRONT



RENAULT
RENAULT
RENAULT
RENAULT
RENAULT
RENAULT

TRAFIC II (EL)
TRAFIC II (FL)
TRAFIC II (JL)
TRAFIC III (EG_)
TRAFIC III (FG_)
TRAFIC III (JG_)

520122

APPLICATION

FRONT



RENAULT

SCÉNIC I (JA0/1_)

520126

APPLICATION

FRONT



RENAULT

MEGANE II (BM0/1_,
CM0/1_)

520133

APPLICATION

FRONT



RENAULT

GRAND SCÉNIC II

RENAULT

(JM0/1_)

SCÉNIC II (JM0/1_)

520143

APPLICATION

FRONT



RENAULT

FLUENCE (L30_)

RENAULT

GRAND SCÉNIC III

(JZ0/1_)

RENAULT

LATITUDE (L70_)

RENAULT

MEGANE CC (EZ0/1_)

RENAULT

MEGANE III (BZ_)

RENAULT

MEGANE III (BZ0/1_)

RENAULT

MEGANE III (BZ0_)

RENAULT

MEGANE III (DZ0/1_)

RENAULT

MEGANE III (KZ0/1)

RENAULT

SCÉNIC III (JZ0/1_)

520154

APPLICATION

FRONT



RENAULT

CLIO IV (BH_)

RENAULT

CLIO IV (KH_)

520155

APPLICATION

REAR



RENAULT

TWINGO I (C06_)

520172

APPLICATION

FRONT



RENAULT

CAPTUR (J5_)

RENAULT

CAPTUR (J5_) | KAPTUR

RENAULT

CAPTUR (J5_, H5_)

RENAULT

CLIO (KR0/1_)

RENAULT

CLIO Grandtour

(KR0/1_)

RENAULT

CLIO III (BR0/1, CR0/1_)

RENAULT

CLIO III (SB_, SR_)

RENAULT

CLIO IV

RENAULT

CLIO IV (BH_)

RENAULT

CLIO IV (KH_)

RENAULT

MODUS / GRAND MO-

DUS (F/JPO_)

RENAULT

ZOE (BFM_)

DACIA - RENAULT

SHOCK ABSORBER PROTECTION KITS

520174

APPLICATION

FRONT



RENAULT

CLIO II (SB0/1/2_)

520216

APPLICATION

FRONT



RENAULT

KANGOO (FW0/1_)

RENAULT

KANGOO / GRAND

RENAULT

KANGOO (KW0/1_)

KANGOO BE BOP

(KW0/1_)

520217

APPLICATION

FRONT



RENAULT

FLUENCE (L30_)

RENAULT

GRAND SCÉNIC III

(JZ0/1_)

RENAULT

LATITUDE (L70_)

RENAULT

MEGANE CC (EZ0/1_)

RENAULT

MEGANE III (BZ0_)

RENAULT

MEGANE III (DZ0/1_)

RENAULT

MEGANE III (KZ0/1)

RENAULT

SCÉNIC III (JZ0/1_)

APPLICATION

FRONT



DAIHATSU

CHARADE

DODGE
520075**SHOCK ABSORBER PROTECTION KITS****APPLICATION**

FRONT

DODGE

CARAVAN (RG_)



FORD 520004

SHOCK ABSORBER PROTECTION KITS

FRONT



FORD
FORD
FORD
FORD

C-MAX (DM2)
FOCUS C-MAX
FOCUS II
FOCUS II (DA_)

APPLICATION

520014

FRONT



FORD
FORD
FORD
FORD
FORD
FORD

FORD
FORD
FORD
FORD

ESCORT '81 (AVA)
ESCORT '86 (AVF)
ESCORT III (ALD)
ESCORT III (AWA)
ESCORT III (GAA)
ESCORT IV (ABFT, AWF, GAF)
ESCORT IV (ALF)
ESCORT IV (AVF, AWF)
ESCORT V (ALL)
ESCORT V (GAL)

APPLICATION

FORD
FORD

FORD
FORD
FORD
FORD
FORD
FORD
FORD
FORD

ESCORT VI (GAL)
ESCORT VII (AAL, ABL, GAL)
FIESTA (FVD)
FIESTA (WVFT)
FIESTA I (GFBT)
FIESTA II (FBD)
ORION I (AFD)
ORION II (AFF)
ORION III (GAL)

520018

FRONT



FORD
FORD
FORD

FIESTA V
FIESTA V (JD_, JH_)
FUSION (JU_)

APPLICATION

520035

REAR



FORD

FOCUS C-MAX

APPLICATION

520051

REAR



FORD
FORD
FORD
FORD

ESCORT CLASSIC (AAL, ABL)
ESCORT VII (AAL, ABL, GAL)
ESCORT VII (AFL, GAL)
FIESTA IV (JA_, JB_)

APPLICATION

FORD
520095
SHOCK ABSORBER PROTECTION KITS
APPLICATION

FRONT



FORD

FIESTA III (GFJ)

520103
APPLICATION

REAR

FORD
FORDFOCUS C-MAX
FOCUS II (DA_)
520116
APPLICATION

FRONT



FORD

FUSION (JU_)

520127
APPLICATION

REAR

FORD
FORDFOCUS (DAW, DBW)
FOCUS (DFW)
520150
APPLICATION

FRONT

FORD
FORD
FORDGALAXY (WA6)
MONDEO IV (BA7)
S-MAX (WA6)

FORD
520157

SHOCK ABSORBER PROTECTION KITS

FRONT



FORD
FORD
FORD

GALAXY (WGR)
SCORPIO I (GAE, GGE)
SCORPIO I (GGE)

APPLICATION

520183

REAR



FORD

FOCUS II (DA_)

APPLICATION

520197

FRONT



FORD
FORD

FOCUS C-MAX
FOCUS II (DA_)

APPLICATION

520199

REAR



FORD
FORD

C-MAX (DM2)
FOCUS II

APPLICATION

520204

FRONT



FORD
FORD
FORD
FORD
FORD

MONDEO III (B4Y)
MONDEO III (B5Y)
MONDEO III (BWY)
TOURNEO CONNECT
TRANSIT CONNECT
(P65_, P70_, P80_)

APPLICATION

FORD
520205
SHOCK ABSORBER PROTECTION KITS
APPLICATION

FRONT



FORD

FIESTA VI

520208
APPLICATION

FRONT



FORD

MONDEO IV (BA7)

520209
APPLICATION

REAR

FORD
FORDMONDEO III (B4Y)
MONDEO III (B5Y)

APPLICATION

FRONT



HONDA
HONDA

CIVIC VII (EP, EU, EV)
CIVIC VII (ES)

520121

APPLICATION

FRONT



HONDA
HONDA

JAZZ II (GD, GE3)
JAZZ III (GE_, GG_, GP_)

520147

APPLICATION

FRONT



HONDA

JAZZ II (GD, GE3)

520170

APPLICATION

FRONT



HONDA
HONDA

ACCORD V (CD)
ACCORD V (CE)

520181

APPLICATION

FRONT



HONDA
HONDA

CIVIC VIII (FA, FD)
CIVIC VIII (FK, FN)

HONDA
520186

SHOCK ABSORBER PROTECTION KITS

APPLICATION

REAR



HONDA	ACCORD VII (CL, CN)
HONDA	ACCORD VII (CM)
HONDA	ACCORD VII (CM, CN)
HONDA	ACCORD VIII (CM)

520041

APPLICATION

FRONT



HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
HYUNDAI
KIA
KIA

ACCENT III (MC)
ELANTRA (HD)
ELANTRA (XD)
GETZ (TB)
i30 (FD)
i30 (FD) I AVANTE
MATRIX (FC)
CERATO (LD)
RIO II (JB)

520047

APPLICATION

REAR



HYUNDAI

GETZ (TB)

520077

APPLICATION

FRONT



KIA
KIA
KIA

CEE'D (ED)
CEE'D SW (ED)
PRO CEE'D (ED)

520078

APPLICATION

REAR



HYUNDAI

ACCENT III (MC)

520080

APPLICATION

FRONT



HYUNDAI

SANTA FÉ I (SM)

HYUNDAI - KIA

SHOCK ABSORBER PROTECTION KITS

520081

APPLICATION

REAR

HYUNDAI
KIATUCSON (JM)
SPORTAGE (JE_, KM_)

520115

APPLICATION

FRONT

HYUNDAI
HYUNDAI
HYUNDAIACCENT (X-3)
ACCENT I (X-3)
ACCENT II (LC)

520119

APPLICATION

FRONT

HYUNDAI
KIATUCSON (JM)
SPORTAGE (JE_, KM_)

520132

APPLICATION

FRONT

HYUNDAI
KIASANTA FÉ II (CM)
SORENTO II (XM)

520159

APPLICATION

FRONT



KIA

SORENTO I (JC)

520163

APPLICATION

REAR



HYUNDAI

SANTA FÉ I (SM)

520164

APPLICATION

REAR

HYUNDAI
HYUNDAI
HYUNDAI
KIAELANTRA (XD)
LANTRA II (J-2)
MATRIX (FC)
CERATO (LD)

520193

APPLICATION

FRONT

KIA
KIAPICANTO (BA)
PICANTO (SA)

520194

APPLICATION

REAR

HYUNDAI
HYUNDAI
KIA
KIAACCENT III (MC)
GETZ (TB)
PICANTO (BA)
PICANTO (SA)

520195

APPLICATION

FRONT



HYUNDAI

GETZ (TB)

HYUNDAI - KIA

SHOCK ABSORBER PROTECTION KITS

520196

APPLICATION

FRONT

HYUNDAI
HYUNDAIGETZ (TB)
i20 (PB, PBT)

520202

APPLICATION

FRONT



HYUNDAI

ACCENT III (MC)

520215

APPLICATION

REAR

HYUNDAI
HYUNDAIACCENT III (MC)
GETZ (TB)

520222

APPLICATION

REAR

HYUNDAI
HYUNDAI
HYUNDAIACCENT (X-3)
ACCENT I (X-3)
ACCENT II (LC)

520006
APPLICATION

FRONT


 NISSAN
NISSAN

 KUBISTAR (X76)
KUBISTAR (X80)

520009
APPLICATION

REAR


 NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN
NISSAN

 ALMERA II (N16)
ALMERA TINO (V10)
PRIMERA (P11)
PRIMERA (P12)
PRIMERA (WP11)
PRIMERA (WP12)
PRIMERA Traveller (WP11)

520016
APPLICATION

FRONT


 NISSAN
NISSAN

 SUNNY II (B12)
SUNNY II (N13)

520024
APPLICATION

FRONT


 NISSAN
NISSAN
NISSAN

NISSAN

 ALMERA TINO (V10)
CEFIRO II (A32)
MAXIMA / MAXIMA QX IV (A32)
X-TRAIL (T30)

520026
APPLICATION

FRONT



NISSAN

ALMERA II (N16)

INFINITI - NISSAN

SHOCK ABSORBER PROTECTION KITS

520032

APPLICATION

REAR



NISSAN

X-TRAIL (T30)

520043

APPLICATION

REAR

NISSAN
NISSAN
NISSANALMERA I (N15)
CEFIRO II (A32)
MAXIMA / MAXIMA QX
IV (A32)

520046

APPLICATION

FRONT



NISSAN

ALMERA I (N15)

520050

APPLICATION

FRONT



NISSAN

MICRA I (K10)

520056

APPLICATION

FRONT

NISSAN
NISSAN
NISSANCHERRY III (N12)
PRAIRIE (M10, NM10)
SUNNY I (B11)

520056

APPLICATION

REAR



NISSAN

PRAIRIE (M10, NM10)

520069

APPLICATION

FRONT



NISSAN
NISSAN
NISSAN

PRIMERA (P10)
PRIMERA (P11)
PRIMERA (WP11)

520104

APPLICATION

FRONT



NISSAN
NISSAN
NISSAN
NISSAN

NV300 (X82)
PRIMASTAR
PRIMASTAR (X83)
PRIMASTAR Van (X83)

520107

APPLICATION

FRONT



NISSAN
NISSAN

NISSAN
NISSAN
NISSAN

CEFIRO III (A33)
MAXIMA / MAXIMA QX
V (A33)
MURANO I (Z50)
PRIMERA (P12)
PRIMERA (WP12)

520125

APPLICATION

REAR



NISSAN
NISSAN
NISSAN

MICRA C+C III (K12)
MICRA III (K12)
NOTE (E11, NE11)

INFINITI - NISSAN

SHOCK ABSORBER PROTECTION KITS

520135

APPLICATION

FRONT



NISSAN

MICRA II (K11)

520177

APPLICATION

FRONT

NISSAN
NISSAN
NISSANMICRA C+C III (K12)
MICRA III (K12)
NOTE (E11, NE11)

APPLICATION

FRONT



LADA

SAMARA (2108, 2109,
2113, 2115)

520096

APPLICATION

FRONT



LADA
LADA
LADA

LARGUS
LARGUS (F90)
LARGUS (R90)

520152

APPLICATION

FRONT



LADA

LADA

SAMARA (2108, 2109,
2113, 2115)
SAMARA FORMA
(21099, 2115)

LEXUS - TOYOTA

SHOCK ABSORBER PROTECTION KITS

520008

APPLICATION

FRONT

TOYOTA
TOYOTASTARLET (_P8_)
STARLET (_P9_)

520028

APPLICATION

FRONT

TOYOTA
TOYOTAAVENSIS (_T25_)
COROLLA (_E12_)

520031

APPLICATION

REAR

TOYOTA
TOYOTA
TOYOTA
TOYOTAECHO (_P1_)
YARIS (_P1_)
YARIS VERSO (_P2_)
YARIS VERSO VAN
(_P2_)

520050

APPLICATION

REAR

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTAAVENSIS (_T22_)
CAMRY (_V1_)
CAMRY (_V2_)
CARINA E (_T19_)
CARINA II (_T15_)
CARINA II (_T17_)
CELICA (_T16_)
COROLLA (_E10_)

TOYOTA

COROLLA (_E10_,
AE102)

TOYOTA

COROLLA (_E8_)

TOYOTA

COROLLA (_E9_)

TOYOTA

COROLLA FX (E8B)

520053

APPLICATION

FRONT

TOYOTA
TOYOTARAV 4 I (_A1_)
RAV 4 II (_A2_)

520056

APPLICATION

FRONT



TOYOTA

CAMRY (_V2_)

520056

APPLICATION

REAR

TOYOTA
TOYOTA
TOYOTAAVENSIS (_T22_)
CARINA E (_T19_)
COROLLA (_E10_,
AE102)

520071

APPLICATION

FRONT

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTAAVENSIS (_T22_)
CARINA E (_T19_)
CARINA II (_T15_)
CARINA II (_T17_)
CORONA (_T17_)

520072

APPLICATION

REAR

TOYOTA
TOYOTA
TOYOTACOROLLA (_E12_)
PRIUS (_W1_)
PRIUS (_W2_)

520073

APPLICATION

FRONT



TOYOTA

RAV 4 III (_A3_)

LEXUS - TOYOTA

SHOCK ABSORBER PROTECTION KITS

520074

APPLICATION

FRONT

TOYOTA
TOYOTATOYOTA
TOYOTACOROLLA (_E12_)
COROLLA (R1_, ZER_,
ZZE12_)
PRIUS (_W1_)
PRIUS (_W2_)

520076

APPLICATION

REAR



TOYOTA

AVENSIS (_T25_)

520077

APPLICATION

FRONT



LEXUS

RX (GSU3_, MCU3_,
MHU3_)

520083

APPLICATION

FRONT

TOYOTA
TOYOTAYARIS (_P1_)
YARIS VERSO (_P2_)

520092

APPLICATION

FRONT



TOYOTA

LAND CRUISER 80
(_J8_)

520095

APPLICATION

FRONT



TOYOTA

COROLLA (R1_, ZER_,
ZZE12_)

520145

APPLICATION

FRONT



TOYOTA

AVENSIS VERSO (_M2_)

520161

APPLICATION

REAR

TOYOTA
TOYOTAAVENSIS (_T22_)
CARINA E (_T19_)

520162

APPLICATION

FRONT



TOYOTA

PICNIC (CXM1_,
SXM1_)

520201

APPLICATION

FRONT

TOYOTA
TOYOTA
TOYOTA
TOYOTAVERSO S (_P12_)
VIOS/YARIS (_P9_)
YARIS (_P13_)
YARIS (_P9_)

LEXUS - TOYOTA

SHOCK ABSORBER PROTECTION KITS

520216

APPLICATION

FRONT



TOYOTA

LAND CRUISER (GRJ2_,
UZJ2_, VDJ2_)

520221

APPLICATION

REAR

TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTA
TOYOTAAYGO (_B1_)
AYGO (_B4_)
IQ (_J1_)
URBAN CRUISER (_P1_)
VERSO S (_P12_)
VIOS/YARIS (_P9_)
YARIS (_P13_)
YARIS (_P9_)

520230

APPLICATION

FRONT

TOYOTA
TOYOTAAYGO (_B1_)
AYGO (_B4_)

520231

APPLICATION

FRONT

LEXUS
TOYOTA
TOYOTACT (ZWA10_)
AURIS (_E15_)
COROLLA (E14_, E15_)

MAZDA

520004

SHOCK ABSORBER PROTECTION KITS

APPLICATION

FRONT



MAZDA
MAZDA
MAZDA
MAZDA

3 (BK)
3 (BL)
5 (CR19) MPV
5 (CW) MPV

520018

APPLICATION

FRONT



MAZDA

2 (DY)

520051

APPLICATION

REAR



MAZDA
MAZDA
MAZDA

121 III (JASM, JBSM)
929 I (LA)
929 II (HB)

520056

APPLICATION

REAR



MAZDA

MPV II (LW) MPV

520064

APPLICATION

REAR



MAZDA

PREMACY (CP) MPV

MAZDA

520067

SHOCK ABSORBER PROTECTION KITS

APPLICATION

REAR



MAZDA

DEMIO (DW)

520085

APPLICATION

REAR

MAZDA
MAZDA
MAZDA
MAZDA
MAZDA
MAZDA323 C V (BA)
323 F V (BA)
323 F VI (BJ)
323 P V (BA)
323 S V (BA)
323 S VI (BJ)

520088

APPLICATION

FRONT

MAZDA
MAZDA
MAZDA323 F VI (BJ)
323 S VI (BJ)
PREMACY (CP) MPV

520091

APPLICATION

FRONT

MAZDA
MAZDA
MAZDA
MAZDA323 C V (BA)
323 F V (BA)
323 P V (BA)
323 S V (BA)

520094

APPLICATION

FRONT

MAZDA
MAZDA6 (GG)
6 (GY)

MAZDA

520174

SHOCK ABSORBER PROTECTION KITS

APPLICATION

FRONT



MAZDA 6 (GG)
MAZDA 6 (GY)

520205

APPLICATION

FRONT



MAZDA 2 (DE)

520213

APPLICATION

FRONT



MAZDA 3 (BK)
MAZDA 5 (CR19) MPV
MAZDA 5 (CW) MPV

520226

APPLICATION

FRONT



MAZDA 3 (BL)
MAZDA 5 (CR19) MPV

MAZDA

MERCEDES-BENZ

SHOCK ABSORBER PROTECTION KITS

520013

APPLICATION

REAR



MERCEDES-BENZ T2/L

520019

APPLICATION

FRONT



MERCEDES-BENZ C-CLASS (CL203)
 MERCEDES-BENZ C-CLASS (S203)
 MERCEDES-BENZ C-CLASS (W203)
 MERCEDES-BENZ CLC-CLASS (CL203)
 MERCEDES-BENZ CLK (A209)
 MERCEDES-BENZ CLK (C209)

520020

APPLICATION

FRONT



MERCEDES-BENZ SPRINTER 2-t (901,
 902)
 MERCEDES-BENZ SPRINTER 3-t (903)
 MERCEDES-BENZ SPRINTER 4-t (904)
 MERCEDES-BENZ SPRINTER 5-t (905)
 MERCEDES-BENZ SPRINTER CLASSIC
 3,5-t (909)
 MERCEDES-BENZ SPRINTER CLASSIC
 4,6-t (909)

520036

APPLICATION

FRONT



MERCEDES-BENZ V-CLASS (638/2)
 MERCEDES-BENZ VITO (638)

520110

APPLICATION

FRONT



MERCEDES-BENZ A-CLASS (W169)
 MERCEDES-BENZ B-CLASS (W245)

520126

APPLICATION

MERCEDES-BENZ E-CLASS (C207)

FRONT



520168

APPLICATION

MERCEDES-BENZ 124 Coupé (C124)
 MERCEDES-BENZ 124 Saloon (W124)
 MERCEDES-BENZ 190 (W201)
 MERCEDES-BENZ E-CLASS (C124)
 MERCEDES-BENZ E-CLASS (S124)
 MERCEDES-BENZ E-CLASS (W124)
 MERCEDES-BENZ KOMBI (S124)

FRONT



520169

APPLICATION

MERCEDES-BENZ 124 Saloon (W124)
 MERCEDES-BENZ E-CLASS (W124)
 MERCEDES-BENZ SL (R129)

FRONT



APPLICATION

FRONT

MG

MG ZT



520044
APPLICATION

FRONT



MITSUBISHI

 LANCER (CG, CH, CJ,
CS_A, CT0)

MITSUBISHI

LANCER (CH, CS_W)

MITSUBISHI

 OUTLANDER I (CU_W,
ZE, ZF)

520058
APPLICATION

FRONT



MITSUBISHI

CARISMA (DA_)

MITSUBISHI

GALANT III (E1_A)

520065
APPLICATION

REAR



MITSUBISHI

CARISMA (DA_)

520084
APPLICATION

FRONT



MITSUBISHI

PAJERO II (V3_W)

MITSUBISHI

PAJERO II (V3_W) I

SHOGUN

MITSUBISHI

 PAJERO III (V6_W,
V7_W)

MITSUBISHI

 PAJERO IV (NS, NT, NW,
NX, V8_W, V9_W)

MITSUBISHI

 PAJERO IV (V8_V, V80,
V90)

MITSUBISHI

SHOCK ABSORBER PROTECTION KITS

520087

APPLICATION

REAR



MITSUBISHI
MITSUBISHI
MITSUBISHI
MITSUBISHI
MITSUBISHI

ASX (GA_W_)
ASX (GA_W_, XA, XB)
ASX Van (GA_W_)
ECLIPSE CROSS (GK_)
LANCER (CG, CH, CJ, CS_A, CT0)
LANCER (CH, CS_W)
LANCER (CJ, CY/Z_A)
LANCER CARGO (CS3W)
LANCER SPORTBACK (CJ, CX_A)

MITSUBISHI
MITSUBISHI
MITSUBISHI

LANCER VIII (CY_A, CZ_A)
OUTLANDER II (CW_W, ZG, ZH)
OUTLANDER III (GG_W, GF_W, ZJ)
OUTLANDER III (GG_W, GF_W, ZJ, ZL)

520124

APPLICATION

FRONT



MITSUBISHI

PAJERO PININ (H6_W, H7_W, QA)

520175

APPLICATION

REAR



MITSUBISHI

DELICA D5 (CV_W)

520198

APPLICATION

FRONT



MITSUBISHI
MITSUBISHI
MITSUBISHI
MITSUBISHI
MITSUBISHI

ASX (GA_W_)
ASX (GA_W_, XA, XB)
ASX Van (GA_W_)
GRANDIS (BA, NA_W)
LANCER (CG, CH, CJ, CS_A, CT0)
LANCER (CH, CS_W)
LANCER (CJ, CY/Z_A)
LANCER CARGO (CS3W)

MITSUBISHI
MITSUBISHI
MITSUBISHI
MITSUBISHI

LANCER SPORTBACK (CJ, CX_A)
LANCER VIII (CY_A, CZ_A)
OUTLANDER II (CW_W, ZG, ZH)
OUTLANDER II (CW_W, ZG, ZH)
SPACE RUNNER (N6_W)
SPACE WAGON (N8_W, N9_W, UG)

APPLICATION

FRONT



ROVER

75 (RJ)

SAAB
520005
SHOCK ABSORBER PROTECTION KITS
APPLICATION

FRONT

SAAB

9-3 (YS3F)


520034
APPLICATION

FRONT

SAAB

9-3 (YS3F)


520099
APPLICATION

FRONT

SAAB

9-3 (YS3F)


520137
APPLICATION

FRONT

SAAB

9-5 (YS3G)


520164
APPLICATION

REAR

SAAB

9-3 (YS3F)



520008

APPLICATION

FRONT



SUBARU

JUSTY II (JMA, MS)

520095

APPLICATION

FRONT



SUBARU

IMPREZA (GG)

520112

APPLICATION

REAR

SUBARU
SUBARU
SUBARUFORESTER (SG)
IMPREZA (GD)
IMPREZA (GG)

520136

APPLICATION

FRONT

SUBARU
SUBARU
SUBARU
SUBARU
SUBARUFORESTER (SF)
FORESTER (SG)
LEGACY II (BD)
LEGACY II (BG)
LEGACY OUTBACK (BG)

520178

APPLICATION

FRONT



SUBARU

JUSTY III (G3X)

SUBARU

520221

SHOCK ABSORBER PROTECTION KITS

APPLICATION

REAR



SUBARU

TREZIA

APPLICATION

FRONT



SUZUKI
SUZUKI
SUZUKI

SWIFT (SF413)
SWIFT II (AH, AJ)
SWIFT II (EA, MA)

520034

APPLICATION

FRONT



SUZUKI

GRAND VITARA I (FT, HT)

520036

APPLICATION

FRONT



SUZUKI

VITARA (ET, TA)

520082

APPLICATION

FRONT



SUZUKI

GRAND VITARA II (JT, TD, TE)

520142

APPLICATION

FRONT



SUZUKI
SUZUKI

SX4 (EY, GY)
SX4 (GY)

SUZUKI**SHOCK ABSORBER PROTECTION KITS****520158****APPLICATION**

FRONT

SUZUKI
SUZUKILIANA (ER)
LIANA (ER, RH_)**520178****APPLICATION**

FRONT

SUZUKI
SUZUKI
SUZUKIIGNIS II (MH)
WAGON R
WAGON R+ (MM)

TALBOT
520036

SHOCK ABSORBER PROTECTION KITS

APPLICATION

FRONT



TALBOT
TALBOT

SAMBA (51A)
SAMBA (51E)

520056

APPLICATION

FRONT



TALBOT

TAGORA

TALBOT

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520002

APPLICATION

REAR



AUDI	A1 (8X1, 8XK)	VOLKSWAGEN	BORA (1J6)
AUDI	A2 (8Z0)	VOLKSWAGEN	EOS (1F7, 1F8)
AUDI	A3 (8L1)	VOLKSWAGEN	GOLF IV (1J1)
AUDI	A3 (8P1)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	LEON (1M1)	VOLKSWAGEN	GOLF IV Van (1J1)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	GOLF V (1K1)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	GOLF VAN IV Variant (1J5)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	JETTA I (1K2)
SKODA	OCTAVIA (1U2)	VOLKSWAGEN	JETTA IV (162, 163)
SKODA	OCTAVIA (1U5)	VOLKSWAGEN	NEW BEETLE (1C1, 9C1)
SKODA	OCTAVIA I (1U5)	VOLKSWAGEN	NEW BEETLE (1Y7)
SKODA	RAPID (NH3)	VOLKSWAGEN	POLO (9N_)
SKODA	ROOMSTER (5J)		
VOLKSWAGEN	BEETLE (5C1, 5C2)		
VOLKSWAGEN	BORA (1J2)		

520003

APPLICATION

REAR



AUDI	A4 (8E2, B6)	VOLKSWAGEN	PASSAT (3B2)
AUDI	A4 (8E5, B6)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A4 (8EC, B7)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A4 (8ED, B7)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A4 (8H7, 8HE, B6, B7)		
AUDI	A6 (4B2)		
AUDI	A6 (4B2, C5)		
AUDI	A6 (4B5, C5)		
SKODA	SUPERB (3U4)		

520005

APPLICATION

FRONT



SEAT	IBIZA III (6K1)
SKODA	FABIA (6Y3)

520007

APPLICATION

REAR



SEAT
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
VOLKSWAGEN

TOLEDO I (1L)
FAVORIT (781)
FAVORIT (785)
FAVORIT (787)
FELICIA Cube Van (6U5)
FELICIA I (6U1)
FELICIA I (6U5)
FELICIA I (797)
FELICIA II (6U1)
FELICIA II (6U5)
CADDY II (9U7)

VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
CORRADO (53I)
GOLF II (19E, 1G1)
GOLF III (1E7)
GOLF III (1H1)
GOLF IV (1E7)
GOLF Mk III (1H1)
JETTA II (165, 19E, 1G2)
PASSAT (32B)
PASSAT (3A2, 35I)
SANTANA (32B)
VENTO (1H2)

520011

APPLICATION

REAR



AUDI
AUDI
AUDI
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

50 (86)
A4 (8D2, B5)
A4 (8D5, B5)
CORRADO (53I)
DERBY (80, 86C)
DERBY (86)
PASSAT (3A2, 35I)
PASSAT (3A5, 35I)
POLO (80, 86C)

VOLKSWAGEN
POLO (86)

520012

APPLICATION

REAR



VOLKSWAGEN
VOLKSWAGEN

TOURAN (1T1, 1T2)
TOURAN (1T3)

520013

APPLICATION

REAR



AUDI
AUDI
AUDI
AUDI
AUDI
SEAT
SEAT
SKODA
SKODA

A4 (8E2, B6)
A4 (8E5, B6)
A4 (8EC, B7)
A4 (8ED, B7)
Q3 (8U)
EXEO (3R2)
EXEO (3R5)
OCTAVIA (1Z3)
OCTAVIA (1Z5)

SKODA
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
SUPERB (3T4)
SUPERB (3T5)
PASSAT (362)
PASSAT (365)
PASSAT (3C2)
PASSAT (3C5)
PASSAT ALLTRACK (365)
TIGUAN (5N_)

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520014

APPLICATION

FRONT



SEAT

RONDA (022A)

520001

APPLICATION

FRONT



AUDI	80 (89, 89Q, 8A, B3)	VOLKSWAGEN	GOLF III (1H1)
AUDI	80 (8C, B4)	VOLKSWAGEN	GOLF III (1H5)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	GOLF IV (1E7)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF Mk III (1H1)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	JETTA I (16)
SEAT	INCA (6K9)	VOLKSWAGEN	JETTA II (165, 19E, 1G2)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	PASSAT (32)
VOLKSWAGEN	CADDY I (14)	VOLKSWAGEN	PASSAT (32B)
VOLKSWAGEN	CADDY II (9K9A)	VOLKSWAGEN	PASSAT (33)
VOLKSWAGEN	CADDY II (9U7)	VOLKSWAGEN	PASSAT (3A2, 35I)
VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)	VOLKSWAGEN	PASSAT (3A5, 35I)
VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)	VOLKSWAGEN	POLO (6KV2)
VOLKSWAGEN	CORRADO (53I)	VOLKSWAGEN	POLO (6KV5)
VOLKSWAGEN	GOLF I (155)	VOLKSWAGEN	POLO (6NF)
VOLKSWAGEN	GOLF I (17)	VOLKSWAGEN	SANTANA (32B)
VOLKSWAGEN	GOLF II (19E, 1G1)	VOLKSWAGEN	SCIROCCO (53)
VOLKSWAGEN	GOLF III (1E7)	VOLKSWAGEN	SCIROCCO (53B)
		VOLKSWAGEN	VENTO (1H2)

520020

APPLICATION

FRONT



VOLKSWAGEN	LT 28-35 II (2DB, 2DE, 2DK)
VOLKSWAGEN	LT 28-46 II (2DA, 2DD, 2DH)
VOLKSWAGEN	LT 28-46 II (2DC, 2DF, 2DG, 2DL, 2DM)

520025

APPLICATION

FRONT



AUDI	A3 (8P1)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A3 (8P7)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
AUDI	A3 (8PA)	VOLKSWAGEN	CADDY IV (SAA, SAH)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
SKODA	OCTAVIA (1Z5)		
SKODA	ROOMSTER (5J)		
VOLKSWAGEN	BEETLE (5C1, 5C2)		
VOLKSWAGEN	CADDY ALLTRACK (SAA)		
VOLKSWAGEN	CADDY ALLTRACK (SAB)		

520030

APPLICATION

FRONT



AUDI
SEAT
SEAT
SEAT
SKODA
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

A3 (8L1)
LEON (1M1)
LEON (1P1)
TOLEDO II (1M2)
OCTAVIA (1U2)
OCTAVIA (1U5)
BORA (1J2)
BORA (1J6)
GOLF IV (1J1)

VOLKSWAGEN
VOLKSWAGEN

GOLF IV (1J5)
NEW BEETLE (1C1, 9C1)

520039

APPLICATION

REAR



AUDI
AUDI
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

A6 (4B2, C5)
A6 (4B5, C5)
SUPERB (3U4)
PASSAT (3B2)
PASSAT (3B3)
PASSAT (3B5)
PASSAT (3B6)

520045

APPLICATION

FRONT



AUDI
AUDI

AUDI
AUDI
AUDI
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SEAT
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA
SKODA

A1 (8X1, 8XK)
A1 Sportback (8XA, 8XF)
A3 (8L1)
TT (8N3)
TT (8N9)
AROSA (6H)
IBIZA V (6J1, 6P5)
IBIZA V (6J5, 6P1)
IBIZA V (6J8, 6P8)
LEON (1M1)
TOLEDO II (1M2)
TOLEDO IV (KG3)
FABIA (542, 5J)
FABIA (545, 5J)
FABIA (NJ3)
FABIA (NJ5)
OCTAVIA (1U2)
OCTAVIA (1U5)
OCTAVIA (1Z3)
RAPID (NH1)
RAPID (NH3)
ROOMSTER (5J)

SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

ROOMSTER Praktik (5J)
BORA (1J2)
BORA (1J6)
CADDY II (9K9A)
FOX (5Z1, 5Z3)
GOLF III (1E7)
GOLF III (1H1)
GOLF III (1H5)
GOLF IV (1J1)
GOLF IV (1J5)
GOLF Mk III (1H1)
LOAD UP
LUPO (6E1, 6X1)
NEW BEETLE (1C1, 9C1)
NEW BEETLE (1Y7)
POLO (60, 61, 6C, 6R)
POLO (6N1)
POLO (6NF)
POLO Van (6R)
UP
VENTO (1H2)

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520051

APPLICATION

REAR



AUDI	80 (80, 82, B1)
AUDI	80 (81, 85, B2)
VOLKSWAGEN	GOLF I (155)
VOLKSWAGEN	GOLF I (17)
VOLKSWAGEN	JETTA I (16)
VOLKSWAGEN	SCIROCCO (53)
VOLKSWAGEN	SCIROCCO (53B)

520052

APPLICATION

REAR



AUDI	A4 (8D2, B5)
AUDI	A4 (8D5, B5)

520061

APPLICATION

REAR



SEAT	ALTEA (5P1)
SEAT	ALTEA XL (5P5, 5P8)
SEAT	LEON (1P1)
SEAT	TOLEDO III (5P2)
VOLKSWAGEN	BEETLE (5C1, 5C2)

520067

APPLICATION

REAR



SEAT	CORDOBA (6K1, 6K2)
SEAT	CORDOBA (6K2)
SEAT	CORDOBA (6K5)
SEAT	IBIZA II (6K1)
SEAT	IBIZA III (6K1)
VOLKSWAGEN	POLO (6KV2)
VOLKSWAGEN	POLO (6KV5)
VOLKSWAGEN	POLO (6N1)
VOLKSWAGEN	POLO (6N2)

520068

APPLICATION

REAR



SEAT	TOLEDO I (1L)
VOLKSWAGEN	CORRADO (53I)
VOLKSWAGEN	GOLF II (19E, 1G1)
VOLKSWAGEN	GOLF III (1E7)
VOLKSWAGEN	GOLF III (1H1)
VOLKSWAGEN	GOLF IV (1E7)
VOLKSWAGEN	GOLF Mk III (1H1)
VOLKSWAGEN	JETTA II (165, 19E, 1G2)
VOLKSWAGEN	VENTO (1H2)

520070

APPLICATION

REAR



VOLKSWAGEN POLO (6KV2)
 VOLKSWAGEN POLO (6N1)
 VOLKSWAGEN POLO (6N2)

520089

APPLICATION

REAR



AUDI	Q3 (8U)	VOLKSWAGEN	PASSAT (3C2)
SEAT	ALHAMBRA (710, 711)	VOLKSWAGEN	PASSAT (3C5)
SKODA	SUPERB (3T4)	VOLKSWAGEN	PASSAT ALLTRACK (365)
SKODA	SUPERB (3T5)	VOLKSWAGEN	PASSAT CC (357)
SKODA	YETI (5L)	VOLKSWAGEN	SHARAN (7N1, 7N2)
VOLKSWAGEN	CC (358)	VOLKSWAGEN	TIGUAN (5N_)
VOLKSWAGEN	GOLF VI (5K1)	VOLKSWAGEN	TOURAN (1T1, 1T2)
VOLKSWAGEN	GOLF VI (AJ5)	VOLKSWAGEN	TOURAN (1T3)
VOLKSWAGEN	GOLF VI Van (5K1_)	VOLKSWAGEN	TOURAN (5T1)
VOLKSWAGEN	PASSAT (362)		
VOLKSWAGEN	PASSAT (365)		
VOLKSWAGEN	PASSAT (3A5, 35I)		

520090

APPLICATION

REAR



AUDI 100 (4A, C4)
 AUDI A6 (4A, C4)

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520092

APPLICATION

FRONT



AUDI	A3 (8P1)	VOLKSWAGEN	GOLF VAN VI Variant (AJ5)
AUDI	A3 (8PA)	VOLKSWAGEN	GOLF VI (517)
SEAT	ALHAMBRA (710, 711)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF VI (AJ5)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF VI Variant (AJ5)
SEAT	LEON (1P1)	VOLKSWAGEN	GOLF VI Van (5K1_)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	GOLF VI Variant (AJ5)
SKODA	OCTAVIA (1Z3)	VOLKSWAGEN	JETTA I (1K2)
SKODA	OCTAVIA (1Z5)	VOLKSWAGEN	JETTA III (1K2)
SKODA	OCTAVIA (5E5)	VOLKSWAGEN	JETTA IV (162, 163)
SKODA	OCTAVIA III (5E5)	VOLKSWAGEN	PASSAT (362)
SKODA	ROOMSTER (5J)	VOLKSWAGEN	PASSAT (365)
SKODA	SUPERB (3T4)	VOLKSWAGEN	PASSAT (3C2)
SKODA	SUPERB (3T5)	VOLKSWAGEN	PASSAT (3C5)
VOLKSWAGEN	BEETLE (5C1, 5C2)	VOLKSWAGEN	PASSAT CC (357)
VOLKSWAGEN	BEETLE (5C7, 5C8)	VOLKSWAGEN	SCIROCCO (137, 138)
VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)	VOLKSWAGEN	SCIROCCO Van (137)
VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)	VOLKSWAGEN	SHARAN (7N1, 7N2)
VOLKSWAGEN	CADDY IV (SAA, SAH)	VOLKSWAGEN	TIGUAN (5N_)
VOLKSWAGEN	CADDY IV (SAB, SAJ)	VOLKSWAGEN	TOURAN (1T1, 1T2)
VOLKSWAGEN	CC (358)	VOLKSWAGEN	TOURAN (1T3)
VOLKSWAGEN	EOS (1F7, 1F8)	VOLKSWAGEN	TOURAN (5T1)
VOLKSWAGEN	GOLF IV (1J5)	VOLKSWAGEN	TRANSPORTER V (7EA, 7EH, 7HA, 7HH)
VOLKSWAGEN	GOLF PLUS (521, 5M1)		
VOLKSWAGEN	GOLF PLUS Van (521)		
VOLKSWAGEN	GOLF V (1K1)		
VOLKSWAGEN	GOLF V (1K5)		

520095

APPLICATION

FRONT



AUDI	A4 (8D2, B5)	AUDI	A6 (4F5, C6)
AUDI	A4 (8D5, B5)	AUDI	A8 (4D2, 4D8)
AUDI	A4 (8E2, B6)	AUDI	TT (8N9)
AUDI	A4 (8E5, B6)	SEAT	EXEO (3R2)
AUDI	A4 (8EC, B7)	SEAT	EXEO (3R5)
AUDI	A4 (8ED, B7)	SKODA	SUPERB (3U4)
AUDI	A4 (8H7, 8HE, B6, B7)	VOLKSWAGEN	PASSAT (3B2)
AUDI	A6 (4B2)	VOLKSWAGEN	PASSAT (3B3)
AUDI	A6 (4B2, C5)	VOLKSWAGEN	PASSAT (3B5)
AUDI	A6 (4B5, C5)	VOLKSWAGEN	PASSAT (3B6)
AUDI	A6 (4F2, C6)		

520097

APPLICATION

REAR



SEAT
SKODA
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

ALTEA XL (5P5, 5P8)
OCTAVIA (1Z3)
OCTAVIA (1Z5)
GOLF PLUS (521, 5M1)
GOLF PLUS Van (521)
GOLF V (1K1)
GOLF V (1K5)
GOLF VAN VI Variant (AJ5)

VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

GOLF VI (5K1)
GOLF VI (AJ5)
GOLF VI Van (5K1_)
GOLF VI Variant (AJ5)
JETTA III (1K2)
TOURAN (1T1, 1T2)

520105

APPLICATION

FRONT



AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI

50 (86)
80 (81, 85, B2)
80 (89, 89Q, 8A, B3)
80 (8C, B4)
90 (81, 85, B2)
90 (89, 89Q, 8A, B3)
COUPE B2 (81, 855, 856)
COUPE B3 (89, 8B3)

AUDI
VOLKSWAGEN
VOLKSWAGEN

QUATTRO (85)
PASSAT (32B)
SANTANA (32B)

520106

APPLICATION

REAR



AUDI
AUDI
SEAT
SEAT
SKODA
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

A3 (8P1)
A3 (8PA)
ALTEA (5P1)
ALTEA XL (5P5, 5P8)
OCTAVIA (1Z3)
OCTAVIA (1Z5)
GOLF PLUS (521, 5M1)
GOLF PLUS Van (521)
GOLF V (1K1)

VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN

GOLF V (1K5)
GOLF VAN VI Variant (AJ5)
GOLF VI (5K1)
GOLF VI (AJ5)
GOLF VI Van (5K1_)
GOLF VI Variant (AJ5)
JETTA III (1K2)
TOURAN (1T1, 1T2)

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520113

APPLICATION

FRONT



SEAT	ALTEA (5P1)	VOLKSWAGEN	GOLF VAN VI Variant (AJ5)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	GOLF VI (517)
SEAT	LEON (1P1)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	GOLF VI (AJ5)
SKODA	OCTAVIA (1Z3)	VOLKSWAGEN	GOLF VI Van (5K1_)
SKODA	OCTAVIA (1Z5)	VOLKSWAGEN	GOLF VI Variant (AJ5)
SKODA	OCTAVIA (5E5)	VOLKSWAGEN	JETTA I (1K2)
SKODA	OCTAVIA III (5E5)	VOLKSWAGEN	JETTA III (1K2)
SKODA	ROOMSTER (5J)	VOLKSWAGEN	JETTA IV (162, 163)
VOLKSWAGEN	BEETLE (5C1, 5C2)	VOLKSWAGEN	PASSAT (362)
VOLKSWAGEN	BEETLE (5C7, 5C8)	VOLKSWAGEN	PASSAT (365)
VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)	VOLKSWAGEN	PASSAT (3C2)
VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)	VOLKSWAGEN	PASSAT (3C5)
VOLKSWAGEN	CADDY IV (SAA, SAH)	VOLKSWAGEN	PASSAT ALLTRACK (365)
VOLKSWAGEN	CADDY IV (SAB, SAJ)	VOLKSWAGEN	PASSAT CC (357)
VOLKSWAGEN	CC (358)	VOLKSWAGEN	SCIROCCO (137, 138)
VOLKSWAGEN	EOS (1F7, 1F8)	VOLKSWAGEN	SCIROCCO Van (137)
VOLKSWAGEN	GOLF PLUS (521, 5M1)		
VOLKSWAGEN	GOLF PLUS Van (521)		
VOLKSWAGEN	GOLF V (1K1)		
VOLKSWAGEN	GOLF V (1K5)		

520114

APPLICATION

FRONT



AUDI	A2 (8Z0)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
AUDI	A3 (8P1)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
SEAT	ALTEA (5P1)	VOLKSWAGEN	CADDY IV (SAA, SAH)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	FOX (5Z1, 5Z3)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	FOX Van (5Z1)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF VI (5K1)
SEAT	CORDOBA (6L2)	VOLKSWAGEN	JETTA III (1K2)
SEAT	IBIZA III (6K1)	VOLKSWAGEN	PASSAT (3C5)
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	PASSAT CC (357)
SEAT	LEON (1P1)	VOLKSWAGEN	POLO (6KV2)
SEAT	TOLEDO III (5P2)	VOLKSWAGEN	POLO (6KV5)
SKODA	FABIA	VOLKSWAGEN	POLO (6N1)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	POLO (6N2)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	POLO (9A4)
SKODA	FABIA (6Y2)	VOLKSWAGEN	POLO (9N_)
SKODA	FABIA (6Y3)	VOLKSWAGEN	POLO Van (6V5)
SKODA	FABIA (6Y5)	VOLKSWAGEN	TIGUAN (5N_)
SKODA	FABIA II (542)	VOLKSWAGEN	TOURAN (1T1, 1T2)
SKODA	FABIA II (545)	VOLKSWAGEN	TOURAN (1T3)
SKODA	OCTAVIA (1Z3)		
SKODA	OCTAVIA (1Z5)		
SKODA	ROOMSTER (5J)		
SKODA	ROOMSTER Praktik (5J)		
SKODA	SUPERB (3T4)		

520118

APPLICATION

FRONT



AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI

A4 (8E2, B6)
A4 (8E5, B6)
A4 (8EC, B7)
A4 (8ED, B7)
A4 (8H7, 8HE, B6, B7)
A6 (4B2)
A6 (4B2, C5)
A6 (4B5, C5)
A6 (4F2, C6)

AUDI
SEAT
SEAT
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
A6 (4F5, C6)
EXEO (3R2)
EXEO (3R5)
PASSAT (362)
PASSAT (3B3)
PASSAT (3B6)
PASSAT Variant (3B6)

520126

APPLICATION

FRONT



AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI

A4 (8K2, B6)
A4 (8K2, B8)
A4 (8K5, B8)
A5 (8F7)
A5 (8T3)
A5 (8TA)
A6 (4G2, 4GC, C7)
A6 (4G5, 4GD, C7)

AUDI
AUDI
A6 Sportwagon (4G5, 4GD, C7)
A7 (4GA, 4GF)

520139

APPLICATION

FRONT



AUDI
AUDI
AUDI

100 (4A, C4)
200 (44, 44Q)
A6 (4A, C4)

520141

APPLICATION

FRONT



SEAT
SEAT
SEAT

IBIZA I (021A)
MALAGA (023A)
RONDA (022A)

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520146

APPLICATION

FRONT



VOLKSWAGEN

MULTIVAN V (7EF, 7EM, 7EN, 7HF, 7HM, 7HN)

VOLKSWAGEN

MULTIVAN VI (SGF, SGM, SGN)

VOLKSWAGEN

TRANSPORTER Mk VI (SFD, SFE, SFL, SFZ)

VOLKSWAGEN

TRANSPORTER V (7EA, 7EH, 7HA, 7HH)

VOLKSWAGEN

TRANSPORTER V (7EB, 7EC, 7EF, 7EG, 7EJ, 7HB, 7HF, 7HJ)

VOLKSWAGEN

TRANSPORTER V (7FD, 7FE, 7FL, 7FY, 7FZ, 7JD, 7JE, 7JL, 7JY, 7JZ)

VOLKSWAGEN

TRANSPORTER VI (SFD, SFE, SFL, SFZ)

VOLKSWAGEN

TRANSPORTER VI (SGA, SGH)

VOLKSWAGEN

TRANSPORTER VI (SGB, SGG, SGJ)

520148

APPLICATION

REAR



VOLKSWAGEN

PASSAT (3A2, 35I)

VOLKSWAGEN

PASSAT (3A5, 35I)

520152

APPLICATION

FRONT



SEAT

CORDOBA (6K1, 6K2)

SEAT

CORDOBA (6K5)

SEAT

IBIZA II (6K1)

SEAT

INCA (6K9)

SEAT

TOLEDO I (1L)

VOLKSWAGEN

CADDY I (14)

VOLKSWAGEN

CADDY II (9K9A)

VOLKSWAGEN

CORRADO (53I)

VOLKSWAGEN

GOLF I (155)

VOLKSWAGEN

GOLF I (17)

VOLKSWAGEN

GOLF II (19E, 1G1)

VOLKSWAGEN

GOLF III (1E7)

VOLKSWAGEN

GOLF III (1H1)

VOLKSWAGEN

GOLF III (1H5)

VOLKSWAGEN

GOLF IV (1E7)

VOLKSWAGEN

GOLF Mk III (1H1)

VOLKSWAGEN

JETTA I (16)

VOLKSWAGEN

JETTA II (165, 19E, 1G2)

VOLKSWAGEN

PASSAT (32)

VOLKSWAGEN

PASSAT (32B)

VOLKSWAGEN

PASSAT (33)

VOLKSWAGEN

PASSAT (3A2, 35I)

VOLKSWAGEN

PASSAT (3A5, 35I)

VOLKSWAGEN

POLO (6KV2)

VOLKSWAGEN

POLO (6KV5)

VOLKSWAGEN

SANTANA (32B)

VOLKSWAGEN

SCIROCCO (53)

VOLKSWAGEN

SCIROCCO (53B)

VOLKSWAGEN

VENTO (1H2)

520173

APPLICATION

REAR



VOLKSWAGEN

PASSAT (3A2, 35I)

520157

APPLICATION

FRONT

SEAT
VOLKSWAGENALHAMBRA (7V8, 7V9)
SHARAN (7M6, 7M8,
7M9)

520165

APPLICATION

REAR

AUDI
SEAT
SKODA
SKODA
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGENA3 (8P7)
ALTEA XL (5P5, 5P8)
OCTAVIA (1Z3)
OCTAVIA (1Z5)
BEETLE (5C1, 5C2)
BEETLE (5C7, 5C8)
EOS (1F7, 1F8)
GOLF PLUS (521, 5M1)
GOLF PLUS Van (521)
GOLF V (1K1)VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGENGOLF VI (517)
GOLF VI (5K1)
GOLF VI Van (5K1_)
JETTA I (1K2)
JETTA III (1K2)
JETTA IV (162, 163)
SCIROCCO (137, 138)
SCIROCCO Van (137)

520170

APPLICATION

REAR

AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI100 (43, C2)
80 (80, 82, B1)
80 (81, 85, B2)
80 (89, 89Q, 8A, B3)
80 (8C, B4)
90 (81, 85, B2)
90 (89, 89Q, 8A, B3)
COUPE B2 (81, 855,
856)VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGEN
VOLKSWAGENGOLF I (155)
GOLF I (17)
JETTA I (16)
SCIROCCO (53)
SCIROCCO (53B)

520176

APPLICATION

FRONT

AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDI
AUDIA4 (8K2, B6)
A4 (8K2, B8)
A4 (8K5, B8)
A4 Allroad (8KH, B8)
A5 (8T3)
A5 (8TA)
A6 (4G2, 4GC, C7)
A6 (4G5, 4GD, C7)AUDI
AUDI
AUDIA6 Sportwagon (4G5,
4GD, C7)
A7 (4GA, 4GF)
Q5 (8R)

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520177

APPLICATION

FRONT



VOLKSWAGEN

TOURAN (1T1, 1T2)

520200

APPLICATION

REAR



AUDI

A1 (8X1, 8XK)

SKODA

FABIA (6Y3)

AUDI

A1 Sportback (8XA, 8XF)

SKODA

FABIA (6Y5)

AUDI

A2 (8Z0)

SKODA

FABIA (NJ3)

SEAT

CORDOBA (6L2)

VOLKSWAGEN

FOX (5Z1, 5Z3)

SEAT

IBIZA IV (6L1)

VOLKSWAGEN

POLO (60, 61, 6C, 6R)

SKODA

FABIA

VOLKSWAGEN

POLO (9A4)

SKODA

FABIA (542, 5J)

VOLKSWAGEN

POLO (9N_)

SKODA

FABIA (545, 5J)

VOLKSWAGEN

POLO Van (6R)

SKODA

FABIA (6Y2)

520203

APPLICATION

FRONT



AUDI

A3 (8P1)

VOLKSWAGEN

GOLF V (1K1)

AUDI

A3 (8PA)

VOLKSWAGEN

GOLF V (1K5)

SEAT

ALTEA (5P1)

VOLKSWAGEN

GOLF VAN VI Variant (AJ5)

SEAT

ALTEA XL (5P5, 5P8)

VOLKSWAGEN

GOLF VI (517)

SEAT

LEON (1P1)

VOLKSWAGEN

GOLF VI (5K1)

SEAT

TOLEDO III (5P2)

VOLKSWAGEN

GOLF VI (AJ5)

SKODA

OCTAVIA (1Z3)

VOLKSWAGEN

GOLF VI Van (5K1_)

SKODA

OCTAVIA (1Z5)

VOLKSWAGEN

GOLF VI Variant (AJ5)

SKODA

OCTAVIA (5E5)

VOLKSWAGEN

JETTA I (1K2)

SKODA

OCTAVIA III (5E5)

VOLKSWAGEN

JETTA III (1K2)

SKODA

ROOMSTER (5J)

VOLKSWAGEN

JETTA IV (162, 163)

SKODA

SUPERB (3T4)

VOLKSWAGEN

PASSAT (362)

SKODA

SUPERB (3T5)

VOLKSWAGEN

PASSAT (365)

VOLKSWAGEN

BEETLE (5C1, 5C2)

VOLKSWAGEN

PASSAT (3C2)

VOLKSWAGEN

BEETLE (5C7, 5C8)

VOLKSWAGEN

PASSAT (3C5)

VOLKSWAGEN

CADDY III (2CA, 2CH, 2KA, 2KH)

VOLKSWAGEN

PASSAT CC (357)

VOLKSWAGEN

CADDY III (2CB, 2CJ, 2KB, 2KJ)

VOLKSWAGEN

SCIROCCO (137, 138)

VOLKSWAGEN

CADDY IV (SAA, SAH)

VOLKSWAGEN

SCIROCCO Van (137)

VOLKSWAGEN

CADDY IV (SAB, SAJ)

VOLKSWAGEN

CC (358)

VOLKSWAGEN

EOS (1F7, 1F8)

VOLKSWAGEN

GOLF PLUS (521, 5M1)

VOLKSWAGEN

GOLF PLUS Van (521)

520214

APPLICATION

FRONT



SEAT	ALHAMBRA (710, 711)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	PASSAT (362)
SKODA	KAROQ (NU7)	VOLKSWAGEN	PASSAT (365)
SKODA	OCTAVIA (1Z5)	VOLKSWAGEN	PASSAT (3C2)
SKODA	OCTAVIA (5E5)	VOLKSWAGEN	PASSAT (3C5)
SKODA	ROOMSTER (5J)	VOLKSWAGEN	SHARAN (7N1, 7N2)
SKODA	YETI (5L)	VOLKSWAGEN	TIGUAN (5N_)
VOLKSWAGEN	BEETLE (5C1, 5C2)	VOLKSWAGEN	TOURAN (1T1, 1T2)
VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)	VOLKSWAGEN	TOURAN (1T3)
VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)		
VOLKSWAGEN	CADDY IV (SAA, SAH)		

520218

APPLICATION

FRONT



AUDI	A2 (8Z0)	VOLKSWAGEN	CADDY III (2CA, 2CH, 2KA, 2KH)
SEAT	ALTEA XL (5P5, 5P8)	VOLKSWAGEN	CADDY III (2CB, 2CJ, 2KB, 2KJ)
SEAT	CORDOBA (6L2)		
SEAT	IBIZA IV (6L1)	VOLKSWAGEN	CADDY IV (SAA, SAH)
SKODA	FABIA (6Y2)	VOLKSWAGEN	CADDY IV (SAB, SAJ)
SKODA	FABIA (6Y3)	VOLKSWAGEN	POLO (9N_)
SKODA	FABIA (6Y5)		
SKODA	OCTAVIA (1Z5)		
SKODA	ROOMSTER (5J)		
VOLKSWAGEN	BEETLE (5C1, 5C2)		

520223

APPLICATION

FRONT



AUDI	A1 (8X1, 8XK)	SKODA	ROOMSTER (5J)
AUDI	A1 Sportback (8XA, 8XF)	SKODA	ROOMSTER Praktik (5J)
SEAT	CORDOBA (6K1, 6K2)	VOLKSWAGEN	BORA (1J6)
SEAT	CORDOBA (6K2)	VOLKSWAGEN	GOLF III (1E7)
SEAT	CORDOBA (6K5)	VOLKSWAGEN	GOLF III (1H1)
SEAT	IBIZA II (6K1)	VOLKSWAGEN	GOLF III (1H5)
SEAT	LEON (1M1)	VOLKSWAGEN	GOLF IV (1E7)
SEAT	TOLEDO I (1L)	VOLKSWAGEN	GOLF IV (1J1)
SEAT	TOLEDO II (1M2)	VOLKSWAGEN	GOLF IV (1J5)
SEAT	TOLEDO IV (KG3)	VOLKSWAGEN	GOLF IV Van (1J1)
SKODA	FABIA (542, 5J)	VOLKSWAGEN	GOLF Mk III (1H1)
SKODA	FABIA (545, 5J)	VOLKSWAGEN	GOLF VAN IV Variant (1J5)
SKODA	FABIA (NJ3)	VOLKSWAGEN	PASSAT (3A2, 35I)
SKODA	FABIA (NJ5)	VOLKSWAGEN	PASSAT (3A5, 35I)
SKODA	FABIA II (542)	VOLKSWAGEN	POLO (60, 61, 6C, 6R)
SKODA	FABIA II (545)	VOLKSWAGEN	POLO (60_, 61_)
SKODA	FABIA III (NJ3)	VOLKSWAGEN	POLO Van (6R)
SKODA	FABIA III (NJ5)	VOLKSWAGEN	POLO Van (6R) POLO CityVan
SKODA	OCTAVIA (1U2)		
SKODA	OCTAVIA (1U5)	VOLKSWAGEN	VENTO (1H2)
SKODA	OCTAVIA I (1U5)		
SKODA	RAPID (NH1)		
SKODA	RAPID (NH3)		
SKODA	RAPID Spaceback (NH1)		

VAG: AUDI - PORSCHE - SEAT - SKODA - VW

SHOCK ABSORBER PROTECTION KITS

520224

APPLICATION

REAR



AUDI	A1 (8X1, 8XK)
SEAT	ALTEA XL (5P5, 5P8)
SKODA	OCTAVIA (1Z3)
SKODA	OCTAVIA (1Z5)
SKODA	YETI (5L)
VOLKSWAGEN	GOLF PLUS (521, 5M1)
VOLKSWAGEN	GOLF V (1K5)
VOLKSWAGEN	GOLF VI (5K1)
VOLKSWAGEN	GOLF VI (AJ5)

VOLKSWAGEN	JETTA IV (162, 163)
VOLKSWAGEN	TOURAN (1T1, 1T2)
VOLKSWAGEN	TOURAN (1T3)

520225

APPLICATION

REAR



SEAT	ALTEA XL (5P5, 5P8)
SKODA	OCTAVIA (1Z5)
VOLKSWAGEN	GOLF V (1K1)
VOLKSWAGEN	GOLF V (1K5)
VOLKSWAGEN	GOLF VAN VI Variant (AJ5)
VOLKSWAGEN	GOLF VI (AJ5)
VOLKSWAGEN	JETTA III (1K2)

520228

APPLICATION

REAR



AUDI	A4 (8E2, B6)
AUDI	A4 (8E5, B6)
AUDI	A4 (8EC, B7)
AUDI	A4 (8ED, B7)
AUDI	A4 (8H7, 8HE, B6, B7)
SEAT	EXEO (3R2)
SEAT	EXEO (3R5)
SKODA	OCTAVIA (1Z3)
SKODA	SUPERB (3T4)

SKODA	SUPERB (3T5)
VOLKSWAGEN	PASSAT (3C2)
VOLKSWAGEN	PASSAT (3C5)

520229

APPLICATION

REAR



AUDI	A4 (8K2, B6)
AUDI	A4 (8K2, B8)
AUDI	A4 (8K5, B8)
AUDI	A4 Allroad (8KH, B8)
AUDI	A5 (8T3)
AUDI	A5 (8TA)
AUDI	Q5 (8R)

VOLVO **520004**

SHOCK ABSORBER PROTECTION KITS

APPLICATION

FRONT



VOLVO
VOLVO

S40 II (MS)
V50 (MW)

520008

APPLICATION

FRONT



VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO
VOLVO

850 (LS)
850 (LW)
C70 I
S70 (LS)
V70 I (LV)
V70 II (SW)
V70 III (BW)

520021

APPLICATION

FRONT



VOLVO

S90

520058

APPLICATION

FRONT



VOLVO
VOLVO

S40 I (VS)
V40 (VW)

520065

APPLICATION

REAR



VOLVO
VOLVO

S40 I (VS)
V40 (VW)

VOLVO
520109
SHOCK ABSORBER PROTECTION KITS
APPLICATION

FRONT


VOLVO
VOLVO
VOLVO
VOLVO

S60 I
S80 I (TS, XY)
V70 II (SW)
XC70 CROSS COUNTRY

520130
APPLICATION

FRONT



VOLVO

XC90 I

520178
APPLICATION

FRONT


VOLVO
VOLVO
VOLVO
VOLVO

C30
C70 II
S40 II (MS)
V50 (MW)

520197
APPLICATION

FRONT


VOLVO
VOLVO
VOLVO
VOLVO

C30
C70 II
S40 II (MS)
V50 (MW)

520199
APPLICATION

REAR


VOLVO
VOLVO
VOLVO
VOLVO

C30
S40 II (MS)
V50 (545)
V50 (MW)

UNIVERSAL C.V. JOINT BOOT KITS

TO BE CUT		WITHOUT CUTTING		
500284E Cars	500325E Vans and 4x4	500087E / 500160E Cars		500086E Vans and 4x4
				

UNIVERSAL STEERING BOOT KITS

500088E
Manual steering



500001E
Power steering



NOTES

NOTES

NOTES

NOTES

NOTES

NOTES

NOTES

NOTES

NOTES

NOTES

NOTES

ert



SEINsa®
Corporation
Our people, our success